

NO.	PAGE	AMP	*PREVOST	LOCATION	FUNCTION
D1	7	3A	561740	ALARM JCT BOX	LO-AIR SONALERT-PRIMARY
D2	7	3A	561740	ALARM JCT BOX	LO-AIR SONALERT-SECONDARY
D4	10	3A	561740	FR JCT BOX	WARNING HAZARD-RH
D5	10	3A	561740	FR JCT BOX	WARNING HAZARD-LH
D9	17	3A	561740	ALARM JCT BOX	HOSTESS & PASSENGER CHIME
D11	23	3A	561740	RR JCT BOX	LAVATORY OCCUPIED SIGN
D12	23	3A	561740	RR JCT BOX	LAVATORY OCCUPIED SIGN
D13	23	3A	561740	FR DEST. SIGN	FR DESTINATION SIGN
D14	23	3A	561740	FR DEST. SIGN	FR DESTINATION SIGN
D15	24	3A	561740	FR JCT BOX	KNEELING SYSTEM CTR-UP
D16	24	3A	561740	FR JCT BOX	KNEELING SYSTEM CTR-DOWN
D17	10	3A	561740	FR JCT BOX	WARNING HAZARD-LH
D18	10	3A	561740	FR JCT BOX	WARNING HAZARD-RH
D19	9	3A	561740	FR JCT BOX	DAYTIME RUN LTS-PARK BRK CALL SW.
D20	9	3A	561740	FR JCT BOX	DAYTIME RUN LTS-HEAD LT SW
D21	24	3A	561740	FR JCT BOX	KNEELING SYSTEM FEED BACK
D25	13	3A	561740	FR JCT BOX	LUGGAGE DOOR AJAR T.T.LT.
D26	13	3A	561740	FR JCT BOX	LUGGAGE DOOR AJAR T.T.LT.
D27	13	3A	561740	FR JCT BOX	LUGGAGE DOOR AJAR T.T.LT.
D28	13	3A	561740	FR JCT BOX	LUGGAGE DOOR AJAR T.T.LT.
D29	13	3A	561740	FR JCT BOX	LUGGAGE DOOR AJAR T.T.LT.
D30	13	3A	561740	FR JCT BOX	LUGGAGE DOOR AJAR T.T.LT.
D31	13	3A	561740	FR JCT BOX	LUGGAGE DOOR AJAR T.T.LT.
D35	32&35	3A	561740	RR JCT BOX	WCL DOOR AJAR ALARM T.T.LT.
D58	24	3A	561740	FR JCT BOX	RR HIGH BUOY - KNEELING
D60	18	3A	561740	RR JCT BOX	A/C COMPR.CLUTCH SUPPRESSOR
D61	10	3A	561740	FR JCT BOX	KNEELING SIDE FR RH DIRECTIONNAL LT
D62	18	3A	561740	A/C JCT BOX	WATER PUMP FEED
D63	23	3A	561740	ALARM JCT BOX	LAVATORY SONALERT
D64	23	3A	561740	ALARM JCT BOX	WCL DOOR ALARM
D65	18	3A	561740	A/C JCT BOX	WATER PUMP - PRE-HEAT FEED
D66	18	3A	561740	A/C JCT BOX	WATER VALVE - HEAT SW. FEED
D67	10	3A	561740	UNDER DASH	AUDIBLE FLASHER RLY - RH
D68	10	3A	561740	UNDER DASH	AUDIBLE FLASHER RLY - LH
D70	24	3A	561740	FR JCT BOX	FR HIGH BUOY - KNEELING
D71	24	3A	561740	FR JCT BOX	FR HIGH BUOY - KNEELING
D72	24	3A	561740	FR JCT BOX	FR HIGH BUOY - KNEELING
D73	24	3A	561740	FR JCT BOX	FR HIGH BUOY - KNEELING
D74	1	3A	561740	FR JCT BOX	DASH MASTER CUT OUT SW.
D75	4	3A	381351	BAT CPT	STARTER-SUPPRESSOR COIL RLY
D77	24	3A	561740	FR JCT BOX	PARKING BRAKE - KNEELING
D78	17	3A	561740	LH CONSOLE	PRE-HEAT WATER HEATER SW.
D79	17	3A	561740	LH CONSOLE	PRE-HEAT WATER HEATER SW.
D80	9	3A	561740	FR JCT BOX	DAYTIME RUN LTS-HEAD LTS CALL SW.
D81	24	3A	561740	FR JCT BOX	PIEZO-KNEELING
D82	24	3A	561740	FR JCT BOX	PIEZO-KNEELING
D83	8	3A	561740	RR JCT BOX	FAN CLUTCH W/RETARDER
D84	18	3A	561740	A/C JCT BOX	WATER VALVE
D85	18	3A	561740	A/C JCT BOX	WATER PUMP
D86	22	3A	561740	UNDER DASH RH	ENTRANCE DOOR SEDAN
D87	22	3A	561740	UNDER DASH RH	ENTRANCE DOOR SEDAN
D88	22	3A	561740	UNDER DASH RH	ENTRANCE DOOR SEDAN
D89	22	3A	561740	UNDER DASH RH	ENTRANCE DOOR SEDAN
D90	22	3A	561740	UNDER DASH RH	ENTRANCE DOOR SEDAN
D91	22	3A	561740	UNDER DASH RH	ENTRANCE DOOR SEDAN

NO.	PAGE	AMP	*PREVOST	LOCATION	FUNCTION
-----	------	-----	----------	----------	----------