

PREVOST

XL Series Motorcoach

TABLE OF CONTENTS

FOREWORD	1 - 1	Exterior compartments (XL-45)	2 - 35
		Engine compartment doors	2 - 36
		Engine air intake ducts	2 - 36
		Fuel tank filling door	2 - 36
		Entrance door	2 - 36
		Engine compartment components	2 - 37
		Baggage compartment	2 - 38
		Spare wheel & tire compartment	2 - 38
		A/C & heating and condenser compartment doors	2 - 39
		Service doors	2 - 39
		L.H. side rear service compartment and main power compartment	2 - 39
		Battery compartment	2 - 40
		Interior compartments	2 - 40
		Lavatory	2 - 40
		Parcel racks	2 - 41
		Safety equipment compartment	2 - 41
		Accessories	2 - 41
		Preheating system timers (auxiliary)	2 - 46
		SAFETY	3 - 1
		Brakes	3 - 1
		Antilock braking system (ABS)	3 - 2
		Air system emergency fill valve	3 - 2
		Back up alarm	3 - 3
		Kneeling system	3 - 3
		Hi-buoy system	3 - 3
		Low-buoy system	3 - 3
		Emergency exits	3 - 4
		Day time running lights	3 - 5
		Fog lights	3 - 5
		Horns	3 - 5
		Alarm system	3 - 6
		Safety equipment	3 - 6
CONTROLS/INSTRUMENTS	2 - 1		
Keys	2 - 1		
Main battery disconnect switch	2 - 2		
Fuel tank filling	2 - 2		
Controls and instrument panels	2 - 3		
L.H. side control panel	2 - 4		
Cruise control switches	2 - 5		
Dashboard (without tachograph)	2 - 7		
Dashboard (with tachograph)	2 - 8		
Dashboard indicator/warning lights	2 - 9		
L.H. lower switch panel	2 - 14		
R.H. lower switch panel	2 - 15		
R.H. console	2 - 15		
Audio/Video control unit.	2 - 16		
Public address (P.A.)	2 - 18		
Video cassette player	2 - 19		
TV tuner	2 - 19		
Detroit diesel PRODRIVER™ controls	2 - 20		
R.H. lateral console	2 - 22		
Automatic transmission	2 - 23		
Manual transmission	2 - 25		
Steering column controls	2 - 26		
Foot-operated controls	2 - 27		
Tilt steering wheel and telescopic steering column	2 - 28		
Entrance door	2 - 28		
Seats	2 - 29		
Driver's seat	2 - 29		
Seat belts	2 - 31		
Passenger seats	2 - 31		
Tour guide seat	2 - 32		
Mirrors	2 - 32		
Exterior compartments (XL-40)	2 - 34		

TABLE OF CONTENTS

Safety precautions.....	3 - 7
Defensive driving.....	3 - 8

**STARTING AND STOPPING
PROCEDURES 4 - 1**

General information.....	4 - 1
Detroit Diesel Electronic Control (DDEC).....	4 - 2
World Transmission WT Electronic Control System.....	4 - 3
Manual transmission	4 - 7
Cold weather starting	4 - 7
Daily inspection	4 - 8
Recommendations	4 - 9
Heating and air conditioning	4 - 10
Preheating systems.....	4 - 13
Windshield washer reservoir.....	4 - 14
Jump starting	4 - 15
Electric circuit protection	4 - 16
Tires	4 - 18
Jacking points.....	4 - 20
Towing	4 - 20
Retractable tag axle	4 - 21
Tag axle unloaded.....	4 - 21

TECHNICAL INFORMATION 5 - 1

Dimensions.....	5 - 1
Weights.....	5 - 2
Capacities	5 - 2
Fuel type	5 - 2
Wheels and tires.....	5 - 2
Belts	5 - 3
Engines.....	5 - 3
Transmissions	5 - 3
Drive axle ratio.....	5 - 3
Brakes.....	5 - 4
Antilock braking system (ABS)	5 - 4
Steering	5 - 4
Electrical system.....	5 - 4

Sound system	5 - 5
Video system.....	5 - 5
Suspension	5 - 5
Alignment	5 - 5
Heating and air conditioning	5 - 5
Oil specifications	5 - 6
Preheating systems	5 - 7
Storage volume.....	5 - 7
Seats	5 - 7
Data plate and certification	5 - 7
Light bulb data.....	5 - 10
DDEC III diagnostic codes.....	5 - 12
World transmission WT diagnostic codes.....	5 - 14

CARE AND MAINTENANCE 6 - 1

Interior cleaning.....	6 - 1
Exterior cleaning	6 - 3
Oil verification.....	6 - 4
Air tanks	6 - 7
Coolant level verification.....	6 - 7
Water separator	6 - 7
Belt tensioners	6 - 8
A/C and heating air filters	6 - 8
Flexible hose maintenance.....	6 - 9
Lubrication.....	6 - 9
Fire extinguishers.....	6 - 9
110-120 volt in-station lighting.....	6 - 9
110-120 volt in-station connectors	6 - 9
Back-up camera.....	6 - 10
Filter restriction indicator.....	6 - 10
Lavatory maintenance	6 - 10
First service on new vehicle	6 - 12
Lubrication and servicing schedule	6 - 13

SERVICE LITERATURE 7 - 1

PREVOST

XL Series Motorcoach

TABLE OF CONTENTS

FOREWORD	1 - 1	Exterior compartments (XL-45)	2 - 35
		Engine compartment doors	2 - 36
		Engine air intake ducts	2 - 36
		Fuel tank filling door	2 - 36
		Entrance door	2 - 36
		Engine compartment components	2 - 37
		Baggage compartment	2 - 38
		Spare wheel & tire compartment	2 - 38
		A/C & heating and condenser compartment doors	2 - 39
		Service doors	2 - 39
		L.H. side rear service compartment and main power compartment	2 - 39
		Battery compartment	2 - 40
		Interior compartments	2 - 40
		Lavatory	2 - 40
		Parcel racks	2 - 41
		Safety equipment compartment	2 - 41
		Accessories	2 - 41
		Preheating system timers (auxiliary)	2 - 46
		SAFETY	3 - 1
		Brakes	3 - 1
		Antilock braking system (ABS)	3 - 2
		Air system emergency fill valve	3 - 2
		Back up alarm	3 - 3
		Kneeling system	3 - 3
		Hi-buoy system	3 - 3
		Low-buoy system	3 - 3
		Emergency exits	3 - 4
		Day time running lights	3 - 5
		Fog lights	3 - 5
		Horns	3 - 5
		Alarm system	3 - 6
		Safety equipment	3 - 6
CONTROLS/INSTRUMENTS	2 - 1		
Keys	2 - 1		
Main battery disconnect switch	2 - 2		
Fuel tank filling	2 - 2		
Controls and instrument panels	2 - 3		
L.H. side control panel	2 - 4		
Cruise control switches	2 - 5		
Dashboard (without tachograph)	2 - 7		
Dashboard (with tachograph)	2 - 8		
Dashboard indicator/warning lights	2 - 9		
L.H. lower switch panel	2 - 14		
R.H. lower switch panel	2 - 15		
R.H. console	2 - 15		
Audio/Video control unit.	2 - 16		
Public address (P.A.)	2 - 18		
Video cassette player	2 - 19		
TV tuner	2 - 19		
Detroit diesel PRODRIVER™ controls	2 - 20		
R.H. lateral console	2 - 22		
Automatic transmission	2 - 23		
Manual transmission	2 - 25		
Steering column controls	2 - 26		
Foot-operated controls	2 - 27		
Tilt steering wheel and telescopic steering column	2 - 28		
Entrance door	2 - 28		
Seats	2 - 29		
Driver's seat	2 - 29		
Seat belts	2 - 31		
Passenger seats	2 - 31		
Tour guide seat	2 - 32		
Mirrors	2 - 32		
Exterior compartments (XL-40)	2 - 34		

XL Series Motorcoach

FOREWORD

The PRÉVOST "XL Motorcoach" Operator's Manual has been prepared to thoroughly acquaint you, the operator, with vehicle equipment and features in order to fully appreciate and safely enjoy your vehicle. Of course, you are anxious to drive your new coach and test its features, but first please read this publication carefully for enjoyable and trouble free operation, while ensuring optimum safety and passenger comfort.

This book should be kept inside the vehicle at all times for convenient reference. It is also suggested that it remain with the vehicle at the time of resale. Please notify PRÉVOST CAR INC. when the vehicle's ownership is transferred so that our records can be kept up to date. Do this by filling out the appropriate form at the end of this manual.

The specifications, descriptions and figures given are based on the latest information available at printing time. And because at PRÉVOST, we are constantly striving to better our product, we reserve the right to make changes at any time without notice and/or obligation on our part.

Please note that this publication applies only to XL Motorcoaches, manufactured by PRÉVOST CAR INC.. It describes and explains all the equipment and options available for installation in our factory. Therefore, there may be equipment described herein that is not installed on your vehicle.

This Manual encompasses both XL-40 & XL-45 models; therefore, variations between them are identified as such.

This manual, or portions thereof, cannot be reproduced in any form whatsoever, in whole or in part, without the written consent of PRÉVOST CAR INC.

The following words are used to emphasize particularly important information:

WARNING: Identifies instructions which if not followed, could result in serious personal injury or loss of life.

CAUTION: Denotes instructions which if not followed, could cause serious damage to vehicle components.

NOTE: Indicates supplementary information needed to fully understand and complete an instruction.

For your own safety and to ensure prolonged service life of your coach, heed our cautions, warnings and notes; Ignoring them could result in extensive damage and/or serious personal injury.

PREVOST

XL Series Motorcoach

TABLE OF CONTENTS

FOREWORD	1 - 1	Exterior compartments (XL-45)	2 - 35
		Engine compartment doors	2 - 36
CONTROLS/INSTRUMENTS	2 - 1	Engine air intake ducts	2 - 36
Keys	2 - 1	Fuel tank filling door	2 - 36
Main battery disconnect switch	2 - 2	Entrance door	2 - 36
Fuel tank filling	2 - 2	Engine compartment components	2 - 37
Controls and instrument panels	2 - 3	Baggage compartment	2 - 38
L.H. side control panel	2 - 4	Spare wheel & tire compartment	2 - 38
Cruise control switches	2 - 5	A/C & heating and condenser compartment	
Dashboard (without tachograph)	2 - 7	doors	2 - 39
Dashboard (with tachograph)	2 - 8	Service doors	2 - 39
Dashboard indicator/warning lights	2 - 9	L.H. side rear service compartment and	
L.H. lower switch panel	2 - 14	main power compartment	2 - 39
R.H. lower switch panel	2 - 15	Battery compartment	2 - 40
R.H. console	2 - 15	Interior compartments	2 - 40
Audio/Video control unit.	2 - 16	Lavatory	2 - 40
Public address (P.A.)	2 - 18	Parcel racks	2 - 41
Video cassette player	2 - 19	Safety equipment compartment	2 - 41
TV tuner	2 - 19	Accessories	2 - 41
Detroit diesel PRODRIVER™ controls	2 - 20	Preheating system timers (auxiliary)	2 - 46
R.H. lateral console	2 - 22		
Automatic transmission	2 - 23	SAFETY	3 - 1
Manual transmission	2 - 25	Brakes	3 - 1
Steering column controls	2 - 26	Antilock braking system (ABS)	3 - 2
Foot-operated controls	2 - 27	Air system emergency fill valve	3 - 2
Tilt steering wheel and telescopic steering		Back up alarm	3 - 3
column	2 - 28	Kneeling system	3 - 3
Entrance door	2 - 28	Hi-buoy system	3 - 3
Seats	2 - 29	Low-buoy system	3 - 3
Driver's seat	2 - 29	Emergency exits	3 - 4
Seat belts	2 - 31	Day time running lights	3 - 5
Passenger seats	2 - 31	Fog lights	3 - 5
Tour guide seat	2 - 32	Horns	3 - 5
Mirrors	2 - 32	Alarm system	3 - 6
Exterior compartments (XL-40)	2 - 34	Safety equipment	3 - 6

Controls/Instruments

KEYS

Depending on optional equipment, up to nine (9) different key models may have been supplied with your vehicle. They are used as described below:




FIGURE 1
23014A

1. Ignition switch.
2. Tachograph.
3. Towel dispenser.
4. Lavatory door lock.
5. Entrance door lock.
Baggage compartments door lock.
Front electric compartment door lock.
Steering compartment door lock.
Rear service compartments door lock (XL-45 only).
Main power compartment (XL-45 only).
6. Video system compartment door lock.
7. Toilet tissue dispenser.
8. Moist towel dispenser.
9. Video monitor lock.

NOTE: Baggage doors can also be remotely locked/unlocked using the Central Locking System Switch, located on L.H. Side Control Panel.

NOTE: For added security, record the key numbers and keep this information in a safe place. Do not keep these records inside vehicle. It is also advisable to deposit a duplicate of each key in a safe place, so they can be obtained without difficulty in case of an emergency or loss.

MAIN BATTERY DISCONNECT SWITCH

XL-40

The manual switch which connects or disconnects both the 12 and 24 volt systems is located next to the R.H. Side Rear Baggage Compartment door.




FIGURE 2

06047

XL-45

The toggle switch which disconnects both the 12 and 24 volt systems is located on the back wall of the Main Power Compartment. Use this switch for maintenance purposes only. The remote battery master switch which also disconnects both 12 and 24 volt systems is located on the L.H. lower switch panel (see item #2 on page 2-14).



FIGURE 3

06102A

CAUTION: When the vehicle is parked overnight or for an extended period of time, the main battery disconnect switch (XL-40) or the battery master switch (XL-45) (see page 2-14) should be set to the "OFF" position in order to avoid battery voltage imbalance.

NOTE: When the battery disconnect switch (XL-40) or the battery master switch (XL-45) is set to the "OFF" position, the electrical supply from the Batteries is cut off, with the exception of the Fire Detection System, the Engine & Transmission Electronic Controls, the Auxiliary Heating System, the Battery Equalizers and the Digital Clock(s).

FUEL TANK FILLING

On **XL-40** vehicles, the fuel filler neck is accessible by opening a small door located amidships on the R.H. side of the vehicle. On **XL-45** vehicles, each of the two fuel filler necks is accessible by opening a small door located amidships on either the R.H. or L.H. side of the vehicle.



FIGURE 4

18013A

NOTE: Provided vehicle is parked level, an automatic nozzle will shut off when tank is filled to approximately 95% capacity.

CAUTION: Do not fill to more than 95% of fuel tank capacity. Do not "top off" the tank; doing so may result in fuel spillage when the fuel expands.

CONTROLS AND INSTRUMENT PANELS




FIGURE 5
18114A

No.	Panel	Pg.	No.	Panel	Pg.
1	L.H. Side Control Panel	2-4	5	Detroit Diesel PRODRIVER™ Controls	2-20
2	L.H. Lower Switch Panel	2-14	6	R.H. Console	2-15
3	Dashboard (without Tachograph) Dashboard (with Tachograph)	2-7 2-8	7	R.H. Lateral Console	2-22
4	R.H. Lower Switch Panel	2-15			

L.H. Side Control Panel

1. Adjustable louver

The louver is manually adjustable, so the heated or cooled air flow can be directed towards driver or side window.

2. Cruise control switches (see page 2-5)

3. Baggage door lock (Optional)

Push up rocker switch to unlock the baggage doors and push down to lock. For additional information see page 2-38 under heading "Baggage compartment".

4. Transmission retarder (Optional) or Engine retarder (Optional) or Blank

Transmission retarder: Push down rocker switch to actuate transmission retarder. For system description, see page 4-4.

"Jacobs" engine retarder: Push down rocker switch to the first position to actuate system to 2/3 engine brake and press to the second position for a full application of engine brake. For system description, see page 4-3.

5. Destination sign

Push down rocker switch to energize the destination sign.

6. Exterior mirror heating switch

Push down rocker switch to operate the heating elements that clear frost, fog or thin ice from rear-view mirrors.

7. Stop/Service chime power switch

Push down rocker switch to power the chimes system (optional) which allows passenger operation of both the stop (disembarking) button and the service button. See page 2-44 for system description.

8. Driver's light switch (overhead lights)

Push down rocker switch to turn on the two (2) ceiling lights above driver. These lights are frequently used for nighttime operation when passengers board or leave the coach.




FIGURE 6: L.H. SIDE CONTROL PANEL

18108A

9. Fluorescent lighting

Push down rocker switch to turn on the interior fluorescent lights, located under parcel racks. Use of these lights should be avoided when engine is not running.

10. Reading lamps

Reading lamps are controlled by two (2) different switches. Push down this rocker switch to energize the whole reading lamp circuit. Individual lamps can then be activated by each passenger using the switch incorporated in lamp body. Reading lamps are mounted under parcel racks.

11. Dome lights

Push down rocker switch to turn on the aisle dome lights located on front of parcel racks.

12. Kneeling/Hi-Buoy control switch (Optional)

Kneeling: Momentarily push down rocker switch to lower the front end of coach 4 inches (100 mm), and up to return the coach to normal driving height. See page 3-3 for system description.

Hi-Buoy: Push up and hold rocker switch to raise the front end of the coach or both front and rear ends (depending on option) 4 inches (100 mm). Release the rocker switch to return the coach to normal driving height. See page 3-3 for system description.

13. Galley power switch (Optional)

Push down rocker switch to energize the galley's electrical circuit.

14. Microphone jack

Driver's P.A. system microphone jack (see page 2-18 for details).

15. L.H. outside mirror control (Optional)

Turn pointer knob to the left for mirror head adjustments and to the right for convex mirror adjustments, then push down on either of the button's four (4) sides to adjust the selected mirror's viewing angle.

NOTE: If the mirror assemblies on your vehicle do not include convex mirrors, only one (1) "Outside Mirror Control" will be installed for both mirrors (replacing items 15 & 16).

To operate, turn pointer knob to the left for L.H. mirror adjustments and to the right for R.H. mirror adjustments, then push down on either of the four (4) sides to adjust the selected mirror's viewing angle.

16. R.H. outside mirror control (Optional)

Turn pointer knob to the left for mirror head adjustments and to the right for convex mirror adjustments, then push down on either of the button's four (4) sides to adjust the selected mirror's viewing angle.

17. Diagnostic data reader connector

Datalink for DDEC 3, WT World Transmission and ABS brakes.

CRUISE CONTROL**Introduction**

The cruise control is an automatic speed control system that allows you to maintain a constant cruising speed above 20 m.p.h. (32 km/h) without depressing the accelerator pedal. The four (4) control switches are located on the L.H. side control panel (see page 2-4, items #2).

WARNING: Do not use the cruise control system when driving conditions do not permit maintaining a constant speed, such as in heavy traffic or on roads that are windy, icy, snow covered, slippery, or with a loose driving surface.

Setting vehicle speed

To turn on the system, push down "CRUISE" rocker switch, set the vehicle speed by accelerating to the desired speed, momentarily press and release the "SET" switch, and then remove your foot from accelerator pedal. This sets the cruising speed and stores it in memory, thus maintaining speed automatically.

NOTE: Cruise control system will not accept speed settings, nor will the "RESUME" switch operate, below approximately 20 m.p.h. (32 km/h).

Increasing set speed

Vehicle speed setting may be increased by one of the following methods:

1. Press and hold the "RESUME" switch until the desired speed is obtained. Releasing the "RESUME" switch will set the new higher speed.
2. Depress accelerator pedal until the desired speed is obtained, then press and release the "SET" switch.

decrease or increase in speed (respectively) of 0.6 m.p.h. (1.0 km/h) for every touch.

NOTE: *When driving with cruise control in operation, the speed may be increased for passing, etc., by depressing the accelerator in the usual manner. Once the foot is removed from the accelerator pedal, the cruise control will return to the set speed.*

Decreasing set speed

Vehicle speed setting may be decreased by one of the following methods:

1. Press and hold the "SET" switch until the desired lower speed is obtained. Releasing the "SET" switch will set the new speed.
2. The cruise control can be disengaged without losing the speed memory by either of two methods:
 - a) Lightly applying the brakes, or
 - b) momentarily depressing the "DECEL" switch button.

After either of these disengagements, you may return to the previously set speed by pressing and releasing the "RESUME" switch, provided the speed is higher than 20 m.p.h. (32 km/h). The cruise control is completely shut off and the speed memory is lost when turning off the "CRUISE" rocker switch.

NOTE: *Cruise control is inoperative when speed drops below 20 m.p.h. (32 km/h), therefore the setting instructions must be repeated if vehicle speed drops below this mark. When the cruise control system is canceled, objectionable vehicle motions are minimized by lightly depressing accelerator, before disengaging cruise control.*

WARNING: *It is important to know that toggling the "SET" or the "RESUME" switch will result in a*

Dashboard (without Tachograph)




FIGURE 7

18113A

- | | |
|--|---|
| 01.....Kneeling/Hi-buoy, or Low Buoy,
or High Buoy (All Optional), or Blank | 19.....Primary air pressure gauge |
| 02.....Water separator (Optional), or Blank | 20.....Fuel gauge |
| 03.....Tag axle unloading, or Retractable
tag axle (Optional) | 21.....Voltmeter |
| 04.....Lavatory door lock | 22.....Differential oil temperature
gauge (Optional), or Blank |
| 05.....Parking brake | 23.....Electrical systems (XL-45 only), or Blank |
| 06.....L.H. turn signal - Hazard | 24.....Baggage compartment door lock
(Optional), or Blank |
| 07.....Low secondary air pressure | 25.....Antilock braking system
(Optional), or Blank |
| 08.....Low primary air pressure | 26.....Transmission "DO NOT SHIFT" light |
| 09.....R.H. turn signal - Hazard | 27.....Low fuel level (Optional), or Blank |
| 10.....High beams | 28.....Preheating system (Optional), or Blank |
| 11.....Battery | 29.....Output retarder (Optional), or Blank |
| 12.....Battery balance | 30.....Brake light |
| 13.....High or low battery voltage | 31.....Check engine |
| 14.....Secondary air pressure gauge | 32.....Stop engine |
| 15.....Engine coolant temperature gauge | 33.....Speedometer-Odometer |
| 16.....Engine oil pressure gauge | 34.....Tachometer |
| 17.....Transmission oil temperature
gauge (Optional), or Blank | 35.....Instrument and switch
brightness control |
| 18.....Turbo boost pressure
gauge (Optional), or Blank | |

Dashboard (with Tachograph)




FIGURE 8

18112A

- | | |
|---|--|
| 01.....Kneeling/Hi-buoy, or Low Buoy, or High Buoy (All Optional), or Blank | 19.....Fuel gauge |
| 02.....Water separator (Optional), or Blank | 20.....Voltmeter |
| 03.....Tag axle unloading, or Retractable tag axle (Optional) | |
| 04.....Lavatory door lock | 21.....Turbo boost pressure, differential oil temperature gauge (Optional), or Blank |
| 05.....Parking brake | 22.....Brake light |
| 06.....L.H. turn signal - Hazard | 23.....Baggage compartment door lock (Optional), or Blank |
| 07.....Low secondary air pressure | 24.....Output retarder (Optional), or Blank |
| 08.....Low primary air pressure | 25.....Antilock braking system (Optional), or Blank |
| 09.....R.H. turn signal - Hazard | 26.....Preheating system (Optional), or Blank |
| 10.....High beams | 27.....Electrical systems (XL-45 only), or Blank |
| 11.....Battery | 28.....Transmission "DO NOT SHIFT" light |
| 12.....Battery balance | 29.....Low fuel level (Optional), or Blank |
| 13.....High or low battery voltage | 30.....Stop engine |
| 14.....Secondary air pressure gauge | 31.....Check engine |
| 15.....Engine coolant temperature gauge | 32.....Tachograph (Optional) |
| 16.....Engine oil pressure gauge | 33.....Instrument and switch brightness control |
| 17.....Transmission oil temperature gauge (Optional), or Blank | |
| 18.....Primary air pressure gauge | |

Dashboard indicator/warning lights and instruments



Kneeling/Hi-buoy (Optional), or **Low Buoy** (Optional), or **High Buoy** (Optional)

Lights when either of the three (3) Optional Suspension Systems is operating. See page 2-5 for Kneeling/Hi-buoy and High Buoy system descriptions and page 2-23 for Low Buoy.



Water separator (Optional)

Lights when the accumulated water in the diesel fuel filter/water separator should be drained (see page 6-7).



Tag axle unloading (Standard), or **Retractable tag axle** (Optional)

Depending on which system was installed on your coach, the indicator light will illuminate when the tag axle is unloaded or retracted. Furthermore, an alarm will sound, telling the driver that the axle is unloaded/retracted. See pages 2-23 & 4-21 for both system descriptions.



Lavatory door lock

Illuminates when the lavatory door is locked.



Parking brake

Lights when parking brake is applied (see page 2-23).



L.H. turn signal - Hazard

Flashes when L.H. turn signal is selected with multifunction lever or when hazard switch is turned on. (When hazard switch is turned on both L.H. and R.H. turn signals will flash.)



Low primary air pressure

Lights when air pressure in primary system is too low. For System information, see "BRAKES" on page 3-1.



Low secondary air pressure

Lights when air pressure in secondary system is too low. For System information, see "BRAKES" on page 3-1.



R.H. turn signal - Hazard

Flashes when R.H. turn signal is selected with multifunction lever or when hazard switch is turned on. (When hazard switch is turned on both L.H. and R.H. turn signals will flash.)



High beams

Lights when headlight high beams are selected.



Battery

Lights when alternator is not functioning properly.



Battery balance


Lights when batteries are out of balance.

NOTE: Before seeking assistance, check that the demand for the 12 volt power is not exceeding rated amperage output of battery equalizer(s), and also check circuit breaker on battery equalizer(s) (for location, see page 4-17). Allow at least 15 minutes to balance batteries after corrective measures have been taken.



High or low battery voltage

Lights when battery voltage exceeds 30 volts or drops below 24 volts.




Engine coolant temperature gauge

Indicates engine coolant temperature. Normal reading should vary from 190 to 215°F (88 to 102°C).

In extremely hot weather and high altitude, the coolant temperature can reach 215°F (102°C) and more when climbing a long grade at full throttle. If this situation occurs, the "check engine" light will come on (at 217°F - 103°C) and the engine overtemperature protection system (EOP) will be activated. If the cooling system is properly maintained, the temperature should stabilize below the shut back temperature of


222°F (106°C) so the vehicle can operate normally. See also item # 31 on page 2-7.

NOTE: Engine is not considered "overheating" when below 215°F (102°C).



Oil pressure gauge


Indicates engine oil pressure. Normal reading at operating temperature should vary from 50 to 70 psi (345 to 483 Kpa) at cruising speed.



Transmission oil temperature gauge (Optional)

Indicates transmission oil temperature. Normal reading can vary from 160 to 250°F (70 to 120°C).

NOTE: On vehicles equipped with a transmission retarder, the temperature may rise to a maximum of 330°F (165°C) if operated for extended periods.




Turbo boost pressure gauge (Optional)

Indicates turbo boost pressure in psi. Reading depends on engine rpm and load conditions. It is


normal that pressure reaches the gauge's maximum level.

NOTE: If the "Differential oil temperature gauge" is not a chosen option on your vehicle, then "Turbo boost pressure gauge" will be located in its position.



Primary and secondary air pressure gauges (Brakes)


Indicate air pressure in the primary and secondary systems. Normal readings vary from 95 to 125 psi (655 to 860 Kpa).



Fuel gauge


Indicates the amount of fuel remaining in the fuel tank. If your vehicle has an optional auxiliary tank, the gauge will show the total fuel level, as the tanks are interconnected.

CAUTION: Operating the vehicle when the reading is below 1/8 full is not recommended.



Voltmeter

Indicates electrical system voltage. With engine operating, normal reading should be 27.5 volts.



Differential oil temperature gauge (Optional)

Indicates differential oil temperature. Normal reading should not exceed 250°F (120°C).

NOTE: If "Differential oil temperature gauge" is not a chosen option on your vehicle, then "Turbo boost pressure gauge" will be located in this position if it is a selected option.



Electrical systems indicator (XL-45), Dummy (XL-40)

Illuminates if the battery master switch (located on L.H. Lower Control Panel - see page 2-14) is left "ON" when ignition switch is turned "OFF".



Baggage compartment door lock indicator (Optional)

Will light if any one or several of the baggage compartment doors are unlocked.



Antilock braking system (Optional)

Lights until vehicle speed reaches 4 mph (7 km/h), and when the antilock braking system is malfunctioning.



Transmission "DO NOT SHIFT" light

See page 4-5 for description.



Low fuel level

XL-40 vehicles:

Lights when approximately 12 U.S. gallons (45 liters) of fuel remains in the tank.

It is recommended that you do not exceed a distance of 75 miles (120 km) after light has turned on. Light will illuminate "ON" & "OFF" just before running out of fuel. Fill tank as soon as possible.

XL-45 vehicles:

Lights when approximately 17 U.S. gallons (64 liters) of fuel remains in the tank.

It is recommended that you do not exceed a distance of 100 miles (160 km) after light has turned on. Light will illuminate "ON" & "OFF" just before running out of fuel. Fill tank as soon as possible.



Preheating system (Optional)

Lights when preheating system is turned on. For systems description, see pages 4-13 & 4-14.



Output retarder (Optional)

Lights when transmission's output retarder is activated. For system description, see page 4-4.



Brake light

Lights when brakes are activated.



Check engine

Will light if a minor engine malfunction is detected by the DDEC (Detroit Diesel Electronic Control) system. This includes any situation where the engine coolant reaches 217°F (103°C) because of cooling system problems or because of situations described on page 2-10 (Engine coolant temperature gauge). This light will remain illuminated until malfunction is corrected. Furthermore, this indicator flashes to indicate engine malfunction codes when the required procedure outlined on page 5-12 has been performed.

NOTE: As a light bulb and systems check, this indicator will illuminate when the ignition switch is turned "ON". After about five seconds the light will turn off.




Stop engine

Will light when major engine problems occur. The engine power will automatically begin to decrease gradually and will be followed by an automatic shutdown after 30 seconds. This 30 second delay period may be repeated using the "Stop Engine Override Switch" outlined further on page 2-15 (item #5).

NOTE: Once engine is stopped, it cannot be restarted until malfunction is corrected.

As a light bulb and systems check, this indicator will illuminate when the ignition switch is turned "ON". After about five seconds the light will turn off.




Speedometer-odometer

The speedometer indicates the vehicle speed. The odometer indicates the distance driven;


U.S. vehicles: Miles/Kilometers (Miles predominant)

Canadian vehicles: Kilometers/Miles (Kilometers predominant)



Tachometer

The tachometer indicates the operating speed of the engine in hundreds of revolutions per minute (RPM x 100). The tachometer serves as a guide for gear shifting, and helps prevent engine overspeeding when going downhill with the Jacobs engine brake operating. The maximum allowable engine speed is 2,450 rpm.



Tachograph (Optional)

Speedometer

Indicates coach speed in miles per hour (mph - US models) or Kilometers per hour (km/h - Can. models).

The speed-warning light, located in the lower section of the dial, is set by the adjusting screw

located in the left half of the tachograph body. The speed at which the warning occurs is displayed in a small window.




FIGURE 9

18115B

CAUTION: The Tachograph is factory programmed. Do not change dip-switch positions.

Odometer

The odometer registers the distance traveled either in miles (US models) or kilometers (Can. models).

Tachometer

Indicates the operating speed of the engine in hundreds of revolutions per minute (RPM x 100). The tachometer serves as a guide for gear shifting, and helps prevent engine overspeeding when going downhill with the Jacobs engine brake operating. The maximum allowable engine speed is 2,450 rpm.

Clock

The clock operates continuously, even if the main battery disconnect switches are set to the OFF position. To set the clock, open the tachograph cover using the key provided, and set the time using the thumb wheel on the L.H. side of the tachograph.

Diagram Chart

The diagram chart recording speedometer and tachometer data covers a 24-hour period. Open the tachograph cover using the key provided, then insert the diagram chart with the MPH or KM/H side facing up. Make sure the chart is correctly positioned on the drive boss before closing the cover.

CAUTION: To prevent damage to the mechanism, do not run the engine with a damaged diagram chart or without a diagram chart. Install a dummy plastic card (Prévost part no. 590251) if the coach is operated without a diagram chart.

Instrument & switch brightness control

Adjust as required. Brightness is progressively dimmed as control knob is rotated clockwise.

NOTE: Dashboard panel gauges show approximate readings and should not be relied upon for mechanical adjustments.

L.H. lower switch panel




FIGURE 10

18116A

Switches

1. Ignition

The ignition switch has four (4) positions:

"ACCESSORIES": Turn key counterclockwise; only the vehicle accessories are operational and key cannot be removed.

"OFF": Ignition is "OFF" and key can be removed.

"ON": Ignition is "ON" and key cannot be removed.

"START": Starting position; spring-loaded ignition switch returns to "ON" position after starting. Ignition key must be returned to "OFF" position before trying to restart.

WARNING: Do not engage starter for more than 15 seconds. Allow starter time to cool before engaging again. This will prevent starter from overheating and will allow the time delay relay to cool.

2. XL-40: Blank for additional switch.

2. XL-45: Battery master switch

Both the 12 volt and the 24 volt systems are activated by the master switch. The indicator light (located on dashboard - see page 2-7, item #23) will illuminate if switch is left "ON" when ignition switch is turned "OFF".

CAUTION: When vehicle is parked overnight or for an extended period of time, battery master switch should be set to the "OFF" position.

NOTE: When battery master switch is set to the "OFF" position, the electrical supply from the batteries is cut off, with the exception of the Fire Detection System, the Prodriver™, the Engine & Transmission Electronic Controls, the Auxiliary Heating System, the Battery Equalizer and the Tachograph power supply.

3. Fast idle

Push down rocker switch to engage fast idle, thus increasing engine speed to approximately 1100 rpm. Use this switch for extended stops.

CAUTION: Idling produces sulfuric acid which breaks down the oil and eats into bearings, rings, valve stems and engine surfaces. If you must idle the engine, the high idle function should be used.

NOTE: If parking brake is released and/or transmission is shifted with the engine running at fast idle, engine will reduce its speed to idle and maintain this rpm as long as parking brake is not applied and/or transmission is in the neutral position. If engine is stopped with the fast idle

switch in the "ON" position, this control will automatically be canceled when restarting the engine; the driver must then shut off, and reset rocker switch to reactuate fast idle. Fast idle should be reduced to low idle before shutting off engine.

4. Ether cold starting aid (Optional) or Blank

Activates ether cold starting device in engine compartment (see "Cold weather starting" page 4-7).

5. "Stop Engine" override

Push down rocker switch to reset the 30 second delay period and the shutdown procedure. This switch can be repeatedly depressed, i.e. **one (1) pulse is sufficient for each 30 second period**, for engine power in an emergency situation.

NOTE: The stop engine override switch will be operative only if it has been depressed before the end of the 30 second delay period.

CAUTION: The "Stop Engine" override must be used only in emergency situations to bring vehicle to a safe stop. Excessive use of this switch could cause serious damage to the engine.

R.H. lower switch panel




FIGURE 11

18021C

Switches

1. Hazard flashers

Push down rocker switch and all turn signal lights will flash simultaneously. Turn signal indicator lights in dashboard will also flash.

2. Fog lights (Optional) or Blank

Push down rocker switch to activate fog lights as well as clearance, tail and marker lights. Before using fog lights, remove protective covers by pulling on their edges.

WARNING: Before removing protective covers, stop engine and apply parking brake.

3. Exterior lighting switch

Push down rocker switch to the first position to activate clearance, tail & marker lights and to the second position for headlights.

4. Blank for additional switch

5. Auxiliary A/C (Optional) or Blank

Push down rocker switch to activate auxiliary A/C system (see page 4-13, item #9).

6. Blank for additional switch

7. Blank for additional switch

R.H. console




FIGURE 12

18111A

1. Audio/Video control unit

The control unit is used to control audio and video in the coach.

For more information refer to the Audio/Video Control Unit section below.

2. Central A/C - heating system controls

These controls are used to obtain desired temperature inside vehicle. For system description see page 4-11.

3. AM/FM stereo cassette receiver with CD changer remote

Instructions for proper utilization of AM/FM stereo unit are included in the technical publications package supplied with the coach.

4. Driver's A/C - heating system controls

These controls are used to obtain desired temperature in driver's area. For system description see page 4-12.

5. Adjustable louver

The louver is manually adjustable, so the heated or cooled air flow can be directed as desired.

NOTE: An additional adjustable louver is located on L.H. side control panel to defrost window. A third adjustable louver is located at extreme right of dashboard and can be used to concentrate warm air on windshield area used to view exterior R.H. side mirror.

AUDIO/VIDEO CONTROL UNIT

The control unit allows the driver to control up to three audio selections. The unit also contains a video section for controlling the video cassette player (VCP).





FIGURE 13

23112

1. Adjusting the sound

Controlling the volume/bass/treble.



Each time the SELECT button is pressed, the display indicator will change and show BASS, TREB, or VOL. Once the display shows the parameter you wish to adjust, press the V button to decrease or the Δ button to increase adjustment level.

FIGURE 14

23113

2. Controlling the Passenger Section

The three buttons (RADIO, VIDEO, and AUX) in the PASSENGER section are used to control what audio input is being sent to the passenger's speakers. The display will indicate the current selection. If the current selection button is pressed again, the passenger's audio will be muted. The display will indicate this by alternately displaying the current selection and MUTE. The audio will be restored if any of the level controls are activated or the Passenger Selection buttons are pressed again. See figure 16 for the functions of the buttons in the passenger section.




FIGURE 15

23114




FIGURE 16

23115

3. Controlling the Video Section

Once the VIDEO button is pressed, the video system goes into a ten second delay. This is to allow the VCP time to position the tape. This is indicated by the display flashing VID on and off. During this time, there will be no passenger audio. If a video function button is pressed during this time, the command will be retained and performed after the delay is complete.




FIGURE 17

23116

4. Controlling the Driver Section

The driver may select between the radio or the auxiliary audio. The current selection is indicated by the LED next to the button. Pressing the active button a second time will mute the driver's audio. To restore the driver's audio, press the desired driver's selection button. The driver's sound is

controlled by the Volume and Tone controls on the front of the radio. These controls have no effect on the passengers audio. The radio must be in the "On" position in order to have radio audio available for either the passengers or the driver.




FIGURE 18

5. Controlling the PA Section

The external speaker option (EXT) of the PA section is not used as only internal speakers are installed at the factory.

PUBLIC ADDRESS (P.A.)

Microphone jacks

There are two (2) standard PA system microphone jacks installed on vehicle; one just below driver's L.H. side control panel and the other on central console. Five (5) optional microphone jacks can be installed in the following locations:

- One on back of modesty panel.
- One on back of driver's guard.
- One on R.H. lateral panel.
- One on lavatory's exterior front wall.
- One on parcel rack of owner's choice.

Whenever any of the microphone inputs are activated, the control unit switches over to the PA mode. The PA has priority over all the other

selections. When activated, all other audio is muted and the radio cassette player is stopped. The PA system may be activated even when the control unit's Power button is not activated. When this is done, there is a short delay while the amplifier is powering up.

As an option, a wireless microphone (fig. 19) and receiver (fig. 20) may also be installed. To operate the wireless microphone, simply slide the microphone power switch to the ON position and push in the receiver power switch.

The 9 volt battery of the microphone should be replaced if the battery-low indicator (LED) stays on when the power switch is at the ON position (if the battery is good, the indicator will only flash once as the switch is slid to the ON position.)




FIGURE 19: WIRELESS MICROPHONE

23119




FIGURE 20

23120

The back-up PA system is provided in the event that the PA function of the control unit is not operating properly. Figure 21 shows the location of the back-up PA system.




FIGURE 21

23121

Interphone (Optional)

Use the Interphone for communications between driver and host/hostess. Master receiver is located in driver's area and secondary receiver is installed on lavatory exterior front wall. To use system, simply unhook receiver and press button identified with an asterisk (*); buzzer will sound at other end.

VIDEO CASSETTE PLAYER

Activate all video system components by depressing the POWER and VIDEO buttons located on the Audio/video control unit mounted on R.H. console. The VCP can be operated from the control unit and VCP front panel.

NOTE: The video will not operate unless the control unit is energized and the VIDEO button depressed. After the audio/video control unit is energized, there is a ten second delay before the VCP and monitors power on.




FIGURE 22

23117

1. Video Cassette Compartment

2. Power button

3. Rew (Rewind/Reverse Picture Search) button

Push to rewind the video tape. When a tape is playing, momentarily press to engage the reverse search mode.

4. Play button

Push to play the video tape. When auto tracking is working, the PLAY indicator light blinks.

5. FF (Fast forward/Forward Picture Search) button

Push to fast-forward the video tape. Push momentarily to engage the forward search mode.

6. Stop/Eject button

Push to stop video tape play.

7. Tracking Control Knob.

Use this control during playback to correct picture alignment.

8. Auto Repeat Button

Push this button to turn on the auto repeat feature. With this feature activated, the VCP automatically rewinds the tape and returns to the play mode. If this feature is not activated, the VCP rewinds and ejects the tape when the end of the tape is reached.

9. Record Button

10. Infrared Remote Sensor

Receives information from the infrared remote control.

11. Record Speed Button

TV TUNER

1. Power Button

Turns unit on or off.

2. Power Indicator

Dim light when power present but unit turned off. Bright light when unit is turned on.

3. Auto Programming Button

Press once to program tuner.

4. Channel Change Buttons.

Press once to change channel.

5. Infrared Sensor

Provided for optional remote control.




FIGURE 23

23118

Engine data display & computer - ProDriver™




FIGURE 24

18034

ProDriver™ is a graphic device that displays and records operational data transmitted by the Detroit Diesel Electronic Controls (DDEC) on the diagnostic data link. It utilizes a vacuum fluorescent (VF) display for wide viewing angles and excellent visibility in all ambient light conditions.

ProDriver™ has many driver friendly features designed to provide instantaneous feedback to the driver. This allows him to understand the effect of his actions on engine and vehicle performance. There are two (2) display screens automatically shown, which offer real time feedback based on the vehicle activity. Should an alert message be sent out by the ECM, the driver will be shown what is wrong and how the engine power will change.

Data available from ProDriver™ includes:


- Instantaneous and average fuel economy
- Trip time, miles, fuel used, fuel economy, average speed
- Driving time, percentage, miles, fuel used, fuel economy
- Idle time, fuel and percentage
- Cruise time, percentage, miles, fuel used, fuel economy
- Top gear time, percentage, miles, fuel used, fuel economy
- VSG (Variable Speed Governor) time, fuel used, and percentage


- Overspeed time and percentage for two (2) speed thresholds
- Over-rev time and percentage
- Maximum vehicle speed and RPM
- Coasting time and percentage
- Automated oil change interval tracking
- Hard braking incident records
- Driver initiated incident records
- Stop and check engine code logs.
- Optimized Idle™ active time, idle time, and estimated fuel savings
- J1587 data link timeouts and power interruptions
- Leg time, miles, fuel used, fuel economy, average speed, and cruise time and percentage
- Accident Incident Records.



ProDriver™ - Quick Reference

NOTE: The following information is only for reference and does not attempt to teach how to operate the ProDriver™. You must refer to Detroit Diesel ProDriver™ User Manual (6SE701 9511), for a full description on how to set up and operate your ProDriver™ display.

Button functions

 Displays main menu or previous menu level.

 Displays selected menu options; saves new data.

 /  Move selection arrow up or down, or move from screen to screen when multiple screens are available

Button combinations

Press  and  at the same time to store an incident record.

Special button functions

Alternate labels are displayed along the bottom of the screen directly over each button when the buttons are used to perform special functions.

DISPLAY SCREENS

Idle time

Automatically displayed when engine is idling. Shows idle time for current leg of the trip and as a percentage of engine running time. A bar graph shows the idle percentage compared to the fleet goal.

Fuel economy

Automatically displayed when the vehicle is moving. Shows average fuel economy for current leg of the trip digitally and as a bar graph, with the fleet goal centered on the screen. Instantaneous economy is shown as a series of arrows. UP arrows show an improving leg average, while DOWN arrows show a decrease. The number of arrows shows the amount of change.

Warning screens

Speeding, over revving, excessive idling and oil change screens will be displayed until acknowledged by pressing any button or the condition ceases. The display will return to the screen previously shown.


Alert screens

Shown if a warning condition exists with the engine. Will be displayed until acknowledged by pressing any button.

NOTE: Menu displays are available only when the vehicle is stationary. The display may be viewed with the ignition OFF by pressing "MENU".

To edit the main menu at idle

IDLE SCREEN,  = MAIN MENU,

 = IDLE SCREEN.

To review leg summary information at idle

IDLE SCREEN, **INFO** = SUMMARY 1,
INFO = SUMMARY 2, **INFO** = IDLE SCREEN.

To review trip summary information at idle

IDLE SCREEN, **MENU** , → TRIP SUMMARY,
INFO = view trip summary page 1,
INFO or **DOWN** = view trip summary page 2.
 Continue to press **INFO** or **DOWN** to view all
 the trip summary pages.
MENU = Main Menu, or
MENU , **MENU** = Idle Screen

To review leg summary info while in motion

ECONOMY SCREEN, **INFO** = SUMMARY 1,
INFO = SUMMARY 2, **INFO** = ECONOMY
 SCREEN.

Display brightness

Temporary adjustments may be made while in
 the Fuel Economy, Idle or Leg Summary
 screens by pressing:

UP or **DOWN**

The normal setting returns the next time the
 engine is started.

Entering driver ID

From the Main Menu screen, →
 Configuration **INFO** , → Driver ID **INFO** ,
 Press **UP** to increment the selected digit.
 Press **DOWN** to select the next digit to the right.
 Press **INFO** to save the completed entry or
 press **MENU** to exit without saving changes.

R.H. LATERAL CONSOLE




FIGURE 25

18117A

1. Tag axle unloaded or retractable

Vehicle can be fitted with either the standard tag axle unloaded system or the optional retractable tag axle system. When valve is switched to the "Wheels up" position, the tag axle air springs are unloaded (depleted) with the tag axle unloaded system or, tag axle is raised with the retractable tag axle system. For both systems' descriptions, see page 4-21.

2. Parking brake control

See "Combination emergency and parking brakes" on page 2-28.

3. Door override

In the event of a malfunction in the front entrance door air lock mechanism, press this button to release air lock (see page 3-4).

4. Parking brake override (Optional) or Low-Buoy (Optional)

Parking brake override: If during normal operation, primary system air pressure drops below 40 psi (276 kPa), spring-loaded parking brakes will automatically be applied at full capacity on drive axle to stop vehicle. Cause of pressure loss should be determined and corrected before proceeding. However, vehicle may also be equipped with an optional parking brake release system (Parking brake override) which will allow driving the vehicle for a short period of time to a safe parking area. To operate, push and hold down the control knob with vehicle in motion.

Low-Buoy: Low-buoy option is used to lower the coach by approximately 4 inches (100 mm) when valve is positioned towards "LOW-BUOY". For system description, see page 3-3.

5. Auxiliary Preheating System Timer (Optional) (WEBASTO (shown) OR ESPAR)

See pages 2-46 & 2-47 for description of both heaters.

5A. Preheater switch

Push down rocker switch to turn "ON" Preheating system; supplementing Central Heating System when required. Preheater will turn "ON" and "OFF" automatically depending on coolant temperature.

6. Transmission push-button shifter

Use shifter to select forward, neutral or reverse gears of transmission. "AUTOMATIC TRANSMISSION" system operations are described hereafter.

AUTOMATIC TRANSMISSION

The operation and driving of this vehicle with an automatic transmission is similar to that of an automobile equipped with an automatic transmission. Proper ranges should be selected according to driving speeds to improve vehicle performance and control. The transmission is fully automatic. Speed ratio of power converter changes automatically as vehicle speed increases and direct-drive goes in and out as necessary, modulated by vehicle speed, and accelerator position.

Range selection - Push-button shifter

The push-button shifter is used by the operator to select Neutral (N), Reverse gear (R), or a range of forward gears. When a forward gear range has been selected, the transmission starts in the lowest gear of the range and, as conditions permit, automatically upshifts until the highest gear in the selected range is in use.




FIGURE 26

18015

The digital display indicates the readout of two (2) digits:

- SELECT** - Range of gears selected by the operator.
- MONITOR** - Current gear of transmission operation.

Each time a button is pressed on the shifter a short "beep" will be heard to identify that the ECU has received instructions to change operation. The function of each button is as follows:
Select **REVERSE** gear by pressing "**R**".

Select **NEUTRAL** by pressing "**N**". Note the raised edge around the "**N**" button so the driver can orient his hand to the push-buttons by touch, without looking at the display. It is not necessary to press this button prior to starting the vehicle.

Select **DRIVE** range by pressing "**D**". The highest forward gear will appear on the *SELECT* display and the transmission will shift to the starting gear as indicated on the *MONITOR* display.

The *UPSHIFT* and *DOWNSHIFT* (arrow) buttons are used to shift to a higher (if not in "**D**") or lower (if not in "**1**") range selected. One press changes the range selected by one range. If the button is pressed continuously, the range selected continues to change up or down until the button is released or until the highest or lowest possible range of gears is selected.

Function of the mode button

This button is used to invoke a special function (mode) that has been programmed into the ECU. The two most common modes are:

- ⌚ the "*ECONOMY*" mode which allows for more efficient operation of the transmission and thereby helps contribute to improve fuel economy. The mode status will be indicated on the digital display by lighting "*MODE ON*" when the function has been selected.
- ⌚ the "*PERF*" (performance) mode which allows for higher performance than the economy mode but with a higher fuel consumption. The mode status will be indicated on the digital display by lighting "*MODE ON*" when the function has been selected.

Shift schedule

PRIMARY - This shift schedule is used each time the vehicle is started. Typically, this is used for normal vehicle operation.

SECONDARY - This is an alternate shift schedule that the ECU may use upon request. Select the secondary shift schedule (*ECONOMY*) via the **MODE** button.

HOLD UPSHIFT - This shift schedule permits upshifts if an overspeed condition should occur by the transmission remaining in a lower range. These shifts occur at speeds higher than normal upshifts.

In most cases the control system logic protects the transmission from abuse. Such actions as full throttle neutral-to-range shifts and high speed direction changes are inhibited.

Operation

When a push-button pad is depressed, a beep sounds and the pad lights up indicating the transmission is ready to operate in the selected range. When the electronic control system detects a serious problem in the transmission, a buzzing tone sounds for 5 seconds, and the "*DO NOT SHIFT*" light on the dashboard (see page 2-11) illuminates to warn the driver that the transmission is held-in-gear. If another pad is depressed, the buzzing sound will continue until the original range is selected.

NOTE: *As a light bulb and systems check, the "DO NOT SHIFT" light will illuminate when the ignition switch is turned "ON". After about two seconds the light will turn off. If the "DO NOT SHIFT" light remains on, the self-diagnostic system has detected a problem. If the problem disappears, the light will go out, but a trouble code will remain stored in the ECU.*

A) Reverse (R)

Use this position to back up vehicle. Stop completely before shifting from forward to reverse or from reverse to forward. Touch the reverse (R) pad, the pad will light up and the reverse warning signal will be activated.

B) Neutral (N)

Use this position to start engine. Select neutral (N) when checking vehicle accessories, and for extended periods of engine idle operation; parking brake must then be applied. The pushbutton shifter will automatically select neutral when the master switch is turned on.

CAUTION: *Detroit Diesel engines should not be idled for extended periods at "low" idle. For extended idling, engine should run at "fast" idle.*

WARNING: *Always apply parking brake before leaving driver's seat.*

Do not allow your vehicle to "coast" in Neutral. This practice can result in transmission damage. Also, no engine braking is available in Neutral.

C) Drive (D)

Use this position for all normal driving conditions. After touching this pad, the vehicle will start in first or second range and will automatically upshift to a higher range as output speed increases. As the vehicle slows down, output speed decreases, and the transmission automatically downshifts to the correct range. If a locked brake or a slick surface condition should occur, the ECU (Electronic Control Unit) will command converter operation (disconnect lockup) and inhibit downshifts for a period of time or until normal wheel speed has been restored.

NOTE: *The transmission should normally be allowed to shift itself, but manual shifting can be used as described below.*

D) Fourth (4) and Third (3) ranges

Select these ranges when driving on moderate grades, or when load and traffic conditions require the use of limited speed.

E) Second (2) range

Select this range when operating in heavy and congested traffic. The transmission will start in first and automatically upshift to second. When slowing, the transmission will automatically downshift to first range. Low ranges provide progressively greater engine(*) and retarder(*) braking power (the lower the range, the greater the engine(*) and retarder(*) braking effect).

F) First (1) range

Select this range when pulling through mud and snow, or when speed control is needed for driving up steep grades. This range also provides maximum engine(*) braking power or retarder(*) braking effect. In the lower ranges (1, 2, 3, and 4), transmission will not upshift above the highest gear selected unless recommended engine governed speed for that gear is exceeded.

CAUTION: *Service brakes (foot pedal) should not be used to control the speed of vehicle on long, steep descents. Instead, lower transmission ranges should be used (in conjunction with output retarder(*)). When descending in lower ranges, care must be taken that engine speed does not exceed 2450 rpm. This procedure keeps service brakes cool and ready for emergency stopping.*

- (*) - Refers to "JACOBS engine brake" and "Transmission output retarder" options. See pages 4-3 & 4-4 for details regarding both systems.

MANUAL TRANSMISSION 6 OR 7-SPEED

The manual transmission has 6 or 7 forward speeds (including creeper) and one reverse.

NOTE: *A Spicer PS145-7A, 7-speed transmission, is specified with the 12.7 liter, series-60, 400-horsepower engine and a PS130-6B, 6-speed, is specified with the optional 11.1 liter, 325-horsepower engine.*




FIGURE 27

07008

The transmission shift lever located to the right of the driver's seat is used to select gears. The coach is equipped with a safety switch to prevent accidental starter engagement if the shift lever is not in the neutral position.

When shifting from neutral to first or reverse gear, depress the clutch pedal fully to activate the clutch brake. This makes it easier to shift from neutral to forward or reverse.

CAUTION: To avoid damaging the clutch brake mechanism, do not fully depress the clutch pedal when the coach is in motion.

Upshifting

Always start moving the coach forward with the transmission in first gear, then shift to second, third, fourth, fifth, sixth and seventh gears (if applicable). Do not skip gears. Do not shift to the next higher gear until the engine speed has reached 1,900 rpm. Double clutching is recommended for shifting gears.

Downshifting

Double-clutching is also recommended for downshifting. Always change to a lower gear to avoid engine lugging. Use lower gears when driving uphill or downhill, and when driving on ice, snow or mud (minimum 1,400 rpm).

Use lower gears when driving downhill to make full use of engine compression. Never let the engine operate above 2,450 rpm.

Under normal driving conditions, it is not always necessary to downshift through all gears. Downshift from seventh to first gear after bringing the coach to a complete stop.

CAUTION: Never let the engine operate above 2,450 rpm.

CAUTION: Always leave the shift selector in neutral when the coach is parked.

CAUTION: To prevent premature clutch wear, always start driving the coach with the transmission in first gear.

CAUTION: Before ascending or descending a long or steep grade, reduce speed and shift to a lower gear. Use lower gears to control speed and avoid prolonged or frequent braking which will result in brake overheating and reduce brake effectiveness. To reduce brake wear, use the Engine Retarder System "JACOB" when descending a steep grade.

WARNING: Shifting to lower gears on slippery surfaces should be done with caution. Sudden engine compression braking could cause drive wheels to lock-up, and may result in loss of control.

STEERING COLUMN CONTROLS

Multifunction lever




FIGURE 28

18024

Use the "Multifunction lever" to operate the following accessories:

1. Turn signal

Move the lever up to upper position 1 to signal a right-hand turn, and down to lower position 1 to signal a left-hand turn. When the turn is completed, the signal will be canceled and lever will automatically return to its initial position.

2. Lane change signal

Move the lever up or down, part way to either positions 1, and hold it there. The lever will return to its initial position when released.

3. Headlight beam changer

High beams or low beams can be selected by respectively pushing the lever towards the dashboard or by pulling it towards the driver.

4. Headlight flasher

High beams can be flashed momentarily by pulling the lever completely towards the driver and then releasing it.

5. Courtesy-type blinkers

Clearance lights (blinkers) can be operated by pressing the button located at the tip of lever.

6. Washer controls

Push the external ring at the end of lever towards the steering column to activate windshield washers. When the ring is released, washers stop immediately but wipers will continue to run twice over to dry windshield.

WARNING: In cold weather, windshield should first be warmed up with defroster before using washers, in order to prevent icing and serious visibility impairment.

CAUTION: To avoid damaging pump mechanism, never operate washers when windshield washer fluid level is insufficient.

7. Windshield wipers

Turn lever forward to activate the two (2) elect/synchro arms; the first position corresponds to low speed and the second to high speed. Turn lever backwards to activate intermittent mode.

CAUTION: Do not run wiper blades on dry windshields as this may cause scratches. To avoid damaging wiper mechanism, always loosen frozen blades from windshield before operating wipers.

Electric horns

Can be activated by pressing button in center of steering wheel.

Transmission retarder lever (Optional)




FIGURE 29

18018A

Located on R.H. side of steering column. Use lever to select transmission's retardation level ("OFF" or 1 to 6). For system description, see page 4-4.

FOOT-OPERATED CONTROLS




FIGURE 30

18118

AIR HORNS

Use the air horns only on highways. Air is released and the horn is activated when the push-button valve, located on the floor at driver's L.H. side, is depressed.

CLUTCH PEDAL

Used to engage and disengage the manual transmission.

BRAKES

Service brakes

This vehicle is equipped with a dual braking system, the front brakes being independent of the rear brakes. Normally both systems are activated by the single brake pedal. This brake system becomes a modulated emergency system if a pressure drop occurs in the rear brake system.

Service brakes are applied by depressing the brake pedal, the rate of braking varying according to the gradual increase of pressure until the required rate of braking is obtained. When brake pedal is depressed, vehicle stoplights automatically light up.

For system information, see "BRAKES" on page 3-1.

Combination emergency and parking brakes

The spring-loaded, manually operated parking brake is activated by pulling up on the control valve knob located on R.H. lateral console (see item #2 on page 2-22).

This same brake system will automatically be applied in an emergency situation, whenever the control valve supply pressure drops below 40 psi (275 kPa).

For system information, see "BRAKES" on page 3-1.

ACCELERATOR PEDAL

Controls engine rpm.

NOTE: Pedal will be inoperative when the "DDEC-TEST" switch in steering compartment is in the "ON" position.

TILT STEERING WHEEL AND TELESCOPIC STEERING COLUMN

To unlock, use the handle located on the steering column's left hand side. Pull handle down to permit a maximum variation of 11° in steering wheel angle, and a telescopic wheel movement of 2" (5 cm). Push handle up to lock both mechanisms.

WARNING: Never try to adjust the steering wheel while the vehicle is in motion; wheel could move unexpectedly, making you lose control of the vehicle.




FIGURE 31

18027

ENTRANCE DOOR

Inside operation




FIGURE 32

18119A

Entrance door is supplied with an air-operated locking system. The door is opened and closed by a handle, mounted directly on the dash to the driver's right, which automatically activates the

air-operated lock. Handle must be turned counterclockwise to open door and clockwise to close.

CAUTION: Door handle must be fully pushed in (clockwise) to ensure that air locking mechanism has properly closed door. Door handle should be manipulated slowly to prevent damage to the air locking system components.

Emergency opening

In the event of a malfunction in the door air lock mechanism, press the door override button on R.H. Lateral Console (see pages 2-23 & 3-4).

Outside operation

Open the door from the outside by first depressing push-button on L.H. side of door and then pulling on door handle. To close, simply push in door; air locking system will automatically be activated and will complete closing. Use supplied key (see page 2-1) to lock door from the outside.

CAUTION: Before closing door from the outside, make sure keylock is in the unlocked (fully counterclockwise) position so as to avoid damage to the mechanism.

NOTE: When opening door, the stepwell lights will turn on if exterior lighting switch (see page 2-15, item #3), located on R.H. Lower Switch Panel, is "ON".




FIGURE 33

18120A

SEATS

Driver's seat - "ISRI"

Two distinct "ISRI" model driver's seats may be supplied with your vehicle: one with mechanical suspension (std), and the other with a sophisticated air suspension system (opt). Both seats may be equipped with lumbar supports and adjustable armrests. Seats can be adjusted to the desired driving position by following the instructions listed below:




FIGURE 34: MECHANICAL SUSPENSION SEAT OFH3B220

WARNING: Never try to adjust seat while driving vehicle as this could result in loss of vehicle control.

NOTE: Seat controls can be located either on the seat's L.H. or R.H. side.

1. Rotate control knob to select desired armresting angle. When not in use, raise armrest parallel with backrest.
2. Lift lever to select proper adjustment angle of backrest.
3. Pull handle up, and push down or pull up on front of seat cushion to raise or lower the front section of seat cushion.
4. Pull handle up, and push down or pull up on rear of seat cushion to raise or lower the rear section of seat cushion.

WARNING: Before proceeding with seat cushion adjustments, lower seat belt retractor to avoid pinching fingers between retractor and control knobs.

5. Pull handle up and slide seat forwards or backwards to adjust distance between driver and dashboard.

NOTE: This control may also be located at the front of the seat.

6. For maximum suspension performance, rotate handwheel until your body weight is selected on indicator.

NOTE: On "ISRI" seat equipped with air suspension, the suspension is self-adjusting to the weight of the driver, thus deleting the suspension adjustment handwheel (6).

7. Push on upper section of rocker switches to inflate lumbar support bellows inside the seat backrest, and push on lower section of rocker switches to deflate bellows.

NOTE: Rear and front rocker switches are respectively for lower and upper lumbar support bellows.




FIGURE 35: PNEUMATIC SUSPENSION SEAT 18026A

WARNING: Never try to adjust seat while driving vehicle as this could result in loss of vehicle control.

1. Rotate control knob to select desired armresting angle. When not in use, raise armrest parallel with backrest.
2. Lift lever to select proper adjustment angle of backrest.
3. Pull handle up and slide seat forwards or backwards to adjust distance between driver and dashboard.
4. Pull handle up, and push down or pull up on front of seat cushion to raise or lower the front section of seat cushion.
5. For maximum suspension performance, push down on knob until required weight is reached.
6. Press on "+" or "-" to respectively raise or lower driver's seat.

7. Push on upper section of rocker switches to inflate lumbar support bellows inside the seat backrest, and push on lower section of rocker switches to deflate bellows.

NOTE: Rear and front rocker switches are respectively for lower and upper lumbar support bellows.

Seat belts - Driver's seat

Each driver's seat is equipped with a retractable seat belt as required by State, Provincial and Federal regulations. To fasten, pull seat belt out of the retractor and insert the latch plate into the buckle until it clicks. No special adjustment is required since the reel device is self-adjusting. If seat belt operation becomes defective, report to Manufacturer's Service Center.




FIGURE 36

18028

NOTE: The seat belt must be pulled out slowly and continuously, otherwise it will lock the reel before the latch plate reaches the buckle. If this happens, allow the belt to retract completely and repeat the procedure correctly.

WARNING: A snug fit with the lap belt positioned low on the hips is necessary to ensure motorist's safety. Belt should not be worn twisted; avoid pinching belt and/or belt hardware in seat mechanism. Do not wear belt over rigid or breakable objects, such as eyeglasses, pens, or keys as these may cause injuries.

CAUTION: Never bleach or dry clean safety belt.

To unfasten belt, press red button in center of buckle and allow belt to retract. If belt does not fully retract, pull it out and check for kinks or twists. Make sure that it remains untwisted as it retracts.




FIGURE 37

18029

WARNING: Seat belts should always be worn by motorists using seats supplied with belts since this is required by most State and Provincial laws.

Passenger seats

Passenger seats may be equipped with grip handles, ashtrays, newspaper holders, tables, audio control modules and footrests.




FIGURE 38

18121A

All seats are track-mounted so that the seating configuration can be changed (2 + 2 or 2 + 1). Each seat is mounted on oval aluminum pedestals to make it easier to clean between the pedestal and side wall.

Passenger seat backrests can be tilted by using the push-button located on the side of the seat cushion. Depress and hold push-button, then adjust backrest to the desired angle. Release push-button to lock backrest in position. The hydraulic seat back adjustment mechanism is equipped with a pull-off spring.

One folding armrest is installed on the aisle side of the passenger seat and is spring-loaded to lower automatically. The other folding armrest is located between the two seats and can be raised for passenger convenience. A fixed armrest is installed on the window side of the seat.

Swivel seats

The coach can be equipped with two optional sets of swivel seats to allow installation of card tables. The swivel seat can be rotated for passenger privacy. To rotate seats, unscrew the wing nut from under each seat cushion then remove cushions. Remove the four wing screws, pull seats toward the aisle and rotate the seat counterclockwise. Align mounting holes, secure with wing screws and install seat cushions.

NOTE: Instructions for making swivel seat adjustments are affixed on the rear frame under the seat cushion.

Tour guide seat (Optional)

The optional tour guide seat is installed on driver's R.H. side over front steps. The seat folds up automatically when host/hostess stands up for convenience when embarking and disembarking passengers.

The tour guide seat can easily be removed and stored in parcel racks by simply lifting and unhooking seat assembly.

MIRRORS

Interior mirror

The interior rearview mirror is located between windshields, above driver's area. It enables the driver to see passenger circulation in the aisle. Adjust to desired viewing angle by hand without loosening screw.

Exterior mirrors




FIGURE 39: STANDARD MIRROR

18035A

Your vehicle is equipped with two (2) exterior mirrors. These mirrors have an electric heating system which serves to minimize ice and condensation in extreme weather conditions. Integral thermostats are installed in both mirrors to avoid continual heating. Use the appropriate switch on the L.H. side control panel (item #6 on page 2-4) to activate the defroster system on both mirrors simultaneously.

The standard mirrors can easily be adjusted by using the remote control knobs located on L.H. side control panel (items #15 & 16 on page 2-4).

On the optional two-glass mirror, only the flat mirror can be remotely adjusted. The convex mirror must be adjusted manually.

The exterior mirrors can be manually adjusted as per the following method:

- To obtain desired vehicle width, adjust the mirror arm angle by loosening the adjusting "Allen" screw located at body end of mirror arm. Adjust mirror arm to desired position, then tighten adjusting screw.

- Mirror head can be rotated and/or tilted by loosening the adjusting "Allen" screw located at the base of mirror head. Adjust to desired position, then tighten adjusting screw.

CAUTION: Do not overtighten. Do not install a convex mirror on the heated mirror glass. This prevents even distribution of heat in the heated mirror and could cause the glass to break.

WARNING: Objects in convex mirror are closer than they appear.

Mirrors should not extend beyond body of coach any more than necessary.

NOTE: It is important for safe driving that you have good rear vision on each side of the vehicle; therefore, adjust mirrors **before** driving and immediately after adjusting your seat.

CAUTION: Do not overtighten.




FIGURE 40: OPTIONAL MIRROR

18036A

EXTERIOR COMPARTMENTS (XL-40)




FIGURE 41: XL-40 EXTERIOR COMPARTMENTS

18030B

- | | | | |
|----------|---|---------|---|
| 01 | Engine air intake duct | 10..... | Engine rear doors |
| 02 | Lavatory access door | 11..... | Engine oil reserve tank filling,
Block heater plug &
(Water heater plug [Optional]) |
| 03 | Engine R.H. side door | 12..... | Spare wheel & tire compartment |
| 04 | Main battery disconnect switch door | 13..... | Front electrical compartment |
| 05 | Baggage compartment
(* Access to battery compartment) | 14..... | Steering compartment |
| 06 | Fuel tank filling door | 15..... | 110 volt interior lighting (Optional) |
| 07 | Condenser compartment | 16..... | A/C & Heating compartment |
| 08 | Entrance door | 17..... | Engine L.H. side door |
| 09 | Coolant surge tank filling door | | |

The above figure identifies all exterior compartments and access doors. See page 2-36 for securing and accessing procedures.

NOTE: If doors are supplied with locks, refer to page 2-1 to select the appropriate key.

EXTERIOR COMPARTMENTS (XL-45)




FIGURE 42: XL-45 EXTERIOR COMPARTMENTS

18031B

- | | |
|--|--|
| 01 Engine air intake duct | 11 Engine oil reserve tank filling, Block heater plug & (Water heater plug [Optional]) |
| 02 Lavatory access door | 12 Spare wheel & tire compartment |
| 03 Engine R.H. side door | 13 Front electrical compartment |
| 04 N/A | 14 Steering compartment |
| 05 Baggage compartment | 15 110 volt interior lighting (Optional) |
| 06 Fuel tank filling door | 16 A/C & Heating compartment |
| 07 Condenser compartment | 17 Engine L.H. side door |
| 08 Entrance door | 18 L.H. side rear service compartment |
| 09 Coolant surge tank filling door | 19 Main power compartment |
| 10 Engine rear doors | |

The above figure identifies all exterior compartments and access doors. See page 2-36 for securing and accessing procedures.

NOTE: If doors are supplied with locks, refer to page 2-1 to select the appropriate key.

Engine compartment doors

(doors #3 & 10)

For access to the engine compartment, two rear doors and one R.H. side door are provided. To open rear doors, turn lock release handle counterclockwise and pull open doors. Doors are held in open position by a mechanical locking device located at top of each door.



FIGURE 43

01009A




FIGURE 44

01010A

A switch located on R.H. side of rear junction box can be used to actuate the engine compartment lights.

To close doors, first release mechanical locking device by pushing in with fingers, then return doors to closed position; always starting with left (driver's side) door.




FIGURE 45

18037

The side door can be opened by pulling the release handle and then pulling on the door. The engine L.H. side compartment door, which opens similarly to the R.H. side compartment door, is designed to provide access to the radiator.

Engine air intake ducts

(items #1)

Engine air intake ducts are not accessible; they are designed only for engine compartment air circulation.

Fuel tank filling door

(door #6)

Fuel filler neck is accessible by simply pulling out door's R.H. side finger notch.

Note: XL-45's have filler necks on both sides of vehicle.

Entrance door

(door #8)

See instructions on page 2-28.

ENGINE COMPARTMENT COMPONENTS




FIGURE 46

01014A

Components identification:

01	Coolant surge tank	12.....	Preheater (Webasto or Espar)
02	Rear junction box	13.....	Engine air cleaner
03	Transmission oil dipstick (Auto. trans. only)	14.....	Engine primary fuel filter
	Engine oil dipstick (Manual trans. only) *	15.....	A/C compressor (Central system)
04	Belt tensioner pressure releasing valve	16.....	Engine oil dipstick (Auto. trans. only)
05	Engine compartment light switch	17.....	Engine secondary fuel filter
06	Starter selector switch	18.....	Muffler
07	Rear start push-button switch	19.....	Radiator fan gearbox
08	Power steering oil tank	20.....	Radiator
09	Engine oil pressure gauge	21.....	Alternator 24V 270A
10	Engine oil temperature gauge	22.....	A/C compressor (Auxiliary system)
11	Engine oil reserve tank	23.....	Fire detector
		24.....	Engine oil filler cap

(*) - There is no Manual Transmission Dipstick; to check oil level, use the fill plug located on transmission (see page 6-5).

Baggage compartment (doors #5)

An optional elect. door locking system may be installed on all baggage compartment doors. The switch is located on the L.H. side control panel (see item # 3 on page 2-4). Push up rocker switch to unlock the doors and push down to lock. An indicator light will illuminate on dashboard if one (1) or several baggage compartment doors are unlocked.

The baggage compartment doors may also be locked or unlocked from outside using the key provided (see "KEYS" on page 2-1)

To open a baggage compartment door, insert fingers under lower edge of operating handle, pull out and up to unlatch door, grab handle rod and pull up compartment door. The opening action is assisted by gas cylinders which also hold the door in the open position.




FIGURE 47

18043

Opening of baggage door will actuate a microswitch that will turn on the compartment lights.

NOTE: In case of malfunction or special conditions, use the safety lock to keep the door securely opened.

To close a baggage compartment door, first release safety lock, then pull handle rod out and down as far as door will allow, then push down handle to complete procedure and latch door.

WARNING: Always open and close baggage compartment doors using the handle rod ONLY. Keep hands off all door edges.

CAUTION: Do not slam baggage compartment doors. This can only damage door weather stripping and/or locking mechanism.

NOTE: To prevent theft and/or vandalism, always lock baggage doors before leaving vehicle.




FIGURE 48

18038

Spare wheel & tire compartment (door #12)

The front bumper is of the "reclining-type". To open, carefully remove the large bolt at each end using the wheel nut wrench, then slowly lower the bumper (see also page 4-19).

WARNING: This compartment has not been designed for storage. Never leave any loose objects in this area since they may interfere with steering linkage mechanism.

Additional care should be taken when opening this compartment since bumper weights 100 lbs (45 kg).

CAUTION: After compartment panel has been secured, the two (2) bumper retaining bolts should be checked to make sure they are tightly fastened.

A/C & heating and Condenser compartment doors

(doors # 7 & 16)

The A/C & heating and Condenser compartment doors can be opened manually or mechanically, depending on options. Open the door manually by first, removing the "Phillips" retaining screws (qty = 2) and then pulling on side of door where screws are located.




FIGURE 49

18039

Open the door mechanically by first opening the Baggage Compartment located aft of A/C or Condenser Compartment, then pull on door knob (see fig. below).




FIGURE 50

18056

Service doors

(doors #2,9,11,13 & 14)

Service doors can be opened by turning the slotted head "Dzus" fasteners 1/4 turn counterclockwise and then pulling on the door.




FIGURE 51

18044

Doors #13 & 14 are each provided with a microswitch which when actuated, will turn on compartment light.

CAUTION: Special care must be taken not to damage the paint around the "Dzus" fasteners when using a screwdriver or a coin.

L.H. side rear service compartment and main power compartment (XL - 45 only) (doors #18 & 19)

To access these compartments, use key provided (see "KEYS" on page 2-1). To secure, simply push in door.

WARNING: These compartments are designed to give access to compartment components only and cannot be used for storage.

Battery compartment (XL-40 only)

(access through door #5 with *)




FIGURE 52

06103

Batteries are accessible by means of an access door which is located on the back wall of the rear baggage compartment (#5*). To open battery access door, simply take out handle from it's cavity, turn 1/4 turn counterclockwise and pull on the handle.

INTERIOR COMPARTMENTS

Lavatory

The lavatory is located in the rear R.H. corner of coach and may be equipped with the following items:




FIGURE 53

23015A

- 01..... Towel dispenser
- 02..... Mirror
- 03..... Water supply valve (faucet)
- 04..... Washbasin
- 05..... Liquid soap dispenser
- 06..... Flush button (timed)
- 07..... Door handle
- 08..... Door lock
- 09..... Grip handle
- 10..... Hygienic toilet tissue dispenser
- 11..... Waste paper container (trap)
- 12..... Toilet
- 13..... Access door (cleaning)

Locking the lavatory door from the inside will illuminate a incandescent light in the lavatory, an exterior "occupied" sign and an indicator light on Dashboard (see item #4 on pages 2-7 & 2-8). Compartment night-light is lit when vehicle headlights are "ON".

If emergency assistance is required, the lavatory occupant can actuate a buzzer that will sound in driver's area. The buzzer's push-button (c/w instruction label) is located on the inner curbside wall of lavatory.

The lavatory has its own ventilation system that operates only when ignition switch is in the "ON" position.

An auxiliary sump tank (optional) allows main tank to be drained by manually opening an interconnecting tank valve. Lavatory can then be operated for longer periods until coach can be serviced at a facility equipped for disposal.

The fresh water tank, located behind compartment mirror, may be equipped with a thermal drain valve that will drain the tank when water temperature approaches the freezing point preventing damage to the tank. An immersion water heater for the lavatory fresh water tank is also available; it can be connected to a 110-120 volt AC power source through an extension cord by the engine oil reserve tank filling door (see item 11 on pages 2-34 & 35).

An access door is also provided on curbside wall to facilitate lavatory compartment cleaning. This door can only be opened from the outside. For reservoir draining and filling, see page 6-11.

Parcel racks

Passenger carry on luggage is stored in overhead compartments on each side of the coach. An optional video cassette player can be installed in the first or second front L.H. side parcel rack.

To open the closed-type parcel racks, pull the door handle up to release the latch, then lift the door open. A pressurized cylinder mechanically assists in opening the door and also holds it open.

NOTE: An optional lock can be installed on video system parcel rack door. See page 2-1 for key selection.

Safety equipment compartment




FIGURE 54
23016

The safety equipment compartment, located above L.H. side of entrance stairwell, includes a first aid kit and may also include a fire hatchet.

To open access door, turn button counterclockwise, lightly pull on button, then (while holding door with both hands) slide door towards center of vehicle. Reverse procedure to close door.

ACCESSORIES

Back-up camera/TV monitor (Optional)

The back-up camera/TV monitor system provides the driver with visual assistance when backing-up.

The monitor is located on post between driver's window and windshield.

The system switches on automatically when the transmission is put in the reverse (R) range.

Driver's window

Pull handle towards you to unlock, then slide window open. Reverse operation to close window.

Mechanical destination sign (Optional)

To change the name on your destination sign simply pull to unlock handle and rotate until sign shows desired destination. Release handle to lock.

NOTE: The destination sign is equipped with a light which illuminates automatically when the headlight or fog light switch is activated.

Also, the driver's name can be written on an optional nameplate holder on destination sign.




FIGURE 55

23017A

Electrical destination sign (Optional)

Turn the optional destination sign lighting on and off using the rocker switch located on the L.H. control panel.

Depress the selector switch until the desired destination appears in the sight glass and is aligned with the arrow.




FIGURE 56

23122

Electronic destination sign (Optional)

To change the destination, depress the selecting switches until the desired destination appears in the LCD display.




FIGURE 57

23123

NOTE: The destination sign must be programmed with a computer connected to the RS-232 connector prior to first use. Follow the instructions on the computer disk to install and run the software.

Driver's fan (Optional)

Driver's fan is mounted on dashboard and can be used to help defrost windshields or just give driver's area extra air circulation. Loosen the wing nut to redirect fan.

Driver's coat hook

Driver's coat hook is located on post at rear upper left side of driver.

WARNING: Make sure coat is securely hooked and that it will not impair driver vision and movement.

Waste container

Passenger area waste container is located at rear of vehicle in between lavatory front wall and passenger seats.

Blinds

The driver's area may be supplied with three blinds: one (1) on driver's side window and two (2) on windshield.

To operate driver side window and L.H. windshield blinds, pull down tab to the required position and then release; the blind will remain in position. To raise blind, pull on release cord on it's L.H. side.




FIGURE 58

23019

To operate R.H. windshield blind, pull down tab and position bar in hooks on central beam. To raise blind, simply unhook bar then slowly lift blind.




FIGURE 59

23020A

Each passenger window may also be provided with a blind. Pull shade and lock in first or second hook, as desired.




FIGURE 60

23021

Adjustable A/C & heating louvers

The vehicle is supplied with five (5) adjustable A/C & heating louvers. These can be adjusted manually so the heated or cooled air flow can be directed as desired.

Adjustable louvers are located as follows:

- One on L.H. side control panel.
- Two on L.H. side of driver's seat.
- One on center console.
- One over steps, near entrance door.

NOTE: The louver on L.H. side control panel can be used to defrost driver's window or airflow can be directed towards driver.

Mud flaps & splash guards

Mud flaps are installed behind front and tag axle wheels in order to minimize dirt on the lower panels of vehicle and to reduce stone projections on vehicles behind you. Optional splash guards may also have been installed behind each dual wheel of the drive axle in order to reduce stone projections on tag axle wheels.

Stop/Service/Reading lamp




FIGURE 61

23022A

1. Reading lamp

Can be adjusted manually to desired angle.

2. Reading lamp switch

Press to turn reading lamp ON or OFF.

3. Hostess signal switch

Depress rocker switch to activate chime in driver's area. A light illuminates inside rocker switch to indicate passenger position to the hostess.

4. Driver's signal switch

Depress rocker switch to activate chime in driver's area indicating to driver the passenger's intention to disembark.

"Quick-Lounge" system (Optional)

"Quick-Lounge" is a quick-fit modular system providing luxurious seating accommodations for passengers.

This system occupies the same space as the paired seating configuration it replaces. The existing seat spacing remains unchanged.

Card tables

Two (2) card tables are supplied as standard equipment and are used in the passenger swivel seat configuration. The card tables are stored in the parcel racks in separate stowage bags.

To install the card table, hold it at 45° (degrees) to the side wall. Insert the spring-loaded pin first into the hinge, then insert locking pin. Push on the locking clamp to release the leg; then unfold leg until clamp locks into place.




FIGURE 62

23023

Galley (Optional)

The Mini-Chef galley can include features such as a microwave oven and refrigerator to accommodate hot/cold food and beverage service. The galley's electrical power circuit is activated by a rocker switch located on L.H. side control panel (see item #13 on page 2-4).

Hubodometer (Optional)

A wheel hubodometer can be installed on the R.H. side of the drive axle. It indicates the total distance in miles or kilometers covered by the coach since leaving the factory, including road testing.




FIGURE 63

23024

Spare Parts Kit

A Spare Parts Kit is supplied with your vehicle; parts are stored in a cardboard box located inside the forward baggage compartment. Kit contents depend on certain vehicle options as shown below:

- 1** = Series 60 Engine + Full A/C System.
- 2** = Series 60 Engine + Full A/C System + 110 volt interior lighting.
- 3** = Series 50 Engine + Full A/C System.
- 4** = Series 50 Engine + Full A/C System + 110 volt interior lighting.

Part No.	Description	Quantity			
		Option 1	Option 2	Option 3	Option 4
561122	Light Bulb, 24V	2	2	2	2
561166	Light Bulb #464, 24V, 3W	2	2	2	2
562278	Light Bulb, 24V, 10W	4	4	4	4
561707	Relay, 24V	1	1	1	1
561797	Circuit Breaker, 3 Amp	1	1	1	1
561790	Circuit Breaker, 6 Amp	1	1	1	1
561791	Circuit Breaker, 8 Amp	1	1	1	1
561792	Circuit Breaker, 10 Amp	1	1	1	1
561793	Circuit Breaker, 15 Amp	1	1	1	1
561794	Circuit Breaker, 20 Amp	1	1	1	1
561795	Circuit Breaker, 25 Amp	1	1	1	1
561880	Light Bulb, 12V, 21W	3	3	3	3
561881	Light Bulb, 12V, 10W	2	2	2	2
561882	Light Bulb, 12V	1	1	1	1
506690	V-Belt, AX-74	3	3		
506688	Belt, Multi-V	1	1		
506669	Belt, Poly V12	1	1	1	1
506664	Belt, BX-97	1	1	1	1
061204	Cable assy (110 volt interior lighting)		1		1
506748	Belt, AX-72			1	
506691	V-Belt, AX-73				3

PREHEATING SYSTEM TIMERS (AUXILIARY) (Optional)

The timer, located on R.H. lateral console (see page 2-22 items 5 & 5A), is used to program the starting and stopping time of the preheating system. One of two optional Timers (*Espar* or *Webasto*) may be installed in your vehicle. The system indicator light, located on dashboard (see item #28 on page 2-7) illuminates when system is functional. The following offers system descriptions for both timers.

CAUTION: *The preheating system should not operate for more than one hour before starting engine as this could discharge batteries.*

WARNING: *Preheating system must not operate when vehicle is parked inside or during fuel fill stops.*

NOTE: *Preheating system uses the same fuel as the engine.*

In case of failure:

1. Shut off and turn on again.
2. Check main circuit breaker and overheating switch (*Espar*) or overheat fuse (*Webasto*).
3. Have system repaired in a specialized shop.

ESPAR (41 000 BTU)




FIGURE 64

18045

Setting the time and weekday for the first time.

Press  key briefly.



12:00 flashes on the display.


Set the clock time with < or >.

The time is stored as soon as it stops flashing.

Then the weekday flashes. Set the current weekday with < or >. It is stored as soon as it stops flashing. When the ignition is switched on, the clock time and weekday are displayed continuously. When the ignition is switched off, the display goes out after 15 seconds.



Setting the clock time and weekday.

Press  key and hold it down until the clock time flashes. Proceed as described above. If you only want to change the clock time, press the  key after setting the clock time to skip weekday adjustment.


After changing the weekday, flashing duration of the weekday can be reduced by pressing the  key.



Heating without preselection when ignition is "Off".

Heating symbol  = Observe operating display



Switching on heater. To switch on heater, press  key briefly. Operating display  appears.



Changing the heating duration once only. After power-on: To reduce heating duration: Press < key. To increase heating duration (to max. 120 minutes): Press > key.

Changing the heating duration permanently. Do not switch on . Press the < key and hold it down (approx. 3 seconds) until the display appears and flashes. Release key briefly. Then set the heating duration using the < or > key. The new heating duration is set when the display disappears.

Switching off heater. Press  key briefly. Operating display  disappears. The blower automatically continues to operate to cool the heater down.





Heating without preselection when ignition is "on."

Switch on the heater. Press  key briefly. The operating display  appears. The heating stays in operation until the ignition is switched off.

If the ignition is switched off, a residual heating period of 15 minutes remains. This can be extended to max. 120 minutes by pressing the  key or reduced by pressing the  key.

Heating operation preselection.

Setting and activating the memory for heating operation and the alarm clock.

Press **P** several times until the required memory No. (1, 2, 3) appears flashing on the display. Press  or  key briefly, and release. Then set the preselected time for the heater using the  or  key.

As soon as this stops flashing and the weekday flashes, set the weekday.

The preselected time and weekday are stored as soon as the time display disappears or changes over to clock time.

The memory number indicates what memory is activated. Only one memory can be activated.

WEBASTO (45 000 or 80 000 BTU)

OPERATION WITH DIGITAL TIMER








FIGURE 65

18046


1. To set the clock

If the time display e.g. 18:33 is wrong, or if it flashes 8:88, press button  and at the same time press either  (backwards) or  (forwards). The longer you hold the button down, the quicker the display changes. The last few minutes are set accurately by quick pushes. Adjust to get exact time, e.g. 23:59. The display fades after 20 secs.



2. Do you want to know the time?

Just press  at any time. The display appears again.

3. You can get instant heat...

with the button 5, which switches your heater on (or off) immediately. The green light is on while the heater is switched on.

4. ... or you can program the heater to come on up to 24 hours ahead.

Press button "1"6 - and the display shows the time at which the heater will start. You can alter starting time by pressing button 7 (backwards) or 8 (forwards). The longer you press the button, the faster the display changes. The last few minutes are set accurately by quick pushes. The display fades after 20 secs. The symbol 1 remains in the display, and the yellow light stays on. Your starting time is now activated.

5. Button "2"9 allows you to program a second starting time

Press button "2"112, which de-activates starting time 1. Then proceed as in (4).


The activation of the second starting time is indicated by the symbol 2.


6. Do you want to check (or activate) your starting time?

Press button "1"1314 or "2"1516 briefly. The display shows, for 20 secs., the programmed starting time. This activates the timer to start the heater at the time shown.



7. Do you want to cancel a programmed start?

Press button "1"1718 or "2"1920 briefly. The appropriate number in the display goes out, together with the yellow light.

Switching off heater. Press  key briefly.

Operating display  disappears. The blower automatically continues to operate to cool the heater down.

Heating without preselection when ignition is "on."

Switch on the heater. Press  key briefly. The operating display  appears. The heating stays in operation until the ignition is switched off. If the ignition is switched off, a residual heating period of 15 minutes remains. This can be extended to max. 120 minutes by pressing the \triangleright key or reduced by pressing the \triangleleft key.

Heating operation preselection.

Setting and activating the memory for heating operation and the alarm clock.

Press **P** several times until the required memory No. (1, 2, 3) appears flashing on the display. Press \triangleleft or \triangleright key briefly, and release. Then set the preselected time for the heater using the \triangleleft or \triangleright key.

As soon as this stops flashing and the weekday flashes, set the weekday.

The preselected time and weekday are stored as soon as the time display disappears or changes over to clock time.

The memory number indicates what memory is activated. Only one memory can be activated.

WEBASTO (45 000 or 80 000 BTU)

OPERATION WITH DIGITAL TIMER






FIGURE 65

18046


1. To set the clock

If the time display e.g. 18:33 is wrong, or if it flashes 8:88, press button  and at the same time press either \triangleleft (backwards) or \triangleright (forwards). The longer you hold the button down, the quicker the display changes. The last few minutes are set accurately by quick pushes. Adjust to get exact time, e.g. 23:59. The display fades after 20 secs.



2. Do you want to know the time?

Just press  at any time. The display appears again.

3. You can get instant heat...

with the button , which switches your heater on (or off) immediately. The green light is on while the heater is switched on.

4. ... or you can program the heater to come on up to 24 hours ahead.

Press button "1" - and the display shows the time at which the heater will start. You can alter starting time by pressing button  (backwards) or  (forwards). The longer you press the button, the faster the display changes. The last few minutes are set accurately by quick pushes. The display fades after 20 secs. The symbol 1 remains in the display, and the yellow light stays on. Your starting time is now activated.

5. Button "2" allows you to program a second starting time

Press button "2", which de-activates starting time 1. Then proceed as in (4).

The activation of the second starting time is indicated by the symbol 2.

6. Do you want to check (or activate) your starting time?

Press button "1" or "2" briefly. The display shows, for 20 secs., the programmed starting time. This activates the timer to start the heater at the time shown.

7. Do you want to cancel a programmed start?

Press button "1" or "2" briefly. The appropriate number in the display goes out, together with the yellow light.

PREVOST

XL Series Motorcoach

TABLE OF CONTENTS

FOREWORD	1 - 1	Exterior compartments (XL-45)	2 - 35
		Engine compartment doors	2 - 36
		Engine air intake ducts	2 - 36
		Fuel tank filling door	2 - 36
		Entrance door	2 - 36
		Engine compartment components	2 - 37
		Baggage compartment	2 - 38
		Spare wheel & tire compartment	2 - 38
		A/C & heating and condenser compartment doors	2 - 39
		Service doors	2 - 39
		L.H. side rear service compartment and main power compartment	2 - 39
		Battery compartment	2 - 40
		Interior compartments	2 - 40
		Lavatory	2 - 40
		Parcel racks	2 - 41
		Safety equipment compartment	2 - 41
		Accessories	2 - 41
		Preheating system timers (auxiliary)	2 - 46
		SAFETY	3 - 1
		Brakes	3 - 1
		Antilock braking system (ABS)	3 - 2
		Air system emergency fill valve	3 - 2
		Back up alarm	3 - 3
		Kneeling system	3 - 3
		Hi-buoy system	3 - 3
		Low-buoy system	3 - 3
		Emergency exits	3 - 4
		Day time running lights	3 - 5
		Fog lights	3 - 5
		Horns	3 - 5
		Alarm system	3 - 6
		Safety equipment	3 - 6
CONTROLS/INSTRUMENTS	2 - 1		
Keys	2 - 1		
Main battery disconnect switch	2 - 2		
Fuel tank filling	2 - 2		
Controls and instrument panels	2 - 3		
L.H. side control panel	2 - 4		
Cruise control switches	2 - 5		
Dashboard (without tachograph)	2 - 7		
Dashboard (with tachograph)	2 - 8		
Dashboard indicator/warning lights	2 - 9		
L.H. lower switch panel	2 - 14		
R.H. lower switch panel	2 - 15		
R.H. console	2 - 15		
Audio/Video control unit.	2 - 16		
Public address (P.A.)	2 - 18		
Video cassette player	2 - 19		
TV tuner	2 - 19		
Detroit diesel PRODRIVER™ controls	2 - 20		
R.H. lateral console	2 - 22		
Automatic transmission	2 - 23		
Manual transmission	2 - 25		
Steering column controls	2 - 26		
Foot-operated controls	2 - 27		
Tilt steering wheel and telescopic steering column	2 - 28		
Entrance door	2 - 28		
Seats	2 - 29		
Driver's seat	2 - 29		
Seat belts	2 - 31		
Passenger seats	2 - 31		
Tour guide seat	2 - 32		
Mirrors	2 - 32		
Exterior compartments (XL-40)	2 - 34		

TABLE OF CONTENTS

Safety precautions.....	3 - 7
Defensive driving.....	3 - 8

**STARTING AND STOPPING
PROCEDURES** **4 - 1**

General information.....	4 - 1
Detroit Diesel Electronic Control (DDEC).....	4 - 2
World Transmission WT Electronic Control System.....	4 - 3
Manual transmission	4 - 7
Cold weather starting	4 - 7
Daily inspection	4 - 8
Recommendations	4 - 9
Heating and air conditioning	4 - 10
Preheating systems.....	4 - 13
Windshield washer reservoir.....	4 - 14
Jump starting	4 - 15
Electric circuit protection	4 - 16
Tires	4 - 18
Jacking points.....	4 - 20
Towing	4 - 20
Retractable tag axle	4 - 21
Tag axle unloaded.....	4 - 21

TECHNICAL INFORMATION **5 - 1**

Dimensions.....	5 - 1
Weights.....	5 - 2
Capacities	5 - 2
Fuel type	5 - 2
Wheels and tires.....	5 - 2
Belts	5 - 3
Engines.....	5 - 3
Transmissions	5 - 3
Drive axle ratio.....	5 - 3
Brakes.....	5 - 4
Antilock braking system (ABS)	5 - 4
Steering	5 - 4
Electrical system.....	5 - 4

Sound system	5 - 5
Video system.....	5 - 5
Suspension	5 - 5
Alignment	5 - 5
Heating and air conditioning	5 - 5
Oil specifications	5 - 6
Preheating systems	5 - 7
Storage volume.....	5 - 7
Seats	5 - 7
Data plate and certification	5 - 7
Light bulb data.....	5 - 10
DDEC III diagnostic codes.....	5 - 12
World transmission WT diagnostic codes.....	5 - 14

CARE AND MAINTENANCE **6 - 1**

Interior cleaning.....	6 - 1
Exterior cleaning	6 - 3
Oil verification.....	6 - 4
Air tanks	6 - 7
Coolant level verification.....	6 - 7
Water separator	6 - 7
Belt tensioners	6 - 8
A/C and heating air filters	6 - 8
Flexible hose maintenance.....	6 - 9
Lubrication.....	6 - 9
Fire extinguishers.....	6 - 9
110-120 volt in-station lighting.....	6 - 9
110-120 volt in-station connectors	6 - 9
Back-up camera.....	6 - 10
Filter restriction indicator.....	6 - 10
Lavatory maintenance	6 - 10
First service on new vehicle	6 - 12
Lubrication and servicing schedule	6 - 13

SERVICE LITERATURE **7 - 1**

BRAKES

There are two (2) brake systems on your vehicle, the service brakes and the combination emergency & parking brakes, both of which are described below.

Your vehicle may also be supplied with ABS brakes (antilock braking system) and an additional retardation system. ABS brakes system information is available in this section on page 3-2; for information regarding both optional retardation systems, see "ENGINE RETARDER SYSTEM (JACOBS)" on page 4-3 and "AUTOMATIC TRANSMISSION OUTPUT RETARDER" on page 4-4.

Service brakes

The service brakes use air pressure from a foot pedal-operated master cylinder to actuate cylinders which apply the brakes at each wheel. The air system is divided into two (2) independent circuits to isolate front brakes from rear brakes, thus providing safe braking if one (1) circuit fails. Front axle brakes operate from the secondary air system, while brakes on both the drive axle and tag axle operate from the primary air system.

NOTE: *The tag axle service brakes operate only when the axle is in normal ride position (loaded & down).*

Furthermore, the brake application sequence, which starts with rear brakes and then front brakes, provides uniform braking on slippery surfaces.

For safe brake effectiveness, vehicle air system pressure should reach at least 95 psi (655 kPa) in both primary and secondary air circuits. (see items #14 & 19 on page 2-7)

A warning light turns on (see Dashboard items #7 & 8, page 2-7) and a buzzer sounds when air pressure in one of the primary or secondary circuits drops below 60 psi (413 kPa). Vehicle

must then be stopped and cause of pressure loss must be corrected before further operation.

WARNING: *"FANNING" or "PUMPING" brake pedal is not recommended. This practice will not increase brake system effectiveness, but will instead waste air and thereby reduce brake effectiveness.*

"RIDING" the brake by resting foot on brake pedal when not braking can cause abnormally high brake temperatures, excessive lining wear, possible damage to the brake drums, and loss of brake efficiency.

Combination emergency and parking brakes

Emergency brakes

In normal operation, if air pressure in both brake circuits drops below approximately 40 psi (276 kPa), spring-loaded emergency parking brakes will immediately be applied at full capacity on drive axle wheels (and also on tag axle wheels on XL-45) to stop. In an extreme condition, the emergency brakes might be applied quite rapidly. Vehicle must then be stopped and cause of pressure loss must be corrected before resuming operation.

Parking brakes

Spring-loaded parking brakes are manually applied by pulling up the control valve knob, located on R.H. lateral console (see page 2-22).

They are not designed to be used as service brakes. In normal driving conditions, control valve knob must be pushed all the way down.

NOTE: *Parking brakes can supplement service brakes to stop the vehicle in an emergency condition only. The stopping distance will be considerably longer than with a normal brake application.*

Before releasing parking brakes by pushing down control valve knob, pressure gauges should be checked to ensure that brake system air pressure has built up to a minimum of 95 psi (655 kPa).

WARNING: Always apply parking brake before leaving driver's seat.

NOTE: Each time the parking brake is applied and ignition key is turned or left to the "ON" position, the stoplights automatically light up.

ANTILOCK BRAKING SYSTEM (ABS) (Optional)

The purpose of the antilock braking system is to preserve the stability and steerability of a vehicle during braking, and to minimize its stopping distance whatever the road conditions.

On slippery roads and in emergency situations, overbraking frequently induces wheel locking. Antilock braking system provides maximum braking performance while maintaining adequate steerability on slippery roads.

Also, on smooth or slippery surfaces, the stopping distance with locked wheels is greatly extended; on rough surfaces however the problem is tire abrasion.

ABS constantly monitors wheel behavior during braking. Sensors on each wheel of front and drive axles continually monitor the wheel speed during braking, transmitting this information to a four-channel electronic processor which senses when a wheel is about to lock. Modulating valves quickly adjust the brake pressure (up to 5 times per second) to prevent wheel from locking. Each wheel is thereby controlled according to the grip available between its tire and the road.

In this way the vehicle is brought to a halt in the shortest possible time, while remaining stable and under driver's control.

CAUTION: On slippery roads, motorists behind you may not be able to brake as fast as you; so whenever possible, give a prior warning by lightly depressing brake pedal several times before braking.

AIR SYSTEM EMERGENCY FILL VALVE

The vehicle is equipped with two air system emergency fill valves to supplement the air system when air pressure is low and engine cannot be operated. The rear valve is located in engine compartment and is accessible from engine R.H. side door: On XL-40 vehicles, the valve is positioned next to battery booster block, close to door hinge; on XL-45 vehicles, the valve is positioned directly under back up alarm, close to L.H. side of door opening.




FIGURE 66: XL-40 Rear valve location

12057




FIGURE 67: XL-45 Rear valve location

12011

The front valve is located in the steering compartment close to R.H. side of door frame.




FIGURE 68: Front valve location

12014

These two air system emergency fill valves are fitted with the same valve stems as standard tires, and can be filled by any standard external air supply line.

The rear air system emergency fill valve will supply air for all systems (brakes, suspension and accessories) while the front fill valve will supply air for accessories and suspension only.

CAUTION: Air filled through these two points will pass through the standard air filtering system provided by Prévost. Do not fill air through any other points.

BACK UP ALARM

The back up alarm system serves to warn bystanders of vehicle moving in reverse range. Driver should take extra precautions when backing up. If in doubt, have someone guide you.

KNEELING SYSTEM

This system enables passengers to get on and off the coach without any difficulty by lowering the front end. The system operates rapidly; taking only 5 seconds to lower and 9 seconds to raise.

NOTE: This coach is equipped with an interlock system which will automatically apply the parking brake when the kneeling system is activated.

To operate, stop the coach, set the transmission to neutral(N), then push down the rocker switch located on the L.H. side control panel (Item #12 on page 2-4). The parking brake will be automatically applied and a warning flasher (item

#1 on page 2-7) will indicate that the front of the coach is being lowered.

To raise the front of the coach to its normal height, push up the rocker switch. The front end will rapidly rise up. Release the parking brake, and shift transmission to the desired range.

CAUTION: Avoid parking the coach too close to the sidewalk or other obstacles that could damage the coach during kneeling operations.

NOTE: The kneeling system does not operate when the coach is traveling over 5 mph (8 km/h). Consequently, the driver cannot inadvertently operate the kneeling system at higher speeds.

HI-BUOY SYSTEM

The coach can be equipped with a front Hi-Buoy or full Hi-Buoy.

The front Hi-Buoy system has the same functions as front kneeling. It enables passengers to get on or off the coach easily by raising the front end about 4 inches (100 mm). The front Hi-Buoy is combined with front kneeling to increase flexibility of the system (See item #12 on page 2-4).

The full Hi-Buoy system raises both the front and rear sections of the coach about 4 inches (100 mm). It can be used to enable passengers to get on or off the coach easily, to safely travel roads with high obstacles and to board Ferry Boats etc. (see item #12 on page 2-4 and indicator light #1 on page 2-7).

NOTE: The Hi-Buoy system does not operate when the coach is traveling over 5 mph (8 km/h). Consequently, the driver cannot inadvertently operate the Hi-Buoy system at higher speed.

LOW-BUOY SYSTEM

This system lowers both the front and the rear sections of the coach about 4 inches (100 mm). It enables the coach to drive through underpasses where the height is less than 130.7" (3.3 m), the ground is level and your vehicle is equipped with standard tires.

Operation of the Low-Buoy is controlled by a valve (Item #4 on page 2-22) located on the R.H. lateral console. The valve can be switched to either LOW-BUOY or NORMAL positions. The coach will be lowered automatically. A warning

light (item #1 on page 2-7) on the central dashboard will indicate that the coach is being lowered.

CAUTION: Avoid parking the coach too close to the sidewalk or other obstacles that could damage the coach during the operation of the low-buoy.

NOTE: The Low-Buoy system does not operate when the coach is traveling over 5 mph (8 km/h). Consequently, the driver cannot inadvertently operate the Low-Buoy system at higher speeds.

EMERGENCY EXITS

Side windows




FIGURE 69

18122

Some side passenger windows can be opened from the inside for emergency escape purposes (XL-40 = 4 on driver side and 3 on curb side - XL-45 = 4 on driver side and 4 on curb side). A decal indicating location of nearest emergency exit window is affixed at bottom of each side window. The upper section of each emergency side window is equipped with two blue lights that are activated by the exterior lighting switch located on R.H. lower switch panel (item #3 in figure 11, page 2-15).

To open window, slide fingers under release bar, then push out bottom of window. Instruction decals are affixed to the release bar of each emergency exit window.

To close window, lift window release bar and pull window towards you.

CAUTION: All emergency exits should be kept closed during normal operation. Avoid slamming windows shut; this could damage emergency exit system.

Emergency opening of entrance door from the inside

In the event of a malfunction in the front entrance door air lock mechanism, press the door override button located on R.H. lateral console (see item #3 on page 2-22) to release mechanism, and complete the opening procedure by turning the entrance door opening handle counterclockwise.

Emergency roof escape

An emergency escape hatch is located in the roof at the rear of the coach, and is designed to be opened by passengers. An optional emergency roof hatch can also be installed at the front of the coach. In case of an emergency, fully push out ventilation hatch, then while depressing black tab towards rear of vehicle, push handle out in the same direction; this will release emergency hatch catch.

NOTE: These instructions are also affixed to escape hatch.

In the event of ventilation systems failure, hatch can be used to provide air circulation, by simply pushing hatch upwards.

CAUTION: If running with roof hatch(es) open, beware of low overhead clearances.




FIGURE 70

18051

- 1 Emergency escape hatch
- 2 Instructions decal
- 3 Hatch handle
- 4 Black tab

To relatch handle after use, push vent arms upright in "full open vent" position, then insert edge into bracket and pull handle in. Finally, pull hatch inward, one side at a time.




FIGURE 71

18052

- 1 Edge
- 2 Handle
- 3 Black tab
- 4 Bracket
- 5 Vent arm

DAY TIME RUNNING LIGHTS

This system turns on automatically the low beams at a lower intensity as soon as engine is started and parking brake is released.

This system will be canceled;

- when engine is stopped
- when parking brake is applied
- when the headlight switch is turned on.

WARNING: Never run vehicle at night with these lights only as they have a lesser intensity, and the system does not turn on the marker and clearance lights.

FOG LIGHTS (Optional)

The halogen fog lights recessed in front bumper allow the driver a better visibility in foggy weather, and improve the range of vision just ahead of vehicle. They are also a useful "active safety" factor. For location of ON/OFF switch, see item #2 of figure 11 on page 2-15.

NOTE: Some States or Provinces may restrict the use of these lights. Verify regulations governing each State and/or Province before using fog lights.

HORNS

Air horns

The air horns can only be used on highways. When the push-button valve located on the floor next to driver's left foot is activated, the valve releases air which sounds the horn.

Electric horns

Use the electric horns in cities and suburban areas. They are activated by simply pushing on button located in the center of steering wheel.

ALARM SYSTEM

As an added protection to indicator lights, Prévost vehicles are equipped with audible alarms to inform the driver of the following operating conditions:

Indicator lights	Audible alarm	Condition
Air primary	Beep	Low air pressure
Air secondary	Beep	Low air pressure
"Do not shift"	Beep	Inhibits shifting of transmission
N/A	Beep	Lavatory emergency button is activated
N/A	Chime	Service button activated by passenger
Front kneeling	Beep	Front kneeling, low-buoy or high-buoy is selected
Tag axle	Beep	Tag axle raised or unloaded
N/A	Bell ringing	Fire in engine compartment

NOTE: The alarms for both primary and secondary low air pressure are produced by the same buzzer.

SAFETY EQUIPMENT

First aid kit

A first aid kit is supplied as standard equipment and is located in the Safety Equipment Compartment (see page 2-41).

Extinguishers

Two fire extinguishers are provided with the vehicle and are installed underneath the front L.H. and R.H. side passenger seats. Use Fire Extinguishers as required, while carefully following instructions on Extinguishers' Labels. Learn how to operate fire extinguishers beforehand in case of an emergency.

Emergency warning reflectors

A kit of triangular reflectors (Qty=3) is provided to warn approaching motorists of an immobilized vehicle in a Breakdown Situation. This device indicates an Emergency Situation by reflecting the light emanating from a light source. The three reflectors should be placed as illustrated on inside face of box cover. This kit complies with FMVSS 125 (Federal Motor Vehicle Safety Standards).

The Kit is located inside Forward Baggage Compartment and can be removed by simply

unscrewing Wing Nut and removing Retaining Rod.




FIGURE 72
23010

Jack/Tools

A kit for jacking vehicle is stored inside Forward Baggage Compartment (See above figure). The kit includes a 12 ton hydraulic jack and a wheel nut wrench.

Fire hatchet (Optional)

The fire hatchet is stored within the Safety Equipment Compartment (see page 2-41).

SAFETY PRECAUTIONS

To ensure safe and reliable operation, take note of the following safety precautions:

- a)** Operation and maintenance of the coach must only be performed by qualified personnel.
 - b)** Use caution when embarking and disembarking passengers.
 - c)** Always pay attention to pedestrians passing in front and behind the coach. Always yield to pedestrians at pedestrian walkways.
 - d)** Inspect the coach before operating (see "DAILY WALK-AROUND INSPECTION" on page 6-14).
 - e)** Make sure good visibility is maintained at all times. Keep windshields clean and free of obstructions.
 - f)** Make sure all doors are closed and secured before operating the coach. Before driving, conduct a walk-around inspection to check for security of all baggage compartment doors and equipment access doors.
 - g)** Adjust the driver's seat so that all controls can be easily reached.
 - h)** Always wear safety belt when driving.
 - i)** Check the instrument panel frequently. Do not operate the coach when dials or indicators are not in the normal operating condition.
 - j)** Switch from high beams to low beams when meeting or following other vehicles within 500 feet (150 meters).
 - k)** Do not drive over obstacles on the road. Empty cartons, piles of leaves, and snowdrifts could conceal hidden dangers that could damage the coach suspension and/or underbody.
 - l)** When turning or changing lanes, signal your intention well in advance.
 - m)** When approaching to make a right turn, reduce spacing between coach and curb to make sure other vehicles cannot pass on the right. Since the coach makes wide turns, allow enough space to make safe turns.
 - n)** Never leave the coach unattended with the engine running, or with the key in the ignition. Turn off the engine, remove keys and apply the parking brake before leaving the coach.
 - o)** The service life of the coach depends on the kind of maintenance it receives. Always record any problems and report them immediately to maintenance personnel.
 - p)** Shut-off engine before fueling, adding oil or performing maintenance or servicing tasks, unless stated otherwise.
 - q)** Do not run the engine or HVAC system with access doors left open. Close compartment doors before operating any equipment.
 - r)** Do not remove the surge tank filler cap or the cooling system pressure cap when the engine is hot. Let the engine cool down before removing filler caps.
 - s)** Fuel is highly flammable and explosive. Do not smoke when refueling. Keep away from open flames or sparks.
 - t)** Do not attempt to push or pull-start a coach equipped with an automatic transmission. To avoid damaging gears or bearings in manual transmission-equipped coaches, do not push, pull or roll-start in first or reverse gears.
 - u)** For additional information about safe driving practices, contact the local department of motor vehicles authority.
-

DEFENSIVE DRIVING

a) To keep the coach from drifting across lanes during highway driving, always look over the horizon on the road ahead.

b) Don't stare at the road ahead. Keep your eyes moving. Check all mirrors and dashboard instruments frequently.

c) Establish eye-to-eye contact with other drivers and with pedestrians. Use headlights, high-beams and low-beams, turn signals and horn(s) as needed.

d) For city driving, allow a four to six second travel interval between the coach and the vehicle ahead. Increase this travel interval to six to eight seconds for highway driving. Use increased travel interval for night driving and in bad weather.

e) Adjust your speed according to the road conditions, traffic and visibility. Never exceed the posted speed limits.

f) If a vehicle is close behind, reduce speed to allow vehicle to pass.

g) Be prepared to stop when approaching an intersection. The stopping distance of the coach increases with the weight and speed of the coach.

h) For additional information about defensive driving practices, contact the local department of motor vehicles authority.

DEFENSIVE DRIVING

- a)** To keep the coach from drifting across lanes during highway driving, always look over the horizon on the road ahead.
- b)** Don't stare at the road ahead. Keep your eyes moving. Check all mirrors and dashboard instruments frequently.
- c)** Establish eye-to-eye contact with other drivers and with pedestrians. Use headlights, high-beams and low-beams, turn signals and horn(s) as needed.
- d)** For city driving, allow a four to six second travel interval between the coach and the vehicle ahead. Increase this travel interval to six to eight seconds for highway driving. Use increased travel interval for night driving and in bad weather.
- e)** Adjust your speed according to the road conditions, traffic and visibility. Never exceed the posted speed limits.
- f)** If a vehicle is close behind, reduce speed to allow vehicle to pass.
- g)** Be prepared to stop when approaching an intersection. The stopping distance of the coach increases with the weight and speed of the coach.
- h)** For additional information about defensive driving practices, contact the local department of motor vehicles authority.

TABLE OF CONTENTS

Safety precautions.....	3 - 7
Defensive driving.....	3 - 8

**STARTING AND STOPPING
PROCEDURES** **4 - 1**

General information.....	4 - 1
Detroit Diesel Electronic Control (DDEC).....	4 - 2
World Transmission WT Electronic Control System.....	4 - 3
Manual transmission	4 - 7
Cold weather starting	4 - 7
Daily inspection	4 - 8
Recommendations	4 - 9
Heating and air conditioning	4 - 10
Preheating systems.....	4 - 13
Windshield washer reservoir.....	4 - 14
Jump starting	4 - 15
Electric circuit protection	4 - 16
Tires	4 - 18
Jacking points.....	4 - 20
Towing	4 - 20
Retractable tag axle	4 - 21
Tag axle unloaded.....	4 - 21

TECHNICAL INFORMATION **5 - 1**

Dimensions.....	5 - 1
Weights.....	5 - 2
Capacities	5 - 2
Fuel type	5 - 2
Wheels and tires.....	5 - 2
Belts	5 - 3
Engines.....	5 - 3
Transmissions	5 - 3
Drive axle ratio.....	5 - 3
Brakes.....	5 - 4
Antilock braking system (ABS)	5 - 4
Steering	5 - 4
Electrical system.....	5 - 4

Sound system	5 - 5
Video system.....	5 - 5
Suspension	5 - 5
Alignment	5 - 5
Heating and air conditioning	5 - 5
Oil specifications	5 - 6
Preheating systems	5 - 7
Storage volume.....	5 - 7
Seats	5 - 7
Data plate and certification	5 - 7
Light bulb data.....	5 - 10
DDEC III diagnostic codes.....	5 - 12
World transmission WT diagnostic codes.....	5 - 14

CARE AND MAINTENANCE **6 - 1**

Interior cleaning.....	6 - 1
Exterior cleaning	6 - 3
Oil verification.....	6 - 4
Air tanks	6 - 7
Coolant level verification.....	6 - 7
Water separator	6 - 7
Belt tensioners	6 - 8
A/C and heating air filters	6 - 8
Flexible hose maintenance.....	6 - 9
Lubrication.....	6 - 9
Fire extinguishers.....	6 - 9
110-120 volt in-station lighting.....	6 - 9
110-120 volt in-station connectors	6 - 9
Back-up camera.....	6 - 10
Filter restriction indicator.....	6 - 10
Lavatory maintenance	6 - 10
First service on new vehicle	6 - 12
Lubrication and servicing schedule	6 - 13

SERVICE LITERATURE **7 - 1**

Starting and stopping procedures

GENERAL INFORMATION

CAUTION: Read this section of manual before driving vehicle.

Starting engine from driver's compartment

The following procedure is used to start and stop the engine from the driver's compartment.

Starting engine

1. Make sure the starter selector switch in engine compartment is set to the "NORMAL" position and that main battery disconnect switch (see page 2-2) is set to the "ON" position.
2. Make sure the parking brake control valve knob, located on R.H. lateral console, is pulled all the way up, so that the spring-loaded parking brakes are applied.
3. Make sure transmission is in neutral.
4. Turn ignition key to "START" position, then release it as soon as engine starts.

NOTE: If engine does not start, ignition key must be returned to the "OFF" position prior to restarting.

CAUTION: Special precautions are necessary with turbocharged engines to avoid possible turbine damage. After starting, run the engine at low idle for two minutes to allow flowing of lubricant to the turbocharger. Afterwards, run at fast idle and check oil pressure before attempting to drive the vehicle.

Do not engage starter for more than 15 seconds at a time. If engine does not start within 15 seconds, release ignition key and allow starter to cool for one (1) minute before engaging starter again. Continuous use of the starter without allowing a cooling period may damage the starter motor.

With DDEC engines, pressure must not be applied on accelerator pedal before starting. An

application on pedal will induce a fault information to the Electronic Control Unit, thus affecting the fuel system control.

If accelerator pedal is depressed inadvertently, release it and wait approximately 30 seconds before resuming starting procedure.

Stopping engine

1. Apply parking brake then set transmission to the neutral position.
2. Allow engine to run at slow idle for at least two minutes, then shut off engine. This will ensure that the turbine speed has dropped, and the engine exhaust gas temperature is down to approximately 300°F. If engine is equipped with pyrometers, temperature can be observed.

CAUTION: Do not shut the engine down directly from high rpm.

If vehicle is parked and left unattended for an extended period of time, main battery disconnect switch (see page 2-2) should be set to "OFF".

Starting engine from engine compartment

The following procedure is used to start and stop the engine from the engine compartment.

Starting engine

Switches for starting and stopping the engine from the engine compartment are mounted on the R.H. side of rear junction box.

WARNING: Before attempting to start engine from engine compartment, make sure parking brake is applied and transmission is in neutral.

1. Make sure the starter selector switch in engine compartment is set to the "REAR START" position and the main battery disconnect switch (see page 2-2) is set to the "ON" position.
2. Press starter push button switch and release as soon as engine starts.

STARTING AND STOPPING PROCEDURES

WARNING: Stay away from moving parts, and do not wear loose clothes (no neckties, open jackets, shirttails, etc.).

CAUTION: Steps previously explained with respect to starter use also apply in this situation.

Stopping engine

Stop only by turning the starter selector switch to the "OFF" position.




FIGURE 73

01017A

DETROIT DIESEL ELECTRONIC CONTROL (DDEC)

The major components of DDEC are as follows:




FIGURE 74

01015

DDEC is an advanced technology electronic fuel injection and control system for Detroit Diesel engines. As an integral part of the engine, the

DDEC system provides a number of performance features and driver benefits, including improved fuel economy and performance, reduced cold

STARTING AND STOPPING PROCEDURES

smoke, reduced maintenance and repair cost. These advantages are obtained by optimizing control of the critical engine functions which affect fuel economy, engine reliability and the performance of the injectors.

Its major components include an Electronic Control Module (ECM), Electronic Unit Injectors (EUI) and sensors. The ECM is the brain of the DDEC system and is mounted on side of the engine, close to the starter. Within the ECM is the Electrically Erasable, Programmable, Read Only Memory (EEPROM) that provides instructions for basic engine control functions such as rated speed and power, engine governing, cold start logic and diagnostics, plus an engine protection system.

The ECM continuously monitors and analyzes the DDEC system during engine operation with electronic sensors. The Electronic Unit Injectors (EUI) function in a similar manner to the mechanical unit injector system. However, a solenoid-operated control valve performs the injection timing and metering functions which make injector timing much simpler and more precise.

DDEC provides the capability to quickly diagnose system malfunctions by a self-diagnostic system; the self-diagnostic system monitors all engine sensors and electronic components and recognizes system faults and other engine-related problems by providing the technician with a diagnostic code. Diagnostic codes are logged into the ECM memory and can be read by performing procedure outlined on page 5-12

ENGINE RETARDER SYSTEM (JACOBS)

The "Jacobs brake" is a diesel engine retarder that uses the engine itself to aid in slowing and controlling the vehicle. When activated, the "Jacobs brake" alters the operation of the engine's exhaust valves so that the engine works as a power-absorbing air compressor. This provides a retarding action to the wheels.

The engine brake is a vehicle-slowng device, not a vehicle-stopping device. It is not a substitute for

the service braking system. The vehicle's service brakes must be used to bring the vehicle to a complete stop.

Effectiveness of the engine brake system will vary according to transmission gear in use. The engine brake system is more effective in lower gears and at higher engine speeds.

WARNING: *When descending significant grades, use service brakes as little as possible. If engine does not slow vehicle to a safe speed, apply service brakes and shift to a lower gear. Let the engine (and engine brake) retard the vehicle. Keep brakes cool and ready for emergency stopping.*

NOTE: *Engine brake is operative only when accelerator pedal is released, and when engine speed is over 900 rpm.*

Each time the engine brake system is in operation, the stoplights will automatically light up.

WORLD TRANSMISSION WT ELECTRONIC CONTROL SYSTEM

The WT Electronic Control System consists of five (5) major components connected by wiring harnesses - Electronic Control Unit (ECU), engine throttle position sensor (or direct electronic communication), three (3) speed sensors, pushbutton shifter, and control module (which contains solenoid valves and a pressure switch). The throttle position sensor, speed sensors pressure switch, and pushbutton shifter transmit information to the ECU. The ECU processes this information and sends signals to actuate specific solenoids located on the control module in the transmission. These solenoids control both the oncoming and offgoing clutch pressure during a shift.

Another feature of the World Transmission is its ability to adapt or "learn" as it operates. Each shift is electronically measured, stored and used by the ECU to adapt and "learn" the optimum conditions for future clutch apply and release. It is important to note that if the shift quality of low mileage

STARTING AND STOPPING PROCEDURES

vehicles or vehicles with new or recalibrated ECU's is unacceptable, simply drive the vehicle through its shift ranges for awhile. After this "learning" period any rough shifting will be corrected and shift quality will be restored.

In addition to controlling the operation of the transmission, the ECU monitors the system for conditions that could result in damage to the transmission or improper vehicle operation. When one of these conditions is detected, the ECU is programmed to respond automatically in a manner which will ensure safe operation of the vehicle and the transmission.

Torque converter

The torque converter consists of three (3) elements - pump, turbine, and stator. The pump is the input element and is driven directly by the engine. The turbine is the output element and is hydraulically driven by the pump. The stator is the reaction (torque multiplying) element. When the pump turns faster than the turbine, the torque converter is multiplying torque. When the turbine approaches the speed of the pump, the stator starts to rotate with the pump and turbine. When this occurs, torque multiplication stops and the torque converter functions as a fluid coupling. The lockup clutch is located inside the torque converter and consists of three (3) elements - piston, clutch plate/damper, and backplate. The piston and backplate are driven by the engine. The clutch plate/damper, located between the piston and backplate, is splined to the converter turbine. The lockup clutch is engaged and released in response to electronic signals from the ECU. Engagement of the lockup clutch provides a direct drive from the engine to the transmission gearing. This eliminates converter slippage to provide maximum fuel economy. The torsional damper absorbs engine torsional vibration. The lockup clutch releases at lower speeds and when ECU detects conditions requiring it to be released.

Planetary gears and clutches

A series of three (3) helical planetary gear sets and shafts provide the gear ratios and direction of travel for the vehicle. The planetary gear sets are controlled by five (5) multiplate clutches that work in pairs to produce six (6) speeds. The clutches

are applied and released hydraulically in response to electronic signals from the ECU to the appropriate combination of solenoids.

Cooler circuit

The transmission oil is cooled by a remote-mounted oil cooler. Connections to the cooling circuit are located at the rear of the transmission to facilitate installation of remote cooler lines. Oil ports are internal requiring only coolant to be routed to and from the cooler.




FIGURE 75: Steering Compartment

07005

To enhance troubleshooting and to allow interrogation of the ECU for valuable service information, a DDR (diagnostic data reader) can be used. To use it, plug the appropriate connector (not furnished by the manufacturer) in the terminal located in the steering compartment or the DDR connector located on L.H. side control panel. You can also use your pushbutton shifter to perform certain maintenance operations (see page 4-6 under "Diagnostic codes").

Output retarder (Optional)

The purpose of the retarder is to assist in stopping the vehicle during stop and go driving and to control the downhill speed of the vehicle on a grade. For both of these uses, the retarder serves to extend the life of the service brakes and to enhance vehicle control.

The retarder system is activated by turning "ON" the retarder enable switch (L.H. side control panel-item #4 on page 2-4).

The retarder controls are broken down into two (2) types:

BRAKE APPLY - actuated by brake pressure; applies the retarder at three (3) distinct retardation levels (low = 1/3 - 2 psi, medium = 2/3 - 4 psi, and "full on" - 7 psi) when increasing pressures are detected in the brake system.




FIGURE 76

18018A

AUTOMATIC APPLY - actuated by hand lever located on R.H. side of steering column; retarder capacity is determined by hand lever which permits the operator to select "OFF", or one of six (6) levels of automatically-commanded retardation, the highest of which is maximum retarder capacity "full on".

The controls may be used in combinations such that the retarder can be activated when either of the two (2) controls are actuated. (If both are actuated simultaneously, the level of retardation will correspond to higher input signal).


The optimum retarder control will depend on the vehicle type and retarder use. In general maximum brake savings occur with increased retarder use. In stop and go driving, retarder use can be maximized by using the "BRAKE APPLY".

For downhill speed control, the "AUTOMATIC APPLY" may provide the best operator control.

When the vehicle is equipped with the anti-lock braking system (ABS) and the system is activated, the transmission controls "ABS input" is used to disengage the retarder and the transmission lockup clutch, thus enhancing performance of the ABS system.

Diagnostic telltales

Two (2) diagnostic features are available with the transmission control system to assist in troubleshooting of malfunctions and/or the monitoring of specific operating parameters. These features include a "DO NOT SHIFT" light on the dashboard, and the Diagnostic Data Reader (DDR). When a malfunction is detected in the control system, a series of "diagnostic codes" are used to identify and clarify the nature of the malfunction.



Do not shift - light

The "DO NOT SHIFT" light is located on dashboard.

Illumination of this light, accompanied by eight (8) seconds of short beeps from the shifter, indicates that shifts are being restricted. The *SELECT* digit on the display will be blank. Operation may continue in order to reach service assistance. The ECU may not respond to shifter requests, since operating limitations are being placed on the transmission, i.e. upshifts and downshifts may be restricted. Direction changes will not occur. The ECU will not respond to operator requests while *DO NOT SHIFT* is indicated.

Any time this light has been illuminated, the ECU will register a diagnostic code. It may be identified on the digital display and/or the Diagnostic Data Reader (DDR).

Diagnostic Data Reader (DDR) (Optional)

The purpose of the DDR is to assist in the installation checkout and the troubleshooting of malfunctions as detected by the ECU. The DDR is a portable microcomputerbased receiver/transmitter/display unit. The DDR transmits and receives data to/from the ECU, processes the data and displays appropriate

STARTING AND STOPPING PROCEDURES

information to the servicer. Operating instructions are supplied with each DDR.

Diagnostic codes

Illumination of the *DO NOT SHIFT* light during vehicle operation (start-up), indicates that the ECU has registered a diagnostic code. A summary of diagnostic codes with each associated transmission response is shown on pages 5-17 through 5-28.

Diagnostic codes can be displayed either by the DDR or on the digital display of the shifter. The following information describes use of the diagnostic capabilities of the system without the DDR.

Up to five (5) diagnostic codes can be registered in the ECU at one time. In addition to the code itself, additional information for each code is available: whether or not any inhibits resulting from the code are active; ignition cycle counts to indicate the frequency of the code occurrence. After a fixed number of ignition cycles, any code will automatically disappear from memory if it has not reoccurred.

The general procedure to display the codes is to first enter the diagnostic mode. This is accomplished by pressing the upshift and downshift arrow buttons simultaneously on the pushbutton shifter. Diagnostic mode will be entered only with the vehicle stopped. (The transmission should be shifted to *NEUTRAL* and the vehicle parking brake applied.) For each code stored in memory, beginning with any code that is presently inhibiting the transmission, the four (4) digits of the code and the pertinent parameters are continuously flashed on the display. Pressing the mode button once will cause the next code with pertinent information to be displayed. Dashes indicate all stored codes have been displayed.

To clear any active inhibits, the mode button must be depressed and held for an extended length of time. To clear the code from memory, The mode button must be pressed and held for a longer period of time. All active inhibits will also be cleared during a normal powerdown (ignition switched off followed by zero output and zero engine speeds).

Importance of proper oil level

1. Maintaining the proper oil level is very important. The transmission oil is used to apply clutches and to lubricate and cool the components. If the oil level is too low, the result can be poor performance because clutches will not receive adequate oil supply. If the oil level is too high, overheating results from the oil being churned and aerated.

2. Always check the oil level at least twice to ensure that an accurate check is obtained.

3. Transmission input speed and oil temperature significantly affect the oil level. An increase in input speed lowers the oil level; an increase in oil temperature raises the oil level. Thus, the oil level must always be checked with the engine running at idle (approximately 500 rpm), the parking brake applied, and the transmission in neutral. A final check of the oil level must be made when the transmission reaches normal operating temperature (160 - 250°F; 70 - 120°C).

Fill pipe protection

When adding oil or checking oil level, dirt or foreign material must not be allowed to enter the filler tube. Before removing the dipstick, clean around the end of the filler tube. Refer to "*Care & maintenance*" section for manual oil level check procedure.

Readout of the oil level sensor

The oil level sensor (OLS) is designed to measure transmission oil level only when a specific combination of operating conditions exist:

- engine must be at idle
- **NEUTRAL** must be selected
- zero output speed
- transmission oil must be within a "normal" temperature band
- once the first four (4) conditions are met, a "waiting" period must pass (approx. 2 min., to facilitate consistent oil drainback) before oil level measurement may begin.

To enter OLS readout mode (after meeting the conditions noted above), simultaneously press the *UPSHIFT* and *DOWNSHIFT* arrows on the shifter. If the five (5) conditions noted above are present, the display will immediately enter the reading

STARTING AND STOPPING PROCEDURES

mode. If the "waiting" period has not elapsed, the left digit of the display will become a "chasing" digit and the right digit will count down from (8) to (1) until the waiting period is complete.

After attaining the reading mode, the display will flash "OL-OK", "LO-01", "HI-02", etc., where the suffix "01" or "02" indicate the volume of oil (in quarts) low or high.

At any time in this sequence, simultaneously pressing the **UPSHIFT** and **DOWNSHIFT** arrows directs the ECU to enter the transmission diagnostic mode as described under "Diagnostic Codes" on page 4-6. D, N, or R may also be selected on the shifter at any time - the OLS mode will abort and normal transmission will commence. Shifts are not inhibited.

Oil level sensor (OLS) codes

<u>CODE</u>	<u>CAUSE OF CODE</u>
OL-OK	oil level is correct
LO-01	one quart low
LO-02	two quarts low
HI-01	one quart high
HI-02	two quarts high
OL-50	engine speed (rpm) too low
OL-59	engine speed (rpm) too high
OL-65	neutral must be selected
OL-70	sump oil temperature too low
OL-79	sump oil temperature too high
OL-89	output shaft rotation
OL-95	sensor failure

MANUAL TRANSMISSION

Do not overfill the transmission. Overfilling usually results in oil breakdown due to excessive heat and aeration from the churning action of the gears. Early breakdown of the oil will result in heavy varnish and sludge deposits that plug up oil ports and build up on splines and bearings. Overflow of oil escapes onto clutch or parking brakes causing additional trouble. However, if oil level is too low, gears will be insufficiently lubricated.

CAUTION: Do not tow vehicles equipped with manual transmissions without first pulling the

axles or disconnecting the drive shaft. Lubrication of the internal gear train is inadequate when the vehicle is towed.

COLD WEATHER STARTING

Cold starting aid (Ether)

(Optional)

The vehicle may be equipped with an electrically-operated ether cold starting aid designed to ease engine starting when temperature is below 35°F (2°C). The control rocker switch, located on the L.H. lower switch panel (see page 2-14), is provided with a locking mechanism to avoid accidental use when engine is running. To activate the ether starting aid, proceed as follows:

1. Prior to cranking engine, slide down lock tab while pressing rocker switch for three (3) seconds to fill solenoid valve.
2. Release switch to discharge shot.
3. Allow three (3) seconds for shot to discharge.
4. Start engine, use additional shots if necessary to keep engine running.

CAUTION: This practice should be performed only when absolutely necessary. Excessive use of fluid could result in serious engine damage.

Engine block heater

The vehicle is equipped with an engine immersion-type electric block heater to assist cold weather starting. The heater male electric plug is easily accessible through the engine oil reserve tank access door. To use it, connect the female plug of an electrical extension cord to the heater plug. Some converted vehicles may have the heater connected to the coach AC power system. The extension cord must be plugged into a 110-120 V AC power source only. The engine block heater should be used whenever the vehicle is parked for an extended period of time in cold weather and a suitable power source is available.

CAUTION: Use only a 110-120 V AC power source. Extension cord must be of the grounded type (three prongs) and have a minimum rated capacity of 15 amps. Be sure to disconnect cord before starting and/or moving the vehicle.

STARTING AND STOPPING PROCEDURES

Engine warm-up

After starting the engine, run it at low idle for two (2) minutes to allow flowing of lubricant to the turbocharger, then increase speed to fast idle for warm-up period by using "FAST IDLE" switch located on L.H. lower switch panel (see page 2-14). Run the engine at fast idle and no load for about five (5) minutes to allow it to warm-up before applying a load. Parking brakes should be kept applied throughout warm-up. Gauges and indicator lights should be monitored to check that all conditions are normal. If an abnormal condition should develop, stop engine immediately and have condition corrected.

WARNING: *Never let the engine run in an enclosed, non-ventilated area. Exhaust fumes from the engine contain dangerous gases which can be fatal if inhaled.*

NOTE: *The engine will come up to normal operating temperature shortly after you start driving; if possible, avoid going to full throttle until engine coolant temperature reaches 140°F (60°C).*

Transmission warm-up

When temperature is below -20°F (-29°C), the "DO NOT SHIFT" and "CHECK TRANS" will stay "ON" after the engine is started. The transmission will stay in neutral, regardless of the gear range selected until it warms past -20°F (-29°C). At that point, the "DO NOT SHIFT" light will turn off and the transmission will operate only in first gear or reverse. When the "CHECK TRANS" light goes out at 20°F (-7°C), the transmission is warm enough to safely operate in all gear ranges.

DAILY INSPECTION

With engine stopped

General

Check general vehicle condition and verify all exterior lighting. Also check for loose nuts and bolts.

Extinguishers

Ensure that fire extinguishers are in working order and easily accessible.

Emergency exits

Check that emergency exits can be easily opened.

Driver's area

Adjust mirrors and seat.

Doors

Make sure that all exterior doors and windows are closed.

Tools and spares

Check for wheel nut wrench and jack, door keys, spare belts and emergency reflectors.

Washer reservoir

Check that it is full. To prevent the windshield washer fluid from freezing during the winter, use antifreeze windshield washer.

Tires

All tires, including the spare, should be inspected for cuts and correct inflation. On both aluminum alloy and steel wheels, nuts should be checked using a torque wrench. Torque to 450-500 ft•lbs (610-680 N•m).

Wheel bearings

Check oil level in sight glass (see page 6-6).

CAUTION: *During a fuel stop, especially if a brake job has been performed recently, apply hand on wheel bearing cover and check for overheating.*

Leaks

Check thoroughly under vehicle and in compartments. Report all leaks to maintenance personnel.

STARTING AND STOPPING PROCEDURES

Coolant level

The cooling system is completely filled when the coolant (cold) is visible in the sight glass on the right side of the surge tank. If topping-up is necessary, fill the system with the same mixture ratio already used (50-50), as instructed in the "Maintenance Manual".

WARNING: Hot engine coolant is under pressure. Never remove cap until coolant has cooled.

Engine oil

Check oil level; refill directly into engine or from reserve tank (see page 6-4).

Air system

Purge accessory tank by opening remote drain valve located underneath accessory air filter (see page 6-7).

Power steering oil tank

Check oil level (see page 6-6).

Belts

Check for worn belts.

Belt tensioners

Visually check belt tension and the space between tensioning bellows' brackets (see page 6-8).

Seats

Make sure all seats and seat cushions are firmly attached.

Lavatory

Inspect for cleanliness and paper, towels & water supply.

With engine running

NOTE: Vehicle must be on level ground.

Gauges and buzzers

Gauges should be in normal position, warning lights and buzzers off.

Fuel level

Be sure level is sufficient.

Transmission

Check oil level (see page 6-4).

Leaks

Inspect around vehicle and listen for any air leak.

Turbocharger

Look for any leaks or unusual sounds coming from the turbo compressor.

Service brakes

Check for pressure build-up. With engine stopped and no brake applied, loss should not exceed 3 psi/min. (21 kPa/min.). Make a full brake application; loss should not exceed 7 psi (48 kPa).

Parking and emergency brakes

With air pressure above 65 psi (448 kPa), lower pressure with brake pedal applications, check that buzzer works and that control button lifts up. Wait until air pressure exceeds 95 psi (655 kPa) before releasing parking brakes.

RECOMMENDATIONS

- Make sure the basic principles of operation of the vehicle are understood.
- Maintain the vehicle in good running condition.
- Do not drive your vehicle with an extremely low fuel level. This advice is very important, especially if your vehicle is equipped with an auxiliary fuel tank. Unlike a gasoline engine, if a diesel engine runs out of fuel it will not simply restart after fuel is added to the tank. The engine must be "primed" (see procedure in the Maintenance Manual).
- Allow engine to run at slow idle for at least 2 minutes before turning it off.
- Engine should always be at idle speed when shifting from neutral to reverse or forward range.
- Automatic transmission shift pattern does not include a park position. Parking brake must therefore be applied to hold vehicle when it is

STARTING AND STOPPING PROCEDURES

unattended. Gearshift should then be in neutral position. If engine is stopped without applying the parking brake, a warning buzzer will sound until the parking brake is applied and your foot is removed from the brake pedal.

- Perform procedures as detailed in this manual.
- Unless otherwise specified, engine should be turned off for all lubrication and maintenance procedures.
- Do not attempt to push-start or pull-start the vehicle.
- Do not tow vehicle without first removing the drive axle shafts or disconnecting the drive shaft. Internal lubrication of the transmission is inadequate when the vehicle is towed.
- Fire extinguishers are stored underneath the front L.H. and R.H. passenger seats. In case of fire, get everyone out of the vehicle, then think of your own safety before attempting to fight the fire.
- When driving on ice or snow, accelerations or decelerations should be done gradually.

NOTE: Normal operation as well as some emergencies or abnormal conditions are covered in this booklet. Any malfunction interfering with satisfactory operation should be corrected immediately, particularly when safety may be involved.

HEATING AND AIR CONDITIONING

Ventilation

Driver should always try to introduce as much circulation of outside fresh air as possible without hampering heating and air conditioning systems. Under extreme temperature conditions however, when maximum capacity is required, the adjustable intake dampers (see following pages) should be closed.

It should be remembered that the inside of vehicle should always be slightly pressurized to minimize the entrance of dust and moisture.

Vehicle heating and air conditioning systems have been designed to allow circulation of some outside fresh air, so windows should be kept closed at all times.

In case of air conditioning system failure, substitute ventilation may be provided by opening roof-mounted emergency vent(s).

NOTE: The driver's area A/C & heating and defrost systems are independently controlled from the central system.

A/C & heating system controls




FIGURE 77

18123A




FIGURE 78: R.H. Lower Switch Panel

18124

Central A/C & heating system

1. "A/C-heat" switch

This switch has three positions: "A/C - OFF - HEAT". Set the switch to:

- "A/C" position (L.H. side) when vehicle's interior needs to be cooled or dehumidified.
- "HEAT" position (R.H. side) when vehicle's interior needs to be warmed or ventilated.
- "OFF" position (center) before stopping the vehicle.

NOTE: Fuel economy is slightly reduced when "A/C" position is used.

To operate air conditioning system when vehicle is stationary, run engine at fast idle. During operation of air conditioning system, windows should be kept closed and door not left open longer than necessary.

In order to prevent battery discharge, A/C & heating system will not operate if battery charging system is not working properly.

CAUTION: "A/C" position should not be used when outside temperature is below 40°F (5°C).

While the A/C system is running, make sure the vehicle is parked at least four (4) feet (1,2m) from other vehicles and/or buildings to allow a sufficient air flow through the condenser core.

2. "Temperature" control

Once the A/C-heat switch is set to the proper position, select the desired temperature by turning the temperature control knob clockwise to raise or counterclockwise to lower temperature. Only a slight movement of knob is generally sufficient to change temperature setting.

Temperature control knob is used to select interior temperature within the range of 65 to 78°F (18 to 26° C). Once temperature is selected, system will automatically maintain it within close limits.

At extreme clockwise position, full heat will be maintained.

3. "Heat" indicator light

This indicator will be illuminated when hot water is circulating through the water valve, no matter which mode has been selected (A/C or heating).

4. "A/C" warning light

This light is designed to light up when the "A/C" system is not working properly. If this happens, first stop "A/C" system, then perform the following checks:

- Check the condenser for obstruction. Clean if necessary. (Refer to "Maintenance Manual").
- Check that the evaporator and condenser motors are operating.
- Check evaporator filter for cleanliness. Clean or replace as required. (Refer to "Care and Maintenance" section, page 6-8).
- Check the air return duct(s) for obstruction. Ducts are located on the left side or on both sides of the vehicle floor, approximately in the center. Clean if necessary.

After these checks, test the system. If the "A/C" warning light does not turn off, set the "A/C - heat" switch to "OFF" position, and seek qualified service assistance.

How to use the controls

- To ventilate without heat or air conditioning

Turn the "temperature" control knobs to the maximum counterclockwise position (cool), then set the "A/C-heat" switch to the "heat" position.

- To heat

To ensure maximum efficiency of heating system, set the "A/C-heat" switch to the "heat" position, then adjust the temperature control knobs to a comfortable setting.

- To dehumidify

Because an air conditioner dehumidifies as it cools, you can use it in cool weather to help in drying air. Set the "A/C-heat" switch to the "A/C" position, then adjust the "temperature" control to a comfortable setting. With this set-up, the A/C and

STARTING AND STOPPING PROCEDURES

heating will run simultaneously, thus drying air as it flows through the evaporator and then heating it as it flows through the heater radiator.

CAUTION: The air conditioning system should not be used when outside temperature is below 40° F (5°C).

- To turn everything OFF

Set the "A/C-heat" switch to the "OFF" position (center).

An adjustable air intake damper is located in the evaporator compartment (third compartment on the L.H. side of vehicle). The damper should normally be left open. However, under extreme temperature conditions, it can be closed to block the addition of ambient air and heat or cool air inside of coach as desired. As soon as extreme heating or cooling is no longer required, the damper should be reopened.




FIGURE 79

22004

Driver's compartment A/C & heating system

5. "Fan" speed control

Turn knob clockwise at the first position to obtain minimum air flow and to start "Driver's system" to circulate warm, cool, or outside air, according to

settings of temperature control knob (driver's), "A/C-heat" switch and "Recirc.-fresh air" control. Turn clockwise again to obtain the desired ventilation speed.

6. "Temperature" control

Once the A/C-heat switch is set to the proper position and fans are on, select the desired temperature by turning the temperature control knob clockwise to raise or counterclockwise to lower temperature. Only a slight movement of knob is generally sufficient to change temperature setting.

Temperature control knob is used to select interior temperature within the range of 65 to 78°F (18 to 26° C). Once temperature is selected, system will automatically maintain it within close limits.

At extreme clockwise position, full heat will be maintained.

WARNING: Excessive high temperature in driver's area could induce drowsiness, affecting driver's ability to operate the coach safely.

NOTE: Driver's air conditioning system will only operate simultaneously with main air conditioning system, but heating and defrost systems are independent from main system.

Driver's A/C & heating system also affects the two (2) front rows of passenger seats, and should be used in concert with main system, not in opposition.

7. "Recirc.-fresh air" control

This knob should normally be rotated clockwise to allow maximum fresh air admission. When outside temperature is extremely high and maximum cooling is required or when outside temperature is extremely low and maximum heating is required, the knob should be rotated counterclockwise to shut off the fresh air admission, thus recirculating the air inside vehicle.

This position should also be selected when driving vehicle on dusty roads and in air polluted areas to avoid admission of contaminated air inside vehicle.

WARNING: Keep in mind that the "Recirc.-fresh air" control must be reset to the "fresh air" position following these special road conditions in order to prevent contamination of air in driver's area.

STARTING AND STOPPING PROCEDURES

NOTE: In order to improve air circulation when A/C system is inoperative, open the roof escape(s) and position the "Recirc.-fresh air" control to the extreme right position (fresh-air).

8. "Feet air outlet" control

This control is used to control the air flow delivered under the dash on the driver's side. Turn control knob clockwise to increase air flow and counterclockwise to decrease.

9. "A/C auxiliary" switch

Push down rocker switch to actuate the optional auxiliary A/C system located at rear of coach to supplement the central A/C system.

How to use the controls

- To ventilate without heat or air conditioning

Turn the "temperature" control knob to the maximum counterclockwise position (cool), turn the "recirc.-fresh air" control knob to the maximum clockwise position (fresh air), then set the "A/C-heat" switch to the "heat" position and turn the fan speed control knob to the desired position.

- To defrost

To obtain the maximum defrosting efficiency, switch the "fan" speed control to the highest position, turn the "recirc.-fresh air" control knob to the maximum clockwise position (fresh air), turn the "feet air outlet" control knob to the maximum counterclockwise position (defrost position), then turn the "temperature" control to the maximum clockwise position (warm).

- To dehumidify

Because an air conditioner dehumidifies as it cools, you can use it in cool weather to help defog the windows. Set the "A/C-heat" switch to the "A/C" position, turn the "feet air outlet" control knob to the maximum counterclockwise position (defrost position) then adjust the "temperature" control to a comfortable setting. With this set-up, the A/C and heating will run simultaneously, thus drying air as it flows through the evaporator and then heating it as it flows through the heater radiator.

CAUTION: The air conditioning system should not be used when outside temperature is below 40° F (5°C).

- To turn everything OFF

Set the "A/C-heat" switch and "fan speed" control knob to the "OFF" position and turn the "temperature" control knobs to the maximum counterclockwise position (cool).

PREHEATING SYSTEMS

(Optional)

ESPAR (EBERSPÄCHER):

Description of operations

This Auxiliary Preheating System is used for preheating and retaining the heat of water-cooled engines. It can be used before starting the engine to ease its starting and to provide immediate inside heat upon operation of the heating system. It can also be used with engine running to maintain coolant heat and maintain the set temperature inside vehicle.

The heater operates independently of the vehicle engine. It is connected to the cooling and heating circuits, the fuel system and the electrical system of the vehicle.

The pilot lamp turns on when the heater is switched on. Combustion air flows in to flush out the combustion chamber, and the water circulation pump is put into operation. The fuel metering pump conveys fuel in precise doses to the combustion chamber, where fuel and combustion air form a combustible mixture which is ignited by the glow plug.

Once the flame sensor has signaled to the control unit that combustion has taken place correctly, the glow-spark plug and ignition coil are switched off.

The hot combustion gases are diverted at the end of the flame pipe, then pass through the indirect heating surfaces of the heat exchanger and transmit their heat to the water passing through the heat exchanger.

The heat is thermostatically controlled, and operates intermittently, i.e. the switched-on times of the burner vary depending on the heat

STARTING AND STOPPING PROCEDURES

requirement. The water temperature depends on the setting of the built-in water thermostat.

The water circulation pump remains in operation as long as the heater is operating - even in the regulation intervals and during the delayed cutout of the switched-off heater. The pump can also be operated independently of the heater by means of an appropriate circuit. The heater can be switched on at any time, i.e. during the delayed cutout period too. Ignition takes place once this delay time is over.

When the heater is switched off, the fuel supply is interrupted. The flame goes out, and at the same time a delayed cutout of some 2.5 minutes begins. The combustion air still flowing flushes the remaining combustion gases out of the chamber and cools off the hot parts on the exhaust side of the heat exchanger, while the water circulation pump still running transmits the heat present in the heat exchanger, thus preventing local overheats. Once the delayed cutout time is over, both the combustion air blower and the water circulation pump switch off automatically. A cutout will take place in case of any failure of the preheater.

WEBASTO:

Description of operations

Switch on the heater, the operation indicator lamp comes on and the heater motor & circulating pump begin to run. After about 10-25 seconds the solenoid valve opens and fuel is sprayed into the combustion chamber. At the same time the electronic ignition unit produces high voltage (8000V) and the mixture of fuel and air in the combustion chamber is ignited by the spark on the ignition electrodes. The flame is indicated by the flame detector, then the electronic ignition unit stops producing high voltage and combustion continues by itself (spark on electrodes is required only to ignite the flame). At this moment the heater is working and produces heat.

If the heater is switched off by the on/off switch, the solenoid valve interrupts fuel supply, combustion stops and indicator lamp turns off. Combustion air fan still blows air, cleaning the combustion chamber of any fumes and cooling down the combustion chamber. Coolant circulation pump pumps coolant, making a purge cycle for approximately 2-3 minutes, thus protecting the heater against overheating.

If the heater is not switched off by the on/off switch, the control thermostat will switch off the heater when coolant temperature reaches $165^{\circ} \pm 6^{\circ} \text{ F}$ ($75^{\circ} \pm 3^{\circ} \text{ C}$) and turns it on at $154^{\circ} \pm 9^{\circ} \text{ F}$ ($68^{\circ} \pm 5^{\circ} \text{ C}$). During this time the heater (combustion) is off, the indication lamp and coolant pump are on. Combustion air fan blows air for 2-3 minutes and then turns off.

WINDSHIELD WASHER RESERVOIR

Windshield washer reservoir is located in front left compartment (steering compartment) below driver's floor. This reservoir has a capacity of approximately 5 U.S. gallons (19 liters). Its spin-on type cover is provided with a removable cap to ease windshield washer reservoir filling. Check windshield washer fluid level regularly.

Spray jets are mounted under windshield wiper arms. The reservoir's fluid is forced by two electric pumps through rubber tubes into spray jets and onto windshield.



FIGURE 80

23011

STARTING AND STOPPING PROCEDURES

JUMP STARTING

Whenever it becomes necessary to start the engine while batteries are discharged, use another power source of the same voltage (24 volt DC), negative grounded and proper jumper cables.

WARNING: Procedure other than the one outlined could cause injury or damage from battery acid spray, explosion, or charging system overload.

- Never connect to the negative post of the discharged battery.
 - Never allow the two vehicles or the jumper cable clamps to touch each other.
 - Never attempt to jump start a vehicle if the discharged battery fluid is frozen or if the battery fluid level is low, as the battery may rupture or explode.
 - Do not jump start vehicles equipped with maintenance-free batteries if the test indicator is light yellow.
 - Turn off all lights, heaters and other electrical accessories. Make sure the parking brake is applied and the transmission is set to "NEUTRAL" before attempting to jump start the engine.
- Wear eye protection and remove rings, watches with metal bands and other metal jewelry.

1. Connect one end of the red jumper cable to the positive (+) post of the booster power source.
2. Remove the red protective cap from Booster Block's Positive Stud, then connect the other end of the red jumper cable to this stud.
3. Connect one end of the black jumper cable to the negative (-) post of the booster power source.
4. Remove the black protective cap from Booster Block's Negative Stud, then connect the other end of the black jumper cable to this stud.
5. Start the engine in the vehicle that is providing the jump start. Let the engine run for a few minutes, then start the engine in the vehicle that has the discharged batteries.

WARNING: Do not engage starter for more than 15 seconds. Allow starter time to cool before engaging again. This will prevent starter from overheating and will allow time delay relay time to cool.

6. To remove the cables, perform the above procedure in reverse order, then replace the protective caps on booster block posts.

NOTE: Jumper cables must withstand 500 cranking amperes. If cable length is 20 feet (6 m) or less, use 2/0 (AWG) gage wires. If cable length is between 20-30 feet (6-9 m), use 3/0 (AWG) gage wires.

NOTE: If, after doing this procedure, Starter turns but Engine still doesn't run; (with Jumper Cables in place) wait approximately 15 minutes (to give battery equalizers time to balance 12V and 24V charges), then try again. If engine still doesn't run, repeat procedure once again.

On **XL-40** vehicles, booster block is located in the engine compartment and is accessible through engine R.H. side door.




FIGURE 81

06098

On **XL-45** vehicles, booster block is located in main power compartment (refer to figure 82).




FIGURE 82

06097

ELECTRIC CIRCUIT PROTECTION

Two types of cutoff mechanisms are installed to protect the vehicle's electrical system; fuses and manually-resettable circuit breakers. If an electrical device is inoperative, check the corresponding cutoff mechanism.

CAUTION: Never replace a fuse with a higher rated one because it will cause severe damage to the electrical system.

Main breakers

Most of the manually-resettable circuit breakers are located in the front & rear junction boxes and in the rear baggage compartment (XL-40) or the main power compartment (XL-45). An identification decal is affixed on the inside face of each door.

XL-40 vehicles are equipped with six (6) main breakers; they are installed just below rear R.H. side baggage compartment's ceiling and can be identified as follows:




FIGURE 83

06099

1. Condenser fan motor (CB8) 105 amps-24 volts
2. Evaporator fan motor (CB9) 105 amps-24 volts
3. Rear junction box (CB7) 90 amps-24 volts
4. Front junction box (CB6) 90 amps-24 volts
5. Front junction box (CB4) 90 amps-12 volts
6. Rear junction box (CB3) 70 amps-12 volts

XL-45 vehicles are equipped with eleven (11) main breakers; five (5) are installed in A/C junction box located in condenser compartment and the other six (6) are installed in main power compartment and can be identified as follows:




FIGURE 84: A/C junction box

06100A

1. (From left to right)
- CB134: Condenser fan motor 15 amps-24 volts
- CB135: Condenser fan motor 15 amps-24 volts
- CB136: Condenser fan motor 15 amps-24 volts
- CB137: Condenser fan motor 15 amps-24 volts

STARTING AND STOPPING PROCEDURES

2.CB9: Evaporator fan motor 105 amps-24 volts




FIGURE 85

06101

- | | |
|------------------------------|-------------------|
| 1.Rear junction box (CB3) | 70 amps-12 volts |
| 2.Front junction box (CB4) | 90 amps-12 volts |
| 3.Video system (Opt.)(CB131) | 40 amps-12 volts |
| 4.Rear junction box (CB6) | 90 amps-24 volts |
| 5.Front junction box (CB7) | 90 amps-24 volts |
| 6.A/C main (CB1) | 200 amps-24 volts |

Locate burned fuses as follows:

R.H. console (at back of temperature control buttons)

Temperature control.....1.5 amps (qty=2)

Rear L.H. side baggage compartment ceiling
(for vehicles equipped with video system)

Video inverter2 amps (qty=2)

To gain access to the fuses, simply remove the inverter's front protective screen.




FIGURE 86

06104

Steering compartment

Kneeling module 3 amps (qty=1)
Speed limit switch 3 amps (qty=2)




FIGURE 87

06105

Battery equalizers

On **XL-40** vehicles the two (2) battery equalizers ("VANNER"-50 amps-12 & 24 volts) are installed just below rear L.H. side baggage compartment's ceiling. The reset buttons are located on the end of equalizers facing the center of the coach. Refer to figure 88.

STARTING AND STOPPING PROCEDURES




FIGURE 88

06106

XL-45 vehicles have one (1) equalizer ("VANNER"-100 amps-12 & 24 volts). It is located inside Main power compartment and is equipped with auto reset, therefore there is no reset button.

TIRES

Tire pressure

The condition and pressure of the tires can greatly affect both useful tire life and road safety.

NOTE: The recommended tire inflation pressures are given in the "Technical Information" section, page 5-2. Also, cold tire inflation pressures are listed on the Department of Transport's certification plate, affixed below L.H. side control panel in driver's area. Tire pressure must be adjusted according to vehicle loading - see table in "Coach Final Record" (NOT NECESSARILY THE V.I.N. PLATE).

At regular intervals, verify the tire pressures. Use an accurate tire pressure gauge when checking inflation pressures. Never exceed the maximum tire inflation pressure specified on each tire.

Cold tire inflation pressure means: When a vehicle has not been driven for at least 3 hours or less than 1 mile (1.6 km).

WARNING: Incorrect tire pressures cause increased tire wear and adversely affect road holding of the vehicle, leading to loss of vehicle control.

NOTE: Always include the spare tire during a pressure verification.

Changing wheels

Tire failure is a rare event these days, if tires are properly cared for. In case of a flat tire, move vehicle a safe distance away from traffic and apply the parking brake. Remember to switch "ON" the hazard flashers and according to the highway code regulations, set up the triangular reflectors (see "Emergency warning reflectors" on page 3-6) at an adequate distance to warn incoming motorists.

Spare wheel and tire are stored in the Spare wheel and tire compartment and are accessible by lowering the reclining front bumper. Use the wheel nut wrench to unscrew the two (2) bumper retaining bolts.

WARNING: It is recommended that two (2) people do this operation since bumper weighs 100 lbs (45 kg).

CAUTION: This compartment has not been designed for storage. Never leave any loose objects in this area since they may interfere with steering linkage mechanism.

Removing spare wheel and tire from compartment

To pull out spare wheel and tire, open reclining bumper according to the previous instructions, unscrew the wing nut retaining the support and rail extension assembly (stored on R.H. side of wheel), then take out the assembly. Install assembly by matching its two (2) holes to the corresponding mounting pins located in front center of spare tire compartment. Unscrew the retaining bracket's T-handle to release the wheel and dolly assembly and pull out bracket. Pull out wheel using strap then remove tire covering. Separate wheel and tire from dolly by unscrewing the two (2) mounting nuts.

CAUTION: After reclining bumper has been secured, the two (2) retaining bolts should be checked to make sure that they are tightly fastened.

STARTING AND STOPPING PROCEDURES




FIGURE 89

13005

NOTE: Reinstall support and rail extension assembly, then secure tire with retaining bracket before moving vehicle.

Jack and wheel nut wrench are stored at right in forward R.H. side baggage compartment.




FIGURE 90

23012

Check the spare tire's inflation pressure periodically to keep it ready for use. Inflate spare tire to the pressure of the tire which has the highest pressure on the vehicle.

Also, make sure that retaining bracket is securely fastened in order to prevent it from moving around inside compartment.

Procedure

Step 1

Stop engine, apply parking brake, take out jack and wrench, then remove spare wheel and tire from their compartment.

Step 2

Remove hub cap (with appropriate wrench) or cover from wheel.

Step 3

With supplied wrench, loosen all wheel nuts to about one (1) full turn.

NOTE: For stud-mounted wheels, turn nuts counterclockwise on R.H. side of vehicle and clockwise on L.H. side. For hub-mounted wheels, turn nuts counterclockwise on both sides of vehicle.

Step 4

Use the hydraulic jack to raise the vehicle. Raise vehicle to the height required to remove wheel.

NOTE: For hydraulic jack placement, refer to "Jacking points", next in this section.

WARNING: Place jack on stable and level ground; if necessary, place a board under the jack.

Do not raise the vehicle until you are sure the jack is securely engaged.

WARNING: To prevent personal injury and/or equipment damage, use only the recommended jacking points.

Passengers must not remain inside vehicle while wheel is being replaced.

Step 5

Fully unscrew the wheel nuts, then remove nuts and wheel. Install spare wheel with existing nuts, then slightly tighten nuts in a crisscross pattern before lowering the vehicle.

Step 6

Lower vehicle (until tire touches ground) by slowly unscrewing the jack's hydraulic valve.

STARTING AND STOPPING PROCEDURES

Step 7

Torque all nuts, in a crisscross pattern, to 450-500 ft•lbs (610-680 N•m).

Step 8

Completely lower the coach and remove jack. Adjust tire pressure according to the cold tire inflation pressures.

Step 9

Store damaged wheel in spare tire compartment. Repair and balance the flat tire as soon as possible.

JACKING POINTS

One (1) jacking point on each side of each axle is provided on vehicle. Refer to the following illustrations for details.

CAUTION: Remember that only these jacking points can be used.




FIGURE 91: Front Axle Jacking Points

10005

CAUTION: The jacking points on tag axle must be used only to lift this axle.




FIGURE 92: Tag Axle Jacking Points

18086

CAUTION: To prevent damage to suspension components, always raise or unload tag axle before jacking coach using drive axle jacking points.




FIGURE 93: Drive Axle Jacking Points

11005

Several kinds of hydraulic jacks can be used but they all must support the following capacities:

Front axle - 13,000 lbs (5 900 kg)

Drive axle - 25,000 lbs (11 365 kg)

TOWING

Two tow eyes are provided at front and rear under vehicle. Towing should be done from these points only by means of a solid link tow bar and a safety chain. This recommended method prevents damaging the vehicle. If required, connect an auxiliary air supply to the vehicle to release the vehicle brakes. The engine cannot be started by pushing or towing.

WARNING: Never allow passengers to ride in a towed vehicle for any reason whatsoever.

CAUTION: Internal lubrication of the transmission is inadequate when the vehicle is towed. Remove the axle shafts (refer to the Maintenance Manual for correct procedure) before towing to avoid possibility of damaging transmission.

NOTE: When the axle shafts are reinstalled, ensure that the nuts are tightened to the appropriate torques and the axle shafts are properly installed (R.H. & L.H.). Refer to the "Maintenance Manual" for torque values.

RETRACTABLE TAG AXLE

Operation of the tag axle is controlled by a valve located on the R.H. Lateral Console. The valve can be flipped to either one of two positions, "Wheels up" or "Wheels down". Axle will automatically be raised or lowered by air pressure according to valve position (see page 2-23).

Tag axle service brakes operate only when axle is down. Never lower tag axle while vehicle is moving. When tag axle is up, the corresponding indicator light will illuminate, and a beep will sound to remind you that axle is up. Tag axle can be raised in tight maneuvering areas as in parking lots or to help in turning a short corner, thus shortening the wheelbase and allowing tighter turning. Raising tag axle transfers extra weight and additional traction to the drive wheels on a slippery surface.

CAUTION: *Always raise tag axle before lifting vehicle to prevent damage to suspension components.*

After either of the above uses, vehicle must be stopped, then tag axle must be lowered before resuming normal driving.

TAG AXLE UNLOADED

This standard system allows unloading of the tag axle air springs, without raising the axle. This system is controlled by the same valve that applies to the retractable tag axle, and is used in the same situations described in "RETRACTABLE TAG AXLE" section. Follow the same recommendations that apply to the retractable axle.

TABLE OF CONTENTS

Safety precautions.....	3 - 7
Defensive driving.....	3 - 8

**STARTING AND STOPPING
PROCEDURES** **4 - 1**

General information.....	4 - 1
Detroit Diesel Electronic Control (DDEC).....	4 - 2
World Transmission WT Electronic Control System.....	4 - 3
Manual transmission	4 - 7
Cold weather starting	4 - 7
Daily inspection	4 - 8
Recommendations	4 - 9
Heating and air conditioning	4 - 10
Preheating systems.....	4 - 13
Windshield washer reservoir.....	4 - 14
Jump starting	4 - 15
Electric circuit protection	4 - 16
Tires	4 - 18
Jacking points.....	4 - 20
Towing	4 - 20
Retractable tag axle	4 - 21
Tag axle unloaded.....	4 - 21

TECHNICAL INFORMATION **5 - 1**

Dimensions.....	5 - 1
Weights.....	5 - 2
Capacities	5 - 2
Fuel type	5 - 2
Wheels and tires.....	5 - 2
Belts	5 - 3
Engines.....	5 - 3
Transmissions	5 - 3
Drive axle ratio.....	5 - 3
Brakes.....	5 - 4
Antilock braking system (ABS)	5 - 4
Steering	5 - 4
Electrical system.....	5 - 4

Sound system	5 - 5
Video system.....	5 - 5
Suspension	5 - 5
Alignment	5 - 5
Heating and air conditioning	5 - 5
Oil specifications	5 - 6
Preheating systems	5 - 7
Storage volume.....	5 - 7
Seats	5 - 7
Data plate and certification	5 - 7
Light bulb data.....	5 - 10
DDEC III diagnostic codes.....	5 - 12
World transmission WT diagnostic codes.....	5 - 14

CARE AND MAINTENANCE **6 - 1**

Interior cleaning.....	6 - 1
Exterior cleaning	6 - 3
Oil verification.....	6 - 4
Air tanks	6 - 7
Coolant level verification.....	6 - 7
Water separator	6 - 7
Belt tensioners	6 - 8
A/C and heating air filters	6 - 8
Flexible hose maintenance.....	6 - 9
Lubrication.....	6 - 9
Fire extinguishers.....	6 - 9
110-120 volt in-station lighting.....	6 - 9
110-120 volt in-station connectors	6 - 9
Back-up camera.....	6 - 10
Filter restriction indicator.....	6 - 10
Lavatory maintenance	6 - 10
First service on new vehicle	6 - 12
Lubrication and servicing schedule	6 - 13

SERVICE LITERATURE **7 - 1**

Technical information

DIMENSIONS

SPECIFICATION	XL-40	XL-45
Overall length	40.0' (12 190 mm)	45.0' (13 716 mm)
Overall width	102" (2 590 mm)	102" (2 590 mm)
Overall height (over closed roof hatch(es))	130.7" (3 320 mm)	130.7" (3 320 mm)
Entrance door width	26" (660 mm)	26" (660 mm)
Headroom (Floor to ceiling)	76.5" (1 943 mm)	76.5" (1 943 mm)
Aisle width	14" (355 mm)	14" (355 mm)
Step height from ground	15" (381 mm)	15" (381 mm)
Other step height	8.5" (216 mm)	8.5" (216 mm)
Cabin floor height	48.5" (1 232 mm)	48.5" (1 232 mm)
Ground clearance	11" (279 mm)	11" (279 mm)
Wheel base (Front axle's center to drive axle's center)	280" (7 112 mm)	315" (8 000 mm)
Front overhang	69" (1 753 mm)	69" (1 753 mm)
Rear overhang	82.7" (2 100 mm)	107.7" (2 736 mm)
Front track	85.67" (2 176 mm)	85.67" (2 176 mm)
Drive track	76.5" (1 943 mm)	76.5" (1 943 mm)
Rear track (Tag axle)	82" (2 083 mm)	82" (2 083 mm)
Turning circle radius (Exterior front corner)	41' 5" (12 624 mm)	45' 7" (13 894 mm)

WEIGHTS

Dry weight (w/series 60 & World trans.)

XL-40	29 350 lbs (13 341 kg)
XL-45	30 850 lbs (14 023 kg)

Dry weight (w/series 50 & World trans.)

XL-40	28 940 lbs (13 155 kg)
XL-45	30 440 lbs (13 836 kg)

Gross vehicle weight rating

XL-40	42 690 lbs (19 400 kg)
XL-45	46 800 lbs (21 270 kg)

Gross axle weight rating

Front axle	14 400 lbs (6 545 kg)
Drive axle	20 400 lbs (9 270 kg)
Tag axle	12 000 lbs (5 455 kg)

The Gross Vehicle Weight Rating (G.V.W.R.) and the Gross Axle Weight Ratings (G.A.W.R.) for front, drive and rear axles are listed on a certification plate located on the panel at the L.H. side of driver's seat, under the side control panel.

CAPACITIES

Engine oil (series 60)

Crankcase	37 U.S. qts (35 liters)
Reserve tank	10 U.S. qts (9,5 liters)

Engine oil (series 50)

Crankcase	29.5 U.S. qts (28 liters)
Reserve tank	10 U.S. qts (9,5 liters)

Fuel tank

XL-40	180 U.S. gal. (681 liters)
XL-45	208 U.S. gal. (787 liters)

Cooling system.....27.6 U.S. gal. (104 liters)

Transmissions

Automatic transmission
(excluding external circuits) 10 U.S. gal. (38 liters)

Manual transmission

7 speed	24 U.S. qts (22,7 liters)
6 speed	20.5 U.S. qts (19,4 liters)

Differential oil 13.7 U.S. qts (13 liters)

Power steering

reservoir 4.0 U.S. qts (3,8 liters)

Windshield washer

reservoir5 U.S. gal. (19 liters)

Refrigerant

Driver's and central system	24 lbs (11 kg)
Auxiliary system (opt.).....	3.5 lbs (1,6 kg)

FUEL TYPE

ASTM specification	D-975
Recommended grade	1-D
Acceptable grade	2-D

WHEELS AND TIRES

Steel wheels	8.25 X 22.5
Inner drive axle.....	8.25 X 22.5

Aluminum forged wheels	9 X 22.5
Except inner drive axle (steel)	8.25 X 22.5

Tires.....12 R 22.5 or 315/80 R 22.5

NOTE: *It is recommended that all tires on coach be of the same type.*

Recommended tire inflation pressure (cold)

Front axle	115 psi (792 kPa)
Drive axle	90 psi (620 kPa)
Tag axle.....	95 psi (655 kPa)

CAUTION: *These tire pressures are established in accordance with the maximum allowable load on each axle. A lower pressure is recommended if the axle load is less than the above specifications. Weigh vehicle fully loaded and pressurize according to tire manufacturer's recommendations.*

For other tire and wheel specifications, refer to the "Prévost Special Specifications" label affix on the panel at the L.H. side of driver's seat, below the certification plate.

BELTS

Radiator fan drive (transfer) (series 60 only)

Make: Dayco
Model: AX 74
Qty: 3

Radiator fan drive (transfer) (series 50 only)

Make: Dayco
Model: AX 73
Qty: 3

Radiator fan drive (fan)

Make: Dayco
Model: Multi-V, 5100510
Qty: 1

A/C compressor (Driver's and central system)

Make: Gates
Model: BX 97
Qty: 2

A/C compressor (Auxiliary system, opt.)

Make: Gates
Model: Hi-Power A 35
Qty: 1

Alternator 24 V 270 amps

Make: Dayco
Model: Multi-V, 23521337 20-6966
Qty: 1

ENGINES

Detroit Diesel DDEC III Series 60, 12.7 liters inline 6 cylinders, 400 BHP.

Detroit Diesel DDEC III Series 60, 11.1 liters inline 6 cylinders, 325 BHP.

Detroit Diesel DDEC III Series 50, 8.5 liters inline 4 cylinders, 315 BHP.

TRANSMISSIONS

Automatic transmission

Allison six speed automatic World Transmission B500 or B500R with Electronic Control.

Gear

Ratio

1 st	3.51
2 nd	1.91
3 rd	1.43
4 th	1.00
5 th	0.74
6 th	0.64
Rev	4.80

Converter (Series 60, 12.7 liters)..... 1.79

Converter (Series 60, 11.1 liters and Series 50)..... 2.34

Output retarder (Optional)

NOTE: Gear ratios do not include torque converter multiplication.

Manual transmissions

Spicer PS145-7A, 7-speed

Gear	Ratio
1 st	10.13
2 nd	5.99
3 rd	3.56
4 th	2.57
5 th	1.84
6 th	1.33
7 th	1.00
Rev	10.13

Spicer PS130-6B, 6-speed

Gear	Ratio
1 st	8.53
2 nd	4.87
3 rd	3.00
4 th	1.90
5 th	1.33
6 th	1.00
Rev	8.53

DRIVE AXLE RATIO

World transmission (Series 60) 4.89:1 (std)
..... 4.56:1 (opt)
World transmission (Series 50) 4.89:1

Manual transmissions (Series 60) 3.07:1 (std)
..... 3.21:1 (opt)
Manual transmissions (Series 50) 3.21:1

SOUND SYSTEM

- AM/FM/Stereo cassette receiver.
- AM/FM/Stereo CD receiver (optional).
- 2 Microphones with 6-foot extension cords.
- Wireless microphone and receiver (optional).
- Microphone jacks (two standard).
- P.A. and Back-up P.A.
- 12 Blaupunkt Hi-Fi speakers.
- 45 watts, two channel, 24 volts audio amplifier.
- Digital audio / video control unit for driver's control.
- Two Hi-Fi speakers in driver's area (optional).
- Compact disc player - 6 stacks (optional).
- Cellular phone antenna (optional).
- CB antenna (optional).

VIDEO SYSTEM (optional)

- VHS video cassette player.
- TV monitors (mounted under parcel racks) (qty 3, 4, or 5).
- TV receiver (with video system only).

SUSPENSION

Front axle

- 2 air springs.
- 2 shock absorbers.
- 3 longitudinal radius rods.
- 1 transversal radius rod.
- 1 height control valve.
- 1 sway bar.

Drive axle

- 4 air springs.
- 4 shock absorbers.
- 3 longitudinal radius rods.
- 1 transversal radius rod.
- 2 height control valves.

Tag axle

- 2 air springs.
- 2 shock absorbers.
- 3 longitudinal radius rods.
- 1 transversal radius rod.

Extra lift and/or extra low suspension

Hi-Buoy system (optional).

Low-Buoy system (optional).

Kneeling system (optional).

ALIGNMENT

Front axle

Toe-in: +3/32" \pm 1/32" (2,4 mm \pm 0,8 mm)

Caster: + 2 3/4° \pm 3/4°

Camber: - 1/8° \pm 3/8°

Tag axle

Toe: 0" \pm 1/16" (0 mm \pm 1,6 mm)

HEATING AND AIR CONDITIONING

Driver's system

Air conditioning capacity: 19,000 Btu/hr.

Refrigerant type: R-134a

Heating capacity: 37,800 Btu/hr.

Air flow: 450 cfm (12,7 m³/min.)

Central system

Air conditioning capacity: . 110,000 Btu/hr. (XL-45)

Air conditioning capacity: 98,000 Btu/hr. (XL-40)

Refrigerant type: R-134a

Heating capacity: 152,000 Btu/hr.

Air flow: 2,700 cfm (76,4 m³/min.)

PREHEATING SYSTEMS (Optional)

ESPAR (EBERSPÄCHER)

Heater: Model D12W
 Heating capacity: 12 kW
 Heating output: 41,000 Btu/hr
 Fuel type: Same as engine
 Fuel consumption: 0.44 U.S. gal.
 (1,65 liters) / hour
 Rated voltage: 24 ± 4 volts
 Electric power consumption: 55 watts

WEBASTO

Heater: Model DBW2020
 Heating capacity: 23.3 kW
 Heating output: 80,000 Btu/hr
 Fuel type: Same as engine
 Fuel consumption: 0.8 U.S. gal.
 (3 liters) / hour
 Rated voltage: 24 ± 4 volts
 Electric power consumption: 120 watts

Heater: Model DBW2010
 Heating capacity: 13.1 kW
 Heating output: 45,000 Btu/hr
 Fuel type: Same as engine
 Fuel consumption: 0.4 U.S. gal.
 (1.5 liters) / hour
 Rated voltage: 24 ± 4 volts
 Electric power consumption: 85 watts

STORAGE VOLUME

Exterior baggage compartments:

XL-40 315 ft³ / 8,9m³
 XL-45 407ft³ / 11,5m³

Parcel racks:

XL-40 75ft³ / 2,13m³
 XL-45 86ft³ / 2,43m³

SEATS

Seating capacity:

XL-40 47 passengers
 XL-45 55 passengers

Several seating layouts may be achieved through a combination of available equipment with the addition or removal of some items such as passenger seats, card table(s), galley, lavatory etc..

DATA PLATE AND CERTIFICATION

Data plates

The main components of the vehicle such as engine, transmission, axles and chassis are identified by different serial numbers. It may be necessary to locate these numbers for warranty purposes.

Engine

The engine serial number is stamped on the cylinder block under the exhaust manifold (oil filter side) close to the water pump. In addition, four plates are located on the rocker cover (oil filter side). Contents of the plates include the engine serial and model numbers and a list of the optional equipment on the engine. The information is primarily used when ordering replacement parts.




FIGURE 94
01012




FIGURE 97: Front axle

10003




FIGURE 95: Transmission data plate

07019

Vehicle identification number (V.I.N.)

The vehicle identification number is stamped on a plate located on dashboard louver (entrance door side), so that it is visible from the outside through the windshield. It is extremely important to give the correct vehicle identification number when ordering replacements parts. Use of these numbers will prevent delay and errors in obtaining the correct material.




FIGURE 98: V.I.N.

18041A




FIGURE 96: Drive axle
11004

Coach final record

This is a complete and detailed record of all data pertaining to the assembly of the vehicle. This information sheet is included in the technical publication box delivered with the new vehicle

and should be kept in vehicle where it will be readily available for reference.

Safety attestation

All the components on this vehicle meet government requirements:

- Material and parts conform to ASTM and/or SAE standards in effect at time of manufacturing.
- Welding is in accordance with Canadian and US standards.
- All factory-installed interior materials meet F.M.V.S.S. 302 on fire resistance.
- Certified according to Provincial, State and Federal Safety standards (Can. & US) B.M.C.S.S., F.M.V.S.S., C.M.V.S.S.

Other certification labels are affixed to the specific components on the vehicle.

DOT certification label

This is your assurance that your new vehicle complies with all applicable Federal Motor Vehicle Safety Standards which were in effect at the time the vehicle was manufactured. You can find this label affixed below L.H. Side Control Panel in driver's compartment.




FIGURE 99
18042

EPA engine label

The exhaust emission certification label affixed on the lower R.H. side corner of the rear junction box certifies that the engine conforms to federal and any state exhaust emission regulations. It gives the operating conditions at which certification was made.




FIGURE 100

01011

LIGHT BULB DATA

When replacing a light bulb, special attention must be paid to the voltage rating (refer to light bulb data hereafter).

Note: All exterior lights are 12 volts and interior lights are 24 volts, except for the Check engine and Stop engine warning lights and flasher indicator lights which are also on 12 volt system.

EXTERIOR LIGHTING						
APPLICATION	PREVOST PART NO.	TRADE OR SAE NUMBER	WATTS OR CANDLE POWER	VOLTS	QTY XL-40	QTY XL-45
Headlight Hi/Lo	930291	9004	65 W/45 W	12	2	2
Fog (Optional)	561882	H3(Osram)	55 W	12	2	2
License plate (sealed)	930266	---	12 W	12	2	2
Side directional	561917	1893	2 cp	12	12	12
Side marker	561917	1893	2 cp	12	12	12
Identification	562059	194	2 cp	12	6	6
Clearance	562059	194	2 cp	12	8	8
Front directional (hazard & marker)	562135	3057	32/3 cp	12	2	2
Rear directional	560589	1156	32 cp	12	8	8
Stop	560589	1156	32 cp	12	8	8
Back-up	560589	1156	32 cp	12	4	4
Center stop	560589	1156	32 cp	12	2	2
Tail	560123	67	4 cp	12	8	8
Exterior compartment (except engine)	562278	6429 (78207)	10 W	24	12	12
Engine compartment	560601	456	2 cp	24	6	6

INTERIOR LIGHTING						
APPLICATION	PREVOST PART NO.	TRADE OR SAE NUMBER	WATTS OR CANDLE POWER	VOLTS	QTY XL-40	QTY XL-45
Check engine	562048	E-9 (Norma)	2 W	12	1	1
Stop engine	562048	E-9 (Norma)	2 W	12	1	1
Flasher indicator	562048	E-9 (Norma)	2 W	12	2	2
Other indicator - 1/unit	562049	(Osram)	2 W	24	AR	AR
Speedometer	560145	1829	1 cp	24	2	2
Pyrometer (Opt)	560601	456	2 W	24	1	1
Tachometer	560145	1829	1 cp	24	2	2
Turbo boost (Opt)	561167	3899 (Osram)	3 W	24	1	1
Tachograph (Opt)	561006	1-405-804	1.2 cp	24	3	3
Other instrument - 1/unit	560144	1820	1.6 cp	24	AR	AR
Step	562278	6429 (78207)	10 W	24	3	3
Driver's area	561553	78236	10 W	24	4	4
Lavatory	561553	78236	10 W	24	2	2
Lavatory night light	560601	456	2 cp	24	1	1
Lavatory "Occupied"	560702	1843	0.2 cp	24	2	2
Parcel racks	560144	1820	1.6 cp	24	12	14
"Emergency exit"	560601	456	2 cp	24	14	16
Aisle	560141	1251	3 cp	24	6	7
Switch 1/unit	561123	2741 (Osram)	1 W	24	AR	AR
Reading	562033	961-4940	8 W	24	AR	AR
Fluorescent	830102	F15T8 CW	15 W	---	24	27
Destination sign	560125	16911F	15 W	24	4	4
Parcel rack front neon	830108	PL7	7 W	---	14	16
Rear roof	561553	78236	10 W	24	2	2
R.H. lateral console	562278	6429 (78207)	10 W	24	1	1

DDEC III DIAGNOSTIC CODES

To read codes:

Use a diagnostic data reader plugged in receptacle on L.H. side control panel (item #17 on page 2-4) or momentarily depress the Stop engine "OVERRIDE" switch (located on the L.H. lower switch panel) with the ignition on, engine at idle or not running. Active codes will be flashed on the stop engine telltale (located on central dashboard), followed by the inactive codes being flashed on the check engine telltale (located on central dashboard). The cycle repeats until the operator depresses again the Stop engine "OVERRIDE" switch. A code "43" consists of four flashes, followed by a short pause, then three flashes in quick succession.

DDC Code Number (Flashed)	Description
11	VSG sensor input voltage low
12	VSG sensor input voltage high
13	Coolant level sensor input voltage low
14	Oil, coolant, or intercooler, temp. sensor input voltage high
15	Oil, coolant, or intercooler, temp. sensor input voltage low
16	Coolant level sensor input voltage high
17	Bypass or throttle, valve position sensor input voltage high
18	Bypass or throttle, valve position sensor input voltage low
21	TPS input voltage high
22	TPS input voltage low
23	Fuel temp. sensor input voltage high
24	Fuel temp. sensor input voltage low
25	No active codes
26	Aux. engine shutdown #1, or #2, input active
27	Air inlet or intake air, temp. sensor input voltage high
28	Air inlet or intake air, temp. sensor input voltage low
31	Aux. high side output open circuit or short to ground
32	CEL or SEL short to battery (+) or open circuit
33	Turbo boost sensor input voltage high
34	Turbo boost sensor input voltage low
35	Oil pressure sensor input voltage high
36	Oil pressure sensor input voltage low
37	Fuel pressure sensor input voltage high
38	Fuel pressure sensor input voltage low
41	Too many SRS (missing TRS)
42	Too few SRS (missing SRS)
43	Coolant level low

DDC Code Number (Flashed)	Description
44	Oil, coolant, intercooler or intake air, temp. high
45	Oil pressure low
46	ECM battery voltage low
47	Fuel, air inlet, or turbo boost, pressure high
48	Fuel or air inlet pressure low
52	ECM A/D conversion fault
53	ECM non volatile memory fault
54	Vehicle speed sensor fault
55	J1939 data link fault
56	J1587 data link fault
57	J1922 data link fault
58	Torque overload
61	Injector response time long
63	PWM drive short to battery (+) or open circuit
64	Turbo speed sensor input fault
65	Throttle valve position input fault
66	Engine knock sensor input fault
67	Coolant or air inlet, pressure sensor input voltage fault
68	TPS idle validation switch open circuit or short to ground
71	Injector response time short
72	Vehicle overspeed
73	Gas valve position input fault or ESS fault
74	Optimized idle safety loop short to ground
75	ECM Battery voltage high
76	Engine overspeed with engine brake
81	Oil level, crankcase prs, dual fuel BOI, or exh. temp. volt. high
82	Oil level, crankcase prs, dual fuel BOI, or exh. temp. volt. low
83	Oil level, crankcase prs, exhaust temp., or external pumps prs., high
84	Oil level or crankcase pressure, low
85	Engine overspeed
86	External pump or barometer, pressure sensor input voltage high
87	External pump or barometer, pressure sensor input voltage low
88	Coolant pressure low

WORLD TRANSMISSION (WT) DIAGNOSTIC CODES

Diagnostic code memory

Diagnostic codes are logged in a list in memory (sometimes referred to as the queue), positioning the most recently occurring code first and containing up to five codes. The codes continued in the list have the information recorded as shown in the chart below. Access to the code list position, main code, sub code and active indicator is through either the shifter display or the Pro-Link Diagnostic Data reader (DDR). Access to the ignition cycle counter and event counter is through the DDR only.

Code List Position	Main Code	Sub Code	Active Indicator	Ignition Cycle Counter	Event Counter
d1	21	12	YES	00	10
d2	41	12	YES	00	04
d3	23	12	NO	08	02
d4	34	12	NO	13	01
d5	56	11	NO	22	02
Displayed on shifter display and DDR			YES= ACTIVE= "MODE ON"	Ignition cycle counter and event counter are not available on shifter display	

NOTE: All information is available with a DDR.

The following paragraphs define the different parts of the code list.

Code list position:

The position 1 through 5 which a code occupies in the code list in memory. Positions are shown as "d1" (Diagnostic Code #1) through "d5."

Main code

The general condition or area of fault detected by ECU.

Sub Code

The specific area or condition under the main code in which the condition was detected.

Active Indicator

Will be turned "on" when a fault condition is active (shifter will display "MODE ON" or the DDR will display "YES"). Will be set to "off" when conditions exist to indicate fault condition is gone.

Ignition cycle counter

Used to clear diagnostic codes that are inactive from the code list in memory. Counter is incremented each time a normal ECU powerdown occurs following clearing of the Active Indicator. Code will be cleared from the list when the counter exceeds 25.

Event counter

Used to count the number of occurrences of a diagnostic code that occur prior to the incident being cleared from the code list. The most recent code will be in position "d1". If the most recent code is one which is already in the code list, that code will be moved to position "d1", the Active Indicator will be turned "on" (shifter will display "MODE ON" or the DDR will display "YES"), the Ignition Cycle Counter is cleared and "1" is added to the Event counter.

Clearing the Active Indicator and code records from the Code list in memory:

If the conditions causing a diagnostic code to be set are cleared, the Active Indicator can be manually cleared by holding the "MODE" button down continuously for 3 seconds until a tone is heard from the shifter. To clear code records from the list, hold the "MODE" button down continuously for ten seconds until a second tone sounds. All diagnostic records in the list that are not active will then be cleared and the remaining records will then be moved up the list.

Code reading and code clearing procedures

Diagnostic codes can be read and cleared by two methods: by using the Pro-Link 9000 DDR plugged in receptacle located on L.H. lateral console or by using the shifter display. The use of the Pro-Link 9000 DDR is described in the instruction manual furnished with each tool. The

method of reading and clearing codes described in this section refers to only entering the Diagnostic Display Mode by the proper button.

The Diagnostic Display Mode may be entered for viewing of codes at any speed. Codes can only be cleared when the output speed = 0 and no output speed sensor failure is active.

The following descriptions explain how to use the shifter to read and clear codes:

Reading Codes:

1. Enter the diagnostic display mode by pressing the "↑" and "↓" (upshift and downshift arrows) buttons at the same time on the pushbutton shifter.

NOTE: If a "DO NOT SHIFT" condition is present at this time, the lever should be in the same position as it was at time of code detection. If not, this shifter tone will sound continuously.

NOTE: If an oil level sensor is present, then oil level will be displayed first. Diagnostic code display is achieved by depressing the upshift and downshift arrows or display mode button a second time.

2. Read the first code in the first of five code positions on the digital display of the shifter. For example, we will read code 25 11 in the first position. The display will change every two seconds as follows:

- a. Code list position --"d1"
- b. Main code --"25"
- c. Sub code --"11"
- d. Display will repeat cycle of a., b. and c. above

3. Press the "MODE" button momentarily to view the second position (d2) in the same way as 2. above.

4. To view the third, fourth and fifth positions (d3,d4 and d5), momentarily press the "MODE" button as explained above.

5. Pressing the "MODE" button momentarily after the fifth position is displayed will cause the sequence of code positions to start over with the first position.

6. Any code which is active will be indicated by the "MODE ON" indicator (active indicator) being turned on while in that code position (while in the normal operating mode, the "MODE ON" indicator is turned on to indicate "ECONOMY" mode operation.

7. Any code position in the list which does not have a diagnostic code logged will display "- -" for both the main and sub code displays. All positions after a code position without any code will also not contain any codes.

Clearing Codes:

1. Clearing of the active indicator is automatically done at ECU powerdown on all codes except 69 34 (see code list, page 5-17).

2. Some codes will clear the active indicator automatically when the condition causing the code is no longer detected by the ECU.

3. Manual clearing is possible while in the diagnostic display mode and after the condition causing to code is corrected (output speed must be zero).

- a. To clear all active indicators, hold the "MODE" button down continuously for 3 seconds until the shifter tone sounds for 0.5 seconds.
- b. Release the "MODE" button to return to normal operating mode. If the condition

causing the code was not active at the time, the active indicator will turn off.

CAUTION: *If clearing a code while locked in a Forward or Reverse position (fail-to-range), the transmission will still be in Drive or Reverse when the clearing procedure is completed. Neutral must be manually selected.*

Exiting the diagnostic display mode:

The diagnostic display mode can be exited by any of the following procedures:

1. Press the "↑" and "↓" (upshift and downshift) buttons at the same time on the pushbutton shifter.

2. Press any range button, "D", "N" or "R", on the pushbutton shifter (the shift will be commanded if it is not inhibited by an active code).

3. Do nothing and wait until the calibrated time (approximately 10 minutes) has passed and the system automatically returns to the normal operating mode.

4. Turn off power to the ECU (turn off the vehicle at the ignition switch).

5. After the clearing the active indicator procedure described above has been performed.

Clearing records from the code list in memory

If the requirements for Manual Clearing the Active Indicator have been satisfied, and the "MODE" button is held down continuously for ten seconds while in the display mode until a tone sounds, all diagnostic records in the code list that are not active will be cleared and the remaining records will be moved up in the code list.

Abbreviation found in the code chart

The following responses are used throughout the following chart to command safe operation when diagnostic codes are set.

• DNS (Do Not Shift) Response

- Turn off lockup clutch and inhibit lockup operation.
- Inhibit all shifts.
- Turn on *DO NOT SHIFT* light.

- Pulse the tone generator for 8 seconds when the condition is first detected.

- Blank the select digit in the display.

- Ignore any range selection inputs and disable the button feedback tone for the pushbutton shifter.

• SOL OFF (Solenoid Off) Response

- All solenoids are commanded off (turning solenoids "A" and "B" off electrically causes them to be on hydraulically).

• RPR (Return to Previous Range) Response

- When the ratio or C3 pressure switch tests associated with a shift are not passed, the ECU commands the same range as commanded at the beginning of the shift.

• NNC (Neutral No Clutches) Response

- When certain ratio or C3 pressure switch tests are not passed, the ECU commands a neutral condition with no clutches applied.

World Transmission (WT) Diagnostic code list and description

MAIN CODE	SUB CODE	DESCRIPTION	DO NOT SHIFT LIGHT	INHIBITED OPERATION DESCRIPTION
12	12	Oil level, low	No	No upshift above a calibration range
12	23	Oil level, high	No	No upshift above a calibration range
13	12	ECU input voltage, low	Yes	DNS, SOL OFF (Hydraulic default)
13	13	ECU input voltage, medium low	No	None: Shift adaptive feature will not function.
14	12	Oil level sensor, low	No	None

TECHNICAL INFORMATION

MAIN CODE	SUB CODE	DESCRIPTION	DO NOT SHIFT LIGHT	INHIBITED OPERATION DESCRIPTION
14	23	Oil level sensor, high	No	None
21	12	Throttle position sensor, low	No	Use Throttle default value
21	23	Throttle position sensor, high	No	Use Throttle default value
22	14	Engine speed sensor reasonableness test	No	Use default engine speed
22	15	Turbine speed sensor reasonableness test	Yes	DNS, Lock in current range
22	16	Output speed sensor reasonableness or rapid decel test	Yes	DNS, Lock in current range
23	12	Primary Shifter or RSI Link Fault	No	Hold in last valid direction
23	13	Primary Shifter Mode Function Fault	No	Mode change not permitted
23	14	Secondary Shifter or RSI Link Fault	No	Hold in last valid direction
23	15	Secondary Shifter Mode Function Fault	No	Mode change not permitted
24	12	Sump oil temperature, cold	Yes	DNS
24	23	Sump oil temperature, hot	No	No upshifts above a calibration range
25	00	Output speed reasonableness test, detected at 0 speed, (L)	Yes	DNS, Lock in current range (L)
25	11	Output speed reasonableness test, detected at 0 speed, (1st)	Yes	DNS, Lock in current range (1 st)
25	22	Output speed reasonableness test, detected at 0 speed 2nd	Yes	DNS, Lock in current range (2nd)
25	33	Output speed reasonableness test, detected at 0 speed, 3rd	Yes	DNS, Lock in current range (3rd)
25	44	Output speed reasonableness test, detected at 0 speed, 4th	Yes	DNS, Lock in current range (4th)
25	55	Output speed reasonableness test, detected at 0 speed, 5th	Yes	DNS, Lock in current range (5th)
25	66	Output speed reasonableness test, detected at 0 speed, 6th	Yes	DNS, Lock in current range (6th)
25	77	Output speed reasonableness test, detected at 0 speed, R	Yes	DNS, Lock in current range (R)

TECHNICAL INFORMATION

MAIN CODE	SUB CODE	DESCRIPTION	DO NOT SHIFT LIGHT	INHIBITED OPERATION DESCRIPTION
32	00	C3 pressure switch open, L range	Yes	DNS, Lock in current range (L)
32	33	C3 pressure switch open, 3rd range	Yes	DNS, Lock in current range (3rd)
32	55	C3 pressure switch open, 5th range	Yes	DNS, Lock in current range (5th)
32	77	C3 pressure switch open, R range	Yes	DNS, Lock in current range (R)
33	12	Sump oil temperature sensor, low	No	Use default value of 200° F (93° C)
33	23	Sump oil temperature sensor, high	No	Use default value of 200° F (93° C)
34	12	EEPROM, factory cal. compatibility number wrong	Yes	DNS, SOL OFF (Hydraulic default)
34	13	EEPROM, factory calibration block checksum	Yes	DNS, SOL OFF (Hydraulic default)
34	14	EEPROM, Power Off Block checksum	Yes	Use previous location, or factory calibration and reset adaptive
34	15	EEPROM, Diagnostic Queue Block Checksum	Yes	Use previous location, or clear diagnostic queue
34	16	EEPROM, Real Time Block Checksum	Yes	DNS, SOL OFF (Hydraulic default)
35	00	Power interruption (Code set after power restored)	No	NONE (Hydraulic default during interruption)
35	16	Real Time EEPROM Write Interruption	Yes	DNS, SOL OFF (Hydraulic default)
36	00	Hardware/Software not compatible	Yes	DNS, SOL OFF (Hydraulic default)
41	12	Open or short to ground, A solenoid circuit	Yes	DNS, SOL OFF (Hydraulic default)
41	13	Open or short to ground, B solenoid circuit	Yes	DNS, SOL OFF (Hydraulic default)
41	14	Open or short to ground, C solenoid circuit	Yes	DNS, SOL OFF (Hydraulic default)

TECHNICAL INFORMATION

MAIN CODE	SUB CODE	DESCRIPTION	DO NOT SHIFT LIGHT	INHIBITED OPERATION DESCRIPTION
41	15	Open or short to ground, D solenoid circuit	Yes	DNS, SOL OFF (Hydraulic default)
41	16	Open or short to ground, E solenoid circuit	Yes	DNS, SOL OFF (Hydraulic default)
41	21	Open or short to ground, F solenoid circuit	No	Lock-up inhibited
41	22	Open or short to ground, G solenoid circuit	Yes	DNS, SOL OFF (Hydraulic default)
41	23	Open or short to ground, H solenoid circuit	No	Retarder allowed, differential lock inhibited
41	24	Open or short to ground, J solenoid circuit	No	Low and 1st inhibited
41	25	Open or short to ground, K solenoid circuit	No	K solenoid operation inhibited
41	26	Open or short to ground, N solenoid circuit	No	Low and 1st inhibited
42	12	Short to battery, A solenoid circuit	Yes	DNS, Lock in a range
42	13	Short to battery, B solenoid circuit	Yes	DNS, Lock in a range
42	14	Short to battery, C solenoid circuit	Yes	DNS, Lock in a range
42	15	Short to battery, D solenoid circuit	Yes	DNS, Lock in a range
42	16	Short to battery, E solenoid circuit	Yes	DNS, Lock in a range
42	21	Short to battery, F solenoid circuit	No	Lock-up inhibited
42	22	Short to battery, G solenoid circuit	Yes	DNS, Lock in a range
42	23	Short to battery, H solenoid circuit	No	Retarder allowed, differential lock inhibited

TECHNICAL INFORMATION

MAIN CODE	SUB CODE	DESCRIPTION	DO NOT SHIFT LIGHT	INHIBITED OPERATION DESCRIPTION
42	24	Short to battery, J solenoid circuit	No	Low and 1st inhibited
42	25	Short to battery, K solenoid circuit	No	K solenoid operation inhibited
42	26	Short to battery, N solenoid circuit	No	Low and 1st inhibited
43	21	Low side driver, F solenoid circuit	No	Lock-up inhibited
43	25	Low side driver, K solenoid circuit	No	K solenoid operation inhibited
43	26	Low side driver, N solenoid circuit	No	Low and 1st inhibited
44	12	Short to ground, A solenoid circuit	Yes	DNS, SOL OFF (Hydraulic default)
44	13	Short to ground, B solenoid circuit	Yes	DNS, SOL OFF (Hydraulic default)
44	14	Short to ground, C solenoid circuit	Yes	DNS, SOL OFF (Hydraulic default)
44	15	Short to ground, D solenoid circuit	Yes	DNS, SOL OFF (Hydraulic default)
44	16	Short to ground, E solenoid circuit	Yes	DNS, SOL OFF (Hydraulic default)
44	21	Short to ground, F solenoid circuit	No	Lock-up inhibited
44	22	Short to ground, G solenoid circuit	Yes	DNS, SOL OFF (Hydraulic default)
44	23	Short to ground, H solenoid circuit	No	Retarder allowed. differential lock inhibited
44	24	Short to ground, J solenoid circuit	No	Low and 1st inhibited
44	25	Short to ground, K solenoid circuit	No	K solenoid operation inhibited
44	26	Short to ground, N solenoid circuit	No	Low and 1st inhibited

TECHNICAL INFORMATION

MAIN CODE	SUB CODE	DESCRIPTION	DO NOT SHIFT LIGHT	INHIBITED OPERATION DESCRIPTION
45	12	Open circuit, A solenoid circuit	Yes	DNS, SOL OFF (Hydraulic default)
45	13	Open circuit, B solenoid circuit	Yes	DNS, SOL OFF (Hydraulic default)
45	14	Open circuit, C solenoid circuit	Yes	DNS, SOL OFF (Hydraulic default)
45	15	Open circuit, D solenoid circuit	Yes	DNS, SOL OFF (Hydraulic default)
45	16	Open circuit, E solenoid circuit	Yes	DNS, SOL OFF (Hydraulic default)
45	21	Open circuit, F solenoid circuit	No	Lock-up inhibited
45	22	Open circuit, G solenoid circuit	Yes	DNS, SOL OFF (Hydraulic default)
45	23	Open circuit, H solenoid circuit	No	Retarder allowed differential lock inhibited
45	24	Open circuit, J solenoid circuit	No	Low and 1st inhibited
45	25	Open circuit, K solenoid circuit	No	K solenoid operation inhibited
45	26	Open circuit, N solenoid circuit	No	Low and 1st inhibited
51	10	Offgoing ratio test (during shift), 1 to L	Yes	Low and 1st inhibited
51	12	Offgoing ratio test (during shift), 1 to 2	Yes	DNS, RPR
51	21	Offgoing ratio test (during shift), 2 to 1	Yes	DNS, RPR
51	23	Offgoing ratio test (during shift), 2 to 3	Yes	DNS, RPR
51	43	Offgoing ratio test (during shift), 4 to 3	Yes	DNS, RPR
51	45	Offgoing ratio test (during shift), 4 to 5	Yes	DNS, RPR

TECHNICAL INFORMATION

MAIN CODE	SUB CODE	DESCRIPTION	DO NOT SHIFT LIGHT	INHIBITED OPERATION DESCRIPTION
51	65	Offgoing ratio test (during shift), 6 to 5	Yes	DNS, RPR
52	01	Offgoing C3PS test (during shift), L to 1	Yes	DNS, RPR
52	08	Offgoing C3PS test (during shift), L to N1	Yes	DNS, NNC
52	32	Offgoing C3PS test (during shift), 3 to 2	Yes	DNS, RPR
52	34	Offgoing C3PS test (during shift), 3 to 4	Yes	DNS, RPR
52	54	Offgoing C3PS test (during shift), 5 to 4	Yes	DNS, RPR
52	56	Offgoing C3PS test (during shift), 5 to 6	Yes	DNS, RPR
52	71	Offgoing C3PS test (during shift), R to 1	Yes	DNS, NNC
52	72	Offgoing C3PS test (during shift), R to 2	Yes	DNS, NNC
52	78	Offgoing C3PS test (during shift), R to N1	Yes	DNS, NNC
52	79	Offgoing C3PS test (during shift), R to 2 (R to NNC to 2)	Yes	DNS, NNC
52	99	Offgoing C3PS test (during shift), N3 to N2	Yes	DNS, RPR
53	08	Offgoing speed test (during shift), L to N1	Yes	DNS, NNC
53	18	Offgoing speed test (during shift), 1 to N1	Yes	DNS, NNC
53	28	Offgoing speed test (during shift), 2 to N1	Yes	DNS, NNC
53	29	Offgoing speed test (during shift), 2 to N2	Yes	DNS, RPR
53	38	Offgoing speed test (during shift), 3 to N1	Yes	DNS, NNC

TECHNICAL INFORMATION

MAIN CODE	SUB CODE	DESCRIPTION	DO NOT SHIFT LIGHT	INHIBITED OPERATION DESCRIPTION
53	39	Offgoing speed test (during shift), 3 to N3	Yes	DNS, RPR
53	48	Offgoing speed test (during shift), 4 to N1	Yes	DNS, NNC
53	49	Offgoing speed test (during shift), 4 to N3	Yes	DNS, RPR
53	58	Offgoing speed test (during shift), 5 to N1	Yes	DNS, NNC
53	59	Offgoing speed test (during shift), 5 to N3	Yes	DNS, RPR
53	68	Offgoing speed test (during shift), 6 to N1	Yes	DNS, NNC
53	69	Offgoing speed test (during shift), 6 to N4	Yes	DNS, RPR
53	78	Offgoing speed test (during shift), R to N1	Yes	DNS, NNC
53	99	Offgoing speed test (during shift), N2 to N3 or N3 to N2	Yes	DNS, RPR
54	01	Oncoming ratio test (after shift), L to 1	Yes	DNS, RPR
54	07	Oncoming ratio test (after shift), L to R	Yes	DNS, NNC
54	10	Oncoming ratio test (after shift), 1 to L	Yes	DNS, RPR
54	12	Oncoming ratio test (after shift), 1 to 2	Yes	DNS, RPR
54	17	Oncoming ratio test (after shift), 1 to R	Yes	DNS, NNC
54	21	Oncoming ratio test (after shift), 2 to 1	Yes	DNS, RPR
54	23	Oncoming ratio test (after shift), 2 to 3	Yes	DNS, RPR

TECHNICAL INFORMATION

MAIN CODE	SUB CODE	DESCRIPTION	DO NOT SHIFT LIGHT	INHIBITED OPERATION DESCRIPTION
54	27	Oncoming ratio test (after shift), 2 to R	Yes	DNS, NNC
54	32	Oncoming ratio test (after shift), 3 to 2	Yes	DNS, RPR
54	34	Oncoming ratio test (after shift), 3 to 4	Yes	DNS, RPR
54	43	Oncoming ratio test (after shift), 4 to 3	Yes	DNS, RPR
54	45	Oncoming ratio test (after shift), 4 to 5	Yes	DNS, RPR or SOL OFF (Hydraulic default)
54	54	Oncoming ratio test (after shift), 5 to 4	Yes	DNS,RPR
54	56	Oncoming ratio test (after shift), 5 to 6	Yes	DNS,RPR
54	65	Oncoming ratio test (after shift), 6 to 5	Yes	DNS,RPR
54	70	Oncoming ratio test (after shift), R to L	Yes	DNS,NNC
54	71	Oncoming ratio test (after shift), R to 1	Yes	DNS,NNC
54	72	Oncoming ratio test (after shift), R to 2	Yes	DNS,NNC
54	80	Oncoming ratio test (after shift), N1 to L	Yes	DNS,RPR
54	81	Oncoming ratio test (after shift), N1 to 1	Yes	DNS,RPR
54	82	Oncoming ratio test (after shift), N1 to 2	Yes	DNS,RPR
54	83	Oncoming ratio test (after shift), N1 to 3	Yes	DNS,RPR
54	85	Oncoming ratio test (after shift), N1 to 5	Yes	DNS,RPR

TECHNICAL INFORMATION

MAIN CODE	SUB CODE	DESCRIPTION	DO NOT SHIFT LIGHT	INHIBITED OPERATION DESCRIPTION
54	86	Oncoming ratio test (after shift), NI to 6	Yes	DNS, RPR
54	92	Oncoming ratio test (after shift), R to 2 (R to NNC to 2)	Yes	DNS, NNC
54	92	Oncoming ratio test (after shift), N1 to 2 (N1 to NNC to 2)	Yes	DNS, RPR
54	92	Oncoming ratio test (after shift), N2 to 2	Yes	DNS, RPR
54	93	Oncoming ratio test (after shift), N3 to 3	Yes	DNS, RPR
54	95	Oncoming ratio test (after shift), N3 to 5	Yes	DNS, RPR
54	96	Oncoming ratio test (after shift), N4 to 6	Yes	DNS, RPR
54	97	Oncoming ratio test (after shift), 2 to R (2 to NNC to R)	Yes	DNS, NNC
55	17	Oncoming C3PS test (after shift), 1 to R	Yes	DNS, NNC
55	27	Oncoming C3PS test (after shift), 2 to R	Yes	DNS, NNC
55	80	Oncoming C3PS test (after shift), N1 to L	Yes	DNS, RPR
55	87	Oncoming C3PS test (after shift), N1 to R	Yes	DNS, RPR
55	97	Oncoming C3PS test (after shift), 2 to R or NVL to R (2 to NNC to R)	Yes	DNS, NNC
56	00	Range verification test, L	Yes	DNS, 1st, Low, or SOL OFF (Low)
56	11	Range verification test, 1st	Yes	DNS, 6th
56	22	Range verification test, 2nd	Yes	DNS, 6th or 5th
56	33	Range verification test, 3rd	Yes	DNS, 5th or SOL
56	44	Range verification test, 4th	Yes	DNS, 3rd or 5th
56	55	Range verification test, 5th	Yes	DNS, SOL OFF (5th) or 3rd

TECHNICAL INFORMATION

MAIN CODE	SUB CODE	DESCRIPTION	DO NOT SHIFT LIGHT	INHIBITED OPERATION DESCRIPTION
56	66	Range verification test, 6th	Yes	DNS, 5th, 3rd, or SOL OFF (3rd)
56	77	Range verification test, R	Yes	DNS, N2 or N3
57	11	Range verification C3PS test, 1st	Yes	DNS, SOL OFF (3rd)
57	22	Range verification C3PS test, 2nd	Yes	DNS, 3rd
57	44	Range verification C3PS test, 4th	Yes	DNS, 5th or SOL OFF (3rd)
57	66	Range verification C3PS test, 6th	Yes	SOL OFF (5th), DNS
57	88	Range verification C3PS test, N1	Yes	DNS, N3
57	99	Range verification C3PS test, N2 or N4	Yes	DNS, N3
61	00	Retarder oil temperature, hot	No	None
62	12	Retarder oil temperature sensor, low	No	None
62	23	Retarder oil temperature sensor, high	No	None
63	00	Special function input	No	Depends on special function
64	12	Retarder modulation request sensor, low	No	Retarder operation inhibited
64	23	Retarder modulation request sensor, high	No	Retarder operation inhibited
65	00	Engine rating too high	Yes	DNS
66	00	Serial communications interface fault	No	Use default throttle values
69	12	ECU, A solenoid driver open	Yes	DNS, SOL OFF (hydraulic default)
69	13	ECU, B solenoid driver open	Yes	DNS, SOL OFF (hydraulic default)
69	14	ECU, C solenoid driver open	Yes	DNS, SOL OFF (hydraulic default)
69	15	ECU, D solenoid driver open	Yes	DNS, SOL OFF (hydraulic default)
69	16	ECU, E solenoid driver open	Yes	DNS, SOL OFF (hydraulic default)
69	21	ECU, F solenoid driver open	No	Lock-up inhibited

TECHNICAL INFORMATION

MAIN CODE	SUB CODE	DESCRIPTION	DO NOT SHIFT LIGHT	INHIBITED OPERATION DESCRIPTION
69	22	ECU, G solenoid driver open	Yes	DNS, SOL OFF (Hydraulic default)
69	23	ECU, H solenoid driver open	No	Retarder allowed, differential lock inhibited
69	24	ECU, J solenoid driver open	No	Low and 1 st inhibited
69	25	ECU, K solenoid driver open	No	K solenoid operation inhibited
69	26	ECU, N solenoid driver open	No	Low and 1st inhibited
69	32	ECU, SPI communications link fault	No	Hold in last valid direction
69	33	ECU, Central Operating Processor (COP) timeout	Yes	Reset ECU, Shutdown ECU on 2nd occurrence (power loss: hydraulic defaults)
69	34	ECU, EEPROM write timeout	Yes	DNS, SOL OFF (Hydraulic default)
69	35	ECU, EEPROM checksum	Yes	Induce COP timeout (reset ECU)
69	36	ECU, RAM self test	Yes	Induce COP timeout (reset ECU)
69	41	ECU, I/O ASIC addressing test	Yes	Induce COP timeout (reset ECU)
70	12	Software, minor loop overrun	Yes	Induce COP timeout (reset ECU)
70	13	Software, illegal write to address \$0000	Yes	Induce COP timeout (reset ECU)
70	14	Software, major loop overrun	Yes	Induce COP timeout (reset ECU)

TABLE OF CONTENTS

Safety precautions.....	3 - 7
Defensive driving.....	3 - 8

**STARTING AND STOPPING
PROCEDURES 4 - 1**

General information.....	4 - 1
Detroit Diesel Electronic Control (DDEC).....	4 - 2
World Transmission WT Electronic Control System.....	4 - 3
Manual transmission	4 - 7
Cold weather starting	4 - 7
Daily inspection	4 - 8
Recommendations	4 - 9
Heating and air conditioning	4 - 10
Preheating systems.....	4 - 13
Windshield washer reservoir.....	4 - 14
Jump starting	4 - 15
Electric circuit protection	4 - 16
Tires	4 - 18
Jacking points.....	4 - 20
Towing	4 - 20
Retractable tag axle	4 - 21
Tag axle unloaded.....	4 - 21

TECHNICAL INFORMATION 5 - 1

Dimensions.....	5 - 1
Weights.....	5 - 2
Capacities	5 - 2
Fuel type	5 - 2
Wheels and tires.....	5 - 2
Belts	5 - 3
Engines.....	5 - 3
Transmissions	5 - 3
Drive axle ratio.....	5 - 3
Brakes.....	5 - 4
Antilock braking system (ABS)	5 - 4
Steering	5 - 4
Electrical system.....	5 - 4

Sound system	5 - 5
Video system.....	5 - 5
Suspension	5 - 5
Alignment	5 - 5
Heating and air conditioning	5 - 5
Oil specifications	5 - 6
Preheating systems	5 - 7
Storage volume.....	5 - 7
Seats	5 - 7
Data plate and certification	5 - 7
Light bulb data.....	5 - 10
DDEC III diagnostic codes.....	5 - 12
World transmission WT diagnostic codes.....	5 - 14

CARE AND MAINTENANCE 6 - 1

Interior cleaning.....	6 - 1
Exterior cleaning	6 - 3
Oil verification.....	6 - 4
Air tanks	6 - 7
Coolant level verification.....	6 - 7
Water separator	6 - 7
Belt tensioners	6 - 8
A/C and heating air filters	6 - 8
Flexible hose maintenance.....	6 - 9
Lubrication.....	6 - 9
Fire extinguishers.....	6 - 9
110-120 volt in-station lighting.....	6 - 9
110-120 volt in-station connectors	6 - 9
Back-up camera.....	6 - 10
Filter restriction indicator.....	6 - 10
Lavatory maintenance	6 - 10
First service on new vehicle	6 - 12
Lubrication and servicing schedule	6 - 13

SERVICE LITERATURE 7 - 1

Care & maintenance

INTERIOR CLEANING

To provide consistent and quality passenger service, the coach interior must be kept clean at all times. Scheduled servicing of the coach shall include cleaning of all passenger areas.

NOTE: Use only approved cleaning products obtained through a recognized cleaning product supplier. Never use stain protection products on new fabrics. To prevent permanent staining of fabrics, clean stains soon after they occur. Incorrect treatment of stains can worsen them. Get help from a cleaning specialist to remove stubborn stains.

NOTE: The cleaning information provided in this section are recommended cleaning practices. Cleaning results may vary depending on the condition of the stain. Always clean stain promptly for best results.

Seat Upholstery

Normal Cleaning

Firmly beat the seat upholstery with a blunt object, such as a wooden paddle, to release dust and dirt. Vacuum the seat upholstery fabric in the direction of the stitching using an upholstery nozzle.

NOTE: Upholstery life will be reduced due to the abrasive nature of dirt and grit. Vacuum the seat upholstery regularly.

Removal of Stains and Marks

Remove stains and marks from the wool plush as follows:

Method 1

- Apply a nonflammable solvent (Trichloroethylene) to stained area with a clean, white absorbent rag.
- Clean stain starting at the outer edges of the stain and working in towards the center.
- Blot affected area frequently with a clean, dry absorbent cloth to prevent stain rings caused by excess solvent.

WARNING: Use solvents in a well ventilated area. Open all windows and doors.

Method 2

- Wet the stain with a solution of household detergent and lukewarm water. Do not soak the stain.
- Rub the stain with a damp cloth.
- Rinse cloth after each application.

CAUTION: Do not use soap, soap powder, ammonia, soda, bleach or cleaning products containing any of these compounds.

Beverage Stains

Remove beverage stains by following method 1. If stain persists, repeat method 1 using methylated spirits instead of solvent.

Alcoholic Beverage Stains

Remove alcoholic beverage stains by wetting the stain with water, then clean following method 2.

Burns

Scrape burnt area using a knife or razor blade then clean following method 2. Consult an upholstering specialist when dealing with extensive burns.

CARE & MAINTENANCE

Cosmetic Stains

Remove stains left by cosmetics by following method 1 then method 2.

Ink Stains

Remove ink stains following method 2. If stain persists, apply a warm oxalic acid solution. Rinse with water.

Blood stains

Remove blood stains following method 2.

Urine

Remove urine stains following method 2.

Vomit

Remove vomit stains following method 2.

Copying Ink - Ballpoint Pen Ink

Treat with methylated spirits, blotting frequently to avoid spreading stain, followed by method 2.

Marking Ink (Felt-Tip Pens)

Treat with Methyl-Ethyl-Ketone (MEK) followed by method 2.

Oil, Grease and Paint

Remove excess using a knife. Treat with method 1 followed by method 2. If stain persists, repeat procedure.

Rust

Remove rust stains by following method 2. Apply a warm oxalic acid solution to stained areas. Rinse with water.

Tar

Soften Tar with benzene and then treat using method 1 followed by method 2.

Chewing Gum

Soften gum with cyclohexane. Carefully scrape off stains using a sharp knife or razor blade.

Plastic and vinyl

Use a clean, damp cloth or sponge to keep trim free from dust. For other soilage, use a lukewarm all purpose cleaning solution or a mild saddle soap for vinyl trim. Remove water spots and soap traces with a clean, damp cloth or sponge. Use a clean, soft cloth to rub dry.

Grease, tar or oil stains can be removed with a clean cloth or sponge soaked with an all purpose cleaner or with a solvent-type vinyl cleaning agent.

Occasionally, apply a colorless vinyl or leather preservative to retain the material's luster and pliability.

Windows

To clean inside surface of the windows, use a commercial glass cleaner or a 10 to 1 mix of water and white vinegar. For maximum visibility, keep your windows clean at all times.

Rubber components

Should be treated only with pure water or glycerin.

Pressure laminates

Normal maintenance consists in wiping surfaces with a damp cloth and detergent. Remove spillage at once to avoid permanent stains.

To remove stains, first try cleaning the affected area with a household detergent, methylated

spirits or mineral turpentine. If stain is still present, try a mild abrasive and water solution.

Stainless steel

Use a stainless steel cleaner available at any automotive washing and cleaning specialist and follow manufacturer's instructions.

Formica

Remove stains on formica surfaces with a household detergent, methylated spirits or mineral turps. Clean with a mild abrasive and water solution if stains persist.

Carpet

Vacuum carpets regularly to prolong carpet life.

Floor cleaning

Clean floors with a quality nonionic detergent cleaner. Follow the manufacturer's recommendations for cleaning.

Remove any excess detergent solution using a wet/dry vacuum or mop. Rinse floor with a solution of one part Clorox to ten parts warm water.

Polish dry floor using a high-speed buffer and a smooth, red 3-M polishing pad.

Mop floor periodically with a solution of 5% Clorox in warm water.

EXTERIOR CLEANING

The paint on your vehicle is very durable, but must be protected from harsh weather conditions that can make it lose its luster. Therefore, wash and wax your vehicle often. The longer the dirt is left on the paint, the greater the risk of damaging the glossy finish; either by scratching (if the dirt is rubbed into the paint), or simply by the chemical effect dirt particles have on painted surfaces.

Begin by spraying water over the entire vehicle to remove all loose dirt, then wash with a car washing-soap in the concentration recommended by the manufacturer. Rinse afterwards with a generous stream of water.

NOTE: *The vehicle paintwork needs polishing or preserving when water no longer forms droplets on the surface.*

CAUTION: *Do not use hot water. Lukewarm to cool water is less harmful to the paint. Do not use solutions that can damage the body paint.*

Do not aim the water jet directly into openings such as the A/C & heating compartment door grille to avoid water penetration in the fresh air intake duct. If the water jet is under high pressure, avoid aiming the jet directly on condenser and radiator doors as the fins of cores may be damaged.

Do not wash or wax your vehicle in direct sunlight.

The underside of the vehicle picks up dirt and road salt used to keep streets and highways free of snow and ice. To protect against corrosion, it is important to remove mud, debris and road salt from the underside with a powerful water jet. Be sure to include the wheelhousings, bumpers, muffler, tailpipe and brackets. This should be done twice a year and is best accomplished after the vehicle has been driven through a heavy rain. The exterior of the vehicle, engine, engine compartment, aluminum wheels and mirrors should always be washed as soon as possible after accumulating road salt.

NOTE: *Let engine and exhaust cool down before washing.*

Tar or oil

Do not allow tar or oil to remain on the paint. Remove as soon as possible with tar remover or turpentine. After applying cleaning fluids, always wash with a lukewarm water and soap solution, then apply a new coat of wax.

CARE & MAINTENANCE

Insects

Remove as soon as possible with a lukewarm water and soap solution or insect remover.

Tree sap and bird droppings

Do not allow tree sap or bird droppings to harden on the paint. Remove with a lukewarm water and soap solution.

Windows

Keep silicone sprays off the windshield to avoid wiper smear in rain. Clean all windows regularly to remove road film and bus-wash wax buildup. Use a lukewarm soap and water solution or an alcohol-based cleaning agent. If a chamois is used for polishing the glass, it should be used exclusively for that purpose.

Wiper blades

If wiper blades are frozen, remove ice gently by hand to avoid blade damage. Remove all wiper blades periodically and clean them thoroughly with an alcohol-based solution. Use a sponge or soft cloth and wipe lengthwise. Replace wiper blades if they are damaged or do not clean well.

OIL VERIFICATION

Engine oil level

Ideally, check engine oil level when oil is warm with vehicle on a level surface; for instance, during every fuel filling. First, stop engine and wait at least 10 minutes for the oil to drain back into the oil pan. Then, pull out the dipstick, wipe clean, reinsert the dipstick and note the oil level. Maintain the oil level between the two marks on the dipstick, and never allow it to drop below the "L" mark. If required, add oil from the oil reserve tank using the tank valve, then check oil level again. No advantage is gained by having oil level

above the "F" mark. Do not forget to shut off oil reserve tank valve as too much oil can be harmful to the engine.




FIGURE 101

01027

NOTE: For location of engine oil dipstick and engine oil reserve tank see figure on page 2-37.

Automatic transmission oil level

Manual oil level check procedure

NOTE: For "Electronic Readout of Oil level sensor" and other transmission related information, see pages 4-3 through 4-7.

WARNING: When checking the oil level, be sure that the transmission is in Neutral, parking brake is properly engaged, and the wheels are chocked. Unexpected and possible sudden vehicle movement may occur if these precautions are not taken.

Special care must be taken not to touch the engine coolant tubing and/or exhaust pipe, as this could cause severe burns.

Do not wear loose clothing and stay away from rotating parts during procedure. Personal injury could occur.

NOTE: Clean around the end of fill tube before removing dipstick. This will aid in preventing dirt and/or foreign matter from entering the fluid system, which can cause valves to stick, undue wear of transmission parts, or clog passages.

Cold Check

The purpose of the Cold Check is to determine if the transmission has enough fluid to be operated safely until a Hot Check can be made.

CARE & MAINTENANCE

If the engine has been shut down for an extended period of time, park the vehicle on a level surface and apply the parking brake.

Run the engine for at least 1 minute. Shift to Drive and operate the engine for 30 seconds at 1000-1500 rpm; then shift to Reverse to clear the hydraulic system of air. Then shift to Neutral and allow the engine to idle (500-800 rpm).

After wiping the dipstick clean (see page 2-37 for dipstick location), check the fluid level. If the fluid on the dipstick is within the COLD RUN band, the level is satisfactory. If the fluid level is not within this band, add or drain fluid as necessary to bring the level to the COLD RUN band.

Perform a HOT CHECK at the first opportunity after normal operating temperature (71°C-93°C; 160°F-200°F) is reached.




FIGURE 102

07006

CAUTION: An accurate fluid level check cannot be made unless the engine is idling (500-800 rpm) in Neutral, the transmission fluid is at the proper temperature, and the vehicle is on a level surface.

Hot Check

Because the fluid level rises as temperature increases, the fluid must be hot to ensure an accurate check.

Be sure fluid has reached normal operating temperature (71°C-93°C; 160°F-200°F).

Park the vehicle on a level surface and shift to Neutral. Apply parking brake and allow the engine to idle (500-800 rpm).

After wiping the dipstick clean, check the fluid level. The safe operating level is anywhere within the HOT RUN band on the dipstick.

If the level is not within this band, add or drain fluid as necessary to bring the level within the HOT RUN band.




FIGURE 103

07007

Manual transmission oil level

(6 speed & 7 speed)

Oil check

Manual transmission oil should be checked with engine stopped and cold.

WARNING: Before servicing the coach, park safely over a repair pit, apply parking brake, stop engine and set main battery disconnect switch (XL-40) or battery master switch (XL-45) to the "OFF" position.

Unscrew the fill plug and check if the oil level is at the plug thread level.

Refill

Refill manual transmission oil as follows:

- Remove fill plug.
- Add oil until it overflows.
- Clean oil from the transmission case and the fill plug.
- Replace fill plug.

Clutch pedal master cylinder fluid level

Maintain the clutch pedal master cylinder fluid level at the reservoir seam. The fluid reservoir is located under the dashboard near the clutch pedal.

CARE & MAINTENANCE




FIGURE 104

07009

Power steering oil level

Your vehicle is equipped with an integrated power steering system. The power steering fluid reservoir is located on the upper R.H. side of engine in the engine compartment (see page 2-37). To check fluid level, proceed as follows:

1. Stop engine, and open both engine rear doors.
2. Unscrew and remove the dipstick located on top of reservoir and wipe with a clean rag.
3. Insert dipstick in reservoir, then remove it again to check fluid level.
4. Adjust level to "FULL" mark using proper dipstick side depending on fluid temperature, use "DEXRON IIE or DEXRON III" automatic transmission fluid.
5. Reinsert and tighten the dipstick.

Fan gearbox oil level

The radiator fan is belt driven from the engine crankshaft pulley through a standard gearbox which is designed with two output shafts (for location of gearbox, see page 2-37). To check fluid level, proceed as follows:

1. Stop engine and make sure that all engine safety precautions have been observed.

2. Remove the dipstick located on top of gearbox and wipe with a clean rag.
3. Insert dipstick in gearbox case, then remove again to check fluid level.
4. Adjust level to \diamond Full \diamond mark using Mobil SHC 634 synthetic oil.
5. Reinsert the dipstick.



FIGURE 105: Fan gearbox

05008

A/C compressor

The level is acceptable when oil is visible in the sight glass on R.H. side of compressor. For an accurate reading, release tension on belts, then level compressor. The oil level should be in center of sight glass. (see A/C compressor location on page 2-37). To check oil level on compressor used on the optional auxiliary A/C system, refer to the maintenance manual.

Wheel bearing oil level

The oil level for the front and tag axle wheel bearings must be maintained to the level mark in the cap. The level is determined by a line, indicated by arrows, which is incorporated to the plastic lens and passes underneath the words "OIL LEVEL". To check oil level after vehicle has been driven, wait at least 15 minutes to ensure that oil has settled. Drive axle wheel bearings are lubricated by the differential oil. Maintain differential oil level to ensure adequate lubrication of drive axle wheel bearings at all times.




FIGURE 106

13003A

CAUTION: Wheel bearing oil fill cap is supplied with a very small vent hole in its center. Occasionally insert a small tip (toothpick size) to be sure that hole is not plugged; a plugged hole may cause leakage when heat expands the oil and air.

NOTE: On vehicles equipped with grease-lubricated wheel bearings, pack with wheel bearing grease.

AIR TANKS

The air coming from the air dryer is first forwarded to the wet air tank, then to the primary, supplementary primary, secondary and accessory air tanks. Two additional air tanks may have been installed on the vehicle: the kneeling air tank and emergency/parking brake overrule air tank.

The accessory air tank must be purged during pre-starting inspection. A good practice is to purge this reservoir at the end of every working day by using the remote accessory air tank drain valve located in steering compartment underneath accessory air filter.




FIGURE 107

12012

Furthermore, purge all tanks using their bottom drain valve each time the oil and filters are changed (maximum 12,500 miles 20,000 km)).

For tank locations, refer to figure in "Lubrication and servicing schedule" further in this section.

COOLANT LEVEL VERIFICATION

The cooling system is completely filled when the coolant (cold) is visible in the sight glass of the surge tank (see page 2-37 for location). If topping-up is necessary, fill the system with the same mixture ratio already used in the system.

WARNING: Hot engine coolant is under pressure. Never remove cap when coolant is hot as severe burns can result. Allow engine to cool before checking coolant level.

WATER SEPARATOR (Optional)

A fuel filter/water separator may be installed in engine's primary fuel filter location, in engine compartment, to prevent water infiltration in engine fuel system. It should be drained periodically, or when the water separator indicator lamp lights in dashboard. To drain, loosen self venting drain below separator, and tighten after water has been flushed out.




FIGURE 110

03004

CARE & MAINTENANCE

BELT TENSIONERS

Belt tensioning is applied through air bellows which are adjusted by an air pressure regulating valve mounted in engine compartment above the doors. For proper operation of the air bellows, adjust the upper tensioning bracket to provide a $2\frac{3}{8}$ " - $2\frac{1}{2}$ " (60 - 64 mm) extension with the pneumatic system under normal pressure and the pressure regulating valve set at 50 psi (345 kPa) for Series 60 engines and at 70 psi (482 kPa) for Series 50 engines.




FIGURE 111

12017A

For belt replacement, air pressure must be released from bellows by means of the belt tensioner pressure releasing valve. This valve (see page 2-37 for location) mounted above the engine doors close to the pressure regulating valve, is manually operated. Before handling, be sure that all engine safety precautions have been observed.




FIGURE 112

12110

A/C AND HEATING AIR FILTERS

For maximum air conditioning and heating system efficiency, air filters should be inspected and cleaned as required in maintenance schedule to ensure proper ventilation of the evaporator and heating radiator cores.

Driver's system

Air filter for driver's system is located under dashboard. To gain access, turn counter-clockwise both $\frac{3}{4}$ turn knurled fasteners of A/C and heating unit access panel, then lift and remove panel.





FIGURE 113

22011

Central system

The central system uses two (2) air filters, they are located in the A/C and heating compartment. To gain access, open driver's side baggage compartment, forward of A/C and heating compartment, and open the air filter access panel by unscrewing the three (3) retaining screws. Slide out the upper filter first, then slide out the other.



FLEXIBLE HOSE MAINTENANCE

The performance of engine and related equipment is greatly affected by the flexible hoses' ability to carry fluids or gases. Maintenance of hoses is an important element in ensuring efficient, economical, and safe operation of your vehicle.

Pre-starting inspection

Inspect hoses for leaks, and check all fittings, clamps, and ties carefully. Ensure that hoses are not resting on or touching shafts, couplings, heated surfaces including exhaust manifolds, any sharp edges, or other obviously damaging areas. Since all machinery vibrates and moves to a certain extent, clamps and ties can fatigue with time. To ensure proper support, inspect fasteners frequently and tighten or replace them as necessary.

Leaks

Investigate leaks immediately to determine if fittings have loosened or cracked, and also if hoses have ruptured or worn through. Take corrective action immediately. Leaks are not only potentially detrimental to machine operation, but can also result in added expenses caused by the need to replace lost fluids.

WARNING: *Personal injury and/or property damage may result from fire due to the leakage of flammable fluids, such as fuel or lubricating oil.*

Service life

A hose has a limited service life which is controlled by many factors. With this in mind, it is recommended that all hoses be thoroughly inspected annually. Look for surface damage or indications of twisted, worn, crimped, brittle, cracked, or leaking lines. Hoses having the outer surface worn through or a damaged metal reinforcement should be considered unfit for further service.

It is also recommended that all hoses in this vehicle be replaced during major overhaul and/or after a maximum of five service years.

Replacement hoses and hardware should always be at least equal in quality to that of the O.E.M.

LUBRICATION

A lubrication chart is provided in this section to give locations of key service points on the vehicle. Cleaning, removal or disassembly procedures (required for lubrication purposes) are covered in the applicable sections of this manual.

Lubrication intervals are based on recommendations for normal operating conditions. Where more severe service is encountered, more frequent attention will be required.

FIRE EXTINGUISHERS

In order for fire extinguishers to operate adequately in emergency situations, we strongly recommend that all units be inspected on a monthly basis.

- Check that pressure is adequate and recharge if required.
- Check that seal on handle is intact.
- Check that hose or nozzle is not restricted.
- Keep fire extinguishers clean.
- Note inspection date

110-120 VOLT IN-STATION LIGHTING

An optional exterior connection allows the use of a 110-120 volt lighting system when coach is being serviced or cleaned.

The receptacle for in-station lighting is located L.H. front side of coach between steering compartment door and front axle. A power cable connected at this point will turn on the interior fluorescent lights. It's circuit breaker, located in steering compartment, beneath driver's floor must be reset manually if tripped.

110-120 VOLT IN-STATION CONNECTORS

CARE & MAINTENANCE

The 110-120 volt power connector can be accessed through the engine oil reserve tank service door (see pages 2-34/35 for location). Connect the female extension cord plug to the vehicle's male connector and the other end of the extension cord to a 110-120 VAC outlet only.

Use the heaters whenever the coach is parked for an extended period of time in cold weather and a suitable power source is available.

Both the engine block heater and the water tank heater will automatically be activated when plugged in to an external power source.

CAUTION: Use only a 110-120 VAC power source and only a grounded type (three pronged) extension cord with a minimum rated current capacity of 15 amps. Disconnect the cord before starting engine.

BACK-UP CAMERA

A back-up camera with TV monitor can be installed as an option. When the transmission is placed in (R) reverse range, the camera and TV monitor are automatically switched on. They will switch off when the vehicle is taken out of (R) reverse range.

To clean the camera's protective glass, spray with soapy water and wipe with a clean damp rag or wiper blade.

WARNING: To avoid injury, do not clean camera with transmission in (R) reverse range. Shut-off engine and apply parking brake before cleaning.

CAUTION: To prevent scratches to the camera's protective glass, do not wipe with a dry rag; use a clean damp one.

FILTER RESTRICTION INDICATOR

An optional filter restriction indicator is used to monitor the vacuum level between the air filter and engine. A "red flag" is displayed when the air filter is clogged.

The indicator is located on the engine air intake near the turbocharger. When the "red flag" is

displayed, the air filter must be replaced. Press down on indicator to reset flag.




FIGURE 115

04002

LAVATORY MAINTENANCE

Routine draining and filling of lavatory tanks should be performed by maintenance personnel only. If no appropriate power source (110-120 VAC) is available to connect the optional tank heating element (see page 2-34/35 for heater plug location), and if engine or heating failure occurs in extreme weather conditions, emergency draining of water tanks should be performed under the most suitable conditions and should at all times be supervised by driver.

Fresh water reservoir draining

The fresh water reservoir can be drained by simply opening the fresh water drain cock. Don't forget to close cock when draining is done.

CAUTION: If fresh water tank heater is inoperative or not installed on your vehicle, water should be drained from reservoir under cold weather conditions since it might freeze and damage both reservoir and connecting links.

NOTE: If your vehicle is supplied with a 110-120 volt fresh water tank heater, see "110-120VOLT IN-STATION CONNECTORS" on page 6-9.

Fresh water reservoir filling

Plug the fresh water supply hose to the fresh water tank fill connection; fill the reservoir until the overflow tube leaks, signaling that reservoir is full.

WARNING: Never put antifreeze in fresh water reservoir; antifreeze is toxic.

WARNING: If reservoir has not been drained for an extended period of time, draining and filling operations must be repeated three (3) times in order to clean reservoir and eliminate contaminated water.




FIGURE 116

23025

- 1..... Main sump tank overflow cock
- 2..... Fresh water tank fill connection
- 3..... Toilet sump tank fill connection
- 4..... Main sump tank drain valve
- 5..... Fresh water tank drain cock
- 6..... Auxiliary sump tank drain valve
- 7..... Fresh water tank vent and overflow indicator
- 8..... Main sump tank clear overflow tube

Main sump tank draining

To drain sump tank, simply pull main sump tank drain valve until draining is done.

Main sump tank filling

Open the main sump tank overflow cock and connect a water supply hose to the toilet sump tank fill connection. The main tank is full when water starts flowing into the auxiliary tank through the main sump tank clear overflow tube. Close main sump tank overflow cock.

CAUTION: In cold weather, add 2 gallons (9 liters) of antifreeze (e.g.: ethylene glycol) in the toilet before filling main tank.

Auxiliary sump tank draining

First, remove drain cap located under auxiliary sump tank then pull auxiliary sump tank drain valve lever up. To close, push valve lever completely down to its locking position. Reinstall drain cap.

NOTE: It is unlawful to dump sump tank contents in any location other than those designated as such.

Cleaning cabinet

The access door, located at rear of coach on R.H. side can ease cleaning of lavatory. Use this door to introduce electrical cords, vacuum cleaner hoses etc..




FIGURE 117

23026

CARE & MAINTENANCE

When recirculating water in the toilet is soiled, drain main sump tank into the optional auxiliary tank and perform the filling procedure of the main tank.

When a full draining is required, clean main tank by repeating the draining and filling operations while leaving the auxiliary sump tank drain valve opened. Close valves and pour a pack of commercial toilet deodorant (Prévost part #900329) in toilet before adding the antifreeze and starting final filling of main tank.

WARNING: The toilet deodorant contains products that can be very irritating to skin. Use rubber gloves when handling and then clean toilet seat.

WARNING: Antifreeze must comply with the effective environmental act.

CAUTION: When cold weather is expected and there is no antifreeze in the tank, both sump tanks must be drained.

NOTE: If there is no antifreeze solution in the tank, there is less risk of freezing if engine is operating due to the heat it produces.

New vehicles do not have an antifreeze solution in the sump tanks at time of delivery.

FIRST SERVICE ON NEW VEHICLE

Differential oil

Factory-filled oil in differential on new vehicle should be drained and refilled between 1,000 miles (1 600 km) and 3,000 miles (4 800 km) of initial operation, then according to the lubrication and servicing schedule.

Coolant filter

The coolant filter is designed to recover the soldering residues trapped inside coolant lines during their initial assembly; perform initial element changing once vehicle has run approximately 3,000 miles (4 800 km), then according to the lubrication and servicing schedule. The coolant filter is mounted in A/C & Heating Compartment.

NOTE: If additional soldering has been performed on any points of coolant piping, replace coolant filter element as outlined on new vehicle (3,000 miles (4 800 km)).




FIGURE 119: A/C & Heating Compartment

05021A

Automatic transmission oil filter

Change cartridge after first 3,000 miles (4 800 km), then after each 25,000 miles (40 000 km) as specified in the lubrication and servicing schedule. Check the oil frequently (with engine stopped); if necessary, add sufficient oil to raise level to the proper mark on dipstick.

Manual transmission

We recommend an initial oil change and flush after the transmission is placed in actual service. This change should be made any time following 3000 miles (4800 km), but *never exceeding 5000 miles (8000 km)*.

Engine oil

There is no special break-in period since engine break-in has been done in factory; Therefore oil should be changed according to the lubrication and servicing schedule intervals. Check the oil at every fuel filling. If necessary, add sufficient oil to raise the level to the proper mark on dipstick.

LUBRICATION AND SERVICING SCHEDULE




FIGURE 120

24001D

BEFORE OPERATING VEHICLE, PERFORM EACH POINT LISTED IN "STARTING AND STOPPING PROCEDURES" SECTION UNDER HEADING "DAILY INSPECTION..." (PAGE 4-8).

NOTE: Perform the "FIRST SERVICE ON NEW VEHICLE" as outlined on page 6-12.

DAILY WALK-AROUND INSPECTION

It is a good practice to make a basic visual inspection of key areas on the vehicle on a daily basis and to report any problem areas to maintenance personnel for immediate correction.

A) Outside the vehicle

ITEM*	DESCRIPTION
---	Check for leaks under vehicle and in engine compartment
---	Check that baggage and service compartment doors close properly
---	Inspect tires and wheels for correct tire pressure, wear or damage, and for missing wheel stud and nuts
1	Check windshield washer fluid level and add if necessary
---	Check condition of windshield wiper blades
---	Verify proper operation of all road lights, signal lights, brake lights, marker lights, and back-up lights; Replace light bulbs as required
2	Purge accessory air filter and accessory air tank
5	Check front and tag axle wheel bearing oil level

B) Engine compartment

ITEM*	DESCRIPTION
21	Check engine crankcase oil level; Add if necessary
17	Check automatic transmission oil level (level can be checked from pushbutton shift selector); Add if necessary
20 & 23	Check air cleaner restriction indicator, replace air cleaner when red flag locks in full view
24	Check power steering reservoir fluid level; Add if necessary
19	Check coolant surge tank fluid level; Add if necessary
25	Drain accumulated water in primary fuel filter/water separator (if equipped)

* Item numbers refer to figure on page 6-13

C) Inside the vehicle

ITEM	DESCRIPTION
---	Check for proper operation of the entrance door
---	Inspect cleanliness in the steps, aisles, seating area and lavatory
---	Check that emergency exit windows and roof escape hatches can be opened, then close all windows and hatches securely
---	Verify proper operation of windshield wiper/washer
---	Check rear view mirrors for broken glass; Adjust mirrors for adequate rear view vision
---	Start engine and check for proper operation of all gauges and indicator lights
---	Apply brakes and check both primary and secondary pressure gauges
---	Check for proper operation of horns, and back-up alarm

PERIODIC LUBRICATION AND SERVICING SCHEDULE

A) Service every 6,250 miles (10 000 km) or twice a year, whichever comes first.

ITEM*	DESCRIPTION	REMARKS	LUBRICANT &/OR PART**
23	Engine Air Cleaner	Inspect and clean, replace element if required	Filter: #53-0197
22	A/C Compressor	Check oil level, add if necessary	Polyolester oil
34	A/C Receiver Tank	Check refrigerant level, add if necessary	HFC 134a
35	Refrigerant Moisture Indicator	Replace filter dryer unit according to moisture indicator	Filter: #95-0231 (XL-40) #95-0262 (XL-45)
32	Differential	Check oil level, add if necessary	Varies upon operating areas. See Lubricant Specification Chart
18	Radiator Fan Drive Gearbox	Check oil level, add if necessary	Synthetic oil Mobil SHC 634
31	Propeller Shaft	Grease one fitting on each universal joint and one fitting on slip joint	Multi purpose grease
13	Tag Axle Lever Pivot	Grease one fitting on each pivot	Multi purpose grease
12	Brake Slack Adjuster	Grease one fitting on each slack adjuster (all axles)	Rockwell 0-616-A, Grade 1
7	Steering Damper Cylinder	Grease one fitting at cylinder rod end	Multi purpose grease
36	Steering Tie Rod	Grease one fitting at each end	Multi purpose grease
4	Disc Brake Calipers	Grease two fittings on each of front and tag axles.	Rockwell 0-616-A, Grade 1
3	Steering Drag Link	Grease one fitting at each end	Multi purpose grease
14☐	Manual Transmission	Check oil level, add if necessary	Engine oil: SAE 30, 40, 50 or gear oil: SAE 80, 90
30☐	Lever Ball	Grease one fitting	Multi purpose grease
28☐	Clutch Cross Control Shaft	Grease three fittings	Multi purpose grease
27☐	Clutch Release Bearing	Grease one fitting	Multi purpose grease

* Item numbers refer to figure on page 6-13

** See end of this section for lubricant and part number specifications.

☐ With manual transmission only.

B) Service every 12,500 miles (20 000 km) or once a year, whichever comes first.

ITEM*	DESCRIPTION	REMARKS	LUBRICANT &/OR PART**
15	Engine	Change oil and filters	Motor oil: SAE 15W40, API CF-4 Filters: #51-0458
25	Fuel Filters	Change primary and secondary fuel filters (Fill with clean fuel before installation)	Primary: #51-0137 Prim. w/sep.: #53-1390 Secondary: #51-0128
16	Coolant Filter/Conditioner	See ◇ F) Miscellaneous Service ◇	-----
39▣	Clutch Master Cylinder	Check oil level	Brake fluid (DOT 3)
6	Air Tanks	Drain accumulated water in all tanks	-----
9	A/C and Heating Air Filters	Clean or replace elements	Driver's air filter: # 87-1049 Central air filter: # 87-1069

C) Service every 25,000 miles (40 000 km) or once a year, whichever comes first.

ITEM*	DESCRIPTION	REMARKS	LUBRICANT &/OR PART**
38▣	Clutch Pedal	Check and adjust if necessary	-----
37▣	Shift Control Rod Universal Joints	Grease four fittings	Low Temperature grease
14	Automatic Transmission	Change oil and filters	Dexron-II or Dexron-III

* Item numbers refer to figure on page 6-13

** See end of this section for lubricant and part number specifications.

▣ With manual transmission only.

D) Service every 50,000 miles (80 000 km) or once a year, whichever comes first.

ITEM*	DESCRIPTION	REMARKS	LUBRICANT &/OR PART**
24	Power Steering Reservoir	Replace oil filter cartridge element	Cartridge: #66-0987
10	Coolant Strainer	Replace element	Element # 87-1029
19	Coolant Surge Tank	Test coolant solution	-----
8	Steering Knuckle Pins	Grease two fittings on each knuckle	Multi purpose grease
14▣	Manual Transmission	Change oil	Engine oil: SAE 30, 40, 50 or gear oil: SAE 80, 90
29▣	Shift Lever Pivot	Dismantle and lubricate all components	Low Temperature grease
18	Radiator Fan Drive Gearbox	Change oil	Synthetic oil Mobil SHC 634
---	Flexible hoses	Thoroughly inspect all hoses	-----

E) Service every 100,000 miles (160 000 km) or once every two years, whichever comes first.

ITEM*	DESCRIPTION	REMARKS	LUBRICANT &/OR PART**
2	Accessory Air Filter	Change filter element	Element # 64-1340
33	Air Dryer	Change cartridge	Cartridge # 64-1244
39▣	Clutch Master Cylinder	Drain oil and refill	Brake fluid (DOT 3)
32	Differential	Change oil, clean breathers	Varies upon operating areas. See Lubricant Specification Chart
11	Brake Camshaft	Grease one fitting on each drive axle drum brake	Multi purpose grease

* Item numbers refer to figure on page 6-13

** See end of this section for lubricant and part number specifications.

▣ With manual transmission only.

F) Miscellaneous Service

ITEM*	DESCRIPTION	REMARKS	LUBRICANT &/OR PART
26	Battery Terminals	Clean and coat terminals yearly	Battery terminal coating
19	Cooling System	Drain, flush and refill every two years or 200,000 miles (320 000 km)	Engine coolant
---	Discharge Tubes (rubber tubes located under vehicle)	Every three months: Check 4 condenser's discharge tubes Check 6 evaporator's discharge tubes Check 2 front discharge tubes	-----
16	Coolant Filter/Conditioner	Replace Precharge Element Filter with a Maintenance Element Filter after 12,500 miles (20 000 km) or after one year, whichever comes first. Then, install a new Maintenance Element Filter and replace every 200,000 miles (320 000 km) or two years, whichever comes first. Note: A Precharge Element Filter must be installed each time the cooling system is drained and flushed prior to installing a Maintenance Element filter.	Maintenance Filter: #550630 Precharge Filter: #550629

* Item numbers refer to figure on page 6-13.

Lubricant Specifications

ITEM*	DESCRIPTION	SPECIFICATIONS
21	Engine Oil	SAE Viscosity Grade: 15W40 API Classification: CF-4
24	Power Steering Oil	Automatic Transmission Oil (Dexron-II or Dexron-III)
19	Engine Coolant	Low silicate, ethylene glycol coolant 50% antifreeze/water solution is normally used. Antifreeze concentration should be between 30% and 67%.
22	A/C Compressor Oil	Polyolester Oil, HFC 134A compatible Castrol SW-68 (POE) or equivalent
32	Differential Oil	Multigrade gear oil meeting MIL-L-2105-D: 85W140 is recommended. If temperature drops below 10°F (-12°C), 80W90 should be used, and below -15°F (-26°C), 75W90 should be used. In extreme conditions or for better performance, full synthetic gear oil can be used.
18	Fan Gearbox Oil	Synthetic oil Mobil SHC 634 or equivalent
17	Automatic Transmission Oil	Dexron-II or Dexron-III
	Manual Transmission Oil	Heavy duty engine oil meeting MIL-2104-C: SAE 30 (Northern climate), SAE 40, SAE 50 Straight mineral gear oil: SAE 80 (Northern climate), SAE 90

Lubricant Specifications (Cont'd)

ITEM*	DESCRIPTION	SPECIFICATIONS
39	Clutch Master cylinder Oil	Heavy duty brake fluid meeting DOT 3 specifications
	Low Temperature Grease	Good quality low temperature grease; Prolab AF-100 grade 1, or equivalent
---	Multi Purpose Grease	Good quality lithium-base grease: NLGI No.2 Grade is suitable for most temperatures NLGI No.1 Grade is suitable for extremely low temperatures

* Item numbers refer to figure on page 6-13.

Part Number Specifications

ITEM*	DESCRIPTION	PREVOST NO	SUPPLIER NO
15	Engine Oil Filters	#51-0458	Detroit Diesel: 25014505 AC Rochester Div. GM: PF2100
24	Power Steering Reservoir Oil Filter	#66-0987	Nelson #83804 E
23	Engine Air Cleaner Filter	#53-0197	Nelson: 70337-N Baldwin: PA-2839 Donaldson: P52-2874 Fram: CA-7113
35	Refrigerant Filter Dryer Unit	#95-0231 (XL-40) #95-0262 (XL-45)	Alco controls: EKH 307S (modified) Henry #815031 - XH9
25	Engine Primary Fuel Filter	#51-0137	Detroit Diesel: 23518481 AC Rochester Div. GM: TP-915D
25	Engine Primary Fuel Filter with Water Separator (optional)	#53-1390	Racor # S 3202
25	Engine Secondary Fuel Filter	#51-0128	Detroit Diesel: 23518482 AC Rochester Div. GM: TP-916D
16	Engine Coolant Filter/Conditioner	#55-0630	Detroit Diesel: 23507545 Nalco Chemical Company: DDF3000
9	A/C and Heating, Driver's Air Filter	#87-1049	Permatron Corp.: Model "R"
9	A/C and Heating, Central Air Filter	#87-1069	Permatron Corp.: IN 1x10x37 EXACT
14	Automatic Transmission Oil Filter Kit	#57-1687	Allison: 29503829
10	Coolant Strainer	#87-1029	Parker # 925566
2	Accessory Air Filter	#64-1340	Pneumac #4338-04
33	Air Dryer Cartridge	#64-1244	Allied Signal #107796

* Item numbers refer to figure on page 6-13.

TABLE OF CONTENTS

Safety precautions.....	3 - 7
Defensive driving.....	3 - 8

**STARTING AND STOPPING
PROCEDURES 4 - 1**

General information.....	4 - 1
Detroit Diesel Electronic Control (DDEC).....	4 - 2
World Transmission WT Electronic Control System.....	4 - 3
Manual transmission	4 - 7
Cold weather starting	4 - 7
Daily inspection	4 - 8
Recommendations	4 - 9
Heating and air conditioning	4 - 10
Preheating systems.....	4 - 13
Windshield washer reservoir.....	4 - 14
Jump starting	4 - 15
Electric circuit protection	4 - 16
Tires	4 - 18
Jacking points.....	4 - 20
Towing	4 - 20
Retractable tag axle	4 - 21
Tag axle unloaded.....	4 - 21

TECHNICAL INFORMATION 5 - 1

Dimensions.....	5 - 1
Weights.....	5 - 2
Capacities	5 - 2
Fuel type	5 - 2
Wheels and tires.....	5 - 2
Belts	5 - 3
Engines.....	5 - 3
Transmissions	5 - 3
Drive axle ratio.....	5 - 3
Brakes.....	5 - 4
Antilock braking system (ABS)	5 - 4
Steering	5 - 4
Electrical system.....	5 - 4

Sound system	5 - 5
Video system.....	5 - 5
Suspension	5 - 5
Alignment	5 - 5
Heating and air conditioning	5 - 5
Oil specifications	5 - 6
Preheating systems	5 - 7
Storage volume.....	5 - 7
Seats	5 - 7
Data plate and certification	5 - 7
Light bulb data.....	5 - 10
DDEC III diagnostic codes.....	5 - 12
World transmission WT diagnostic codes.....	5 - 14

CARE AND MAINTENANCE 6 - 1

Interior cleaning.....	6 - 1
Exterior cleaning	6 - 3
Oil verification.....	6 - 4
Air tanks	6 - 7
Coolant level verification.....	6 - 7
Water separator	6 - 7
Belt tensioners	6 - 8
A/C and heating air filters	6 - 8
Flexible hose maintenance.....	6 - 9
Lubrication.....	6 - 9
Fire extinguishers.....	6 - 9
110-120 volt in-station lighting.....	6 - 9
110-120 volt in-station connectors	6 - 9
Back-up camera.....	6 - 10
Filter restriction indicator.....	6 - 10
Lavatory maintenance	6 - 10
First service on new vehicle	6 - 12
Lubrication and servicing schedule	6 - 13

SERVICE LITERATURE 7 - 1

SERVICE LITERATURE

Additional copies of the following Service Literature are available upon request and at low cost.

- **Maintenance Manual**

- **Operator's Manual**

- **Parts Manual**

To order the desired Manual(s), please contact your local distributor or write to:

PRÉVOST CAR INC.

ATTN.: TECHNICAL PUBLICATIONS DEPARTMENT

35 Boulevard Gagnon

Sainte-Claire, Québec

Canada, G0R 2V0

Fax no.: (418) 883 - 4157

Specify your vehicle's complete serial number. Allow 30 days for delivery.

A

ABS brake.....3 - 2, 5 - 4
Accelerator pedal2 - 28
Accessories2 - 41
Adjustable louver.....2 - 4, 2 - 16, 2 - 43
Air conditioning2-16, 4-11
Air filters, A/C & heating6 - 8
Air horn2 - 27, 3 - 5
Air system emergency fill valves.....3 - 2
Air tanks.....6 - 7
Alarm, back up.....3 - 3
Alarm system.....3 - 6
Alignment.....5 - 5
Antilock braking system3 - 2, 5 - 4
Audio/Video control unit2 - 16
Auxiliary sump tank draining.....6 - 11

B

Back-up alarm3 - 3
Back-up camera / TV monitor2 - 41, 6 - 10
Baggage compartment door locks.....2 - 4
Battery disconnect switch, main2 - 2
Battery equalizers.....4 - 17
Belts, engine.....5 - 3
Belt tensioners.....6 - 8
Blinds2 - 42
Block heater, engine.....4 - 7, 6 - 9
Brakes
 Anti-lock (ABS).....3 - 2, 5 - 4
 Emergency2 - 28, 3 - 1
 Engine (Jacob's)2 - 4, 4 - 3
 Parking2 - 23, 3 - 1
 Parking brake override2 - 23
 Service2 - 28, 3 - 1
Breakers, main4 - 16
Bulb chart.....5 - 10

C

Camera, maintenance6 - 10
Capacities, refill.....5 - 2
Card tables.....2 - 44
Care and maintenance6 - 1
Central A/C and heating controls4 - 11
Changing wheels4 - 18
Check engine light2 - 12
Chime, stop/service power switch.....2 - 4, 2 - 44
Cleaning, exterior6 - 3
Cleaning, interior.....6 - 1
Clutch pedal2 - 28
Coach final record.....5 - 8
Cold starting aid (Ether)2 - 15, 4 - 7
Compartments, exterior
 A/C & heating2 - 39
 Baggage2 - 38
 Battery (XL-40)2 - 40
 Condenser2 - 39
 Engine.....2 - 37
 Entrance door2 - 36
 Fuel tank filling door2 - 36
 L.H. side service (XL-45)2 - 39
 Main power (XL-45).....2 - 39
 Service doors2 - 39
 Spare wheel and tire4 - 18
 XL-40 (details)2 - 34
 XL-45 (details)2 - 35
Compartments, interior
 Lavatory2 - 40
 Parcel racks.....2 - 41
 Safety equipment compartment.....2 - 41
Controls and instrument panels.....2 - 3
Coolant level verification.....6 - 7
Cruise control switches.....2 - 5

D

Daily inspection	4 - 8
Dashboard	2 - 7
Data plate & certification	5 - 7
Day time running lights.....	3 - 5
Defensive driving.....	3 - 8
Destination sign.....	2 - 42
Detroit diesel electronic control (DDEC).....	4 - 2
Diagnostic codes	
World transmission (WT).....	5 - 17
Detroit Diesel Electronic Control	5 - 12
Differential oil	5 - 6
Dimensions, vehicle	5 - 1
Dome lights.....	2 - 5
DO NOT SHIFT light	2 - 11, 4 - 5
Door, entrance.....	2 - 28
Door override.....	2 - 23, 3 - 4
DOT certification label.....	5 - 9
Drive axle ratio.....	5 - 3
Driver's A/C - heating system ctrls.....	2 - 16, 4 - 12
Driver's fan.....	2 - 42
Driver's light switch.....	2 - 4
Driver's seat.....	2 - 29
Driver's window	2 - 41

E

Electrical system.....	5 - 4
Electric circuit protection	4 - 16
Electric horns.....	2 - 27, 3 - 5
Emergency	
Exits.....	3 - 4
warning reflectors	3 - 6
Engine	
Block heater	4 - 7
Compartment components.....	2 - 37
DDEC	4 - 2
DDEC III diagnostic codes	5 - 12

Retarder (Jacob's).....	2 - 4, 4 - 3
Starting (from driver's compt.).....	4 - 1
Starting (from engine compt.)	4 - 1
Stop override	2 - 15
Warm-up.....	4 - 8
EPA engine labels.....	5 - 9
Ether, cold starting aid	2 - 15, 4 - 7
Exits, emergency	
Entrance door.....	3 - 4
Roof escape	3 - 4
Side windows	3 - 4
Exterior cleaning	6 - 3
Exterior mirror heating switch	2 - 4
Extinguishers, fire	3 - 6, 6 - 9

F

Filter restriction indicator.....	6 - 10
Fire extinguishers.....	3 - 6, 6 - 9
Fire hatchet	3 - 7
First aid kit	3 - 6
First service on new vehicle	6 - 12
Flexible hose maintenance.....	6 - 9
Fluorescent lighting.....	2 - 5
Fog lights	2 - 15, 3 - 5
Foot-operated controls.....	2 - 27
Fresh water reservoir draining.....	6 - 10
Fresh water reservoir filling	6 - 11
Fuel tank filling	2 - 2
Fuel type.....	5 - 2
Fuses.....	4 - 17

G

Galley	2 - 44
Gauges.....	2 - 7
General information	4 - 1

H

Hatchet, fire	3 - 7
Hazard flashers	2 - 15
Heating and air conditioning	
Central.....	2 - 16, 4 - 11
Driver's	2 - 16, 4 - 12
Ventilation	4 - 10
Heating and air conditioning (tech. info.)	5 - 5
Horns, air	2 - 27, 3 - 5
Horns, electric.....	2 - 27, 3 - 5
Hi-buoy / kneeling control switch	2 - 5
Hi-buoy system.....	3 - 3
Hubodometer.....	2 - 44

I

Identification plates.....	5 - 7
Indicator lights, dashboard	2 - 7
Ignition switch	2 - 14
In-station connectors (110 - 120 volt)	6 - 9
In-station lighting (110 - 120 volt).....	6 - 9
Interphone.....	2 - 19
Interior cleaning.....	6 - 1

J

Jacking points.....	4 - 20
Jack/tools.....	3 - 6
Jacob's engine brake	2 - 4, 4 - 3
Jump starting	4 - 15

K

Keys	2 - 1
Kneeling / hi-buoy control switch	2 - 5
Kneeling system	3 - 3

L

Lavatory.....	2 - 40
Lavatory maintenance	6 - 10
Lever, multifunction.....	2 - 26
Lever, transmission retarder.....	2 - 27
L.H. lower switch panel.....	2 - 14
L.H. outside mirror control	2 - 5
L.H. side control panel	2 - 4
Light bulb data.....	5 - 10
Lighting, exterior.....	2 - 15
Lighting, fluorescent.....	2 - 5
Light switch, driver's.....	2 - 4
Lights	
Day time running	3 - 5
Fog.....	3 - 5
Literature, service	7 - 1
Louver, adjustable.....	2 - 4, 2 - 16, 2 - 43
Low-buoy system	2 - 23, 3 - 3
Lubricant specifications	6 - 19
Lubrication.....	6 - 9
Lubrication and servicing schedule	6 - 13

M

Main battery disconnect switch	2 - 2
Main breakers	4 - 16
Main power compartment (XL-45).....	2 - 39
Main sump tank draining	6 - 11
Main sump tank filling	6 - 11
Manual transmission.....	2 - 25
Microphone jacks	2 - 5, 2 - 18
Mirrors	
Exterior mirrors	2 - 32
Heating switch	2 - 4
Interior mirror	2 - 32
L.H. outside mirror control.....	2 - 5
R.H. outside mirror control	2 - 5

Mud flaps and splash guards 2 - 43
 Multifunction lever..... 2 - 26

N

New vehicle, first service on 6 - 12

O

Oil capacities 5 - 2
 Oil specification 5 - 6
 Oil level verification
 A/C compressor 6 - 6
 Clutch pedal master cylinder 6 - 5
 Engine 6 - 4
 Fan gearbox..... 6 - 6
 Power steering 6 - 6
 Transmission (automatic) 6 - 4
 Transmission (manual)..... 6 - 5
 Wheel bearing..... 6 - 6
 Output retarder, transmission 2 - 4, 4 - 4
 Override, door..... 2 - 23, 3 - 4

P

Public address system (P. A.)..... 2 - 18
 Parcel racks 2 - 41
 Parking brake 2 - 23, 3 - 1
 Parking brake override 2 - 23
 Part number specifications 6 - 20
 Parts kit, spare..... 2 - 45
 Passenger seats..... 2 - 31
 Preheating systems
 Espar 2 - 23, 2 - 46, 4 - 13
 Webasto..... 2 - 23, 2 - 47, 4 - 14
 Prodriver™ - Engine data
 display and computer 2 - 20

Q

"Quick Lounge" system..... 2 - 44

R

Radio AM/FM 2 - 16
 Reading lamps 2 - 5
 Recommendations..... 4 - 9
 Reflectors, emergency warning..... 3 - 6
 Retractable or unloaded tag axle 2 - 23, 4 - 21
 R.H. console..... 2 - 15
 R.H. lateral console..... 2 - 22
 R.H. lower switch panel 2 - 15

S

Safety
 Attestation..... 5 - 9
 Equipment 3 - 6
 Precautions..... 3 - 7
 Seat
 Driver 2 - 29
 Passenger 2 - 31
 Tour guide 2 - 32
 Serial number, vehicle 5 - 8
 Service literature 7 - 1
 Service on new vehicle (first)..... 6 - 12
 Servicing and lubrication schedule..... 6 - 13
 Sound system 5 - 5
 Spare parts..... 2 - 45
 Speed control (cruise)..... 2 - 5
 Splash guards and mud flaps..... 2 - 43
 Starting engine from driver's compt..... 4 - 1

Starting engine from engine compt. 4 - 1
Steering wheel and telescopic column 2 - 28
Stereo receiver, AM/FM 2 - 16

Stop/service chime power switch..... 2 - 4, 2 - 44
Stop/service/reading lamp 2 - 5, 2 - 44
Storage volume 5 - 7
Suspension 5 - 5

Switches

Auxiliary A/C 2 - 15
Baggage door lock..... 2 - 4
Cruise control..... 2 - 5
Dome lights 2 - 5
Ether cold starting aid 2 - 15
Exterior lighting switch 2 - 15
Fast idle..... 2 - 14
Fluorescent lighting..... 2 - 5
Fog lights..... 2 - 15
Galley power 2 - 44
Hazard flashers..... 2 - 15
Ignition 2 - 14
Kneeling/hi-buoy 2 - 5
L.H. outside mirror control 2 - 5
Light, driver's..... 2 - 4
Mirror heating 2 - 4
Reading lamps 2 - 5
Retarder, engine 2 - 4
Retarder, transmission 2 - 4
R.H. outside mirror control..... 2 - 5
"Stop Engine" override 2 - 15
Stop/service chime 2 - 4
Transmission pushbutton 2 - 23
Video power 2 - 17

T

Tachograph 2 - 13
Tachometer 2 - 13
Tag axle, unloaded or retractable 2 - 23

Technical information

Alignment..... 5 - 5
Belts 5 - 3
Brakes..... 5 - 4
Brakes (ABS)..... 5 - 4
Capacities..... 5 - 2
Coach final record 5 - 8
Data plate certification 5 - 7
DDEC III diagnostic codes 5 - 12
Dimensions..... 5 - 1
DOT certification label 5 - 9
Drive axle ratio..... 5 - 3
Electrical system 5 - 4
Engines 5 - 3
EPA engine label..... 5 - 9
Fuel type 5 - 2
Heating and air conditioning 5 - 5
Light bulb data 5 - 10
Oil specifications 5 - 6
Preheating systems..... 5 - 7
Safety attestation..... 5 - 9
Seats..... 5 - 7
Sound system..... 5 - 5
Steering 5 - 4
Storage volume 5 - 7
Suspension..... 5 - 5
Transmissions 5 - 3
Transmission WT, Diag. codes..... 5 - 17
Vehicle identification number 5 - 8
Wheels and tires..... 5 - 2
Weights..... 5 - 2
Timer, preheating system 2 - 23
Tires..... 4 - 18, 5 - 2
Tools/jack 3 - 6
Tour guide seat 2 - 32
Towing..... 4 - 20

Transmission

Automatic	2 - 23
Clutch pedal	2 - 28
Cooler circuit	4 - 4
DDR, diagnostic data reader	2 - 5, 4 - 5
Diagnostic code list	5 - 17
Diagnostic telltales	4 - 5
Electronic control system WT	4 - 3
Importance of proper oil level	4 - 6
Lever, retarder	2 - 27
Light, do not shift	4 - 5
Manual	2 - 25, 4 - 7
Oil level sensor (OLS) codes	4 - 7
Operation (automatic)	2 - 24
Planetary gears & clutches	4 - 4
Pushbutton shifter	2 - 23
Retarder, output	2 - 4, 4 - 4
Torque converter	4 - 4
Warm-up	4 - 8

V

Vehicle identification number (VIN)	5 - 8
Video system	2 - 17

W

Warm-up

Engine	4 - 8
Transmission	4 - 8
Warning lights	2 - 9
Waste container	2 - 42
Water heater timer	2 - 23
Water separator	6 - 7
Weights, vehicle	5 - 2
Wheel bearing oil level	6 - 6
Wheels, changing	4 - 18
Wheels and tires	5 - 2
Windshield washer reservoir	4 - 14

A

ABS brake.....3 - 2, 5 - 4
Accelerator pedal2 - 28
Accessories2 - 41
Adjustable louver.....2 - 4, 2 - 16, 2 - 43
Air conditioning2-16, 4-11
Air filters, A/C & heating6 - 8
Air horn2 - 27, 3 - 5
Air system emergency fill valves.....3 - 2
Air tanks.....6 - 7
Alarm, back up.....3 - 3
Alarm system.....3 - 6
Alignment.....5 - 5
Antilock braking system3 - 2, 5 - 4
Audio/Video control unit2 - 16
Auxiliary sump tank draining.....6 - 11

B

Back-up alarm3 - 3
Back-up camera / TV monitor2 - 41, 6 - 10
Baggage compartment door locks.....2 - 4
Battery disconnect switch, main2 - 2
Battery equalizers.....4 - 17
Belts, engine.....5 - 3
Belt tensioners.....6 - 8
Blinds2 - 42
Block heater, engine.....4 - 7, 6 - 9
Brakes
 Anti-lock (ABS).....3 - 2, 5 - 4
 Emergency2 - 28, 3 - 1
 Engine (Jacob's)2 - 4, 4 - 3
 Parking2 - 23, 3 - 1
 Parking brake override2 - 23
 Service2 - 28, 3 - 1
Breakers, main4 - 16
Bulb chart.....5 - 10

C

Camera, maintenance6 - 10
Capacities, refill.....5 - 2
Card tables.....2 - 44
Care and maintenance6 - 1
Central A/C and heating controls4 - 11
Changing wheels4 - 18
Check engine light2 - 12
Chime, stop/service power switch.....2 - 4, 2 - 44
Cleaning, exterior6 - 3
Cleaning, interior6 - 1
Clutch pedal2 - 28
Coach final record.....5 - 8
Cold starting aid (Ether).....2 - 15, 4 - 7
Compartments, exterior
 A/C & heating2 - 39
 Baggage2 - 38
 Battery (XL-40)2 - 40
 Condenser2 - 39
 Engine.....2 - 37
 Entrance door.....2 - 36
 Fuel tank filling door2 - 36
 L.H. side service (XL-45)2 - 39
 Main power (XL-45).....2 - 39
 Service doors2 - 39
 Spare wheel and tire4 - 18
 XL-40 (details)2 - 34
 XL-45 (details)2 - 35
Compartments, interior
 Lavatory.....2 - 40
 Parcel racks.....2 - 41
 Safety equipment compartment.....2 - 41
Controls and instrument panels.....2 - 3
Coolant level verification.....6 - 7
Cruise control switches.....2 - 5

D

Daily inspection	4 - 8
Dashboard	2 - 7
Data plate & certification	5 - 7
Day time running lights.....	3 - 5
Defensive driving.....	3 - 8
Destination sign.....	2 - 42
Detroit diesel electronic control (DDEC).....	4 - 2
Diagnostic codes	
World transmission (WT).....	5 - 17
Detroit Diesel Electronic Control	5 - 12
Differential oil	5 - 6
Dimensions, vehicle	5 - 1
Dome lights.....	2 - 5
DO NOT SHIFT light	2 - 11, 4 - 5
Door, entrance.....	2 - 28
Door override.....	2 - 23, 3 - 4
DOT certification label.....	5 - 9
Drive axle ratio.....	5 - 3
Driver's A/C - heating system ctrls.....	2 - 16, 4 - 12
Driver's fan.....	2 - 42
Driver's light switch.....	2 - 4
Driver's seat.....	2 - 29
Driver's window	2 - 41

E

Electrical system.....	5 - 4
Electric circuit protection	4 - 16
Electric horns.....	2 - 27, 3 - 5
Emergency	
Exits.....	3 - 4
warning reflectors	3 - 6
Engine	
Block heater	4 - 7
Compartment components.....	2 - 37
DDEC	4 - 2
DDEC III diagnostic codes	5 - 12

Retarder (Jacob's).....	2 - 4, 4 - 3
Starting (from driver's compt.).....	4 - 1
Starting (from engine compt.)	4 - 1
Stop override	2 - 15
Warm-up.....	4 - 8
EPA engine labels.....	5 - 9
Ether, cold starting aid	2 - 15, 4 - 7
Exits, emergency	
Entrance door.....	3 - 4
Roof escape	3 - 4
Side windows	3 - 4
Exterior cleaning	6 - 3
Exterior mirror heating switch.....	2 - 4
Extinguishers, fire	3 - 6, 6 - 9

F

Filter restriction indicator.....	6 - 10
Fire extinguishers.....	3 - 6, 6 - 9
Fire hatchet	3 - 7
First aid kit	3 - 6
First service on new vehicle	6 - 12
Flexible hose maintenance.....	6 - 9
Fluorescent lighting.....	2 - 5
Fog lights	2 - 15, 3 - 5
Foot-operated controls.....	2 - 27
Fresh water reservoir draining.....	6 - 10
Fresh water reservoir filling	6 - 11
Fuel tank filling	2 - 2
Fuel type.....	5 - 2
Fuses.....	4 - 17

G

Galley	2 - 44
Gauges.....	2 - 7
General information	4 - 1

H

Hatchet, fire	3 - 7
Hazard flashers	2 - 15
Heating and air conditioning	
Central.....	2 - 16, 4 - 11
Driver's	2 - 16, 4 - 12
Ventilation	4 - 10
Heating and air conditioning (tech. info.)	5 - 5
Horns, air	2 - 27, 3 - 5
Horns, electric.....	2 - 27, 3 - 5
Hi-buoy / kneeling control switch	2 - 5
Hi-buoy system.....	3 - 3
Hubodometer.....	2 - 44

I

Identification plates.....	5 - 7
Indicator lights, dashboard	2 - 7
Ignition switch	2 - 14
In-station connectors (110 - 120 volt)	6 - 9
In-station lighting (110 - 120 volt).....	6 - 9
Interphone.....	2 - 19
Interior cleaning.....	6 - 1

J

Jacking points.....	4 - 20
Jack/tools.....	3 - 6
Jacob's engine brake	2 - 4, 4 - 3
Jump starting	4 - 15

K

Keys	2 - 1
Kneeling / hi-buoy control switch	2 - 5
Kneeling system	3 - 3

L

Lavatory.....	2 - 40
Lavatory maintenance	6 - 10
Lever, multifunction.....	2 - 26
Lever, transmission retarder.....	2 - 27
L.H. lower switch panel.....	2 - 14
L.H. outside mirror control	2 - 5
L.H. side control panel	2 - 4
Light bulb data.....	5 - 10
Lighting, exterior.....	2 - 15
Lighting, fluorescent.....	2 - 5
Light switch, driver's.....	2 - 4
Lights	
Day time running	3 - 5
Fog.....	3 - 5
Literature, service	7 - 1
Louver, adjustable.....	2 - 4, 2 - 16, 2 - 43
Low-buoy system	2 - 23, 3 - 3
Lubricant specifications	6 - 19
Lubrication.....	6 - 9
Lubrication and servicing schedule	6 - 13

M

Main battery disconnect switch	2 - 2
Main breakers	4 - 16
Main power compartment (XL-45).....	2 - 39
Main sump tank draining	6 - 11
Main sump tank filling	6 - 11
Manual transmission.....	2 - 25
Microphone jacks	2 - 5, 2 - 18
Mirrors	
Exterior mirrors	2 - 32
Heating switch	2 - 4
Interior mirror	2 - 32
L.H. outside mirror control.....	2 - 5
R.H. outside mirror control	2 - 5

Mud flaps and splash guards 2 - 43
 Multifunction lever..... 2 - 26

N

New vehicle, first service on 6 - 12

O

Oil capacities 5 - 2
 Oil specification 5 - 6
 Oil level verification
 A/C compressor 6 - 6
 Clutch pedal master cylinder 6 - 5
 Engine 6 - 4
 Fan gearbox..... 6 - 6
 Power steering 6 - 6
 Transmission (automatic) 6 - 4
 Transmission (manual)..... 6 - 5
 Wheel bearing..... 6 - 6
 Output retarder, transmission 2 - 4, 4 - 4
 Override, door..... 2 - 23, 3 - 4

P

Public address system (P. A.)..... 2 - 18
 Parcel racks 2 - 41
 Parking brake 2 - 23, 3 - 1
 Parking brake override 2 - 23
 Part number specifications 6 - 20
 Parts kit, spare..... 2 - 45
 Passenger seats..... 2 - 31
 Preheating systems
 Espar 2 - 23, 2 - 46, 4 - 13
 Webasto..... 2 - 23, 2 - 47, 4 - 14
 Prodriver™ - Engine data
 display and computer 2 - 20

Q

"Quick Lounge" system..... 2 - 44

R

Radio AM/FM 2 - 16
 Reading lamps 2 - 5
 Recommendations..... 4 - 9
 Reflectors, emergency warning..... 3 - 6
 Retractable or unloaded tag axle 2 - 23, 4 - 21
 R.H. console..... 2 - 15
 R.H. lateral console..... 2 - 22
 R.H. lower switch panel 2 - 15

S

Safety
 Attestation..... 5 - 9
 Equipment 3 - 6
 Precautions..... 3 - 7
 Seat
 Driver 2 - 29
 Passenger 2 - 31
 Tour guide 2 - 32
 Serial number, vehicle 5 - 8
 Service literature 7 - 1
 Service on new vehicle (first)..... 6 - 12
 Servicing and lubrication schedule..... 6 - 13
 Sound system 5 - 5
 Spare parts..... 2 - 45
 Speed control (cruise)..... 2 - 5
 Splash guards and mud flaps..... 2 - 43
 Starting engine from driver's compt..... 4 - 1

Starting engine from engine compt. 4 - 1
Steering wheel and telescopic column 2 - 28
Stereo receiver, AM/FM 2 - 16

Stop/service chime power switch.....2 - 4, 2 - 44
Stop/service/reading lamp2 - 5, 2 - 44
Storage volume 5 - 7
Suspension..... 5 - 5

Switches

Auxiliary A/C 2 - 15
Baggage door lock..... 2 - 4
Battery master switch 2 - 2
Cruise control 2 - 5
Dome lights 2 - 5
Ether cold starting aid 2 - 15
Exterior lighting switch 2 - 15
Fast idle..... 2 - 14
Fluorescent lighting..... 2 - 5
Fog lights..... 2 - 15
Galley power 2 - 44
Hazard flashers..... 2 - 15
Ignition..... 2 - 14
Kneeling/hi-buoy 2 - 5
L.H. outside mirror control 2 - 5
Light, driver's..... 2 - 4
Mirror heating..... 2 - 4
Reading lamps..... 2 - 5
Retarder, engine 2 - 4
Retarder, transmission 2 - 4
R.H. outside mirror control..... 2 - 5
"Stop Engine" override 2 - 15
Stop/service chime 2 - 4
Transmission pushbutton 2 - 23
Video power 2 - 17

T

Tachograph 2 - 13
Tachometer 2 - 13

Tag axle, unloaded or retractable.....2 - 23

Technical information

Alignment.....5 - 5
Belts.....5 - 3
Brakes.....5 - 4
Brakes (ABS).....5 - 4
Capacities.....5 - 2
Coach final record5 - 8
Data plate & certification5 - 7
DDEC III diagnostic codes5 - 12
Dimensions.....5 - 1
DOT certification label.....5 - 9
Drive axle ratio.....5 - 3
Electrical system5 - 4
Engines.....5 - 3
EPA engine label.....5 - 9
Fuel type5 - 2
Heating and air conditioning5 - 5
Light bulb data5 - 10
Oil specifications5 - 6
Preheating systems.....5 - 7
Safety attestation.....5 - 9
Seats.....5 - 7
Sound system.....5 - 5
Steering5 - 4
Storage volume5 - 7
Suspension.....5 - 5
Transmissions5 - 3
Transmission WT, Diag. codes.....5 - 17
Vehicle identification number5 - 8
Wheels and tires.....5 - 2
Weights.....5 - 2

Timer, preheating system2 - 23
Tires..... 4 - 18, 5 - 2
Tools/jack3 - 6
Tour guide seat2 - 32
Towing.....4 - 20

Transmission

Automatic	2 - 23
Clutch pedal	2 - 28
Cooler circuit	4 - 4
DDR, diagnostic data reader	2 - 5, 4 - 5
Diagnostic code list	5 - 17
Diagnostic telltales	4 - 5
Electronic control system WT	4 - 3
Importance of proper oil level	4 - 6
Lever, retarder	2 - 27
Light, do not shift	4 - 5
Manual	2 - 25, 4 - 7
Oil level sensor (OLS) codes	4 - 7
Operation (automatic)	2 - 24
Planetary gears & clutches	4 - 4
Pushbutton shifter	2 - 23
Retarder, output	2 - 4, 4 - 4
Torque converter	4 - 4
Warm-up	4 - 8

V

Vehicle identification number (VIN)	5 - 8
Video system	2 - 17

W

Warm-up

Engine	4 - 8
Transmission	4 - 8
Warning lights	2 - 9
Waste container	2 - 42
Water heater timer	2 - 23
Water separator	6 - 7
Weights, vehicle	5 - 2
Wheel bearing oil level	6 - 6
Wheels, changing	4 - 18
Wheels and tires	5 - 2
Windshield washer reservoir	4 - 14

CHANGE OF ADDRESS OR OWNERSHIP

Any Change in address or ownership should be brought to the attention of the manufacturer by completing and sending out one of the cards supplied below.

CHANGE OF ADDRESS

VEHICLE SERIAL NUMBER

--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--

OLD ADDRESS :

NAME		
NO.	STREET	APT
CITY	STATE/PROVINCE	ZIP/POSTAL CODE
() -	() -	
PHONE	FAX	

NEW ADDRESS :

NAME		
NO.	STREET	APT
CITY	STATE/PROVINCE	ZIP/POSTAL CODE
() -	() -	
PHONE	FAX	

CHANGE OF OWNERSHIP

VEHICLE SERIAL NUMBER

--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--


The ownership of this vehicle is transferred

FROM :

NAME		
NO.	STREET	APT
CITY	STATE/PROVINCE	ZIP/POSTAL CODE
() -	() -	
PHONE	FAX	


TO :

NAME		
NO.	STREET	APT
CITY	STATE/PROVINCE	ZIP/POSTAL CODE
() -	() -	
PHONE	FAX	



P R E V O S T

PRÉVOST CAR INC.
AFTER-SALES SERVICE DEPARTMENT
35, boulevard Gagnon
Ste-Claire, (Québec)
Canada G0R 2V0



P R E V O S T

PRÉVOST CAR INC.
AFTER-SALES SERVICE DEPARTMENT
35, boulevard Gagnon
Ste-Claire, (Québec)
Canada G0R 2V0