

# SECTION 01: ENGINE

## CONTENTS

- 1. ENGINE..... 01-3**
- 2. ENGINE-MOUNTED COMPONENTS ..... 01-3**
  - 2.1 ELECTRONIC CONTROL MODULE ..... 01-4
  - 2.2 N3 ELECTRONIC UNIT INJECTOR ..... 01-4
  - 2.3 VPOD ..... 01-4
    - 2.3.1 VPOD Removal..... 01-5
    - 2.3.2 VPOD Installation..... 01-5
  - 2.4 EGR HYDRAULIC VALVE..... 01-5
  - 2.5 SYNCHRONOUS REFERENCE SENSOR..... 01-5
  - 2.6 TIMING REFERENCE SENSOR ..... 01-5
  - 2.7 TURBO BOOST PRESSURE SENSOR..... 01-6
  - 2.8 COOLANT TEMPERATURE SENSOR ..... 01-6
  - 2.9 FUEL TEMPERATURE SENSOR..... 01-6
  - 2.10 AIR TEMPERATURE SENSOR..... 01-6
  - 2.11 TURBO COMPRESSOR IN TEMPERATURE SENSOR..... 01-6
  - 2.12 ABSOLUTE OIL PRESSURE SENSOR ..... 01-6
  - 2.13 OIL TEMPERATURE SENSOR..... 01-7
- 3. ENGINE-RELATED COMPONENTS ..... 01-7**
  - 3.1 COOLANT LEVEL SYSTEM (CLS) ..... 01-7
  - 3.2 ELECTRONIC FOOT PEDAL ASSEMBLY (EFPA) & THROTTLE POSITION SENSOR ..... 01-7
  - 3.3 CRUISE CONTROL SWITCHES (CCS)..... 01-7
  - 3.4 DIAGNOSTIC SYSTEM ACCESSORIES (DSA) ..... 01-8
    - 3.4.1 Check Engine Telltale Light ..... 01-8
    - 3.4.2 Stop Engine Warning Light ..... 01-8
    - 3.4.3 Stop Engine Override Switch..... 01-8
    - 3.4.4 Diagnostic Data Link (DDL) Connectors..... 01-8
- 4. DDEC V DIAGNOSTIC CODES ..... 01-8**
  - 4.1 READING DIAGNOSTIC CODES – FLASHING LIGHT METHOD:..... 01-8
- 5. ENGINE OIL LEVEL ..... 01-19**
- 6. ENGINE OIL AND FILTER CHANGE ..... 01-19**
- 7. RECOMMENDED ENGINE OIL TYPE ..... 01-20**
- 8. POWER PLANT ASSEMBLY REMOVAL..... 01-20**
- 9. POWER PLANT ASSY. INSTALLATION ..... 01-24**
- 10. VALVE COVER REMOVAL ..... 01-24**
- 11. JAKE BRAKE ..... 01-24**
- 12. ENGINE MOUNTS ..... 01-24**
- 13. ENGINE TROUBLESHOOTING GUIDE..... 01-26**
- 14. SPECIFICATIONS..... 01-27**

**ILLUSTRATIONS**

FIGURE 1: DETROIT DIESEL SERIES 60 ENGINE (TYPICAL)..... 01-3  
FIGURE 2: ELECTRONIC CONTROL MODULE (ECM)..... 01-4  
FIGURE 3: UNIT INJECTOR CROSS SECTION ..... 01-4  
FIGURE 4: VPOD LOCATION ..... 01-4  
FIGURE 5: VPOD INSTALLATION ..... 01-5  
FIGURE 6: EGR VALVE & ACTUATOR ASSEMBLY ..... 01-5  
FIGURE 7: TURBO BOOST PRESSURE SENSOR.....01-6  
FIGURE 8: FUEL TEMPERATURE SENSOR..... 01-6  
FIGURE 9: TURBO COMPRESSOR IN TEMPERATURE SENSOR LOCATION ..... 01-6  
FIGURE 10: ENGINE OPS..... 01-6  
FIGURE 11: ELECTRONIC FOOT PEDAL ASSEMBLY ..... 01-7  
FIGURE 12: ENGINE OIL LEVEL DIPSTICK ..... 01-19  
FIGURE 13: ENGINE COMPARTMENT ..... 01-19  
FIGURE 14: UNDER VEHICLE VIEW ..... 01-20  
FIGURE 15: ENGINE COMPARTMENT ..... 01-21  
FIGURE 16: ENGINE COMPARTMENT ..... 01-21  
FIGURE 17: ENGINE COMPARTMENT H3 COACHES (TYPICAL) ..... 01-23  
FIGURE 18: ENGINE COMPARTMENT VIP (TYPICAL)..... 01-23  
FIGURE 19: RUBBER DAMPER TOLERANCE ..... 01-24  
FIGURE 20: POWER PLANT CRADLE INSTALLATION ..... 01-25

## 1. ENGINE

This vehicle is powered by a 6-cylinder, four-cycle, Detroit Diesel series 60 engine, equipped with an electronic control system (DDEC V).

Two engine displacements are used in the Series 60 engines: 12.7 and 14.0 liters. Summary information on the Electronic Control System is given in this section.

Complete maintenance and repair information on the engine will be found in the current DDEC V Service Manual. This maintenance manual covers engine accessories, controls and related components.

Procedures for engine removal and installation are given at the end of this section. The DDEC system is self-diagnostic. It can identify faulty components and other engine-related problems by providing the technician with a diagnostic code.

Refer to DDEC Troubleshooting Guide published by Detroit Diesel for more complete information on diagnosis of components and system problems.

DDEC V (Detroit Diesel Electronic Control) controls the timing and amount of fuel injected by the electronic unit injectors (EUI). The system also monitors several engine functions using electrical sensors, which send electrical signals to the Electronic Control Module (ECM). The ECM computes the electrical signals and determines the correct fuel output and timing for optimum power, fuel economy and emissions. The ECM also has the ability to display warnings or shut down the engine completely (depending on option selection) in the event of damaging engine conditions, such as low oil pressure, low coolant level, or high oil temperature.

Two categories divide system components: engine-mounted components and engine-related components.

## 2. ENGINE-MOUNTED COMPONENTS

**NOTE: COOLANT LEVEL SENSOR IS MOUNTED ON COOLANT SURGE TANK, LOCATED ON UPPER L. H. SIDE OF ENGINE COMPARTMENT. TURBO COMPRESSOR IN TEMPERATURE SENSOR IS MOUNTED ON ENGINE AIR INTAKE DUCT.**

