

ZF-TRONIC®

10 AS 2301

12 AS 2301, 16 AS 2601

Repair stages 1 - 2

1327 751 101

Subject to alterations in design

Copyright by ZF

These repair instructions are protected by copyright. Any reproduction and dissemination in whatever form – also in adapted, paraphrased or extracted form – in particular as a reprint, photomechanical or electronic reproduction or as a storage in data-processing equipment or data networks without approval by the holder of the copyright is prohibited and will be prosecuted under civil and criminal law.

Printed in Germany

Edition: 2000-02

1327 751 101

	Page
Preface	4
Important safety information	5
Instructions for carrying out repairs	6
Tightening torques	8
Special tools	11
Diagnosis.....	13
1 E module	1-1
2 Range selector	2-1
3 Display	3-1
4 Wiring harness	4-1
5 Clutch actuator	5-1
6 Driver disc	6-1
7 Clutch release device.....	7-1
8 Transmission actuator	8-1
9 Input shaft seal	9-1
10 Transmission brake	10-1
11 Output flange	11-1
12 Output speed sensor	12-1
13 Neutral switchr.....	13-1
14 Intarder.....	14-1
15 Annex.....	15-1

CAUTION

The ZF order numbers used in this publication apply for the ZF standard.

Deviations may occur depending on the vehicle manufacturer. The binding ZF order numbers are listed in the appropriate parts list - parts list no. can be found on the transmission type plate.

This manual is intended for skilled personnel trained by ZF FRIEDRICHSHAFEN AG to carry out maintenance and repair work on ZF products.

This manual deals with a ZF product in accordance with the state of development of test rigs on the date of issue.

However, due to continuing development of function test rigs, repair work might require work practices and test or adjustment data which are not contained in this manual.

We therefore recommend that work done on your ZF product is carried out only by skilled mechanics and fitters who have had their practical and theoretical knowledge updated on a regular basis at our After-Sales Service training courses.

Service points equipped by ZF FRIEDRICHSHAFEN AG all over the world offer you:

1. Well-trained personnel.
2. Specified equipment, e.g. specialized tools.
3. Genuine ZF spares, to our latest specifications.

All work performed in these service points is carried out conscientiously and with care.

Repair work carried out at ZF service points is guaranteed in accordance with the prevailing contractual conditions.

Damage resulting from work performed by non-ZF personnel in an improper and unprofessional manner, together with follow-on costs caused by such work, is excluded from the contractual warranty agreement. This also applies where genuine parts have not been used.

ZF FRIEDRICHSHAFEN AG
Geschäftsbereich Nkw-/Sonder-Antriebstechnik
Service Werk 2
Tel.: (0 75 41) 77-0
Fax: (0 75 41) 77-5726

SAFETY NOTICE

Companies repairing ZF units are responsible for their own work safety.

To avoid injury to personnel and damage to products, all safety regulations and legal requirements which apply to repair and maintenance work must be adhered to.

Before starting work, mechanics must familiarize themselves with these regulations.

Personnel required to carry out repairs on ZF products must receive appropriate training in advance. It is the responsibility of each company to ensure that their repair staff is properly trained.

The following safety instructions appear in this manual:

NOTE

Refers to special processes, techniques, data, use of auxiliary equipment, etc.

CAUTION

This is used when incorrect, unprofessional working practices could damage the product.

⚠ DANGER

This is used when lack of care could lead to personal injury or death.

GENERAL INFORMATION

Read this manual carefully before starting any tests or repair work.

CAUTION

Pictures, drawings and components do not always represent the original object, but are used to illustrate working procedures.

Pictures, drawings and components are not to scale. Conclusions about size and weight should not be drawn (even within a complete illustration). Always follow the working steps as described in the text.

After completion of repair work and testing, skilled staff must satisfy themselves that the product is functioning correctly.

⚠ THREATS TO THE ENVIRONMENT !

Lubricants and cleaning agents must not be allowed to enter the soil, ground water or sewage system.

- **Ask your local environment agency for safety information on the relevant products and adhere to their requirements.**
- **Collect used oil in a suitably large container.**
- **Dispose of used oil, dirty filters, lubricants and cleaning agents in accordance with environmental protection guidelines.**
- **When working with lubricants and cleaning agents always refer to the manufacturer's instructions.**

CAUTION

The transmission must NOT be hung by the input shaft NOR by the output flange.

In case of doubt always turn to the relevant department within ZF After-Sales Services for advice. All work on transmissions is to be performed expertly and under clean conditions. Use specified tools to dismantle and assemble transmissions.

After removing the transmission from the vehicle, clean thoroughly with a suitable cleaning agent before opening.

Pay particular attention to the projections and recesses of housings and covers when cleaning.

Parts joined with Loctite are easier to separate if warmed with a fan heater.

CLEANING PARTS

Remove remains of old gaskets on all seal-faces. Carefully remove burrs or similar patches of roughness using an oil-stone.

Lube bores and grooves must be free of anti-corrosion agents and foreign matter; check for perfect passage.

Carefully cover opened transmissions to prevent foreign matter from entering.

REUSING PARTS

Parts such as ball or roller bearings, multi-discs, thrust washers etc., must be inspected by a competent person, who should decide whether or not they can be re-used. Replace parts which are damaged or have suffered from excessive wear.

GASKETS, LOCKING PLATES

Parts which cannot be removed without being damaged must always be replaced with new parts (e.g. gaskets and locking plates).

SHAFT SEALS

Always change shaft seals with rough, ripped or hardened packing washers. Seal contact surfaces must be totally clean and in perfect condition.

REWORKING

Rework may be carried out on seal contact surfaces using plunge-cut grinding only, never use an emery cloth. Ensure that there are no traces of grinding or riffling.

If rework is needed on distance washers, shims etc. because of clearance settings, ensure that the reworked areas contain no face runout and have the same surface quality.

TRANSMISSION ASSEMBLY

Find a clean site to assemble the transmission. Gaskets are installed without the use of sealing compound or grease. When measuring silicon-coated gaskets, take care **not to include the silicon layer in the measurement.**

During assembly, comply with all adjustment data, checking data and tightening torques in the Repair Manual.

BEARINGS

If bearings are mounted in heated condition, they are to be heated evenly (e.g. heating cabinet). Temperature should be at ca. 85 °C and must not exceed 120 °C. Each mounted bearing must be oiled with operating oil.


SEALING

If a specific sealing agent* is to be used for sealing, comply with the manufacturer's directions for use. Apply a thin layer of sealing agent to the surfaces and spread evenly. Do not allow sealing to enter oil ducts and bores. On oil-carrying ducts and bores, wipe off the sealing agent on the surfaces to be sealed near apertures to ensure that no sealing agent enters the oil feeds when the surfaces are sealed.

SHAFT SEALS

- a) Apply a light coat of sealing agent* on outer edge of shaft seals with "steel surround".
- b) **Never apply sealing agent** to shaft seals with "rubber surround", but apply a thin coat of Vaseline 8420 to the outer edge or wet with a lubricant, e.g. a water-soluble, concentrated washing-up liquid (e.g. Pril, Coin, Palmolive).
- c) Shaft seals with steel and rubber surrounds should be treated on the outer edge of the rubber surround as described above in section b).

- d) Dual shaft seals have two sealing lips. The dust-proof sealing lip (X) must face outwards.



- e) Fill the gap between the sealing lips so it is 60% filled with grease (e.g. produced by Aral such as Aralub HL2 or by DEA such as Spectron FO 20).
- f) If possible, heat shaft seal bores to between 40 and 50 °C (makes fitting easier). Press the seal shaft with mounting or faceplate onto the relevant installation depth plan.

RETAINING AGENTS

Retaining agents* may only be used in places as specified in the parts list. Always comply with manufacturer's directions for use when using retaining agents (e.g. Loctite). During assembly, comply with all adjustment data, checking data and tightening torques.

TRANSMISSION OIL

After completing repairs, fill transmissions with transmission oil. For the procedure and approved oils, refer to the transmission operating manual and List of Lubricants TE-ML (refer to identification plate) which are available from any ZF After-Sales Service Point. After filling the transmission with oil, tighten the screw plugs at the oil filling point and the oil overflow to the specified torques.

* refer to expendable material

Tightening torques for nuts and bolts, extract from ZFN 148

This standard applies to bolts acc. to DIN 912, DIN 931, DIN 933, DIN 960, DIN 961 and to nuts acc. to DIN 934. This Standard contains data on tightening torques (M_A) for bolts and nuts in strength categories 8.8, 10.9 and 12.9 and nuts in strength categories 8, 10 and 12.

Surface condition of bolts: thermally blackened and oiled or galvanized and oiled or galvanized, chrome-plated and oiled.

Tighten screws with a calibrated torque spanner.

NOTE

Irregular tightening torques are listed separately in the Repair Manual.

Regular screw thread			
Size	Tightening torque M_A (Nm) for		
	8.8	10.9	12.9
Bolt	8	10	12
Nut	8	10	12
M 4	2.8	4.1	4.8
M 5	5.5	8.1	9.5
M 6	9.5	14	16.5
M 7	15	23	28
M 8	23	34	40
M 10	46	68	79
M 12	79	115	135
M 14	125	185	215
M 16	195	280	330
M 18	280	390	460
M 20	390	560	650
M 22	530	750	880
M 24	670	960	1100
M 27	1000	1400	1650
M 30	1350	1900	2250

Fine screw thread			
Size	Tightening torque M_A (Nm) for		
	8.8	10.9	12.9
Bolt	8	10	12
Nut	8	10	12
M 8 x 1	24	36	43
M 9 x 1	36	53	62
M 10 x 1	52	76	89
M 10 x 1.25	49	72	84
M 12 x 1.25	87	125	150
M 12 x 1.5	83	122	145
M 14 x 1.5	135	200	235
M 16 x 1.5	205	300	360
M 18 x 1.5	310	440	520
M 18 x 2	290	420	490
M 20 x 1.5	430	620	720
M 22 x 1.5	580	820	960
M 24 x 1.5	760	1100	1250
M 24 x 2	730	1050	1200
M 27 x 1.5	1100	1600	1850
M 27 x 2	1050	1500	1800
M 30 x 1.5	1550	2200	2550
M 30 x 2	1500	2100	2500

Edition: August 1991 / checked 1997

Screw plugs DIN 908, 910 and 7604

The screw plug tightening torques M_A were determined according to DIN 7604 for screwing into steel, grey cast and aluminum alloys.

The values are based on experience and are intended as reference values for the fitter.

The values for the tightening torque M_A apply analogously for screw plugs according to DIN 908 and DIN 910, as the thread geometries are almost identical.

General rule: Screw/bolt class 5, ZFN 148-1
 Screw/bolt material: steel acc. to DIN 7604. Surface condition: as manufactured (without surface protection) and lightly oiled or galvanized, chromated and lightly oiled.

Union screws DIN 7643

The tightening torques M_A were determined for screwing into steel, grey cast and aluminum alloys.

The values are based on experience and are intended as reference values for the fitter.

General rule: screw/bolt class 5, ZFN 148-1
 Material: 9SMnPb28K acc. to DIN 1651
 Surface condition: as manufactured (without surface protection) and lightly oiled or galvanized, chromated and lightly oiled

Screw plugs (DIN 908, 910, 7604)		
Dimensions	Tightening torque screwed into	
	steel/gray cast	Al alloy
M 8 x 1	20	10
M 10 x 1	25 / 30*	15 / 20*
M 12 x 1.5	35	25
M 14 x 1.5	35	25
M 16 x 1.5	40	30
M 18 x 1.5	50	35
M 20 x 1.5	55	45
M 22 x 1.5	60 / 80*	50 / 65*
M 24 x 1.5	70	60
M 26 x 1.5	80 / 105*	70 / 90*
M 27 x 2	80	70
M 30 x 1.5	100 / 130*	90 / 130*
M 30 x 2	95	85
M 33 x 2	120	110
M 36 x 1.5	130	115
M 38 x 1.5	140	120
M 42 x 1.5	150	130
M 42 x 2	145	125
M 45 x 1.5	160	140
M 45 x 2	150	130
M 48 x 1.5	170	145
M 48 x 2	160	135
M 52 x 1.5	180	150
M 60 x 2	195	165
M 64 x 2	205	175

Union screws (DIN7643)		
Pipe outer diameter	Thread	Tightening torque M_A in Nm
4 - 5	M 8 x 1	20 - 25
6	M 10 x 1	25 - 35
8	M 12 x 1.5	30 - 40
10	M 14 x 1.5	35 - 40
12	M 16 x 1.5	45
15	M 18 x 1.5	50
18	M 22 x 1.5	60
22	M 26 x 1.5	90
28	M 30 x 1.5	130
35	M 38 x 1.5	140

* DIN 7604 Form C







Fig. no.	Special tools	Order no.	Application	Qty.	Remarks
1		<p>1X56 099 063</p> <p>Adapter for shaft seal in release flange</p>		1	
2		<p>1X56 137 124</p> <p>Adapter for 105 x 125 x 12 shaft seal on output</p>		1	
3		<p>1X56 138 189</p> <p>Spacer ring (used in conjunction with adapter 1X56 137 124) for Intarder version 105 x 125 x 12 shaft seal on output</p>		1	
4		<p>1X56 138 215</p> <p>Adapter for shaft seal release fork</p>		2	
5		<p>6008 006 002</p> <p>Terminal tester 68-pin</p>		1	<p>35-pin terminal testers can also be used.</p>






Fig. no.	Special tools	Order no.	Application	Qty.	Remarks
6	 <p style="text-align: right;">014860</p>	6008 208 003	Testman diagnosis system Contains : Testman software 6008 308 901 plus DPA 04i adapter 6008 308 600 plus connection cable 6008 308 601 to PC or laptop plus connection cable DPA04i to control unit 0501 211 103	1	
7		Application 6008 308 019 D 6008 308 119 GB 6008 308 219 F 6008 308 319 E 6008 308 419 I		1	
8		6008 307 025	Diagnosis adapter (universal) used in conjunction with 68-pin terminal tester 6008 006 002	1	
9		6008 206 013	Adapter cable, 35/68-pin used in conjunction with 35-pin or 68-pin terminal tester (the 35-pin terminal tester 1P01 137 365 is no longer produced)	1	
10		6008 206 006	Adapter cable 18/20/68-pin bush for 68-pin terminal tester 6008 006 002	1	



Fig. no.	Special tools	Order no.	Application	Qty.	Remarks
11		<p>6008 206 007</p>	<p>Adapter cable 18/20/68-pin connector for 68-pin terminal tester 6008 006 002</p>	1	

Diagnosis in vehicles with ZF standard software

System errors are shown on the display.

If a “Spanner symbol” appears in the display, there is a system error. It is possible that the vehicle may only be driven with limited function.

For example :

Automatic drive mode is deactivated when certain system errors arise and the transmission system remains in manual drive mode.

If “STOP” and the “Spanner symbol” appear in the display, there is a serious system error. The vehicle must not be driven. The vehicle usually has to be towed away.

Calling up of error numbers :*

- Switch on ignition
- Turn rotary switch to “N”
- Hold selector lever in “+” position

The number displayed refers to the error number.

If in a two-digit display, 4 bars are shown in additional to the number displayed, this means: error no. + 100

e.g.: error no. 74
error no. 174

The error number can be decoded using the error list.

The error message and the resultant error response can be deleted via “Ignition off” (wait until the display goes out).

If the display does not go out after “Ignition off”, shut down the system via the main battery switch.

Error list

Key to error list

ABS: Antilock Braking System

ASR: Anti-Slip Control

CAN: Electronic data transfer system

ECU: Electronic transmission control

EDC: Electronic engine control

GP: Range change group

GV: Splitter group

MV: Solenoid valve

ISMA: Automatic

Journey may be continued in automatic mode: yes / no

RESET:

Switch off ignition with vehicle at standstill and wait until the display goes out.

Then turn on ignition.

If the error is still present, a diagnosis must be created.

* also refer to operating manual of vehicle manufacturer.

1 E module*
(ZF no. 6041 322 033)

NOTE


The E module is located in the vehicle's E box.

CAUTION

Only work on the E module if the ignition is off.

1.1 Removal

- 1 Pull 35-pin connector (3) out of E module (2).
- 2 Remove 3 bolts (1) and earth strap (4).



014 700

1.2 Fitting

Installation instructions:

The E module housing must be connected with the chassis strap via an earth strap. The E module must be installed in a protected place in accordance with the approved installation points.

- 1 Screw on E module (2) and earth strap (4). Tighten M5 bolts (1) to 5.5 Nm.
- 2 Snap connector (3) onto E module (2).

CAUTION

Fit connector without tightening the cable and check detent.

1.3 Changing the connector

If the connector has to be changed, please use the standard AMP tool.

For *wiring diagram*, refer to parts list.

* depending on parts list

2 Range selector (ZF no. 6006 029 018)

CAUTION

Only work on the range selector if the ignition is off.

2.1 Console range selector

2.1.1 Removal

- 1 Pull out connector (1) and remove 4 M8 bolts (2).

2.1.2 Fitting

- 1 Snap in connector (1).
- 2 Use 4 M8 bolts (2) to secure console range selector (3).
M8 tightening torque = 23 Nm


CAUTION

Fit connector without tightening the cable and check detent.

2.1.3 Changing the connector

If the connector has to be changed, please use the standard AMP tool.

For wiring diagram 6006 700 579, refer to Annex.



014 650


2.2 Steering column range selector*

2.2.1 Removal

- 1 Pull connector (4) out of wiring harness and remove 2 M5 bolts (5).
- 2 Remove 4 M4 bolts (6) from rotary switch (8) and pull connector (7) off wiring harness.

2.2.2 Fitting

- 1 Snap connector (7) into wiring harness and use 4 M4 bolts (6) to secure rotary switch (8).
M4 tightening torque = 2.8 Nm
- 2 Snap connector (4) into wiring harness and use 2 M5 bolts (5) to secure steering wheel column (9).
M5 tightening torque = 5.5 Nm



014 652

CAUTION

Fit connector without tightening the cable and check detent.

NOTE

Other components (e.g. brake stage switch) must still be accessible.

2.2.3 Changing the connector

If the connector has to be changed, please use the standard AMP tool.

For *wiring diagram*, refer to parts list.

- *Steering column range selector (9),*
ZF no. 0501 211 185
Wiring diagram: 0501 211 185 refer to Annex
- *Rotary switch (8) ZF no. 6006 199 031*
Wiring diagram: 6006 700 586 refer to Annex
- *Version EVOBUS*
ZF no. 6006 199 030
A separate rotary switch and a separate range selector 6006 235 012


* Special version

3 Display*ZF display 0501 211 422 capable of CAN***CAUTION****Only work on the display if the ignition is off.****NOTE**

The display must be accessible from below.

3.1 Removal

- 1 Pull connector (2) off display.
Press on retaining clamps (see arrow) and move display (1) upwards.



014 651

3.2 Installation

- 1 Slide display (1) into aperture.

CAUTION**Fit connector (2) without tightening the cable and check detent.****3.3 Wiring diagram***0501 211 422, refer to Annex*

Connector arrangement

PIN 1: 58 (light on/off) on = GND

PIN 2: AD (piezo) $I_{max} = 200 \text{ mA}$

PIN 3: 58d (light dimmed) on = VP

PIN 4: SD (ZF-BUS)

PIN 5: CAN H

PIN 6: VW (GND)

PIN 7: CAN L

PIN 8: VP (batt): 9 V.....32 V


Max. current capacity 60 mA

Type of protection: IP54 at front, IP30 at rear

3.3.1 Changing the connector

If the connector has to be changed, please use the standard AMP tool.

For vehicle-specific *wiring diagram*, refer to parts list.



014 699

4 Wiring harness (central wiring)

Standard (20-pin) 0501 006 958

Special version (18-pin) 0501 006 959

CAUTION

Only work on the wiring harness if the ignition is off.

4.1 Removal

- 1 Disconnect all plug connections.
- 2 Remove wiring harness from cable clamps.

4.2 Fitting

CAUTION


- Do not bend wiring harness and do not tighten the cable.
- Avoid chafing points.
- Fit connector without tightening the cable and check detent.

- 1 Press wiring harness into cable clamps.
- 2 Reconnect all connectors.

4.3 Vehicle connectors

Standard version
20-pin connector

Special version
Transmission actuator with cable tip.
18-pin connector



014703

5 Clutch actuator
ZF no. 0501 211 799

5.1 Removal

- 1 Remove 4 M8 hex nuts (/030) with washers (/020) and take off clutch actuator (68.010).
- 2 Remove 4 M8 hex bolts (68.154) and take off cover (68.150).
- 3 Take thrust rod (68.210) totally out of release fork (68.060).


<i>Name</i>	<i>ZF no.</i>
<i>Cpl. thrust rod (68.210)</i> <i>(can be set variably)</i>	1314 268 002
<i>Ball pin (/110)</i>	1314 368 008
<i>Thrust rod (/120)</i>	1314 368 004
<i>Hex nut (/130)</i>	0637 002 051

Set thrust rod to dimension (for installation dimensions, refer to parts list) and tighten hex nut (/130) to 52 Nm.

5.2 Thrust rod

Length of thrust rod (68.210) depends on parts list version :

<i>ZF no.</i>	<i>Length in mm</i>
1328 302 026	111.6
1328 302 033	119.1
1328 368 003	127.1
1328 368 004	133.6



014 703

5.3 Fitting

- 1 Insert thrust rod (**68.210**) in pan of release fork (**68.060**).
Use 4 M8 hex nuts (**/030**) to secure clutch actuator (**68.010**) and 4 washers (**/020**).
In so doing, check that the connections are in the correct position and that the thrust rod (**68.210**) is seated correctly in the release fork and clutch actuator.
Tightening torque
Hex nut (**/030**) M8 = 23 Nm
Dowel pin (**/010**) M8 = 10 Nm
- 2 Use 4 M8 hex bolts (**68.154**) to secure cover (**68.150**).
M8 tightening torque = 23 Nm

Bleeding clutch actuator

Unfasten M12x1.5 bolt (**6**).
If the seal on the bolt is torn, replace the seal.
Retighten bolt (**6**) to 22 Nm.

6 Changing the driver disc
(not within ZF's scope of supply)

If the driver disc is changed, the following should be noted:

- The input shaft spline should be coated with grease OLISTA LONGTIME 3EP (ZF no. 0671 190 050).

6.1 Fitting engine, clutch and transmission

NOTE

The release bearing is fitted when the transmission is delivered or supplied. The transmission is in neutral or the highest gear.

- 1 Fit clutch disc and pressure plate (use a mandrel to centre pressure plate).
- 2 Insert input shaft spline into mating teeth inside clutch disc.
- 3 Screw transmission to engine.
- 4 Bleed clutch actuator (refer to chapter 5).
- 5 Press release bearing forwards (engine side) so that the clutch snaps into the snap-on ring of the release bearing.


NOTE

This is done by using a small lever to press down the lower end of the release fork (transmission side). Pass lever through aperture in transmission bell housing to reach the release fork.

CAUTION

Do not damage the pressure plate.

- 6 Insert thrust rod.
- 7 Close aperture on transmission bell housing (refer to chapter 5).




014 794

WARNING

The driver disc, pressure plate and friction lining form part of the customer specification (contained within parts list).

The shift program software is co-ordinated to the characteristics of the clutch components.

If components are modified contrary to the customer specification, this will lead to impaired clutch characteristics and/or component damage.



014 702

7 Clutch release device

7.1 Removal of release fork

- 1 Remove 2 M12 hex bolts (68.130) from release shaft (68.110).
- 2 Take release bearing (68.050) and release fork (68.060) off input shaft.
- 3 Slide release shaft (68.110) off release fork (68.060).
- 4 Dismantle release fork (68.060).
Use suitable tool to remove shaft seal (/140) and bush (/130). Replace ball cup (/120) if damaged or worn.

7.2 Fitting release fork

- 1 Assemble release fork (68.060).
An adapter 1X56 138 215 is required as support for the release fork. The other two adapters 1X56 138 215 are used to press the two bushes (/130) into the release fork (/110) until flush.

NOTE

The shaft seals on the outer edge are coated with spirits.

- 2 Use adapter 1X56 138 215 to drive both shaft seals (/140) fully home.
Grease sealing lip of shaft seal (/140) with OLISTA LONGTIME 3EP (ZF no. 0671 190 050).
- 3 Guide release shaft (68.110) into release fork (68.060) and take care not to damage the shaft seals.
- 4 Position release bearing (68.050) on release flange. **Do not grease sliding seat between release bearing and release flange.**
- 5 Grease locating faces between release fork (68.060) and release bearing (68.050) with OLISTA LONGTIME 3EP (ZF no. 0671 190 050). Mesh release fork (68.060) with release bearing (68.050). Check that thrust rod (68.210) is seated correctly.
- 6 Use 2 M12 hex bolts (68.130) to secure release shaft (68.110) to housing I.
M12 tightening torque = 79 Nm

8 Transmission actuator

20-pin standard version: 6009 074 900

Special 18-pin version: 6009 074 901

The ZF numbers listed above contain:
transmission actuator, gasket and vent.

CAUTION

Only work on the transmission actuator if the ignition is off.


8.1 Removal**CAUTION**

If vehicle-specific parts need to be removed (e.g. fuel pump, exhaust pipe or steering pump), please contact the vehicle manufacturer.

- 1 Disconnect the electrical plug connections on the transmission actuator.
Remove compressed air line from transmission actuator.
- 2 Remove vent (**74.120**) from transmission actuator (**74.030**).
- 3 Remove 15 M8 hex bolts (**74.090**; **74.070**) from transmission actuator (**74.030**).
- 4 Remove transmission actuator from transmission housing.
- 5 Remove the compression springs (**06.050**; **34.140** and **12.090**) and detent pins (**06.040**; **34.130** and **12.080**). Replace the 2 cylindrical pins (**74.050**) if damaged.
- 6 Remove gasket (**74.010**) and clean sealing faces on transmission housing and on transmission actuator.

NOTE

A transmission actuator kit is available. This consists of transmission actuator (**74.030**), gasket (**74.010**) and vent (**74.120**).



015 166

8.2 Installation

CAUTION


If the transmission actuator is changed, the following should be noted.

- Re-program the transmission actuator.
- Transfer vehicle parameters from removed transmission actuator or re-enter them.
- Transfer the position (installation dimensions) of the piston rods from the removed transmission actuator to the actuator to be installed.

- 1 If the ball pin is changed, coat thread of ball pin (06.080) with **Loctite no. 262**. Tighten ball pin to 23 Nm.
- 2 Place new gasket (74.010) on transmission housing.
- 3 Insert the detent pins (06.040; 34.130 and 12.080) and compression springs (06.050; 34.140 and 12.090).
- 4 Fit transmission actuator (74.030). When fitting, ensure that the piston rods of the transmission actuator mesh in the shift rails of the transmission.
- 5 Tighten 6 M8x70 hex bolts (74.090) and 9 M8x45 hex bolts (74.070) to 23 Nm.
- 6 Tighten vent (74.120) to 10 Nm.
- 7 Connect air line to pressure limiting valve of transmission actuator.
- 8 Reconnect transmission and vehicle wiring harness. If this is not done, the function test cannot be conducted.

NOTE

Use diagnosis device to check transmission actuator before the vehicle-specific parts are refitted.



015 166

Warning when changing transmission actuator.

Replace old generation with new generation


6009 374 025 with 6009 374 040 (20-pin) or

6009 374 026 with 6009 374 041 (18-pin)

The GP detent compression spring (34.140)

0732 042 679 (41 mm) should also be replaced with

0732 042 766 (approx. 10 mm longer).



015 019

9 Changing input shaft seal

9.1 Removal

- 1 Remove clutch release device as specified in chapter 7.
- 2 Remove 4 M8 hex bolts (**02.530**) from release flange (**02.520**). Lift off release flange.
- 3 Use suitable tool to remove shaft seal (**02.510**).

9.2 Fitting

NOTE


- Coat outer edge of shaft seal with spirits.
- Sealing lip must face inside of transmission.

- 1 Use tool **1X56 099 063** to press shaft seal (**02.510**) firmly home into release flange (**02.520**). Coat sealing lip of shaft seal with grease.
- 2 Coat sealing face on release flange (**02.520**) with **Loctite no. 574**.


NOTE

Sealing faces must be clean and free of oil and grease.

- 3 Use 4 M8 hex bolts (**02.530**) to secure release flange (**02.520**).
M8 tightening torque = 23 Nm
- 4 Fit clutch release device, as specified in chapter 7.



015 856



014 737

10 Changing transmission brake

10.1 Removal

- 1 Remove clutch release device as specified in chapter 7.
- 2 Remove 22 M10 hex bolts (02.670).
- 3 Use suitable tool to lift off connection plate (02.500).

NOTE

It is easier to lift off the connection plate if the release flange (02.520) is not removed. If the flange is removed, the connection plate tends to tilt.

- 4 Leave shims (03.050 ; 02.100 and 03.150) on the bearings and do not remove them. Shims 03.050 and 03.150 must not be confused with one another.

- 5 **Do not use compressed air** to remove brake cover (03.250) from connection plate (risk of accident) but knock out instead. Remove discs (03.270 and 03.280).

CAUTION


The number of discs (03.270 and 03.280) depends on the parts list.

10.2 Fitting

- 1 Place brake cover (03.250) on the housing sealing face. The 3 ducts of the brake cover (03.250) should face the disc pack.
- 2 Fit outer discs (03.270) and inner discs (03.280) in accordance with parts list.

NOTE

The sealing faces and the M10 threaded bores in the transmission housing must be clean and free of oil and grease.




014 819

- 3 Coat sealing face of connection plate (02.500) with **Loctite no. 574**.

NOTE


The shims (03.050, 02.100 and 03.150) must lie correctly on the outer bearing races.

- 4 Carefully move connection plate (02.500) over input shaft onto transmission housing. Align the pump driver (Z) ensuring that it meshes in the countershaft groove (Y).



014 820

- 5 Coat 22 M10x60 hex bolts (02.670) with **Loctite no. 241** and tighten to 50 Nm.



014 821


11 Output flange

11.1 Removal

- 1 Remove 2 hex bolts (32.550) and washer (32.540).
- 2 Use standard two-armed extractor to pull off output flange (32.510) and remove O-ring (32.530).

NOTE

During extraction process, use an intermediate piece 1X56 138 191 to protect the shaft.



015 171


11.2 Fitting

- 1 Heat output flange (32.510) to max. 70 °C and slide onto spline of planetary carrier until firmly home. When using the Intarder version, ensure that the bolts* (32.520) are inserted.

⚠ DANGER

Only ever touch heated output flange when wearing protective gloves.

- 2 Once the output flange has cooled, insert O-ring (32.530) in groove between shaft and output flange.
- 3 Use 2 M12 hex bolts (32.550) to secure washer (32.540).
M12 tightening torque = 120 Nm



015 169

* depending on parts list

11.3 Removing output cover

- 1 Remove 10 M10 hex bolts (31.070) and lift off output cover (31.050).
- 2 Take off shim (31.030).
- 3 Use suitable tool to remove shaft seal (31.080). When removing seal ensure that output cover is not damaged.


11.4 Fitting output cover

- 1 Coat outer edge of shaft seal (31.080) with spirits and use adapter 1X56 137 124 and ring 1X56 138 189 to press into output cover (31.050) until firmly home. Lightly grease sealing lip.
- 2 Coat sealing face of output cover with **Loctite no. 574**.

NOTE

Sealing faces must be clean and free of oil and grease.

- 3 Fit output cover (31.050) with shim (31.030).
- 4 Tighten 10 M10 hex bolts (31.070) to 46 Nm.



015 170

12 Output speed sensor (impulse sensor) Depends on vehicle manufacturer

12.1 Removal

- 1 Pull out connector.
- 2 Remove impulse sensor (31.260).

12.2 Fitting

CAUTION


- Fit connector without tightening the cable and check detent.
- The impulse sensor may be confused with another type, therefore check the ZF number.

- 1 Screw in impulse sensor (31.260).
(No setting is required)
Tightening torque = 45 Nm


12.3 Changing the connector

If the connector has to be changed, please use the standard AMP tool.

For *wiring diagram*, refer to parts list.



014 813



014 814

Transmission without Intarder

Impulse sensor* (DIN bayonet) 90 mm long

Version	Voltage supply
Hall 0501 210 859	ZF 6.5 – 30 V
Kitas 0501 211 735	Vehicle 6.5 – 9 V

Transmission with Intarder

Impulse sensor* (DIN bayonet) 19.8 mm long

Version	Voltage supply
Hall 0501 210 855	ZF 6.5 – 30 V
Kitas 0501 211 731	Vehicle 6.5 – 9 V

* depending on parts list

13 Changing the neutral switch***13.1 Removal**


- 1 Remove neutral switch (**06.260**) and seal.

13.2 Fitting

- 1 Apply a little grease to plunger of neutral switch. Fit seal and screw down neutral switch (**06.260**). Tightening torque = 50 Nm

NOTE

Pin (**06.250**) must be fitted.



014 815

13.3 Changing the connector

If the connector has to be changed, please use the standard AMP tool.

For *wiring diagram*, refer to parts list.

Name

Neutral switch (DIN bayonet)

Seal

Pin


ZF no.

0501 210 059

0634 801 062

1328 306 024

* Option (refer to parts list)



014 738

14 Changing components on the Intarder

CAUTION

Fit all connectors without tightening the cable and check detent.

14.1 Output speed sensor

- 1 Screw in impulse sensor (1).
Tightening torque = 45 Nm

14.2 Speedometer

- 1 Screw in impulse sensor (2).
Tightening torque = 45 Nm

CAUTION


Speedometer must be calibrated and lead sealed.

14.3 Solenoid valve

- 1 Lightly grease O-ring (02.180) and insert in solenoid valve (02.170) and use 2 M8x22 cylindrical screws (02.190) to secure.
M8 tightening torque = 23 Nm

14.4 Temperature sensor

- 1 Screw in temperature sensor (05.030) and seal.
Tightening torque = 40 Nm



014 738

14.5 Removing 3/2-way valve

- 1 Pull connector off 3/2-way valve (**05.100**) and remove air connection (**7**).
- 2 Remove 2 M8 hex bolts (**05.110**). Lift off 3/2-way valve (**05.100**) and O-ring (ZF no. 0634 313 028).

Fitting 3/2-way valve

- 1 Use 2 M8 hex bolts (**05.110**) to secure new O-ring (ZF no. 0634 313 028) and 3/2-way valve (**05.100**).
M8 tightening torque = 23 Nm
- 2 Connect air connection (**7**).
Tightening torque:
M16x1.5 union screw = 45 Nm

14.6 Removing Intarder wiring harness

- 1 Remove 3 cable clips (**05.440**).
- 2 Remove 4 M4 bolts (**05.430**) and disconnect plug connections.

Fitting Intarder wiring harness

- 1 If the bracket (**05.410**) is damaged, replace it. Tighten M8 hex bolt (**05.420**) to 23 Nm.
- 2 Wiring harness assembly: with nose in upper position, use 4 M4 bolts (**05.420**) to fasten to bracket.
M4 tightening torque = 2 Nm
- 3 Use 3 cable clips (**05.440**) to fasten wiring harness to Intarder.

Connector and mating connector designations
ZF standard pneumatic circuit diagram

Steering wheel switch	0501 211 185
Display	0501 211 422
Wiring diagram for range selector	6006 700 579, 6006 700 586
E module (installation drawing)	6041 622 023
Wiring diagram	
Central consumer with ZF E module	6029 713 020
Central consumer with computer	6029 713 025
End consumer with ZF E module	6029 713 041
Connection diagram	
End consumer with ZF E module	6029 713 040

Connector and mating connector designations

10 AS 2301, 12 AS 2301, 16 AS 2601


Connector	Usage	Type	Manufacturer	ZF number	Manufacturer no.	CKD no.
X1	Transmission actuator	20-pin Bu	Kostal	6029 201 675	09432001 22124472200 10800444521 10800472632	6029 199 090
	Special version transmission actuator	18-pin Bu	Kostal	0501 317 367		
X36	ZF E module	35-pin	AMP	6029 201 262	925379-1 928544-1 925380-1 ISO-1481-screw ST 2.9X9.5-F ZF gasket 6020 303 013	6029 199 091
X21	Diagnosis	6-pin ST MNL	AMP	6029 201 121	926682-3 926887-1	6029 199 027
X21	Mating connector diagnosis	6-pin Bu MNL	AMP	6029 201 120	350715-1 926882-3	6029 199 092
X2	Range selector	14-pin Bu J.P.T	AMP	6029 201 403	927771-3 929504-5	6029 199 042
	Display	8-pin Bu JPT	AMP	6029 201 676	927771-3 929504-3	6029 199 108
	Output sensor	4-pin Bu DIN Bay. angle	AMP	6029 201 618		
X17	Power supply junction	22-pin Bu JPT	AMP	6029 201 336	927771-3 929504-7	6029 199 043
X17 A Mating connector	Power supply junction	22-pin St JPT	AMP	6029 201 354	928930-5 929505-7	6029 199 025
X18	Power supply junction	18-pin Bu JPT	AMP	6029 201 361	927771-3 929504-6	6029 199 084
X18 A Mating connector	Power supply junction	18-pin St JPT	AMP	6029 201 365	928930-5 929505-6	6029 199 026
X18 A Mating connector	CAN power supply junction	6-pin Bu JPT	AMP	6029 201 367		6029 199 109
X18 A Mating connector	CAN power supply junction	6-pin St JPT	AMP	6029 201 366		6029 199 110
X19	Cabin junction	18-pin Bu JPT	AMP	6029 201 361	927771-3 929504-6	6029 199 084
X20 Mating connector to X19	Cabin junction	18-pin St JPT	AMP	6029 201 365	928930-5 929505-6	6029 199 026

Changing the connector


If the connector has to be changed, please use the standard AMP tool.

For *wiring diagram*, refer to parts list.

Example 1



Example 2



Mechanische Daten im Schaltgehäuse:

Schaltwinkel: 8°
 Schaltstellungen: 2 (ohne Rastung mit Raststellung)
 Schaltfunktion: berührungsfreies Reedkontakt
 Material: Al-Druckguss / PA
 Lebensdauer: 1x10⁶ Schaltzyklen
 Betätigungsmoment: 115±20Nm
 Anschlagfestigkeit: >600Nm
 Befestigung: 2 Schrauben M5
 Anwendungsklasse: IP20 DIN40050
 im Griff:
 Schaltfunktionen: 1
 Lebensdauer: ≥10⁶ Betätigungen bei 2,5N

Elektrische Daten:


Betriebsspannung: 5V max. 40V
 Schaltstrom: max. 0,1A DC
 Ausgangsbelastung: siehe Schaltbild
 Gehäuse: potentialfrei!
 Temperaturbereich: -40°C bis 90°C

Mechanical Data of Housing:

operating angle: 8°
 switch positions: 2 (without catch with reset)
 switching function: sensorless Reedcontact
 Material: Al-diecast metal
 longevity: 1x10⁶ switching cycles
 actuation moment: 115±20Nm
 impact strength: >600Nm
 attachment/holding: 2 screws M5
 application grade: IP20 DIN40050
 of lever:
 switching functions: 1
 switching longevity: ≥10⁶ actuations at 2,5N

Electrical Data:

operating voltage: 5V max. 40V
 current on contact: max. 0,1A DC
 output wiring: see circuit diagram
 Housing: without potential
 Temperature range: -40°C to 90°C



Prüfbedingungen


- RI=4h
- voller Umfang
- alle Funktionen des Schalters unbetätigt
- Betriebsspannung U_B = 5V

Conditions of testing

- RI=4h
- full extent
- all functions of switch not actuated
- operating voltage U_B = 5V

Funktion / Function	Swachstellung / Position (S. 2)	Kontakt / Contact	Leitungsfarbe / Color of cable	Stimmkammer / Chamber	Stimmkammer / Chamber	B. Funktion / a. function betätigt / actuated
Hebel vorn / Actuator front	Kammer 2 / chamber 2	S1	blau / blue	offen / open	Kontakt zu gelb / Contact to yellow	
Hebel mitte / Actuator middle	Kammer 6 / chamber 6	S2	brown / brown	offen / open	Kontakt zu gelb / Contact to yellow	
Hebel hinten / Actuator rear	Kammer 3 / chamber 3	S3	rot / red	offen / open	Kontakt zu gelb / Contact to yellow	
Stimmkammer / Front button	Kammer 4 / chamber 4	S4	schwarz / black	offen / open	Kontakt zu gelb / Contact to yellow	
Common	Kammer 1 / chamber 1		gelb / yellow	offen / open	Kontakt zu gelb / Contact to yellow	

Schaltbild:



IND. NO.	MOD. NO.	REV. NO.	NAME	FILE
TECHNICAL INFORMATION				
TITLE DESCRIPTION				
DRAWING NO.				
SELEKTOR				
0	2421	1/99/99-04-12	SCHM	()
TECHN. INFORMATION				
IND. NO. MOD. NO. REV. NO. NAME FILE				
AS-IRONIC-KPL				
BENENNUNG SCHALTER				
ZEICHNUNGS-NUMMER 0501 211 185 (2)				

62 90 006 03

Werkstoffe / Material

Gehäuse / Housing PA 6 GF6K30 schwarz / black ca. RAL 9017
 Flachstecker / Connector Cu Zn 30 F 36 verzinkt / tinned

Steckerbelegung / Connector

Pin Nr.7: CAN L
 Pin Nr.5: CAN H
 Pin Nr.3: EU (light dimmed) on = VP
 Pin Nr.1: EDM (light on/off) on = GND
 Pin Nr.8: VP (Batt): 9V.....32V
 Pin Nr.6: VM (GND)
 Pin Nr.4: SD (ZF-Bus)
 Pin Nr.2: ADM(Piezo): I_{max} = 200mA
 Inductive




max. Stromaufnahme / current 80 mA
 Betriebstemperatur / working temperature -40°C....+80°C
 Lagertemperatur / storage temperature -40°C....+80°C
 Schutzart / Protection vorne IP54 hinten IP30

CAN



CAN Identiffter : Ox1C FF C803
 Baudrate : 250k
 Abschlusswiderstand : nicht bestueckt
 termination resistor: not assembled

Technische Daten nach Spezifikation ZF 1314 761 035
 Technical requirements according specification ZF 1314 761 035

Einbaumaße / Fit in dimension





Herstelldatum: Woche/Jahr
 Production date : week / year



Schaltbild /
 Electrical
 Connection

KLASSIFIZ.	NACH ZFN 904	d	0699/00	00-01-19	SCHWARZ
FREIGABE	99-03-31	IND ANZ	NR. AENDERUNGEN	DATUM	NAME FILM
DATUM	99-03-31	TECHN. INFORMATION			
<input checked="" type="checkbox"/> FREMDTITELDOKUMENTATION NACH ZFN 903	UNTERSCHRIFT		BENENNUNG		
<input type="checkbox"/> KUNDENBESTELL-ZEICHNUNG	KELLER		DISPLAY		
		ZEICHNUNGS-NUMMER		0501 211 422 (3)	

015 179





14-POL AMP
JUNCTION POWER TIMER
STIFT

AUSGABE SIGNAL X1 OUTPUT SIGNAL X1	TIPP CONTROL LEVER HEBEL ADJUSTOK STELLUNG POSITION			
	TS4	TS3	TS1	TS2
3	●	●		
4		●		
6			●	
7				●

AUSGABE SIGNAL X1 OUTPUT SIGNAL X1	DREH SCHALTER STELLUNG POSITION				
	DS1	DS2	DS3	DS4	DS5
12	●				
11		●			
9			●		


● = SIGNAL VORHANDEN
SIGNAL PRESENT




DREHSCHALTER S1
ROTARY SWITCH

COMPUTER DRAWING
DO NOT MODIFY ORIGINAL COPY
COMPUTER-ZEICHNUNG
ORIGINAL NICHT VERÄNDERN

THIS DRAWING MAY NOT BE COPIED OR DISCLOSED TO THIRD PERSONS WITHOUT PERMISSION OF ZF. MAKE THE OWNER OF THIS DESIGN. ZF FRIEDRICHSHAFEN AG		DIESE ZEICHNUNG DARF WEDER KOPIERT NOCH DRITS TERPERSOEN OHNE UNSERE DIESE KONSTRUKTION IST UNSER EIGENTUM. ZF FRIEDRICHSHAFEN AG	
CLASSIF.		CLASSIF.	
SCALE IF UN- SPELIFIED		DRAWING DESIGN STAND.	
TECHNICAL INFORMATION SELECTOR ASTRONIC		DRAWING No.	
CIRCUIT-DIAGRAM		SHEET DIN	
MASS-STAB WO NICHTS ANGEBOBEN		BEARB. 30.01.98 KALLWAJ KONSTR. 29.05.98 KELLER NORM 9	
TECHN.- INFORMATION ASTRONIC, SCHALTER STROMLAUFPLAN		ACC. ZFN 904 SIMILAR DRAWING NACH ZF1904 AENL. ZEICHN.-NR. 6006 700 567	
BEZUGS- ZEICHNUNG		ZEICHNUNG-NR. 6006 700 579	
DRAWING No.		DATE NAME FILM	
IND No. MOD. No. DATE NAME FILM MODIFICATIONS		DATE NAME FILM	
IND ANZ NR. DATUM NAME FILM ÄNDERUNGEN		DATE NAME FILM	




AUSGABE Output SIGNAL	1	2	3		
AD1	●				
AD2		●			
AD3			●		



FAHR
BEREICH
SELECTOR
RANGE
FAHRSCHALTER AS11
SELECTOR AS11

● = SIGNAL VORHANDEN
○ = SIGNAL NICHT VORHANDEN




6-POLE AMP
JUNIOR POWER
TIMER
STIFT

ANSCHLUSS X1
CONNECTION

X1

ZF THIS DRAWING MAY NOT BE COPIED OR DISCLOSED TO THIRD PERSONS WITHOUT THE WRITTEN PERMISSION OF ZF FRIEDRICHSHAFEN AG. WE ARE THE OWNER OF THIS DESIGN.

CLASSIF.:



KLASSIFIZ.:

ZF DIESE ZEICHNUNG DARF WEDER KOPPIERT NOCH DRITTEN PERSONEN OHNE UNSERE ERLAUBNIS MITGETEILT WERDEN. DIESE KONSTRUKTION IST UNSER EIGENTUM. ZF FRIEDRICHSHAFEN AG

COMPUTER DRAWING
DO NOT MODIFY ORIGINAL COPY
COMPUTER-ZEICHNUNG
ORIGINAL NICHT VERÄNDERN


SCALE	DRAWN	IND. No.	MOD. No.	DATE	NAME	FILM
1 : 1						

WIRING DIAGRAM

TECHN. INFORMATION	DRAWING No.	SHEET	OF	DATE
MASS-STAB KONSTR. 24.09.98 KORR	6006 700 586	1	1	11.06.99


TECHN. INFORMATION	DRAWING-NR.	BLATT	DN
AS11 STROMLAUFPLAN	6006 700 586	01	A2

ZULAESSIGE EINBAULAGEN
POSSIBLE FITTING POSITIONS



TECHNISCHE DATEN
TECHNICAL FEATURES

FORMISCH: KONTAKT: 6006 / 61 005
 NENNSPANNUNG: U_n = 24V/2V
 NENNSTROM: I_n = 4A
 STROMLEISTUNG: P_{max}
 TEMPERATURBEREICH: 0°C bis +40°C
 LAGERSPEICHERUNG: +40°C bei 95% Rel. Luftfeuchte, -40°C bei 95% Rel. Humidity
 DIMENSIONEN: L: 64 mm, DIN 40050; B: 41,8 mm, DIN 40050; S: 11,8 mm; MONTAGEWEISE: MIT STECKER AN VERBINDUNGS-EINBAULAGEN
 IDENTIFIZIERUNG: BY USING PLUG ASSY-DRAWING 6029 201 028 (3)
 MASSEBAND VERBUNDEN WERDEN
 TYPISCHE EIGENSCHAFTEN: DAS GEHÄUSE DES ELEKTRONBAUSTEINS MASS MIT DER MASSMASSE DER EINBAULAGE AN EINEM GESCHÜTZTEN ZIT EINZUBAUEN
 TYPISCHE EIGENSCHAFTEN: T-FÜR ÜSTUNG AUF DEN THELEKTRONIK KONTROLLE LINE MÜSST BE VERBUNDEN ZU THE MASSIS GROUND VIA A BRIDGING STRIP
 DAS ELEKTRONBAUSTEIN SOLLTE IM FALLE EINES UNTERSCHIEDS ZWISCHEN DEN FREILEGENEN EINBAULAGEN AN EINEM GESCHÜTZTEN ZIT EINZUBAUEN
 THE ELECTRONIC CONTROL UNIT MUST BE INSTALLED ON ONE OF THE APPROVED PROTECTIVE LOCATIONS




COMPUTER DRAWING
 DO NOT MODIFY ORIGINAL COPY
 COMPUTER-ZEICHNUNG
 ORIGINAL NICHT VERÄNDERN

SCALE MÄSSSTAB	DATE	NO.	REV.	DESCRIPTION
				REVISIONEN
DRAWN GEZEICHNET			DATE	NO.
CHECKED GEPRÜFT			DATE	NO.
APPROVED GEBILDEGT			DATE	NO.
DESIGNED ENTWURFEN			DATE	NO.
DRAWN GEZEICHNET			DATE	NO.
CHECKED GEPRÜFT			DATE	NO.
APPROVED GEBILDEGT			DATE	NO.
DESIGNED ENTWURFEN			DATE	NO.


GLASBECK
 THIS DRAWING MAY NOT BE COPIED
 OR REPRODUCED IN ANY FORM
 OR BY ANY MEANS WITHOUT THE
 WRITTEN PERMISSION OF THE
 DRAWING OFFICE
 1. PLUMBING AND 7.2

ELECTRON MODULE
 THIS DRAWING MAY NOT BE COPIED
 OR REPRODUCED IN ANY FORM
 OR BY ANY MEANS WITHOUT THE
 WRITTEN PERMISSION OF THE
 DRAWING OFFICE
 1. PLUMBING AND 7.2

ELEKTRON-BAUST. 6041 622 023
 REVISIONEN
 BLATT 1001




wiring diagram:
6029.713.021




- 35 17
- 34 16
- 33 15
- 32 14
- 31 13
- 30 12
- 29 11
- 28 10
- 27 9
- 26 8
- 25 7
- 24 6
- 23 5
- 22 4
- 21 3
- 20 2
- 19 1


RMP
35-POL-
BUCHSE




20POL
KOSTAL
BUCHSE
VORN




14-POL RMP
JUNIOR POWER TIMER
BUCHSE



6POL RMP
MATE-N-LOK
STIFT



6-POL RMP
JUNIOR POWER TIMER
BUCHSE



CANNON
10-POL-VG
BUCHSE


POLBILD
zu R36

Polbild zu R1
X1R/X1B

POLBILD
zu R2

POLBILD
zu R21

R 1	Elektr. Steuergeraet EST	Electronic Control Unit ECU
R 2	Fahrschalter	Shift lever
R 4	Kupplungssteller mit Sensorik	Clutch actuator with Clutch position sensor
R 5	Display	Display
R 11	Drehzahlgeber Rottrieb	Sensor Output Speed
R 13	Tachograph	Tachograph
R 14	Drehzahlgeber Rottrieb Tacho	Sensor Output Speed Tacho
R 21	Diagnoseschnittstelle nach DIN ISO 9141	Diagnostic Interface DIN ISO 9141
R 23	Fahrzeug CAN-Schnittstelle	CAN Vehicle Interface
B 4	Sensor "Gang eingelegt"	Switch Gear Engaged
B 5	Megsensor "Maehlen"	Position Sensor "Select"
B 6	Megsensor "Gruppe"	Position Sensor "Range Group"
B 7	Megsensor "Splitter"	Position Sensor "Split"
F 1	Sicherung 10R (K1.30)	Fuse 10R
F 2	Sicherung 10R (K1.15)	Fuse 10R
H 8	Lampe Steuerung	Warning Lamp
H 9	Warnsumner	Buzzer
E 11	PTO 1	PTO 1
E 12	PTO 2	PTO 2
E 13	Rueckfahrseinwerfer	Reversing Light
E 22	Limp home	Limp home
S 4	Schalter Nebenabtrieb 1	Switch PTO 1
S 5	SchalterNebenabtrieb 1 Rückmeldung	Switch PTO 1 Acknowledge
S 8	Tuerschalter	Door Switch
S 13	Schalter Nebenabtrieb 2	Switch PTO 2
S 14	SchalterNebenabtrieb 2 Rückmeldung	Switch PTO 2 Acknowledge
Y 14	MV Kuppl. schliessen schnell (Entlueften)	Sol. Valve Clutch Engage Fast
Y 15	MV Kuppl. schliessen langsam (Entlueften)	Sol. Valve Clutch Engage Slow
Y 16	MV Kuppl. oeffnen schnell (Belueften)	Sol. Valve Clutch Disengage Fast
Y 17	MV Kuppl. oeffnen langsam (Belueften)	Sol. Valve Clutch Disengage Slow





Techn. Information Technical Information
AS TRONIC 2 Mittelteilnehmer


Benennung / Description
STROMLAUFPLAN
 CIRCUIT DIAGRAM

Zeichnungs-Nr. Drawing-No.
6029.713.025

Ind.	Blatt	DIN
	Sheet	
	of	
	1	2
	2	2



R 1	Legende Deutsch Elektro. Steuergeraet EST	Legende Englisch Electronic Control Unit ECU
R 4	Kuppelungssteller mit Sensor-ik	Clutch actuator with clutch position sensor
R 5	Display	Display
R11	Drehzahlgeber Abtrieb	Sensor output speed
R21	Diagnoseschnittstelle nach DIN ISO 9141	Diagnostic Interface DIN ISO 9141
R23	CNN Systemschnittstelle	CNN System Interface
R24	ZF CNN Schnittstelle	ZF CNN Interface
F 1	Sicherung 10A (K1.30)	Fuse 10A
F 2	Sicherung 10A (K1.15)	Fuse 10A
Y14	MV Kuppl. schliessen schnell (Entlueften)	Sol. valve clutch engage fast
Y15	MV Kuppl. schliessen langsam (Entlueften)	Sol. valve clutch engage slow
Y16	MV Kuppl. oeffnen schnell (Belueften)	Sol. valve clutch disengage fast
Y17	MV Kuppl. oeffnen langsam (Belueften)	Sol. valve clutch disengage slow



wiring diagram:
6029.713.040


Techn. Information Technical Information
AS TRONIC 2 Endteilnehmer

Benennung / Description
Stromlaufplan
Circuit Diagram


Zeichnungs-Nr. Drawing-No.
6029.713.041

Ind. Blatt von
Sheet of
1 2


DIN



POLBILD zu R1
zu R36
X1R/X1B




RMP Timer
35-pin



Kostal
20-pin

POLBILD zu R2




RMP JPT
14-pin

POLBILD zu R5




RMP JPT
8-pin

POLBILD zu R21





RMP M-N-L
5-pin

POLBILD zu R4








Cannon VG95234
18-pin

R 1	Elektr. Steuergeraet EST	Electronic Control Unit ECU
R 2	Fahrerschalter	Shift lever
R 4	Kupplungssteller mit Sensorik	Clutch actuator with Clutch position sensor
R 5	Display	Display
R 11	Drehzahlggeber Abtrieb	Sensor Output Speed
R 13	Tachograph	Tachograph
R 14	Drehzahlggeber Abtrieb Tacho	Sensor Output Speed Tacho
R 21	Diagnoseschnittstelle nach DIN ISO 9141	Diagnostic Interface DIN ISO 9141
R 23	Fahrzeug CRN-Schnittstelle	CRN Vehicle Interface
F 1	Sicherung 10R (K1.30)	Fuse 10R
F 2	Sicherung 10R (K1.15)	Fuse 10R
H 8	Lampe Stoerung	Warning Lamp
H 9	Warnsummer	Buzzer
E 11	PTO 1	PTO 1
E 12	PTO 2	PTO 2
E 13	Rückfahrseinerfer	Reversing Light
E 22	Limp home	Limp home
S 4	Schalter Nebenabtrieb 1	Switch PTO 1
S 5	SchalterNebenabtrieb 1 Rückmeldung	Switch PTO 1 Acknowledge
S 8	Tuerschalter	Door Switch
S 13	Schalter Nebenabtrieb 2	Switch PTO 2
S 14	SchalterNebenabtrieb 2 Rückmeldung	Switch PTO 2 Acknowledge
Y 14	MV Kuppl. schliessen schnell (Entlueften)	Sol. Valve Clutch Engage Fast
Y 15	MV Kuppl. schliessen langsam (Entlueften)	Sol. Valve Clutch Engage Slow
Y 16	MV Kuppl. oeffnen schnell (Belueften)	Sol. Valve Clutch Disengage Fast
Y 17	MV Kuppl. oeffnen langsam (Belueften)	Sol. Valve Clutch Disengage Slow



STROMLAUFPLAN:
6029.713.041

MC:+B/1.1	901	1	<- BORDNETZ(K1.30)
MX:+B/1.3	901	2	<- BORDNETZ(K1.30)
MU:EF/1.1	918	3	<- ABTRIEBSDREHZAHL
MV:OP/1.1	919	4	<- (LIMP HOME)
MZ:+Bel/1.1	948	5	<- (+) BEL. DISPLAY
	?	6	
X35:31/1.2	431	7	-> Res.
WK:K/1.3	907	8	-> K-LEITUNG
MR:+Z/1.3	900	9	<- BORDNETZ(K1.15)
X36:13/1.2	413	10	<- PTO 2 ANFORDERUNG
ME:-/1.3	902	11	<- BORDNETZ(K1.31)
MY:-/1.3	902	12	<- BORDNETZ(K1.31)
MJ:+H/1.3	906	13	-> RDVP
X36:16/1.2	416	14	-> WRRNSUMMER
X36:33/1.2	433	15	-> LAMPE STÖRUNG
X36:24/1.2	424	16	<- PTO 1 ANFORDERUNG
X36:30/1.2	430	17	<- TÜRSCHALTER
X36:14/1.2	414	18	-> RÜCKLICHT
X36:23/1.2	423	19	<- PTO 1 RÜCKMELDUNG
X36:5/1.2	406	20	<- PTO 2 RÜCKMELDUNG
X36:15/1.2	415	21	<- RELAIS PTO 1
X36:32/1.2	432	22	<- RELAIS PTO 2



STROMLUFPLRN:
6029.713.041