CONTENTS

SECTION CHANGE LOG		
1.	TORQUE TABLES	3
1	.1 FRONT I-BEAM AXLE AND RELATED COMPONENTS	3
1	2 FRONT I-BEAM AXLE HUB, ROTOR AND BRAKES	5
2	DESCRIPTION	6
۷.		0
2	2.1 REFERENCE MANUALS	6
3.	LUBRICATION	8
4.	MAINTENANCE	8
5		8
5.		
5	5.1 REMOVAL	8
5	5.2 REPLACEMENT	9
6.	SERVICE INSTRUCTIONS FOR STEER AXLE	10
e	5.1 STEERING KNUCKLE KINGPIN INSPECTION	10
	6.1.1 Checking Lateral Slackness	10
	6.1.2 Checking Vertical Slackness	10
e	5.2 STEERING TIE ROD INSPECTION	10
7.	FRONT WHEEL ALIGNMENT	10
8.	SPECIFICATIONS	11

SECTION CHANGE LOG

DESCRIPTION		
1		
2		
3		
4		
5		
6		

1. TORQUE TABLES

The following tables list the tightening torques requiring a specific torque value. When no torque specifications are indicated, use the Standard Torque Specifications table found in Section 00: General Information of the Maintenance Manual.

For other torgue specifications, refer to Dana manuals listed in paragraph 2.1 reference manuals in this section.

18 12 3 5 2 4 16188_1 16187 89 10,11 8 9 7 11 16192_1

FRONT I-BEAM AXLE AND RELATED COMPONENTS 1.1

	13 14		
	FRONT I-BEAM AXI	E	
No	DESCRIPTION	QTY	TORQUE (dry)
1	Sway bar link, upper and lower nuts	4	165-200 lb-ft (224-271 Nm)
2	Sway bar bushing collars (front suspension)	8	80-100 lb-ft (108-136 Nm)
3	Tie rod end clamp bolts	2	118-133 lb-ft (160-180 Nm)
4	Tie rod end ball pin nuts		155-170 lb-ft (210-230 Nm)
5	Steering arm stud nuts		285-315 lb-ft (386-427 Nm)
6	Tie rod arm stud nuts	4	285-315 lb-ft (386-427 Nm)
7	I-beam axle mount nuts	8	230-280 lb-ft (312-380 Nm)
8	Shock absorber upper & lower mounting nuts	2	99-121 lb-ft (134-164 Nm)
9	Shock absorber pins, upper & lower	2	350-400 lb-ft (475-542 Nm)
10	10 Radius rod retaining studs		90-110 lb-ft (122-149 Nm)
11	Radius rod retaining nuts	18	225-255 lb-ft (305-346 Nm)
12	Transverse radius rod taper pin screw	1	206 lb-ft (279 Nm)
13	Drag link clamp bolts	2	118-133 lb-ft (160-180 Nm)
14	14 Drag link ball joint stud nut, fore		165-236 lb-ft (224-320 Nm)
15	15 Steering damper nuts		100-120 lb-ft (136-163 Nm)
16	16 Steering damper bracket bolt		39-45 lb-ft (53-61 Nm)
17 Steering damper bracket nuts		4	30-36 lb-ft (41-49 Nm)
18 Air spring nut		4	25 lb-ft (34 Nm)
19	19 Steering damper arm nuts		285-315 lb-ft (386-427 Nm)
20 Drag link ball joint stud nut, aft			140-200 lb-ft (190-271 Nm)

1.2 FRONT I-BEAM AXLE HUB, ROTOR AND BRAKES



2. DESCRIPTION

The Dana Spicer S84U front axle is of the "Reverse Elliot" type. The front axle consists of a girder section beam with knuckles. Each knuckle is carried on a parallel king pin, with a steep angle taper roller bearing at its top and a plain phosphor bronze bush at bottom.

The unitized hub bearings used on the NDS range of axles, are non-serviceable items. Bearings are preadjusted, lubricated and have seals fitted as part of the manufacturing process. The bearings are greased for life and there is no need or facility for re-lubrication.

Brakes are manufactured by KNORR-BREMSE.

Steering ball joints with hardened balls and rubbing pads incorporate compression springs which automatically take up any wear.

The tie rod simplifies toe-in adjustment. The maximum turning angle is set through stop screws installed on the inner side of the knuckle.

Steering stabilizer (damper) and steering drag link which are mounted on the front axle are described further in Section 14: STEERING of this manual.

2.1 REFERENCE MANUALS

Additional information is found in the following manuals included on your vehicle Technical Publications USB flash drive:

For kingpin rework:

Dana Parts & Service Instructions S84U Steer Axle KING PIN REWORK_ Manual NO 1985 B iss A

For hub bearing rework:

Dana Parts & Service Instructions S84U Steer Axle HUB BEARING REWORK_ Manual NO 1963 B iss A



	TYPICAL S84U AXLE				
ITEM	DESCRIPTION	QTY	ITEM	DESCRIPTION	QTY
1	Flanged Bolt	28	29	Cap - Knuckle Top	2
2	Hub	2	30	Top Steering Lever	1
3	Brake Disc	2	31	Top Steering Lever - Stud L.H.	2
4	Nut – Self Lock	4	32	Top Steering Lever - Stud R.H.	2
5	Brake L.H.	1	33	Nut - Self Lock	8
6	Brake R.H.	1	34	Drawkey - Nut	2
/	Stake Nut	2	35	Drawkey - Washer	2
0		2	30	Drawkov	1
10	Wear Sensor Clip	2	38	V Ring Seal	2
11	Nut – Self Lock	16	39	Back Lock - Stop Bolt	2
12	Brake Mounting Bracket L.H.	1	40	Front Lock - Stop Bolt	1
13	Brake Mounting Bracket R.H.	1	41	Stop bolt - washer	4
14	Actuator L.H.	1	42	ABS Sensor - Bush	2
15	Actuator R.H.	1	43	Bottom Steering Lever L.H.	1
16	Stud	16	44	Bottom Steering Lever R.H.	1
17	Brake fixing - Bolt	12	45	Bottom Steering Lever - Stud	2
18	Knuckle L.H.	1	46	Nut - Self Lock (Tie Rod)	2
19	Knuckle R.H.	1	47	Socket & Tie Rod Assy	
20	Uli Seal Sloova Knuckla Desting	2	48	SOCKELASSY K.H.	2
21	Shim		49 50	Kipapin - Bushing	2
22	Bearing Cup	7 A/R	50		2
23	Bearing Cope	<u> </u>	52	Kingnin	2
24	Washer (Collet)	1	53	Washer	2
20	Nut – Self Lock	2	54	Can - Knuckle Bottom	2
20					
27	Lub Nipple (Straight)	2			-

3. LUBRICATION



Knuckle pins are provided with grease fittings for pressure lubrication. These grease fittings should be serviced at the intervals specified by the Lubrication And Servicing Schedule in Section 24: LUBRICATION & SERVICING.

Good quality lithium-base roller bearing mineral grease NLGI No.1 and 2 like Shell Retinax LX are recommended.



FIGURE 2: FRONT AXLE GREASING POINTS

4. MAINTENANCE

A periodic inspection of the front axle assembly should be made to check that no damage and distortion have taken place. All the bolts and stop screws should be checked and tightened, as required, to the torque specifications given at the beginning of this section. Also check the condition of the steering knuckle kingpins and bushings. In case of excessive looseness, the bushings and kingpins should be replaced.

Any looseness in the steering linkage, under normal steering loads, is sufficient cause to immediately check all pivot points for wear, regardless of accumulated mileage. Steering linkage pivot points should be checked each time the front axle assembly is lubricated. Any looseness can be visually detected while rotating the steering wheel in both directions. Steering knuckles, knuckle pins and bushings can be overhauled or replaced without removing the axle from the vehicle. However, if extensive overhaul work is necessary, the axle assembly should be removed.

Should removal of a locking device be required when undergoing repairs, disassembly or adjustments, always replace with a new one.

5. REMOVAL AND REPLACEMENT

The following procedure deals with the removal of the front axle assembly. The method used to support the axle assembly and suspension components during removal and disassembly depends upon local conditions and available equipment.

5.1 REMOVAL

 Raise the vehicle by its jacking points on the body (see Section 18, "Body" under paragraph "Vehicle Jacking Points") until vehicle body is approximately 20 inches (508 mm) from the floor. Place jack stands under frame. Remove the wheels (if required, refer to Section 13, "Wheels, Hubs and Tires").

Use only the recommended jacking points as outlined in section 18 "Body".

- 2. Exhaust compressed air from the air supply system by opening the drain valve of each reservoir.
- 3. Install jacks under axle jacking points to support the axle weight.
- 4. Disconnect the steering drag link from the steering arm.
- 5. Remove the ABS sensors from their location in hubs (if applicable).
- 6. Disconnect the height control valve link from its support on the axle.
- 7. Disconnect air lines from front brake chambers, and cover line ends and fittings to prevent the entry of foreign matter.

Position the air lines and electric wires so they will not be damaged while removing the front axle assembly.

- 8. Proceed with steps a, b and c, while referring to Section 16: "SUSPENSION".
 - a) Disconnect sway bar links from axle brackets.
 - b) Remove shock absorbers.
 - c) Disconnect five radius rods: one transversal and two longitudinal from subframe, and two upper rods from axle.
- 9. Remove the bolts and nuts fixing the axle to the left-hand and right-hand side air springs mounting supports.
- 10. Using the jacks, slowly lower the axle assembly, and carefully pull away from underneath vehicle.

5.2 REPLACEMENT

Reverse front axle "*Removal*" procedure. Ensure cleanliness of air bellows support mounting plates.

NOTE

Refer to Section 16, "Suspension", Section 14, "Steering" and to paragraph 8 "Specifications" at the end of this section for applicable checks.

Refer to torque tables at the beginning of this section for tightening.

6. SERVICE INSTRUCTIONS FOR STEER AXLE

MAINTENANCE

An inspection should be made at the intervals specified by the Lubrication And Servicing Schedule in Section 24: LUBRICATION & SERVICING.

6.1 STEERING KNUCKLE KINGPIN INSPECTION

Check permissible slackness in the kingpins as follows:

Aspects to be considered are:

Lateral slackness

• Vertical slackness

NOTE

Before commencing checks, apply parking brake, raise wheels off ground and support axle on stands.

6.1.1 Checking Lateral Slackness

Following regular and thorough greasing practices will maximise bushing life. This procedure measures the upper bearing & lower bushing wear due to side and vertical loading. While this is being carried out, the brake must be applied.

- 1. Place a set-square with its stock on ground and its blade against tire wall.
- 2. Place a mark on the ground to indicate position of stock end.
- Insert a lever through bottom cut-out of wheel and lever it upwards thus moving set-square outboard.
- 4. Mark the changed position of the stock end.
- 5. Maximum allowable stock displacement (for 22.5" wheels) is **0.315 in (8mm)**.
- 6. If displacement exceeds stated allowance then need for bushing / bearing attention and possible renewal, is in evidence.

NOTE

To avoid inaccurate measurements, be careful not to let the knuckle turn while moving assembly in and out. Applying brakes will help lock wheel assembly.

6.1.2 Checking Vertical Slackness

- 1. This is measured by a dial indicator anchored to axle beam and having its pointer placed vertical against knuckle top.
- 2. Place a jack against underside of knuckle and, while applying a lifting force, observe any movement on indicator dial.
- 3. If vertical movement is evident and it exceeds 0.030" (0.76mm) then readjustment of knuckle is required by adjusting thickness of bearing adjusting shims. In this case, refer to:

Dana Parts & Service Instructions S84U Steer Axle KING PIN REWORK_ Manual NO 1985 B iss A.

6.2 STEERING TIE ROD INSPECTION



FIGURE 3

The steering tie rod on the axle requires several visual and functional inspections. Refer to Section 14– STEERING under heading FRONT I-BEAM AXLE TIE ROD.

Detailed information can also be found in the following supplier publication:

TRW_Front_Axle_Steering_Bar_Service_Info rmation_XSZ143

7. FRONT WHEEL ALIGNMENT

Refer to Section 14: STEERING.

8. SPECIFICATIONS

Front Axle

Make	
Model	
Front Track	
Rated load capacity	