LAZER FORMAT "A" SCALE 3.2:1

CONNECTORS CODE ID) Page G-1

No.	LOCATION	#ND TYPE	*PIN CAVITY	*SOCKET HOUSING	HOUSING
C1	FR JCT BOX COMPARTMENT	AMP CPC	37	560644	560646
C2	FR JCT BOX COMPARTMENT	AMP CPC	24	560641	560643
C3	FR JCT BOX COMPARTMENT	AMP CPC	37	560734	560713
C4	FR JCT BOX COMPARTMENT	AMP CPC	16	560693	560695
C5	FR SERVICE COMPT.-UNDERNEATH	AMP CPC	37	560644	560646
C6	FR SERVICE COMPT.-UNDERNEATH	AMP CPC	24	560641	560643
C7	FR JCT BOX COMPT.-UNDERNEATH	AMP CPC	24	561561	561566
C8	FR SERVICE COMPT.-UNDERNEATH	AMP CPC	37	560734	560713
C9	AL-ARM JCT BOX	AMP CPC	24	560641	560643
C10	AL-ARM JCT BOX	AMP CPC	37	560644	560646
C11	FR SERVICE COMPARTMENT	AMP CPC	24	560642	560643
C12	FR SERVICE COMPARTMENT	AMP CPC	16	560629	560630
C13	FR SERVICE COMPT.	AMP HNL	6	560920	560915
C15	RR JCT BOX	AMP CPC	24	560641	560643
C16	LH CONSOLE SW-CRUISE ON OFF	SWF	8	-------	561087
C17	LH CONSOLE SW-CRUISE RESUME	SWF	8	-------	561087
C18	LH CONSOLE SW-CRUISE SET	SWF	8	-------	561087
C19	FR JCT BOX-CONDUCTOR	AMP CPC	24	560641	560643
C21	RR JCT BOX	AMP CPC	24	560641	560643
C32	DDEC ENGINE-ECM	PED	38	-------	560680
C45	AL-ARM JCT BOX COMPARTMENT	AMP CPC	24	560642	560643
C47	FR SERVICE COMPARTMENT	AMP CPC	16	560694	560695
C49	BATTERIE COMPT.-L.T	AMP HNL	2	560248	560247
C52	RR JCT BOX	AMP CPC	22	561789	561718
C53	RR JCT BOX	AMP CPC	14	561585	561584
C55	UNDER DASH-SW PANEL	AMP CPC	9	560636	561837
C56	UNDER DASH-SW PANEL	AMP CPC	9	560636	561837
C57	UNDER DASH-SW-ACCESSORIES	AMP CPC	22	561789	561718
C58	EVAPORATOR COMPARTMENT	AMP CPC	14	561585	561583
C59	EVAPORATOR COMPARTMENT	AMP CPC	16	560629	560648
C60	RR JCT BOX COMPT.-LT	AMP HNL	2	560248	560247
C61	LUGGAGE COMPARTMENT L.T.S	AMP HNL	2	560248	560247
C62	LUGGAGE COMPARTMENT L.T.S	AMP HNL	2	560248	560247
C63	LUGGAGE COMPARTMENT L.T.S	AMP HNL	2	560248	560247
C64	LUGGAGE COMPARTMENT L.T.S	AMP HNL	2	560248	560247
C65	LUGGAGE COMPARTMENT L.T.S	AMP HNL	2	560248	560247
C66	LUGGAGE COMPARTMENT L.T.S	AMP HNL	2	560248	560247
C67	LUGGAGE COMPARTMENT L.T.S	AMP HNL	2	560248	560247
C68	LUGGAGE COMPARTMENT L.T.S	AMP HNL	2	560248	560247
C69	RR-AXLE ACC-INSIDE PVC END	PED WP	6	561568	561578
C70	AL-ARM JCT BOX COMPARTMENT	AMP CPC	24	560642	560643
C71	UNDER INSTRUMENT PANEL-LH	AMP CPC	37	560645	560646
C72	UNDER INSTRUMENT PANEL-CENT.	AMP CPC	37	560645	560646
C73	UNDER INSTRUMENT PANEL-CENT.	AMP CPC	16	560629	560648
C74	UNDER INSTRUMENT PANEL-RH	AMP CPC	24	560642	560643

CONNECTORS CODE ID) Page G-1

No.	LOCATION	#ND TYPE	*PIN CAVITY	*SOCKET HOUSING	HOUSING
C76	LUGGAGE COMPT.-AIR RECEIVER	AMP HNL	2	560248	560247
C77	LUGGAGE COMPT.-AIR RECEIVER	AMP HNL	2	560248	560247
C78	FR JCT BOX COMPARTMENT	AMP CPC	22	561789	561718
C80	LUGGAGE COMPT.-UNDERNEATH	AMP CPC	37	560644	560646
C81	LUGGAGE COMPT.-DOOR LOCK	AMP HNL	4	561551	561668
C82	LUGGAGE COMPT.-DOOR LOCK	AMP HNL	4	561551	561668
C83	LUGGAGE COMPT.-DOOR LOCK	AMP HNL	4	561551	561668
C84	LUGGAGE COMPT.-DOOR LOCK	AMP HNL	4	561551	561668
C85	LUGGAGE COMPT.-DOOR LOCK	AMP HNL	4	561551	561668
C86	LUGGAGE COMPT.-DOOR LOCK	AMP HNL	4	561551	561668
C87	RR END ROOF	AMP CPC	9	560636	561837
C88	RR END ROOF-CLEARANCE LTS	AMP HNL	2	560900	560898
C89	RR END ROOF-B/U HORN/TONE	AMP CPC	4	560582	561581
C90	RR JCT BOX	AMP CPC	15	561987	561986
C91	RR JCT BOX	AMP CPC	9	560636	561837
C92	FR JCT BOX COMPT.-WATI SK32	AMP CPC	9	561635	561637
C93	FR JCT BOX COMPT.-WATI SK32	AMP CPC	9	561635	561637
C95	FR AXLE ACCESSORIES	AMP CPC	24	560585	560585
C97	RR AXLE ACC-INSIDE PVC END	PED WP	6	561568	561578
C98	FR SERVICE COMPT.-ELC.F.SPEDAL	PED WP	3	561780	561781
C99	FR SERVICE COMPT.-LTS	AMP HNL	2	560248	560247
C100	FR SERVICE COMPT.-CONNECTS.LT	PED WP	2	561566	561690
C101	FR SERVICE COMPT.-ELEC.-HORNS	PED WP	2	561566	561690
C102	FR SERV & SIDE CPT.-FLUSH.LH	ITT SS	2	561813	561812
C103	FR SERV & SIDE CPT.-HARNESS	ITT SS	2	561813	561812
C104	FR SERV & SIDE CPT.-HARNESS	ITT SS	2	561813	561812
C105	FR SERVICE COMPT.-L.D.S.ALM	PED WP	2	561566	561690
C106	FR SERVICE COMPT.-WATER VALVE	PED WP	2	561566	561690
C107	EVAPORATOR COMPT.-DAMPER	PED WP	2	561566	561690
C111	EVAPORATOR COMPT.-DAMPER	ITT SS	2	561813	561812
C112	BATT.& RR JCB.PT.HARNESS	ITT SS	2	561813	561812
C115	ENGINE COMPT.-AIR DRYER	PED WP	2	561566	561690
C116	ENGINE COMPT.-LTS	PED WP	3	561780	561781
C119	ENGINE CPT-RR DOOR-RH.D.LAMP	PED WP	6	561600	561607
C120	ENGINE CPT-RR DOOR-RH.D.LAMP	PED WP	6	561600	561607
C121	BATTERIE CPT.-DOOR DR.LT.RH	ITT SS	2	561813	561812
C122	ENGINE CPT-CAMERA-DOOR VALVE	PED WP	2	561566	561690
C123	ENGINE CPT-ETHER SW	PED WP	2	561566	561690
C124	RR JL-BOX CPT-DOOR DIR LT LH	ITT SS	2	561813	561812

CONNECTORS CODE ID) Page G-2

No.	LOCATION	#ND TYPE	*PIN CAVITY	*SOCKET HOUSING	HOUSING
C125	ENGINE CPT-RH U-ALARM	PED WP	2	561566	561690
C127	ENGINE CPT-FUEL FILTER	PED WP	2	561566	561690
C129	ENGINE CPT-A/C COMPR.CLUTCH	ITT SS	2	561813	561812
C129	ENGINE CPT-FREI-HEAT WATER	AMP FTE	6	561672	561686
C130	ENGINE CPT-DOOR	ITT SS	2	561813	561812
C131	ENGINE CPT-UALDOOR	ITT SS	2	561813	561812
C132	ENGINE CPT-A/C-LO.PRESS SW	PED WP	2	561566	561690
C133	ENGINE CPT-A/C-HI PRESS SW	PED WP	2	561566	561690
C134	ENGINE CPT-RR DOOR-DOOR CYL	AMP HNL	15	561987	561986
C135	FR JCT BOX-LUGGAGE DOOR CYL	AMP HNL	15	561987	561986
C136	A/C JCT BOX-PRIORI.	WEAH	37	561741	561744
C137	A/C JCT BOX	DEUTSCH	14	562281	562294
C137	A/C JCT BOX-TRANSMITTER	AMP HNL	2	560900	560898
C138	A/C JCT BOX-CONTROL MODULE	AMP HDP	15	-------	562002
C139	A/C JCT BOX-LOGIC MODULE	AMP HDP	15	562001	-------
C230	A/C JCT BOX-CONNECTOR	AMP HNL	9	560636	561837
C146	ENGINE CPT-MODULATOR VALVE	AMPHNDL	2	-------	560412
C147	ENGINE CPT-RR DOOR-DOOR CYL	AMP HNL	15	561987	561986
C148	FR JCT BOX-COMPT.-LTS	AMP CPC	14	561585	561583
C149	CONDENSER CPT-FAN MOTOR	ORDNANCE	3	562555	562600
C152	CONDENSER CPT-ELC.F.SPEDAL	PED WP	2	561566	561690
C153	EVAPORATOR CPT-AIR AMB.SENS	AMP HNL	2	560248	560247
C154	EVAPORATOR CPT-FRESH-AIR SENS	ITT SS	2	561813	561812
C155	EVAPORATOR CPT-WATER VALVE	PED WP	4	561610	561611
C157	EVAPORATOR CPT-WATER VALVE	PED WP	2	561566	561690
C158	CONDENSER CPT-HI-C.L.D.TEMP.	PED WP	2	561566	561690
C159	CONDENSER CPT-LO-C.L.D.TEMP.	PED WP	2	561566	561690
C160	FR AXLE-ABS-WATCH-L	SWF	8	-------	561087
C161	FR AXLE-ABS-RH VALVE	MABCO	3	-------	610198
C162	FR AXLE-ABS-LH VALVE	MABCO	3	-------	610198
C163	FR AXLE-ABS-LH SENSOR	MABCO	2	641132	-------
C164	FR AXLE-ABS-LH SENSOR	DEUTSCH	2	562485	562485
C165	FR AXLE-ABS-LH VALVE	MABCO	3	-------	610198
C166	FR AXLE-ABS-RH VALVE	MABCO	3	-------	610198
C167	FR AXLE-ABS-RH SENSOR	DEUTSCH	2	562486	562485
C168	FR AXLE-ABS-RH SENSOR	MABCO	2	641132	-------
C169	RR JCT BOX-SPEED SW	AMP	9	560636	561837
C170	FR JCT BOX-FL-FLASHER UNIT	TE	2	-------	561968
C171	ALARM JCT BOX-DOOR CYL	AMP CPC	24	560642	560643
C172	FR SERVICE CPT.-LEVEL LOW	AMP CPC	9	560635	561637
C174	UNDER DASH-RH-TTR HOLDLE	AMP HNL	9	561672	561669
C175	UNDER DASH-RH-TTR HOLDLE	AMP HNL	9	561672	561669
C176	UNDER DASH-RH-WIPER PULSE	AMP FTE	6	-------	561686
C177	UNDER DASH-RH WIPER MOTOR	AMP FTE	6	-------	561686
C178	UNDER DASH-RH-FAN	SPARTAN	6	-------	990058
C179	UNDER DASH-RH-FAN	SPARTAN	6	-------	990058
C180	RR JCT BOX-DIODE CONNECTOR	AMP HNL	15	561987	561986
C181	RR JCT BOX-DIODE CONNECTOR	AMP HNL	15	561987	561986
C182	RR JCT BOX-COMPT.-WT VLH	AMP CPC	16	560629	560648
C183	RR JCT BOX-COMPT.-WT VLH	PED	38	-------	560680
C186	RR JCT BOX-SPEED SIGNAL	PED WP	2	561566	561690
C187	RR JCT BOX-RPM REGISTOR CAN	AMP HNL	6	561552	561555

CONNECTORS CODE ID) Page G-2

No.	LOCATION	#ND TYPE	*PIN CAVITY	*SOCKET HOUSING	HOUSING
C189	ENGINE CPT-RR DOOR-B/U.LT.	PED WP	2	561566	561690
C190	ENGINE CPT-RR DOOR-TAIL LT	PED WP	2	561566	561690
C191	ENGINE CPT-RR DOOR-RH STOP L	PED WP	2	561566	561690
C194	ENGINE CPT-RR DOOR-RH DIR.L	PED WP	2	561566	561690
C195	ENGINE CPT-RR DOOR LH STOP L	PED WP	2	561566	561690
C196	ENGINE CPT-RR DOOR-DIR.LP L	PED WP	2	561566	561690
C197	ENGINE CPT-A/C COMPRESSOR	PED WP	4	561610	561610
C198	ENGINE CPT-RR DOOR-DOOR CYL	AMP HNL	15	561987	561986
C199	ENGINE CPT-RR DOOR LOCKING	AMP HNL	15	561987	561986
C201	FR ROOF-STORE LH	AMP HNL	2	560900	560898
C202	FR ROOF-STORE RH	AMP HNL	2	560900	560898
C203	FR ROOF-CLEARANCE LT	AMP HNL	2	560900	560898
C203	FR ROOF-CLEARANCE LT	AMP HNL	2	560900	560898
C207	UNDER DASH-LH-JACOB CLUTCH	SW ITT SS	3	561111	561808
C208	A/C JCT BOX-CONNECTOR	AMP HNL	9	560636	561837
C240	LUGGCPT.-CD-PILOT SEAT HEAT	AMP HNL	2	560900	560898
C241	LUGGCPT.-CD-PILOT SEAT HEAT	AMP HNL	2	560900	560898
C242	FR SERVICE CPT-HARN & DR.L.T	ITT SS	3	561111	561808
C243	FR SERVICE CPT-HEADLAMPS	TE	3	-------	561071
C244	FR SERVICE CPT-LH FOG LAMP	ITT SS	2	561813	561812
C245	FR SERVICE CPT-RH FOG LAMP	ITT SS	2	561813	561812
C246	FR SERVICE CPT-HARN & DR.L.T	ITT SS	3	561111	561808
C247	UNDER SEAT-CD-PIL.-SEAT HEAT	AMP HNL	2	560900	560898
C248	ALARM JCT BOX-DOOR CYL	AMP HNL	15	-------	561938
C358	CONDENSER CPT-HI-C.L.D.TEMP.	PED WP	6	561552	561515
C250	UNDER DASH-LH-TTR HOLDLE	AMP HNL	9	561672	561669
C252	LH SW PANEL-SWITCH L	SWF	8	-------	561087
C253	LH SW PANEL-ETHER	SWF	8	-------	561087
C255	LH SW PANEL-UNDER	SWF	8	-------	561087
C257	INSTRUMENT PANEL CENT-SPEEDO	AMP HNL	4	560851	560852
C258	LH SW PANEL-HULT FUNC.SW	SWF	8	-------	561087
C259	LH SW PANEL-HULT FUNC.SW	AMP FTE	6	-------	561188
C260	UNDER DASH-RH-KEYLESS HOO	HDP PL	14	-------	562066
C263	UNDER DASH-RH-KEYLESS HOO	HDP PL	14	-------	562067
C264	UNDER DASH-RH-TTR HOLDLE	AMP HNL	9	561672	561669
C265	RH SW PANEL-DRIVER'S DOOR SW	SWF	8	-------	561087
C266	RH SW PANEL-DRIVER'S LT SW	SWF	8	-------	561087
C267	UNDER DASH-RH	AMP CPC	24	560642	560643
C268	UNDER DASH-LH-MIRROR	AMP HNL	6	561552	561515
C269	UNDER DASH-RH-MIRROR	AMP HNL	6	561552	561515
C270	LH MIRROR POST	HOLEX	6	562070	562069
C271	RH MIRROR POST	HOLEX	6	562070	562069
C272	LH MIRROR	SPARTAN	6	-------	990058
C273	RH MIRROR	SPARTAN	6	-------	990058
C274	UNDER DASH-RH-3 WAY LTS	AMP HNL	6	561552	561515
C277	UNDERDASH-DDC & CDRN SW.	PED WP	8	-------	561087

CONNECTORS CODE ID) Page G-3

No.	LOCATION	#ND TYPE	*PIN CAVITY	*SOCKET HOUSING	HOUSING
C278	LH CONSOLE-BACK-UP CANCEL SW.	SWF	8	-------	561087
C280	UNDER DASH-RH-3 WAY SW	SWF	8	-------	561087
C281	LH CONSOLE-LEVEL LOW	SWF	8	560851	560825
C279	ENGINE CPT-RH DOOR-RH STOP L	PED WP	2	561566	561690
C283	LH CONSOLE-LOW DOCKING SW.	SWF	8	561562	561559
C284	ENGINE CPT-RH DOOR	PED WP	2	561566	561690
C285	ENGINE CPT-RH DOOR LH STOP L	PED WP	2	561566	561690
C286	RH SW PANEL-A/C & HEAT	SWF	8	-------	561087
C287	LH SW PANEL-FRESH-SW	SWF	8	561562	561559
C288	RH SW PANEL-FRESH-SW	SWF	8	-------	561087
C289	LH SW PANEL-ALL-LIGHTS	SWF	8	561562	561559
C290	LUGGAGE COMPT.-CRNDLE-REC.	RECEPTACLE	40	562220	562284
C291	LUGGAGE COMPT.-DOOR LOCK	AMP HNL	4	561551	561668
C292	RR DRIVE AXLE-WIPER DRIVER	PED WP	2	561566	561690
C294	FR JCT BOX COMPT.-WATI SK32	AMP HNL	9	560851	560852
C297	LH CONSOLE-DRIVER'S SEAT	AMP CPC	15	561987	561986
C300	LH CONSOLE SW-RHEOSTAT	AMP HNL	2	561248	561247 PRION T1324
C301	LH CONSOLE SW-DIM COL.LEVEL	PED WP	2	560830	560829
C303	FR JCT BOX-DIODE CONNECTOR	AMP HNL	15	561987	561986
C304	LH CONSOLE SW-HI-LOW BEAM	SWF	8	561562	561559
C402	LH SW PANEL-MASTER SWITCH	SWF	8	-------	561087
C307	LH CONSOLE SW-PIN STORE	SWF	8	-------	561087
C308	LH CONSOLE SW-WINDOW LIFT SW	SWF	8	-------	561087
C309	LH CONSOLE-DRIVL SEAT HEAT SW	SWF	8	-------	561087
C310	LH CONSOLE SW-DRIVER'S LTS	SWF	8	-------	561087
C320	LH CONSOLE-DRIVL SEAT HEAT SW	SWF	8	-------	561087
C302	LH CONSOLE-PANEL LIFT TILT PED-PN	SWF	8	-------	561087
C303	LH CONSOLE CRUISE CTR SW PAN	AMP HNL	3	560667	561550
C401	LH CONSOLE-DRIVER'S SEAT	AMP CPC	15	561987	561986
C329	ENGINE COMPT.-WATER HEATER	PED WP	2	561566	561690
C336	INSTRUMENT PANEL-RH-DOF DSL T	AMP HNL	3	560667	561550
C337	INSTR PANEL-LH-UP KNEEL	SWF	8	-------	561087
C338	INSTR PANEL-LH-UP DEFROST SW	SWF	8	-------	561087
C339	INSTR PANEL-LH-UP WASHER SW	SWF	8	-------	561087
C340	ALARM JCT BOX-DIRT	AMP HNL	2	560900	560898
C341	INSTR PANEL-HEAT HORNTR SW	SWF	8	-------	561087
C343	INSTR PANEL-LH-HEADLAMP SW	SWF	8	-------	561087
C344	INSTR PANEL-LH-DIM-DIM SW	SWF	8	561562	561559
C345	INSTR PANEL-LH-FOG L.T. SW	SWF	8	-------	561087
C346	INSTR PANEL-LH-SWITCH L.TS	SWF	8	-------	561087
C347	INSTR PANEL-LH-DASH-LT SW	AMP HNL	2	560900	560898
C348	WORLD TRANSM.-RH-DIAGNOSTIC	DEUTSCH	3	560672	560256
C349	RH CONSOLE-RECLI.LED HTR	AMP HNL	2	561248	561247
C350	RH CONSOLE-THERMOMETER	AMP HNL	3	560667	561550
C352	RH CONSOLE-DRV TEMP.REGUL	BURNDY	2	561566	561690
C353	INSTR PANEL-RH-DRV FAN-RDST	AMP HNL	6	561552	561515
C354	INSTR PANEL-RH-FR TEMP SEN	AMP HNL	6	561552	561515
C355	INSTR PANEL-RH-FR TEMP SW	AMP HNL	3	560667	561550
C357	INSTR PANEL-RH-WATER TEMP GA	AMP HNL	3	560667	561550
C358	INSTR PANEL-RH-FUEL LEVEL GA	AMP HNL	3	560667	561550
C359	INSTR PANEL-DIST-TAC & SPD.LT	AMP HNL	2	560900	560898
C360	INSTR PANEL-RH-B-U MONITOR	AMP HNL	2	561248	561247

CONNECTORS CODE ID) Page G-3

No.	LOCATION	#ND TYPE	*PIN CAVITY	*SOCKET HOUSING	HOUSING
C361	FR ROOF-WIPER MOTOR	AMP FTE	6	-------	561686
C366	RH CONSOLE-DRILLER	AMP HNL	2	561248	561247
C372	FR ROOF-DEST.SIGN SPEED SW	HOLEX	4	561477	561476
C374	ALARM JCT BOX COMPT-MASTER SW	AMP HNL	6	560552	561515
C375	ALARM JCT BOX COMPT-LH CONS.	AMP HNL	6	560552	561515
C376	ALARM JCT BOX COMPT-LH CONS.	AMP CPC	37	560734	560705
C378	LUGGAGE COMPT.-WINDOW AJAR	HOLEX	4	561477	561476
C379	WINDOW-WINDOW AJAR	HOLEX	4	561477	561476
C377	LH SW PANEL-STOP ENGDIVERDE	SWF	8	-------	561087
C380	ENGINE CPT-RR DOOR-DIR.LP	PED WP	2	561566	561690
C381	ENGINE COMPT.-CRNDLE-REC.	RECEPTACLE	40	562220	562284
C480	ENGINE COMPT.-BLOCK HEATER	PED WP	3	561781	561782
C481	RR DRIVE AXLE-WIPER DRIVER	PED WP	2	561566	561690
C206	FR JCT BOX COMPT.-WATI SK32	AMP HNL	9	560851	560852
C487	ENGINE COMPT.-SIGNAL	PED WP	6	561686	561687
C488	ENGINE COMPT.-SIGNAL	PED WP	6	561686	561687
C489	ENGINE COMPT.-OIL COOL.LEVEL	PED WP	2	-------	562350
C418	FR JCT BOX-DIODE CONNECTOR	AMP HNL	15	561987	561986
C412	LH SW PANEL-MASTER SWITCH	AMP HNL	6	560552	561515
C412	LH SW PANEL-MASTER SWITCH	AMP HNL	6	560552	561515
C413	ENG CPT-A/C-HI UALOAD PRS SW	PED WP	2	561566	561690
C414	RR JCT BOX	AMP HNL	9	560636	561837
C416	ENGINE CRNDLE-FAN SIGNAL	PED WP	3	561781	561782
C416	ENGINE CRNDLE-FAN SIGNAL	PED P-C	3	562237	-------
C417	FRONT JCT BOX-DIODES	AMP HNL	15	561987	561986
C418	INSTR PANEL-LH-TILT PED-PN	SWF	8	-------	561087
C419	FR JCT BOX-RETARDER DR JACOB	AMP HNL	3	560667	561550
C420	ENGINE COMPT.-WATER HEATER	TC	2	-------	561571
C421	ENGINE COMPT.-WATER HEATER	TC	2	-------	561571
C422	ENGINE COMPT.-WATER HEATER	TC	2	-------	561571
C424	UNDER INSTRUMENT PANEL PED-PN	AMP HNL	2	560667	561558
C425	ALARM JCT BOX-DIODES	AMP HNL	15	561987	561986
C426	ENGINE COMPT.-CRNDLE-FAN	PED HP	2	561781	561782
C429	ALARM JCT BOX COMPT.	AMP HNL	6	561552	561515
C430	LH CONSOLE-WATER HTR TIMER	AMP FTE	8	561088	562363
C431	LH CONSOLE-WATER HTR TIMER	AMP FTE	8	-------	561531
C432	LH CONSOLE-WATER HTR TIMER	AMP FTE	8	561088	562363
C437	RH-HVAC RADIO-ACL FR & RR DEST.	AMP CPC	24	560642	560643
C456	WORLD TRANSM.-RETARDER ACCUM.	PED HP	2	-------	562427
C457	WORLD TRANSM.-MAIN CONNECTOR	DEUTSCH	36	562172	562256
C458	WORLD TRANSM.-TURBINE SP.SENS	PED HP	2	-------	562426
C459	WORLD TRANSM.-ENGINE SP.SENS	PED HP	2	-------	562426
C460	WORLD TRANSM.-SPEED SENSOR	ITT	2	-------	562541
C461	WORLD TRANSM.-RETARDER TEMP.	PED HP	2	561566	561690
C463	WORLD TRANSM.-RETARD SOL.'K'	PED HP	2	-------	562426
C462	WORLD TRANSM.-SENSOR COMP.	DEUTSCH	16	562572	562571
C464	RR JCT BOX-OIL COMPT.-LEVEL	PED HP	2	-------	562350
C465	INSTR PANEL-RH-WATER SELECTOR	T & BET	10	-------	562429
C466	FR SERVICE CPT.-RESIS.HOD.	PED WP	3	-------	562428
C467	FR SERVICE CPT.-RESIS.HOD.	PED WP	3	-------	562428
C468	RR JCT BOX-VHV HOLX.'K'	PED HP	18	-------	562573
C470	FR SERVICE CPT.-SILENT 1800	AMP HNL	2	561248	561247
C471	FR SERVICE CPT.-SILENT 1800	PED WP	2	561566	561690
C472	FR SERVICE CPT.-SILENT 1800	PED WP	2	561566	561690
C473	FR SERVICE CPT.-SILENT 1800	AMP HNL	3	560667	561550

CONNECTORS CODE ID) Page G-2

No.	LOCATION	#ND TYPE	*PIN CAVITY	*SOCKET HOUSING	HOUSING
C483	UNDER DRIV.SEAT-ELECT.SEAT	PED PD	2	562237	-------
C500	ALARM JCT BOX-CPT-PRODRIVER	HOLEX	6	562078	562069
C501	LH CONSOLE-PRODRIVER HOUSLE	PED HP	7	562433	-------
C502	LH CONSOLE-WATER HTR SW	SWF	8	-------	561087
C503	LH CONSOLE-WATER HTR SW	SWF	8	-------	561087
C504	LH CONSOLE WEBASTO TIMER	AMP FTE	8	561088	562363
C505	LH CONSOLE-EBPWR TIMER	AMP	3	-------	562834
C506	LH CONSOLE-LEVEL LOW SW.	SWF	8	-------	561087
C508	RR JCT BOX-COMPT.-WT VLH	AMP HNL	6	560552	561515
Ca	RR JCT BOX-ECU WORLD TRL	T & BET	34	-------	562419
CB	RR JCT BOX-ECU WORLD TRL	T & BET	34	-------	562420