CONNECTORS CODE (C) Page G : 1

No.	LOCATION	(NB) TYPE	#PIN CAVITY	#SOCKET HOUSING	HOUSING	
C1	FR JCT BOX COMPARTMENT	AMP CPC	37	561644	561646	
C2	FR JCT BOX COMPARTMENT	AMP CPC	24	561641	561643	
C3	FR JCT BOX COMPARTMENT	AMP CPC	37	561714	561713	
C4	FR JCT BOX COMPARTMENT	AMP CPC	16	561693	561695	
C5	FR SERVICE COMPT.-UNDERNEATH	AMP CPC	37	561644	561646	
C6	FR SERVICE COMPT.-UNDERNEATH	AMP CPC	24	561641	561643	
C7	FR JCT BOX COMPT.-UNDERNEATH	AMP MNL	15	561987	561986	
C8	FR SERVICE COMPT.-UNDERNEATH	AMP CPC	37	561714	561713	
C9	ALARM JCT BOX	AMP CPC	16	561693	561695	
C10	ALARM JCT BOX	AMP CPC	37	561644	561646	
C11	FR SERVICE COMPARTMENT	AMP CPC	24	561642	561643	
C12	FR SERVICE COMPARTMENT	AMP CPC	16	561639	561640	
C13	FR SERVICE COMPT.	AMP MNL	6	561552	561515	
C15	RR JCT BOX	AMP CPC	24	561641	561643	
C16	LH CONSOLE SW-CRUISE ON OFF	SWF	8	------	561107	
C17	LH CONSOLE SW-CRUISE RESUME	SWF	8	------	561107	
C18	LH CONSOLE SW-CRUISE SET	SWF	8	------	561107	
C20	RR JCT BOX	AMP CPC	37	561644	561646	
C21	RR JCT BOX	AMP CPC	24	561641	561643	
C32	DDEC ENGINE-ECM	PED	30	------	561600	
C45	ALARM JCT BOX COMPARTMENT	AMP CPC	24	561642	561643	
C47	FR SERVICE COMPARTMENT	AMP CPC	16	561694	561695	
C49	BATTERIE COMPT.-LT	AMP MNL	2	561248	561247	
C52	RR JCT BOX	AMP CPC	22	561709	561710	
C53	RR JCT BOX	AMP CPC	14	561585	561584	PRIOR R012
C55	UNDER DASH-RH SW PANEL	AMP CPC	9	561636	561637	
C56	UNDER DASH-RH CONSOLE	AMP CPC	24	561642	561643	
C57	UNDER DASH-RH ACCESSORIES	AMP CPC	22	561989	561710	
C58	EVAPORATOR COMPARTMENT	AMP CPC	14	561585	561583	
C59	EVAPORATOR COMPARTMENT	AMP CPC	16	561639	561640	
C60	RR JCT BOX COMPT.-LT	AMP MNL	2	561248	561247	
C61	LUGGAGE COMPARTMENT LTS	AMP MNL	2	561248	561247	
C62	LUGGAGE COMPARTMENT LTS	AMP MNL	2	561248	561247	
C63	LUGGAGE COMPARTMENT LTS	AMP MNL	2	561248	561247	
C64	LUGGAGE COMPARTMENT LTS	AMP MNL	2	561248	561247	
C65	LUGGAGE COMPARTMENT LTS	AMP MNL	2	561248	561247	
C66	LUGGAGE COMPARTMENT LTS	AMP MNL	2	561248	561247	
C67	LUGGAGE COMPARTMENT LTS	AMP MNL	2	561248	561247	
C68	LUGGAGE COMPARTMENT LTS	AMP MNL	2	561248	561247	
C69	RR AXLE ACC-INSIDE PVC END	PED WP	6	561568	561578	
C70	ALARM JCT BOX COMPARTMENT	AMP CPC	24	561642	561643	
C71	UNDER INSTRUMENT PANEL-LH	AMP CPC	37	561645	561646	
C72	UNDER INSTRUMENT PANEL-CENT.	AMP CPC	37	561645	561646	
C73	UNDER INSTRUMENT PANEL-CENT.	AMP CPC	16	561639	561640	
C74	UNDER INSTRUMENT PANEL-RH	AMP CPC	24	561642	561643	

CONNECTORS CODE (C) Page G : 1

No.	LOCATION	(NB) TYPE	#PIN CAVITY	#SOCKET HOUSING	HOUSING	
C76	LUGGAGE COMPT.-AIR RET.SENS.	AMP MNL	2	561248	561247	
C77	LUGGAGE COMPT.-AIR RET.SENS.	AMP MNL	2	561248	561247	
C78	FR JCT BOX COMPARTMENT	AMP CPC	22	561709	561710	
C79	FR SERVICE COMPT.-UNDERNEATH	AMP CPC	37	561644	561646	
C80	LUGGAGE COMPT.-AIR RET.SENS.	AMP MNL	2	561248	561247	
C81	LUGGAGE COMPT.-DOOR LOCK	AMP MNL	4	561551	561668	
C82	LUGGAGE COMPT.-DOOR LOCK	AMP MNL	4	561551	561668	
C83	LUGGAGE COMPT.-DOOR LOCK	AMP MNL	4	561551	561668	
C84	LUGGAGE COMPT.-DOOR LOCK	AMP MNL	4	561551	561668	
C85	LUGGAGE COMPT.-DOOR LOCK	AMP MNL	4	561551	561668	
C86	LUGGAGE COMPT.-DOOR LOCK	AMP MNL	4	561551	561668	
C87	RR END ROOF	AMP CPC	9	561636	561637	
C88	RR END ROOF-CLEARANCE LTS	AMP MNL	2	560900	560898	
C89	RR END ROOF-B/U NONITOR	AMP CPC	4	561582	561581	
C90	RR JCT BOX	AMP CPC	15	561987	561986	
C91	RR JCT BOX	AMP CPC	37	561714	561713	
C92	FR JCT BOX COMPT-ANTI SKID	AMP CPC	9	561635	561637	
C93	FR JCT BOX COMPT-ANTI SKID	WABCO	35	------	641094	
C96	FR AXLE ACCESSORIES	AMP CPC	14	561585	561585	
C97	RR AXLE ACC-INSIDE PVC END	PED WP	6	561568	561578	
C98	FR SERVICE COMPT-EL.FT.PEDAL	PED WP	3	561782	561781	
C99	FR SERVICE COMPT LTS	AMP MNL	2	561248	561247	
C100	FR SERVICE COMPT-CORNERING LT	PED WP	2	561566	561690	
C101	FR SERVICE COMPT-ELEC. HORNS	PED WP	2	561566	561690	
C102	FR SERV & SIDE CPT-FLASH. LH	ITT SS	2	561813	561812	
C103	FR SERV & SIDE CPT-MARKERS	ITT SS	2	561813	561812	PRIOR R012
C103	FR SERV & SIDE CPT-MARKERS	GROTE	2	------	562155	
C104	FR SERV & SIDE CPT-FLASH. RH	ITT SS	2	561813	561812	PRIOR R012
C104	FR SERV & SIDE CPT-FLASH. RH	GROTE	2	------	562155	
C105	FR SERVICE COMPT-LIQ.S.VALVE	PED WP	2	561566	561690	
C106	FR SERVICE COMPT-WATER VALVE	PED WP	2	561566	561690	
C107	EVAPORATOR COMPT-DAMPER	PED WP	2	561566	561690	
C111	EVAPORATOR COMPT-DAMPER	ITT SS	2	561813	561812	
C113	BATT. & RR J.B.CPT.MARKER LT	ITT SS	2	561813	561812	PRIOR R012
C113	BATT. & RR J.B.CPT.MARKER LT	GROTE	2	------	562155	
C114	RR J. BOX CPT DOOR DIR LT LH	ITT SS	2	561813	561812	PRIOR R012
C114	RR J. BOX CPT DOOR DIR LT LH	GROTE	2	------	562155	
C115	ENGINE COMPT-AIR DRYER	PED WP	2	561566	561690	
C116	ENGINE COMPT. LTS	PED WP	2	561566	561690	PRIOR R012
C116	ENGINE COMPT. LTS	PED WP	1	561605	561577	
C119	ENGINE CPT RR DOOR RH LO LAMP	PED WP	6	561606	561607	
C120	ENGINE CPT RR DOOR LH LO LAMP	PED WP	6	561606	561607	
C121	BATTERIE CPT. DOOR DIR LT RH	ITT SS	2	561813	561812	PRIOR R012
C121	BATTERIE CPT. DOOR DIR LT RH	GROTE	2	------	562155	
C122	ENGINE CPT-CAMERA DOOR VALVE	PED WP	2	561566	561690	
C124	ENGINE CPT-ETHER SW	PED WP	2	561566	561690	

PREVOST CAR inc.	WIRING DIAGRAM	NO: D060870	P. G/$^{1}_{4}$	REVISION 012

CONNECTORS CODE (C) Page G : 2

No.	LOCATION	(NB) TYPE	#PIN CAVITY	#SOCKET HOUSING	HOUSING	
C125	ENGINE CPT-B/U ALARM	PED WP	2	561566	561690	
C127	ENGINE CPT-FUEL FILTER	PED WP	2	561566	561690	
C128	ENGINE CPT-A/C COMPR.CLUTCH	ITT SS	2	561813	561812	
C129	ENGINE CPT-PRE-HEAT WATER	AMP FF	6	561672	561186	
C130	ENGINE CPT-UNLOADER	ITT SS	2	561813	561812	
C131	ENGINE CPT-UNLOADER	ITT SS	2	561813	561812	
C132	ENGINE CPT-A/C LO PRESS SW	PED WP	2	561566	561690	
C133	ENGINE CPT-A/C HI PRESS SW	PED WP	2	561566	561690	
C134	FR JCT BOX-LUGGAGE DIODE CON.	AMP MNL	15	561987	561986	
C135	FR JCT BOX-LUGGAGE DIODE CON.	AMP MNL	15	561987	561986	
C136	A/C JCT BOX (PRIOR)	VEAM	37	561743	561744	
C136	A/C JCT BOX	DEUTSCH	40	562281	562284	
C137	A/C JCT BOX-TRANSMITTER	AMP MNL	2	560900	560898	
C138	A/C JCT BOX-CONTROL MODULE	AMP HDP	15	------	562012	
C139	A/C JCT BOX-LOGIC MODULE	AMP HDP	15	562011	------	
C145	RR JCT BOX CPT-RR SIDE LTS	AMP MNL	9	561670	561669	
C146	ENGINE CPT-MODULATOR VALVE	AMPHENOL	2	------	560412	
C147	BATT & RR J.B.CPT-DOCK.LTS	PED WP	2	561566	561690	
C148	FR.JCT BOX COMPT. LTS	AMP MNL	2	561248	561247	
C149	CONDENSER CPT-FAN MOTOR	ORDNANCE	3	562555	562001	
C152	CONDENSER CPT-FUEL GAUGE	PED WP	4	561610	561611	
C153	EVAPORATOR CPT-AIR AMB. SENS	AMP MNL	2	561248	561247	
C154	EVAPORATOR CPT-FRESH AIR SENS	ITT SS	2	561813	561812	
C155	EVAPORATOR CPT-WATER VALVE	PED WP	4	561610	561611	
C157	EVAPORATOR CPT-WATER PUMP	PED WP	2	561566	561690	
C158	CONDENSER CPT-A/C LO TEMP.	PED WP	2	561566	561690	
C159	CONDENSER CPT-A/C HI TEMP.	PED WP	2	561566	561690	
C160	FR AXLE-ABS RH SENSOR	WABCO	2	641132	------	
C161	FR AXLE-ABS RH VALVE	WABCO	3	------	641098	
C162	FR AXLE-ABS LH VALVE	WABCO	3	------	641098	
C163	FR AXLE-ABS LH SENSOR	WABCO	2	641132	------	
C164	RR AXLE-ABS LH SENSOR	DEUTSCH	2	562486	562485	
C165	RR AXLE-ABS LH VALVE	WABCO	3	------	641098	
C166	RR AXLE-ABS RH VALVE	WABCO	3	------	641098	
C167	RR AXLE-ABS RH SENSOR	DEUTSCH	2	562486	562485	
C168	RR AXLE-ABS OPT ATC	PED WP	4	561610	561611	
C169	RR JCT BOX-SPEED SW	AMP HDP	15	------	562012	
C170	FR JCT BOX-FLASHER UNIT	TC	2	------	561940	
C171	ALARM JCT BOX CPT-LH CONSOLE	AMP CPC	37	561645	561646	
C172	FR. SERVICE CPT.-LEVEL LOW	AMP CPC	9	561635	561637	
C174	UNDER DASH RH-HTR MODULE	AMP MNL	9	561670	561669	
C175	UNDER DASH RH-HTR MODULE	AMP MNL	9	561670	561669	
C176	UNDER DASH RH-WIPER PULSE	AMP FF	6	------	561186	
C177	UNDER DASH RH-WIPER MOTOR	AMP FF	6	------	561186	
C178	UNDER DASH RH-LH FAN	TC	2	561030	560997	
C179	UNDER DASH RH-RH FAN	TC	2	561030	560997	
C180	RR JCT BOX-DIODE CONNECTOR	AMP MNL	15	561987	561986	
C181	RR JCT BOX-DIODE CONNECTOR	AMP MNL	15	561987	561986	
C182	RR JCT BOX COMPT.-WT VIW	AMP CPC	16	561639	561640	
C185	RR JCT BOX COMPT.-WT VIM	PED	30	------	561600	PRIOR R012
C186	RR JCT BOX-SPEED SIGNAL	PED WP	2	561566	561690	
C187	RR JCT BOX-RPM RESISTOR CON.	AMP MNL	6	561552	561515	

CONNECTORS CODE (C) Page G : 2

No.	LOCATION	(NB) TYPE	#PIN CAVITY	#SOCKET HOUSING	HOUSING	
C189	ENGINE CPT RR DOOR B/U LT	PED WP	2	561566	561690	
C190	ENGINE CPT RR DOOR TAIL LT	PED WP	2	561566	561690	
C191	ENGINE CPT RR DOOR RH STOP LT	PED WP	2	561566	561690	
C192	ENGINE CPT RR DOOR RH DIR. LT	PED WP	2	561566	561690	
C194	ENGINE CPT RR DOOR LH DIR. LT	PED WP	2	561566	561690	
C195	ENGINE CPT RR DOOR LH STOP LT	PED WP	2	561566	561690	
C196	ENGINE CPT RR DOOR CYCLOP LT	PED WP	2	561566	561690	
C197	ENGINE CPT-A/C COMPRESSOR	PED WP	4	561889	561890	PRIOR R012
C198	ENGINE CPT-A/C COMPRESSOR	PED WP	4	561889	561890	PRIOR R012
C199	ENGINE CPT RR DOOR LICENCE LT	DOM AUTO	2	930210	------	
C211	FR ROOF-STORE LH	AMP MNL	2	560900	560898	
C212	FR ROOF-STORE RH	AMP MNL	2	560900	560898	
C213	FR ROOF-CLEARANCE LT	AMP MNL	2	560900	560898	
C213	FR ROOF-CLEARANCE LT	AMP MNL	2	560900	560898	
C237	UNDER DASH LH-JACOB CLUTCH SW	ITT SS	3	561111	561080	
C238	A/C JCT BOX-DIODE CONNECTOR	AMP MNL	9	561670	561669	
C240	LUGG.CPT.-CO-PILOT SEAT HEAT.	AMP MNL	2	560900	560898	
C241	FR SERVICE CPT-FOG RESISTOR	AMP CPC	3	561847	561862	
C242	FR SERVICE CPT-MARK & DIR LT	ITT SS	3	561111	561080	
C243	FR SERVICE CPT-HEADLAMPS	TC	3	------	561071	
C244	FR SERVICE CPT-LH FOG LAMP	ITT SS	2	561813	561812	
C245	FR SERVICE CPT-RH FOG LAMP	ITT SS	2	561813	561812	
C246	FR SERVICE CPT-MARK & DIR LT	ITT SS	3	561111	561080	
C247	UNDER SEAT-CO-PIL. SEAT HEAT.	AMP MNL	2	560900	560898	
C248	ALARM JCT BOX-WIPER PULSE GEN	AMP FF	6	------	561108	
C250	ALARM JCT BOX-DASH LTS REGUL.	AMP MNL	6	561552	561515	
C251	LH SW PANEL-FAST IDLE	SWF	8	------	561107	
C252	LH SW PANEL-SWITCH LT	SWF	2	------	561837	
C253	LH SW PANEL-ETHER	SWF	8	------	561107	
C255	LH SW PANEL-JACOB	SWF	8	------	561107	
C257	INSTRUMENT PANEL CENT-SPEEDO	AMP MNL	4	560851	560852	PRIOR R010
C257	INSTRUMENT PANEL CENT-SPEEDO	AMP FF	8	------	562363	
C258	LH SW PANEL-MULTI FUNC. SW	AMP FF	8	561188	------	
C259	LH SW PANEL-MULTI FUNC. SW	AMP FF	6	------	561108	
C262	UNDER DASH RH-KEYLESS MOD	PL. ENG	14	------	562066	
C263	UNDER DASH RH-KEYLESS MOD	HOF PL.	14	------	562067	
C264	UNDER DASH RH-KEYPAD	AMP CPC	9	561636	561637	
C265	RH SW PANEL-DRIVER'S DOOR SW.	SWF	8	------	561107	
C266	RH SW PANEL-DRIVER'S LT SW.	SWF	2	------	561837	
C267	UNDER DASH RH	AMP CPC	24	561642	561643	
C268	UNDER DASH LH-MIRROR	AMP MNL	6	561552	561515	
C269	UNDER DASH RH-MIRROR	AMP MNL	6	561552	561515	
C270	LH MIRROR POST	MOLEX	6	562070	562069	
C271	RH MIRROR POST	MOLEX	6	562070	562069	
C272	LH MIRROR	SPARTAN	6	------	990158	
C273	RH MIRROR	SPARTAN	6	------	990158	
C276	UNDER DASH RH-3 WAY LTS	AMP MNL	6	561552	561515	
C277	LH CONSOLE-DOCK & CORN SW.	SWF	8	------	561107	

PREVOST CAR inc.	WIRING DIAGRAM	NO: D060870	P. G/$^{2}_{4}$	REVISION 012

CONNECTORS CODE (C) Page G : 3

No.	LOCATION	(NB) TYPE	#PIN CAVITY	#SOCKET HOUSING	HOUSING	
C278	LH CONSOLE-BACK-UP CANCEL SW.	SWF	8	------	561107	
C280	UNDER DASH RH-3 WAY SW	SWF	8	------	561107	
C281	LH CONSOLE-LEVEL LOW	SWF	8	560851	560825	
C282	LH CONSOLE-MONITOR OPER.SW.	SWF	8	------	561107	
C283	LH CONSOLE-LOW DOCKING SW.	SWF	8	------	561107	
C285	ENTRANCE DOOR-SOL. DOOR	PED PO	2	------	562076	
C286	RH SW PANEL-A/C & HEAT	SWF	8	------	561107	
C287	ENGINE COMPT-LTS SW	PED WP	2	561566	561690	
C288	RH SW PANEL-FRESH AIR	SWF	8	------	561107	
C289	RH SW PANEL-SWITCH LT	SWF	2	------	561837	
C290	LUGGAGE COMPT.-DOOR LOCK	AMP MNL	4	561551	561668	
C291	LUGGAGE COMPT.-DOOR LOCK	AMP MNL	4	561551	561668	
C297	INSTRUMENT PANEL RH -LTS	AMP MNL	2	560900	560898	
C301	INSTRUMENT PANEL CENT-TACHO	AMP MNL	4	560851	560852	PRIOR R010
C301	INSTRUMENT PANEL CENT-SPEEDO	AMP FF	8	------	562363	
C307	LH CONSOLE-DRIVER'S SEAT HEAT	AMP CPC	4	561686	561687	
C308	LH CONSOLE SW-RHEOSTAT	PED	2	561030	560997	
C309	DDEC ENGINE-ECM POWER CON.	PED MP	5	------	562345	
C310	LH CONSOLE SW-LUG. DOOR LCK	SWF	8	------	561107	
C315	LH CONSOLE SW-LH STORE	SWF	8	------	561107	
C317	LH CONSOLE SW-RH STORE	SWF	8	------	561107	
C318	LH CONSOLE SW-DRV WINDOW LIFT	SWF	8	------	561107	
C319	LH CONSOLE-DRIV. SEAT HEAT SW	SWF	4	------	561107	
C320	LH CONSOLE SW-DRIVER'S LTS	SWF	8	------	561107	
C321	LH CONSOLE-DRIV. SEAT HEAT SW	SWF	4	------	561107	
C322	LH CONSOLE DRV WIND LIFT MOT	PED PO	2	------	561848	
C323	LH CONSOLE CRUISE CTR SW PAN.	AMP CPC	9	561636	561637	
C327	ENGINE COMPT-RR START SW BOX	DEUTSCH	5	562565	562566	PRIOR R012
C327	ENGINE CONTROL RR START SW	DEUTSCH	6	562583	562581	
C329	ENGINE TACHO SIGNAL	PED WP	3	561781	561789	
C336	INSTRUMENT PANEL RH-DIF OIL T	AMP MNL	3	561667	561550	
C337	INSTR PANEL LH-UP WIPER SW	SWF	8	------	561107	
C338	INSTR PANEL LH-UP DEFROST SW	SWF	8	------	561107	
C339	INSTR PANEL LH-UP WASHER SW	SWF	8	------	561107	
C340	ALARM JCT. BOX COMPT.	AMP MNL	2	560900	560898	
C341	INSTR PANEL LH-HEAT MIRROR SW	SWF	8	------	561107	
C342	ENGINE RR START SW	DEUTSCH	2	562586	562585	
C343	INSTR PANEL LH-HEADLAMP SW	SWF	8	------	561107	
C344	INSTR PANEL LH-HAZARD LT SW	SWF	8	------	561107	
C345	INSTR PANEL LH-FOG LT SW	SWF	8	------	561107	
C346	INSTR PANEL LH-SWITCH LTS	SWF	2	------	561837	
C347	INSTR PANEL LH-DASH LT SW	AMP MNL	2	560900	560898	
C348	INSTR PANEL CENT-RACOR MODULE	AMP MNL	3	561667	561550	
C349	RH CONSOLE-RED LED HTR	AMP MNL	2	561248	561247	
C350	RH CONSOLE-THERMOMETER	AMP MNL	3	561667	561550	
C352	RH CONSOLE-DRV TEMP SENSOR	BURNDY	4	------	561104	
C353	INSTR PANEL RH-DRV FAN RHEOST	AMP MNL	6	561552	561515	
C354	INSTR PANEL RH-DRV TEMP CTR	AMP MNL	6	561552	561515	
C355	INSTR PANEL RH-FR TEMP CTR	AMP MNL	3	561667	561550	
C357	INSTR PANEL RH-WATER TEMP GA	AMP MNL	3	561667	561550	
C358	INSTR PANEL RH-FUEL LEVEL GA	AMP MNL	3	561667	561550	
C359	INSTR PANEL CENT-TAC & SPD LT	AMP MNL	2	560900	560898	
C360	INSTR PANEL RH-B/U MONITOR	AMP MNL	2	561248	561247	

CONNECTORS CODE (C) Page G : 3

No.	LOCATION	(NB) TYPE	#PIN CAVITY	#SOCKET HOUSING	HOUSING
C361	FR ROOF-WIPER MOTOR	AMP FF	6	------	561186
C366	RH CONSOLE-GRN LED	AMP MNL	2	561248	561247
C372	FR ROOF-DEST. SIGN SPEED SW	MOLEX	4	561477	561476
C374	ALARM JCT BOX COMPT-MASTER SW	AMP MNL	6	561552	561515
C375	ALARM JCT BOX COMPT-LH CONSOL	AMP MNL	6	561552	561515
C376	ALARM JCT BOX COMPT-LH CONS.	AMP CPC	37	561714	562005
C378	LUGGAGE COMPT.-WINDOW AJAR	MOLEX	4	561477	561476
C379	WINDOW AWNING-WINDOW AJAR	MOLEX	4	561477	561476
C377	LH SW PANEL-STOP ENG.OVERIDE	SWF	8	------	561107
C380	LH CONCOLE-DDR CONNECTOR	DEUTSCH	6	562360	------
C397	ENGINE COMPT. CRADLE ACC.	DEUTSCH	40	562281	562284
C400	ENGINE COMPT. BLOCK HEATER	PED MP	3	561781	561782
C402	RR DRIVE AXLE-AIR DRYER	PED MP	2	------	562251
C406	FR JCT BOX COMPT.-ANTI-SKID	AMP MNL	2	560900	560898
C407	ENGINE COMPT. -SIGNAL	PED WP	6	561606	561607
C408	ENGINE COMPT. -SIGNAL	PED WP	6	561606	561607
C409	ENGINE CPT -LOW COOL. LEVEL	PED MP	2	------	562350
C410	FR JCT BOX-DIODE CONNECTOR	AMP MNL	15	561987	561986
C411	FR JCT BOX-DIODE CONNECTOR	AMP MNL	15	561987	561986
C412	LH SW PANEL-MASTER SWITCH	SWF	8	------	561107
C413	ENG CPT-A/C HI UNLOAD PRS SW	PED WP	2	561566	561690
C414	RR JCT BOX	AMP MNL	9	561670	561669
C415	ENGINE CRADLE-FAN SIGNAL	PED WP	3	561781	561782
C416	ENGINE CRADLE-FAN SIGNAL	PED P-C	3	562237	------
C417	FRONT JCT BOX-DIODES	AMP MNL	15	561987	561986
C418	INSTR. PANEL LH-HTR WINDSH.SW	SWF	8	------	561107
C419	FR JCT BOX-RETARDER OR JACOB	AMP MNL	3	561667	561550
C420	ENGINE COMPT.-WATER HEATER	TC	2	------	561597
C421	ENGINE COMPT.-WATER HEATER	TC	1	------	561073
C422	ENGINE COMPT.-WATER HEATER	TC	2	------	561597
C424	UNDER INSTRUMENT PANEL CENTER	AMP MNL	3	561667	561550
C425	ALARM JCT BOX-DIODES	AMP MNL	15	561987	561986
C426	ENGINE COMPT. CLUTCH CTR FAN	PED MP	3	561781	561782
C429	ALARM JCT BOX COMPT.	AMP MNL	6	561552	561515
C430	LH CONSOLE-WATER HTR TIMER	AMP FF	8	561188	562363
C431	LH CONSOLE-WATER HTR TIMER	AMP TAB	1	------	561539
C432	ENG.CPT.- PROX.SW. DOOR AJAR	DEUTSCH	4	562479	562477
C437	RH HAT RACK-WCL FR & RR SECT.	AMP CPC	24	561642	561643
C456	WORLD TRANSM.-RETARDER ACCUM.	PED MP	2	------	562427
C457	WORLD TRANSM.-MAIN CONNECTOR	DEUTSCH	31	562572	562536
C458	WORLD TRANSM.-TURBINE SP.SENS	PED MP	2	------	562426
C459	WORLD TRANSM.-ENGINE SP.SENS.	PED MP	2	------	562426
C460	WORLD TRANSM.-SPEED SENSOR	ITT	2	------	562541
C461	WORLD TRANSM.-RETARDER TEMP.	PED MP	2	561566	561590
C462	WORLD TRANSM.-RETARD SOL."K"	PED MP	2	------	562426
C463	WORLD TRANSM.-SENSOR CONN.	DEUTSCH	16	562570	562571
C464	RR JCT BOX-DDL CONN W.T.	PED MP	12	------	562574
C465	LH CONSOLE-SHIFTER SELECTOR	T & BET	10	------	562429
C466	FR SERVICE CPT.-RESIS. MOD.	PED WP	3	------	562428
C467	FR SERVICE CPT.-RESIS. MOD.	PED WP	3	------	562428
C468	RR JCT BOX-VIM MOD. W.T.	PED MP	18	------	562573
C470	FR SERVICE CPT.-SILENT 1000	AMP MNL	2	561248	561247
C471	FR SERVICE CPT.-SILENT 1000	AMP MNL	2	561248	561247
C472	FR SERVICE CPT.-SILENT 1000	PED WP	2	561566	561690
C473	FR SERVICE CPT.-SILENT 1000	AMP MNL	3	561667	561550

CONNECTORS CODE (C) Page G : 2

No.	LOCATION	(NB) TYPE	#PIN CAVITY	#SOCKET HOUSING	HOUSING
C474	LUGGAGE COMPT- TEMP. SENSOR	AMP MNL	2	561248	561247
C475	RR JCT BOX SPEED SIGNAL CON.	MOLEX	6	562070	562069
C475M	RR JCT BOX SPEED SIGNAL CON.	MOLEX	6	562070	562069
C475W	RR JCT BOX SPEED SIGNAL CON.	MOLEX	6	562070	562069
C476	RR JCT BOX-VIM WORLD TRANSM.	AMP CPC	16	561639	561640
C477	RR JCT BOX-W. T. SHIFT & RET	AMP CPC	9	561636	561637
C483	UNDER DRIV. SEAT-ELECT.SEAT	PED PO	2	562237	------
C500	ALARM JCT BOX CPT-PRODRIVER	MOLEX	6	562070	562069
C501	LH CONSOLE-PRODRIVER MODULE	PED MP	7	562433	------
C502	LH CONSOLE-WATER HTR SW	SWF	8	------	561107
C503	LH CONSOLE-WATER HTR SW	SWF	2	------	561837
C504	LH CONSOLE WEBASTO TIMER	AMP FF	8	561188	562363
C505	LH CONSOLE ESPAR TIMER	AMP	3	------	562034
C506	LH CONSOLE-LEVEL LOW SW.	SWF	8	------	561107
C508	RR JCT BOX-FAN CLUTCH W/RET.	AMP MNL	6	561552	561515
CA	RR JCT BOX-ECU WORLD TR.	T & BET	34	------	562419
CB	RR JCT BOX-ECU WORLD TR.	T & BET	34	------	562420
FB1	RR JCT BOX-WORLD TR. FUSE BLK	PED MP	8	------	562610

CONNECTORS CODE (C) Page G : 2

No.	LOCATION	(NB) TYPE	#PIN CAVITY	#SOCKET HOUSING	HOUSING

PREVOST CAR inc.
WIRING DIAGRAM
NO: D060869
P. G 4/4
REVISION 012