CIRCUIT NUMBER CODE Page E : 1

No.	SYSTEM	No.	SYSTEM
0	IC - INVERTER CPT GRD	0RH	RS - RR END LAMPS RH GRD
0	GALLEY GRD	0S2	SOUND SYSTEM RADIO GRD
0	BC - BAT. CPT GRD	0S3	SOUND SYSTEM VIDEO GRD
0	CONDENSER CPT GRD	0SS	SOUNS SYSTEM BATT. GRD
0	A/C - A/C JCT BOX GRD	00SS	SOUND SYSTEM BATT. GRD
0	GALLEY GRD	0T	FS - LUG. CPT ACCES. GRD
0	FJB - FR JCT BOX GRD	0V	RR JCT BOX CPT GRD STUD
0	GALLEY GRD	0V	FS - FR JCT BOX CPT GRD STUD
0	VIDEO GRD	0VA	BATTERY TO EQUALISER 0V
0A	A/C - A/C JCT BOX GRD	0W	FS - UNDER DASH CENT GRD
0A	FRS - FR ROOF ACCES. GRD	0W	RS - RR JCT BOX GRD
0A	RS - LUG. CPT ACCES. GRD	0W	FS - FR JCT BOX CPT GRD STUD
0A	AJB - ALARM JCT BOX GRD	0WC	RS - RR JCT BOX GRD (WCL)
0A	FJB - FR JCT BOX GRD	0X	FS - TO LH CONS. C483 NOT USED
0AA	RS - VOLTAGE REGULATOR GRD	0X	FR JCT BOX CPT GRD STUD
0B	EC - ENGINE GRD	0X	RS - RR JCT BOX GRD
0B	FRS - FR ROOF HEAT WIND GRD	0X2	FR JCT BOX CPT GRD STUD
0B	FS - FR ROOF ACCES. GRD	0Y	RR JCT BOX GRD
0B	RS - LUG. CPT ACCES. GRD	0Y	FR JCT BOX CPT GRD STUD
0B	A/C - A/C JCT BOX GRD	0Y	ABS FR JCT BOX CPT GRD STUD
0B	FJB - FR JCT BOX GRD	0Y1	ABS FR JCT BOX CPT GRD STUD
0BE	RJB - BAT. EQUAL. BAT GRD	0Z	FR JCT BOX CPT GRD STUD
0C	EC - STARTER MOTOR GRD	0Z	RR JCT BOX CPT GRD STUD
0C	BAT. EQUALIZER GRD	00	RR JCT BOX CPT BATT. GRD
0C	FS - SERV. CPT ACCES. GRD	1	TACHO SYSTEM
0C	RS - ENGINE ACCES. GRD	2B	A/C & HEAT SYSTEM-COOL 1 SIGN
0C	RJB - SPEED SW. BATT. GRD	2C	A/C & HEAT SYSTEM-LO PRESS SW
0CR	24V DISC. SW. RLY GRD SIGNAL	2D	A/C & HEAT SYSTEM-LO PRESS TT LT
0CS	24V DISC. SW. RLY GRD SIGNAL	4	HOSTESS & PASSENGER CHIME
0D	FS - SERV. CPT ACCES. GRD	4A	HOSTESS & PASSENGER CHIME
0D	RS - HAT RACK ACCES. LH GRD	4B	PASSENGER CHIME
0DF	RS - RR SIDE FLASH & MARK GRD	4C	HOSTESS CHIME
0E	FS - FR LAMPS GRD	5	INTERIOR LTS-AISLE & EMERG. EXIT
0E	RS - HAT RACK ACCES. LH GRD	5	UPPER WINDSHIELD DEFROSTER
0E2	FRS - HEAD & CORNERING LTS GRD	5D	UPPER WINDSHIELD DEFROSTER
0EE	FRS - HEAD & CORNERING LTS GRD	5E	UPPER WINDSHIELD DEFROSTER
0F	RS - HAT RACK ACCES. RH GRD	5N	INTERIOR LTS-EMERGENCY EXIT
0G	RS - HAT RACK ACCES. RH GRD	6	INTERIOR LTS-AISLE
0G	FS - INSTR. PANEL LH GRD	7A	SPEED SW 5 MPH N/O
0H	FS - INSTR. PANEL CENT GRD	7B	ENTRANCE DOOR (SEDAN)
0H	RS - LAVATORY ACCES. GRD	7C	ENTRANCE DOOR (SEDAN)
0I	FS - INSTR. PANEL RH GRD	7D	ENTRANCE DOOR (SEDAN)
0J	FS - SW CONSOLE LH GRD	7DA	ENTRANCE DOOR (SEDAN)
0J	RS - RR ROOF ACCES. GRD	7DB	ENTRANCE DOOR (SEDAN)
0K	RS - RR ROOF ACCES. GRD	8	TACHOMETER GRD SHIELD
0L	RS - ENGINE CPT ACCES. GRD	9	INTERIOR LTS-ENGINE CPT
0L	FS - UNDER DASH RH GRD	9A	INTERIOR LTS-ENGINE CPT
0LA	ENTRANCE DOOR (SEDAN) GRD	9B	ENGINE DOOR AJAR T.T.L.T.
0LH	RS - RR END LAMPS LH GRD	9E	INTERIOR LTS-FR SERVICE CPT
0M	RS - ENGINE CPT ACCES. GRD	9F	INTERIOR LTS-FR SERVICE CPT
0M	FS - UNDER DASH RH GRD	10	INTERIOR LTS-LUGGAGE CPT
0MR	24V DISC. SW. RLY GRD SIGNAL	10A	INTERIOR LTS-LUGGAGE CPT
0MS	24V DISC. SW. RLY GRD SIGNAL	10B	INTERIOR LTS-LUGGAGE CPT
0N	FS - UNDER DASH RH GRD	10D	INTERIOR LTS-LUGGAGE CPT
0N	RS - ENGINE CPT ACCES. GRD	10F	INTERIOR LTS-LUGGAGE CPT
0P	FS - ALARM JCT BOX GRD	10H	INTERIOR LTS-LUGGAGE CPT
0P	RS - ENGINE CPT ACCES. GRD	10K	INTERIOR LTS-LUGGAGE CPT
0R	FS - UNDER DASH LH GRD	10R	INTERIOR LTS-LUGGAGE DOOR AJAR
0R	RS - ENGINE CPT ACCES. GRD	11	FR DESTINATION SIGN
0R	FS - SOUND SYS. JCT PANEL GRD	11A	FR DESTINATION SIGN
0RE	RADIO &CTRL HEAD CHASSIS GRD	11B	FR DESTINATION SIGN

CIRCUIT NUMBER CODE Page E : 1

No.	SYSTEM	No.	SYSTEM
11C	FR DESTINATION SIGN	21B	EXTERIOR LTS-HAZARD
11D	FR DESTINATION SIGN	21C	EXTERIOR LTS-CORNERING LH
11E	FR DESTINATION SIGN	21H	EXTERIOR LTS-DIRECTIONNAL LH
11K	FR DESTINATION SIGN	21K	EXTERIOR LTS-CORNERING
12	BAT CPT 12V BATTERY	21N	EXTERIOR LTS-CORNERING LH
12	FR JCT BOX 12V DISC SW	21P	EXTERIOR LTS-CORNERING LH
12	12V BAT CPT JCT BLOCK	23	EXTERIOR LTS-DIRECTIONNAL RH
12A	FR JCT BOX 12V DISC SW	23	EXTERIOR LTS-DIRECTIONNAL RH
12A	RR JCT BOX 12V DISC SW	23A	EXTERIOR LTS-DIRECTIONNAL RH
12B	FR JCT BOX 12V DISC SW	23B	EXTERIOR LTS-DIRECTIONNAL RH
12B	12V BAT CPT JCT BLOCK	23C	EXTERIOR LTS-CORNERING RH
12BE	BAT. EQUALIZER MONITOR	23N	EXTERIOR LTS-CORNERING RH
12C	FR JCT BOX 12V DISC SW	23P	EXTERIOR LTS-CORNERING RH
12D	BAT CPT 12V BATTERY	24	BAT CPT 24V BATTERY
12E	FR JCT BOX 12V DISC SW	24	FR JCT BOX 24V DISC SW
12E	RR JCT BOX 12V DISC SW	24A	BOOSTER BLOCK 24V DISC SW
12F	FR JCT BOX 12V DISC SW	24A	RR JCT BOX 24V DISC SW
12F	RR JCT BOX 12V DISC SW	24A	FR JCT BOX 24V DISC SW
12F	BAT CPT 12V FJB & IC	24B	RR JCT BOX 24V DISC SW
12I	RR JCT BOX 12V IGNITION	24B	FR JCT BOX 24V DISC SW
12I	12V IGNITION DISTRIBUTION	24B	24V STARTER RLY FEEDING
12IA	FR JCT BOX 12V IGNITION	24BE	RJB CPT-BAT EQ MONITOR HOT WIRE
12IA	12V IGNITION DISTRIBUTION	24C	FR JCT BOX 24V DISC SW
12IB	FR JCT BOX 12V IGNITION	24D	BAT CPT 24V HOT WIRE
12IF	FR JCT BOX 12V IGNITION	24D	FR JCT BOX 24V HOT WIRE
12P	INVERTER CPT 12V DISC SW	24D	RR JCT BOX 24V HOT WIRE
12PV	INVERTER CPT 12V DISC SW	24DP	A/C JCT BOX 24V HOT WIRE
12R	BAT CPT 12V DISC RLY TO RJB	24E	BAT CPT 24V DISC SW
12R	MEMORY BATTERY RADIO	24E	FR JCT BOX 24V DISC SW
12S	SOUND SYSTEM 12V RADIO	24E	RR JCT BOX 24V DISC SW
12S1	SOUND SYSTEM 12V RADIO	24F	FR JCT BOX 24V DISC SW
12S2	SOUND SYSTEM 12V RADIO	24F	RR JCT BOX 24V DISC SW
12SB	SOUND SYSTEM 12V FEEDING	24G	FR JCT BOX 24V DISC SW
12SS	SOUND SYSTEM 12V FEEDING	24G	RR JCT BOX 24V DISC SW
12VA	BATTERY TO EQUALIZER 12V	24H	FR JCT BOX 24V DISC SW
12VD	12V HOT WIRE DISTRIBUTION	24H	RR JCT BOX 24V DISC SW
12VF	BAT CPT 12V FJB & IC	24I	FR JCT BOX 24V IGNITION
12VG	INVERTER CPT 12V DISC SW	24I	RR JCT BOX 24V IGNITION
12VI	12V IGNITION DISTRIBUTION	24IA	FR JCT BOX 24V IGNITION
12VR	BAT CPT 12V DISC RLY TO RJB	24IA	RR JCT BOX 24V IGNITION
12W	12V BATTERY DDEC III	24IB	FR JCT BOX 24V IGNITION
12WA	ENTRANCE DOOR (SEDAN)	24IB	RR JCT BOX 24V IGNITION
12X	FR JCT BOX 12V DISC SW	24IC	FR JCT BOX 24V IGNITION
12X2	FR JCT BOX 12V DISC SW	24ID	FR JCT BOX 24V IGNITION
12Y	FR JCT BOX 12V DISC SW	24IF	FR JCT BOX 24V IGNITION
13A	ALARM & SIGNAL-LO AIR PRIM.	24J	FR JCT BOX 24V DISC SW
13B	ALARM & SIGNAL-LO AIR SEC.	24K	FR JCT BOX 24V DISC SW
14	LAVATORY-FLUSHING PUMP	24P	FR JCT BOX 24V DISC SW
14A	LAVATORY-FLUSHING PUMP	24PV	INVERTER CPT 24V DISC SW
15	EXTERIOR LTS-MULTI FUNC LEVEL	24S	24V DISC SW RLY SIGNAL
15A	WIPER & WASHER UPPER WINDSHIELD	24S1	SOUND SYSTEM 24V AMPLIFIER
16	SPEEDO - SIGN	24S2	SOUND SYSTEM 24V AMPLIFIER
16S	SPEEDO - TRANSMITTER	24S3	SOUND SYSTEM 24V VIDEO
16T	SPEEDO - TRANSMITTER	24S4	SOUND SYSTEM 24V VIDEO
17	EXTERIOR LTS-FLASHER UNIT	24SB	SOUND SYSTEM 24V FEEDING
17A	EXTERIOR LTS-FLASHER UNIT	24SS	SOUND SYSTEM 24V FEEDING
19	DIFFERENTIAL OIL TEMP	24T	RR JCT BOX 24V DISC SW
20	SPEEDO - NEGATIVE SIGN	24V2	RR JCT BOX 24V DISC SW
20T	SPEEDO - NEGATIVE SIGN	24V3	RR JCT BOX 24V DISC SW
21	EXTERIOR LTS-DIRECTIONNAL LH	24V4	RR JCT BOX 24V DISC SW
21A	EXTERIOR LTS-DIRECTIONNAL LH	24V5	RR JCT BOX 24V DISC SW

PREVOST CAR inc.
WIRING DIAGRAM
NO: D060869
P.E / 1/4
REVISION 014

CIRCUIT NUMBER CODE Page E : 2

No.	SYSTEM
24VD	24V HOT WIRE DISTRIBUTION
24VF	BAT CPT 24V SW TO FJB & IC
24VF	INVERTER CPT 24V DISC SW
24VA	BATTERY TO EQUALIZER 24V
24VI	RR JCT BOX 24V IGNITION
24VR	BAT CPT 24V DISC SW TO RJB
24W	RR JCT BOX 24V DISC SW (WCL)
24WC	BATT. CPT TO HYD. PUMP (WCL)
24WL	24V BATTERY-HYD.PUMP (WCL)
24X	FR JCT BOX 24V DISC SW
24X2	FR JCT BOX 24V DISC SW
24Y	FR JCT BOX 24V DISC SW
24Y2	FR JCT BOX 24V DISC SW
25	12VAC GEN RLY ON SIGNAL
25A	NOT GENERATOR-WARNING LT
25B	EXTERIOR LTS-DAYTIME RUN LTS
26	DRIVER'S WINDOW LIFTER
26	CIGAR LIGHTER
26B	DRIVER'S WINDOW LIFTER
26C	DRIVER'S WINDOW LIFTER
27	LAVATORY-EMERGENCY SONALERT
28A	A/C & HEAT SYSTEM-HI PRESSURE
29	A/C & HEAT SYSTEM-DRIVER'S HTR
29A	A/C & HEAT SYSTEM-DRIVER'S HTR
29B	A/C & HEAT SYSTEM-DRIVER'S HTR
30A	GALLEY
31A	A/C & HEAT SYSTEM-UNLOADER
31B	A/C & HEAT SYSTEM-UNLOADER
31B	WIPER & WASHER SYSTEM
31C	WIPER & WASHER SYSTEM
31D	WIPER & WASHER SYSTEM
31E	WIPER & WASHER SYSTEM
31J	WIPER & WASHER SYSTEM
31X	WIPER & WASHER SYSTEM
32	EXTERIOR LTS-BACK-UP
32B	EXTERIOR LTS-BACK-UP
32C	BACK-UP PWR & SIGNAL
32D	BACK-UP ALARM
32F	BACK-UP MONITOR
35	ENTRANCE DOOR (SEDAN)
35B	ENTRANCE DOOR (SEDAN)
35BB	ENTRANCE DOOR (SEDAN)
35D	ENTRANCE DOOR (SEDAN)
36	JACOB BRAKE SYSREM
36A	JACOB BRAKE SYSREM
38	INTERIOR LTS-24V FLUORESCENT
38A	INTERIOR LTS-24V FLUORESCENT
38C	INTERIOR LTS-24V FLUORESCENT
38D	INTERIOR LTS-24V FLUORESCENT
39	INTERIOR LTS-24V LH CONSOLE SW
39A	INTERIOR LTS-DRIVER"S LTS
41	A/C & HEAT SYSTEM-COND FAN MOT
41A	A/C & HEAT SYSTEM-COND FAN MOT
41B	A/C & HEAT SYSTEM-COND FAN MOT
42	A/C & HEAT SYSTEM-COND FAN MOT
42A	A/C & HEAT SYSTEM-COND FAN MOT
44	EXTERIOR LTS-FOG
44A	EXTERIOR LTS-FOG
44B	EXTERIOR LTS-FOG
44C	EXTERIOR LTS-FOG & HAZARD
45B	A/C & HEAT SYSTEM-HEAT 3 SIGN

No.	SYSTEM
45D	A/C & HEAT SYSTEM-WATER VALVE
45E	A/C & HEAT SYSTEM-HEAT 1 SIGN
45G	A/C & HEAT SYSTEM-DRIVER'S HTR
45H	A/C & HEAT SYSTEM-DRIVER'S HTR
45W	A/C & HEAT SYSTEM-DRIVER'S HTR
46	EXTERIOR LTS-MARKER
46A	EXTERIOR LTS-MARKER
46B	EXTERIOR LTS-MARKER
46B	EXTERIOR LTS-MARKER
46C	EXTERIOR LTS-MARKER
47	A/C & HEAT SYSTEM-DRIVER'S HTR
48	ENTRANCE DOOR (SEDAN)
48A	ENTRANCE DOOR (SEDAN)
48B	ENTRANCE DOOR (SEDAN)
48C	ENTRANCE DOOR (SEDAN)
48D	ENTRANCE DOOR (SEDAN)
49	ENTRANCE DOOR (SEDAN)
49A	ENTRANCE DOOR (SEDAN)
49B	ENTRANCE DOOR (SEDAN)
50	AIR DRYER
52	ALARM & SIGNAL-ELEC. HORN
52A	ALARM & SIGNAL-ELEC. HORN
53	ALARM & SIGNAL-ELEC. HORN
53A	WIPER & WASHER SYSTEM
53B	WIPER & WASHER SYSTEM
53C	WIPER & WASHER SYSTEM
53E	WIPER & WASHER SYSTEM
53J	WIPER & WASHER SYSTEM
55	EXTERIOR LTS-HI BEAM
57	EXTERIOR LTS-HI BEAM
57A	EXTERIOR LTS-HI BEAM
57A	A/C & HEAT SYSTEM-WATER PUMP
57B	A/C & HEAT SYSTEM-WATER PUMP
57C	PRE-HEAT WATER HEATER
57E	EXTERIOR LTS-HEAD LTS
58	EXTERIOR LTS-LO BEAM
58A	EXTERIOR LTS-LO BEAM
58B	EXTERIOR LTS-LO BEAM
58E	EXTERIOR LTS-LO BEAM
59A	JACOB BRAKE SYSTEM
61	EXTERIOR LTS-24V FEED SW
61A	EXTERIOR LTS-HEAD SIGNAL
62	LAVATORY-OCCUPIED LT
62A	LAVATORY-FLUOR LT
62B	LAVATORY-FLUOR LT
62E	LAVATORY-OCCUP & FLUOR LT
63	EXTERIOR LTS-CLEARANCE
63A	EXTERIOR LTS-CLEARANCE
63B	EXTERIOR LTS-CLEARANCE
63C	EXTERIOR LTS-MARKER SIGNAL
63D	EXTERIOR LTS-MARKER & TAIL
63E	EXTERIOR LTS-CLEARANCE
63F	EXTERIOR LTS-MARKER BLINKER
63H	EXTERIOR LTS-TAIL
67	A/C & HEAT SYSTEM
67A	A/C & HEAT SYSTEM
67B	A/C & HEAT SYSTEM
67C	A/C & HEAT SYSTEM & HEAT WINDS.
67K	A/C & HEAT SYSTEM-COND FAN CTR
67L	A/C & HEAT SYSTEM-COND FAN CTR
67V	A/C & HEAT SYSTEM-WATER VALVE

CIRCUIT NUMBER CODE Page E : 2

No.	SYSTEM
70	INTERIOR LTS-HAT RACK & RR RUN.
71	EXTERIOR LTS-DOCKING
71C	EXTERIOR LTS-DOCKING
71D	EXTERIOR LTS-DOCKING
71R	EXTERIOR LTS-DOCKING
71G	EXTERIOR LTS-DOCKING
71L	EXTERIOR LTS-DOCKING
72	SUN VISOR-FEEDING
72A	SUN VISOR-RH
72B	SUN VISOR-RH
72C	SUN VISOR-LH
72D	SUN VISOR-LH
73	LAVATORY-FEEDING
74	INTERIOR LTS-READING RH
74A	INTERIOR LTS-READING RH
74D	INTERIOR LTS-READING SIGNAL
75	INTERIOR LTS-READING LH
75A	INTERIOR LTS-READING LH
76	FUEL TANK GAUGE
76B	LOW FUEL LT & ETHER COLD START
76C	LOW FUEL LT
76M	FUEL PRIME PUMP
76P	FUEL PRIME PUMP
77	A/C & HEAT SYSTEM-HI PRESSURE
77A	A/C & HEAT SYSTEM-DRIVER'S HTR
77B	A/C & HEAT SYSTEM-COMPRESSOR
77C	A/C & HEAT SYSTEM-COMPRESSOR
77H	A/C & HEAT SYSTEM-COMPRESSOR
81	EXTERIOR LTS-STOP SW
82	EXTERIOR LTS-STOP SIGNAL
82A	EXTERIOR LTS-STOP SIGNAL
82B	EXTERIOR LTS-STOP LTS
82K	EXTERIOR LTS-STOP PARK BRK
82L	EXTERIOR LTS-LH STOP
82R	EXTERIOR LTS-LH STOP
83	ENGINE CTR-KEY SW ACCES SIGN
84	ENGINE CTR-KEY SW START SIGN
85	ENGINE CTR-KEY SW IGNITION SIGN
85	24V IGNITION SIGNAL
85A	24V IGN DASH INSTRUMENTATION
85B	ENGINE CTR-24V IGNITION
85C	PARKING BRAKE SWITCH
85F	LO AIR SONALERT
85F	ENGINE CTR-ENGINE CTRL SW IGN
85W	24V IGN ANTI SKID
85X	24V IGN ANTI SKID
85Y	ANTI SKID-WARNING LT
86	ENGINE CTR-STARTER SOL SIGN
86A	ENGINE CTR-STARTER SOL SIGN
88	ENGINE CTR-RR START SIGNAL
89	ENGINE CTR-RR START SIGNAL
90A	A/C & HEAT SYSTEM-COND FAN MOT
90B	A/C & HEAT SYSTEM-COND FAN MOT
90B	ENGINE CTR-MAST KEY SW FEED
90C	A/C & HEAT SYSTEM-COND FAN MOT
90D	A/C & HEAT SYSTEM-EVAP FAN MOT
90F	CHARG SYST-VOLTAGE REGUL. "B"
90G	A/C & HEAT SYSTEM-COND FAN MOT
90H	A/C & HEAT SYSTEM-EVAP FAN MOT
90J	A/C & HEAT SYSTEM-COND FAN MOT
91	PARKING BRAKE SW SIGNAL

No.	SYSTEM
91A	DDEC-FAST IDLE SIGNAL
91W	PARK. BRAKE SW. SIGN. (WCL)
92	BATTERY EQUALIZER-CHECK BALANCE
93	BATTERY EQUALIZER-CHECK LO/HI
95A	ENGINE BRAKE & RETARDER SYSTEM
97	TACHOMETER (-)
100	INTERIOR LTS-GENERAL
100A	INTERIOR LTS-GENERAL
100B	INTERIOR LTS-GENERAL
101	24V STARTER SOL FEEDING
101	WORLD TRANSM-LO SIGNAL SOL. LO
102	24V STARTER TO GENERATOR
102	WORLD TRANSM-SOL. GRD 1
102	WORLD TRANSM-SOL. C3
103	LOW BUOY
104	WORLD TRANSM-SOL. FORWARD
105	WORLD TRANSM-RETARDER & SUMP
105W	WORLD TRANSM-RETARDER & SUMP
106	WORLD TRANSM-OIL LEVEL HI
107	CHARG SYST-VOLTAGE REGUL. "F"
107	WORLD TRANSM-LOCKUP SOL. HI
108	WORLD TRANSM-REMOTE PWR WAKE UP
109	WORLD TRANSM-RET. SOL. LO
110	ALARM & SIGNAL-WATER TEMP
110	WORLD TRANSM-LOCKUP SOL. LO
111	WORLD TRANSM-SOL. C6
112	WORLD TRANSM-SPARE OUTPUT (+)
113	ALARM & SIGNAL-OIL PRESS
113	WORLD TRANSM-REVERSE WARNING
114	WORLD TRANSM-SPARE OUTPUT (-)
114	INTERIOR LTS-DASH LT REGUL.
114A	INTERIOR LTS-DASH LT
114B	INTERIOR LTS-DASH LT REGUL.
114D	INTERIOR LTS-DASH LT REGUL.
114E	INTERIOR LTS-DASH LT REGUL.
115	ALARM & SIGNAL-TAG PRESS
115	DDEC III-COOLANT LEVEL
115	WORLD TRANSM-DO NOT SHIFT SIGNAL
115C	DDEC III-COOLANT LEVEL
115W	WORLD TRANSM-DO NOT SHIFT SIGNAL
116	WORLD TRANSM-LO SIGNAL SOL. HI
116B	A/C & HEAT SYSTEM-DRIVER'S HTR
117	WORLD TRANSM-SPARE INPUT (-)
117A	ALARM & SIGNAL-TRANSM OIL TEMP
117A	ALARM & SIGNAL-TRANSM OIL TEMP
118	WORLD TRANSM-SPARE INPUT (+)
119	WORLD TRANSM-ENG BRK INPUT (+)
120	WORLD TRANSM-SOL. C1
121	WORLD TRANSM-SOL. GRD 2
122	WORLD TRANSM-SOL. GRD 4
122	A/C & HEAT SYSTEM-DRIVER'S HTR
122	A/C & HEAT SYSTEM-FRESH AIR
122A	A/C & HEAT SYSTEM-FRESH AIR
123	WORLD TRANSM-NEUTRAL START
123A	ALARM & SIGNAL-FIRE DETECTOR
123B	ALARM & SIGNAL-FIRE DETECTOR
124	WORLD TRANSM-THROTTLE (HI)
125	WORLD TRANSM-RETARDER INDICATOR
125	LAVATORY-FAN
125	GALLEY-LAMP
125W	WORLD TRANSM-RETARDER INDICATOR

PREVOST CAR inc.	WIRING DIAGRAM	NO: D060869	P. E / 2 4	REVISION 014

CIRCUIT NUMBER CODE

Page E : 3

No.	SYSTEM
126	WORLD TRANSM-LUBE PRESS SW.
126	KNEELING SYSTEM
126A	KNEELING SYSTEM
126B	KNEELING SYSTEM
126C	KNEELING SYSTEM
126D	KNEELING SYSTEM
126E	KNEELING SYSTEM
126F	KNEELING SYSTEM
126G	KNEELING SYSTEM
126H	KNEELING SYSTEM
126K	KNEELING SYSTEM
126P	KNEELING SYSTEM
126R	KNEELING SYSTEM
126S	KNEELING SYSTEM
126T	KNEELING SYSTEM
126W	5 MPH N.C. SIGNAL (WCL)
127	WORLD TRANSM-RETARDER FEED SOL.
127	PRE-HEAT WATER HEATER
127A	PRE-HEAT WATER HEATER
127B	PRE-HEAT WATER HEATER
127S	PRE-HEAT WATER HEATER
127W	PRE-HEAT WATER HEATER
128	WORLD TRANSM-SOL. C2
128	PRE-HEAT WATER HEATER
128A	PRE-HEAT WATER HEATER
128B	PRE-HEAT WATER HEATER
128W	PRE-HEAT WATER HEATER
129	PRE-HEAT WATER HEATER
129	WORLD TRANSM-SOL. C5
130	WORLD TRANSM-SOL. GRD 3
131	WORLD TRANSM-SOL. C4
132	WORLD TRANSM-ENG BRK OUTPUT (-)
132W	WORLD TRANSM-ENG BRK OUTPUT (-)
133	WORLD TRANSM-RET. ACTUATOR HI
133	GALLEY-HEAT CONTAINERS
133A	GALLEY-HEAT CONTAINERS
133B	GALLEY-HEAT CONTAINERS
133C	GALLEY-HEAT CONTAINERS
134	WORLD TRANSM-RET. APPLY SOL. HI
134	GALLEY-HEAT CONTAINERS
134A	GALLEY-HEAT CONTAINERS
135	A/C & HEAT SYSTEM-AIR SENSOR
135	WORLD TRANSM-ANALOG GRD
135A	A/C & HEAT SYSTEM-AIR SENSOR
135C	WORLD TRANSM-RETARDER TEMP
135C	A/C & HEAT SYSTEM-AIR SENSOR
135D	WORLD TRANSM-RETARDER RES MOD
135D	A/C & HEAT SYSTEM-AIR SENSOR
136	GALLEY-ACCESSORIES
136	WORLD TRANSM-ECU POWER
136V	WORLD TRANSM-12V BATTERY
136W	WORLD TRANSM-12V BATTERY
136X	WORLD TRANSM-12V BATTERY
137	WORLD TRANSM-RETARDER
137	MIRROR (SPARTAN & RAMCO)
137A	MIRROR (SPARTAN & RAMCO)
137B	RR VIEW MIRROR (SPARTAN)
137C	RR VIEW MIRROR (SPARTAN)
137D	RR VIEW MIRROR (SPARTAN)
137E	RR VIEW MIRROR (SPARTAN)
137F	RR VIEW MIRROR (SPARTAN)
137G	RR VIEW MIRROR (SPARTAN)
138	WORLD TRANSM-RETARDER TEMP
138	ABS SYSTEM
138A	ABS SYSTEM
139	WORLD TRANSM-OUTPUT SPEED HI
139	ABS SYSTEM
140	WORLD TRANSM-OUTPUT SPEED LO
140	ABS SYSTEM
141	ABS SYSTEM
141	WORLD TRANSM-ENGINE SPEED HI
142	ABS SYSTEM
142	WORLD TRANSM-SERIAL COM. A
143	ABS SYSTEM
143	WORLD TRANSM-ECU BATTERY GRD
143A	ABS SYSTEM
143W	WORLD TRANSM-BATTERY GRD
143X	WORLD TRANSM-BATTERY GRD
144	WORLD TRANSM-ECU CHASSIS GRD
144	ABS SYSTEM
144A	ABS SYSTEM
145	ABS SYSTEM
146	ABS SYSTEM
146	WORLD TRANSM-IGNITION SENSE
146W	WORLD TRANSM-12V IGNITION
146X	WORLD TRANSM-12V IGNITION
147	WORLD TRANSM-OIL TEMP
147	ABS SYSTEM
147	ETHER COLD START
147C	ETHER COLD START
148	WORLD TRANSM-OUTPUT SPEED LO
148	ABS SYSTEM
149	WORLD TRANSM-TURBINE SPEED HI
149	ABS SYSTEM
149A	ABS SYSTEM
150	WORLD TRANSM-ENGINE SPEED LO
150	DDEC III-ECM BATTERY GRD
150A	DDEC III-ECM BATTERY GRD
151	DDEC III-ECM BATTERY GRD
151	WORLD TRANSM-SERIAL COM. B
151	ABS SYSTEM
151A	ABS SYSTEM
152	ABS SYSTEM
152A	ABS SYSTEM
153	WORLD TRANSM-SPARE INPUT (-)
153	ABS SYSTEM
154	WORLD TRANSM-ABS RETARDER INPUT
154	ABS SYSTEM
155	WORLD TRANSM-SPARE INPUT (-)
155	ABS SYSTEM
156	WORLD TRANSM-THROTTLE POS.
156	ABS SYSTEM
156A	ABS SYSTEM
157	WORLD TRANSM-SPEEDOMETER SIGNAL
157	ABS SYSTEM
157A	ABS SYSTEM
157B	ABS SYSTEM
158	WORLD TRANSM-DIMMER
160	ALARM & SIGNAL-TAG PRESS SW
160	WORLD TRANSM-SER. INTERFACE (-)
161	WORLD TRANSM-SIGNAL GRD
161B	WORLD TRANSM-SIGNAL GRD

CIRCUIT NUMBER CODE

Page E : 3

No.	SYSTEM
162	WORLD TRANSM-PRESS. SW C3
163	WORLD TRANSM-RETARDER ENABLE
164	WORLD TRANSM-RET. ACTUATOR SIGN
165	WORLD TRANSM-OIL LEVEL SIGNAL
165	A/C & HEAT SYSTEM-TRANSMITER
165A	A/C & HEAT SYSTEM-TRANSMITER
165B	A/C & HEAT SYSTEM-TRANSMITER
165C	A/C & HEAT SYSTEM-TRANSMITER
165D	A/C & HEAT SYSTEM-TRANSMITER
166B	A/C & HEAT SYSTEM-EVAP. MOD.
167	A/C & HEAT SYSTEM-TEMP. CTR
167A	A/C & HEAT SYSTEM-TEMP. CTR
168	WORLD TRANSM-SER. INTERFACE (+)
168	A/C & HEAT SYSTEM-HUMIDISTAT
168A	A/C & HEAT SYSTEM-HUMIDISTAT
170	LUGGAGE DOOR LOCK
170C	LUGGAGE DOOR LOCK
170E	LUGGAGE DOOR LOCK
170H	LUGGAGE DOOR LOCK
180	DIGITAL THERMOMETER
181	DIGITAL THERMOMETER
197	FUEL WATER FILTER
197A	FUEL WATER FILTER
197B	FUEL WATER FILTER
201	WORLD TRANSM-SPARE
202	WORLD TRANSM-SPARE
203	WORLD TRANSM-SPARE
204	WORLD TRANSM-SPARE
205	WORLD TRANSM-SPARE
206	WORLD TRANSM-SPARE
214	WORLD TRANSM-BACK UP SIGNAL
231	NEUTRAL SIGNAL GRD
231W	NEUTRAL SIGNAL GRD (WCL)
240	DDEC III-ECM 12V FEEDING
241	DDEC III-ECM 12V FEEDING
251	DDEC III - PRODRIVER 12V H.W.
253	GALLEY-MICROWAVE
254	GALLEY-12V FRIGO NORCOLD
254A	GALLEY-FRIGO
255	GALLEY-COFEEMAKER
255A	GALLEY-COFEEMAKER
257	WINDSHIELD HEATED
257A	WINDSHIELD HEATED
257B	WINDSHIELD HEATED
257C	WINDSHIELD HEATED
257D	WINDSHIELD HEATED SPARE
257E	WINDSHIELD HEATED SPARE
258	WINDSHIELD HEATED
258A	WINDSHIELD HEATED
259	WINDSHIELD HEATED
259A	WINDSHIELD HEATED
290	FAN CLUTCH RADIATOR
290A	FAN CLUTCH RADIATOR
291	FAN CLUTCH RADIATOR SPD 1
292	FAN CLUTCH RADIATOR SPD 2
300	DOOR AJAR MAGN.SW. (WCL)
300A	POWER SYSTEM SW. (WCL)
300B	DOOR AJAR ALARM (WCL)
301	POWER SYSTEM SW. (WCL)
302	DOOR AJAR T.T.L.T. (WCL)
302A	DOOR AJAR ALARM SIGN.(WCL)
302B	DOOR AJAR MAGN.SW. (WCL)
303	REMOTE WALL SW. DWN (WCL)
304	REMOTE WALL SW. UP (WCL)
305	PARK. BRAKE SOL. VALVE (WCL)
305A	PARK. BRAKE SAFETY SW. (WCL)
306	CONTROL SYSTEM (WCL RICON)
307	CONTROL SYSTEM (WCL RICON)
308	CONTROL SYSTEM (WCL RICON)
309	CONTROL SYSTEM (WCL RICON)
417	DDEC III-LIMIT SPEED GOVERNOR
419	DDEC III-CHECK ENGINE LIGHT
439	DDEC III-12V IGNITION
440	DDEC III-12V IGNITION
440A	DDEC III-12V IGNITION
451	DDEC III-A/C FAN CLUTCH
505	DDEC III-TACHOMETER DRIVE
509	DDEC III-STOP ENGINE LIGHT
510	DDEC III-FAST IDLE SIGNAL
524	DDEC III-ENGINE BRAKE DISABLE
525	DDEC III-FAST IDLE SIGNAL
528	DDEC III-STOP ENG. OVERRIDE
531	DDEC III-CRUISE CLUTCH RELEASE
541	DDEC III-CRUISE SET SW
543	DDEC III-CRUISE STOP SW CUT IN
544	DDEC III-CRUISE ON/OFF SW
545	DDEC III-CRUISE RESUME SW
555	DDEC III-FAN CLUTCH SPEED# 1
556	DDEC III-VEHICLE SPEED (+)
557	DDEC III-VEHICLE SPEED (-)
563	DDEC III-FAN CLUTCH SPEED# 2
564	DDEC III-DIGITAL OUTPUT
565	DDEC III-ENGINE BRAKE ACTIVE
583	DDEC III-ENGINE BRAKE 4 CYL.
900	DDEC III-DATA LINK (+)
901	DDEC III-DATA LINK (-)
908	DDEC III-HYDRAULIC PWM#1 OUTPUT
916	DDEC III-SENSOR SUPPLY (5VDC)
952	DDEC III-SENSOR RETURN
953	DDEC III-BATTERY GRD
979	DDEC III-ENGINE BRAKE 2 CYL.
B00	RR JCT BOX CPT BATT GRD
B000	RR JCT BOX CPT BATT GRD
BA	INTERIOR LTS-110V FLUORESCENT
BB	INTERIOR LTS-110V FLUORESCENT
D1	SOUND SYSTEM-FR RH SPEAKER
D2	SOUND SYSTEM-FR RH SPEAKER
D3	SOUND SYSTEM-FR RH SPEAKER
D4	SOUND SYSTEM-RR RH SPEAKER
D5	SOUND SYSTEM-RR RH SPEAKER
D6	SOUND SYSTEM-RR RH SPEAKER
D9	SOUND SYSTEM-DRIVER SPEAKER
D10	SOUND SYSTEM-DRIVER SPEAKER

PREVOST CAR inc.	WIRING DIAGRAM	NO: D060869	P. E / $^{3}{}_{4}$	REVISION 019

CIRCUIT NUMBER CODE Page E : 4

No.	SYSTEM
G1	SOUND SYSTEM-FR LH SPEAKER
G2	SOUND SYSTEM-FR LH SPEAKER
G3	SOUND SYSTEM-FR LH SPEAKER
G4	SOUND SYSTEM-RR LH SPEAKER
G5	SOUND SYSTEM-RR LH SPEAKER
G6	SOUND SYSTEM-RR LH SPEAKER
G9	SOUND SYSTEM-DRIVER SPEAKER
G10	SOUND SYSTEM-DRIVER SPEAKER
L1A	INTERIOR LTS-110V FLUORESCENT
L1B	INTERIOR LTS-110V FLUORESCENT
L2	INTERIOR LTS-110V FLUORESCENT
L2A	INTERIOR LTS-110V FLUORESCENT
L2B	INTERIOR LTS-110V FLUORESCENT
L3A	GALLEY-110V FRIGO
L4	GALLEY-110V FRIGO
LL0	110V RECEPTACLE
LL1	110V RECEPTACLE
LL2	110V RECEPTACLE
LL3	GALLEY-110V FRIGO
L7	GALLEY-110V MICROWAVE OVEN
L8	ENG. BLK & WATER TANK-HEATER
L9	ENG. BLK & WATER TANK-HEATER
N1	VIDEO SYSTEM-110V INVERTER
N7	GALLEY-110V MICROWAVE OVEN
RA	INTERIOR LTS-110V FLUORESCENT
RB	INTERIOR LTS-110V FLUORESCENT
YC	INTERIOR LTS-110V FLUORESCENT
YD	INTERIOR LTS-110V FLUORESCENT
WC	A/C & HEAT SYST-EVAP CTR SIGN
SH2	SPEEDOMETER-SHIELD GRD
SH4	SPEEDOMETER-SHIELD GRD
SP2	SPARE-FJB TO FR SERV CPT
SP3	SPARE-FJB TO CENTER DASH
SP4	SPARE-FJB TO CENTER DASH
SP5	SPARE-RJB TO LUGG CPT #2
SP6	SPARE-RJB TO LUGG CPT #1
SP7	SPARE-RJB TO LUGG CPT #1
SP8	SPARE-RJB TO LUGG CPT #1
SP9	SPARE-RJB TO LUGG CPT #2
SP10	SPARE-RJB TO LUGG CPT #1
SP11	SPARE-RJB TO ENGINE
SP12	SPARE-RJB TO ENGINE
SP13	SPARE-RJB TO ENGINE
SP14	SPARE-FJB TO FR SERV CPT
SP15	SPARE-RJB TO ENGINE
SP16	SPARE-RJB TO ENGINE
SP17	SPARE-RJB TO ENGINE
SP18	SPARE-FJB TO FR SERV CPT
SP24	SPARE-RJB TO LH HAT RACK
SP25	SPARE-RJB TO LH HAT RACK
SP26	SPARE-RJB TO LH HAT RACK
SP27	SPARE-RJB TO LH HAT RACK
SP28	SPARE-RJB TO LH HAT RACK
SP31	SPARE-RJB TO RH HAT RACK
SP32	SPARE-RJB TO RH HAT RACK
SP33	SPARE-FJB TO RJB
SP36	BACK-UP MONITOR-RJB TO LH SW PANEL
SP37	SPARE-ALARM JCT BOX
SP38	SPARE-ALARM JCT BOX TO RJB
SP39	SPARE-ALARM JCT BOX TO FJB
SP40	SPARE-ALARM JCT BOX TO FJB
SP43	SPARE-FJB TO RJB
SP45	SPARE-FJB TO RJB
SP46	SPARE-RJB TO LH FR ROOF
SP48	SPARE-RJB TO RH FR ROOF
SP56	SPARE-FJB TO RH SW PANEL
SP57	SPARE-FJB TO ENGINE
SP58	SPARE-FJB TO ENGINE
SP59	SPARE-FJB TO ENGINE
SP61	SPARE-FJB TO RH CONSOLE
SP68	SPARE-FJB TO ENGINE ECM
SP69	SPARE-FJB TO FR AXLE
SP70	SPARE-FJB TO FR AXLE
SP71	SPARE-FJB TO RH SW PANEL
SP72	SPARE-FJB TO FR SERV CPT
SP74	SPARE-FJB TO LH CONSOLE
SP77	SPARE-FJB TO A/C JB CPT
SP78	SPARE-FJB TO A/C JCT BOX
SP79	SPARE-FJB TO A/C JCT BOX
SP80	SPARE-TO A/C JCT BOX CPT
SP82	SPARE-FJB TO LH CONSOLE
SP83	SPARE-FJB TO RH CONSOLE
SP84	SPARE-FJB TO RH CONSOLE
SP85	SPARE-FJB TO LH CONS & SW PAN
SP86	SPARE-FJB TO LH CONS & SW PAN
SP87	SPARE-RJB TO LH HAT RACK
SP88	SPARE-RJB TO RH HAT RACK
SP92	SPARE-RJB TO A/C JCT BOX
SP93	SPARE-RJB TO EVAPORATOR CPT
SP94	SPARE-RJB TO RR ROOF
SP95	SPARE-RJB TO RR ROOF
SP96	SPARE-RJB TO LUGG CPT #2
SP97	SPARE-RJB TO LUGG CPT #3
SP98	SPARE-RJB TO LUGG CPT #3
SP100	SPARE-DATA LOGGER
SP101	SPARE-DATA LOGGER
SP104	SPARE-RJB TO ENGINE CPT
SP105	SPARE-DASH TO ENGINE CRADLE ACCES.
SP106	SPARE-RJB TO BATT. CPT.
SP107	SPARE-RJB TO BATT. CPT.
SP108	SPARE-RJB TO BATT. CPT.
SP109	SPARE-RJB TO ENGINE CPT.
SP110	SPARE-RJB TO ENGINE CPT.
SP111	SPARE-RJB TO ENGINE CPT.
SP112	SPARE-RJB TO ENGINE CPT.
SP113	SPARE-RJB TO WCL JCT BOX RICON

CIRCUIT NUMBER CODE Page E : 4

No. SYSTEM No. SYSTEM

PREVOST CAR inc.

WIRING DIAGRAM

NO: D060869

P. E / 4 4

REVISION 019