LAZER FORMAT "A" CHELLE 8.2:

CONNECTORS CODE ID Page G-1

No.	LOCATION	#WD TYPE	*PIN CAVITY	*SOCKET HOUSING	HOUSING
C1	FR JCT BDO COMPARTMENT	AMP CPC	37	560644	560646
C2	FR JCT BDO COMPARTMENT	AMP CPC	24	560641	560643
C3	FR JCT BDO COMPARTMENT	AMP CPC	37	560714	560713
C4	FR JCT BDO COMPARTMENT	AMP CPC	16	560493	560495
C5	FR SERVICE COMPT.-UNDERNEATH	AMP CPC	37	560644	560646
C6	FR SERVICE COMPT.-UNDERNEATH	AMP CPC	24	560641	560643
C7	FR JCT BDO COMPT.-UNDERNEATH	AMP CPC	37	560714	560716
C8	FR SERVICE COMPT.-UNDERNEATH	AMP CPC	37	560714	560713
C9	ALARM JCT BDO	AMP CPC	37	560644	560646
C10	ALARM JCT BDO	AMP CPC	24	560641	560643
C11	FR SERVICE COMPARTMENT	AMP CPC	24	560642	560643
C12	FR SERVICE COMPARTMENT	AMP CPC	16	560639	560640
C13	LH CONSOLE-HEATER MOR.	AMP HML	2	561248	561247
C14	FR SERVICE COMPT.	AMP HML	8	560562	561315
C15	LH CONSOLE-CE THRROR	AMP HML	6	561552	561515
C16	UNDER DASH-LH MIRROR	AMP HML	6	561552	561515
C17	RR JCT BDO	AMP CPC	24	560641	560643
C18	LH CONSOLE-RH MIRROR	AMP HML	8	560562	561315
C19	LH CONSOLE-CE CTR MIRROR	AMP HML	6	561552	561515
C20	LH CONSOLE-CRUISE ON/OFF	SWF	8	------	561107
C21	LH CONSOLE-CRUISE RESUME	SWF	8	------	561107
C22	UNDER DASH-LH MIRROR	AMP HML	6	561552	561515
C23	RR JCT BDO	AMP CPC	37	560644	560646
C24	RR JCT BDO	AMP CPC	24	560641	560643
C25	HYD & HAN TRANSM.-NEUT.& B.U.	PED WP	4	561610	561611
C26	HYD & HAN TRANSM.-SPEED SENS.	PED WP	2	561766	561767
C27	DOOR ENGINE-ECH	PED	30	------	561600
C28	RR JCT BDO	AMP CPC	24	560641	560643
C29	EMERGENCY EXIT LTS	AMP HML	2	561248	561247
C30	RR SECTION-LH HAT RACK	AMP HML	6	560661	561662
C31	RR SECTION-RH HAT RACK	AMP HML	6	560661	561662
C32	RR JCT BDO	AMP CPC	16	560639	560640
C33	LAVATORY-ROOF FLUORESCENT	AMP HML	2	560920	560898
C34	LAVATORY-BACK WALL-WTR TANK	AMP HML	2	560920	560898
C35	LAVATORY-BACK WALL-ACCESS.	AMP HML	6	560661	561662
C36	ALARM JCT BDO COMPARTMENT	AMP CPC	24	560642	560643
C37	LAVATORY-ROOF FLUORESCENT	AMP HML	2	560920	560898
C38	BATTERY COMPARTMENT	AMP HML	4	561605	561517
C39	FR SERVICE COMPT.-LOW BLOC	PED WP	1	561605	561517
C40	FR JCT BDO	AMP CPC	22	560714	560716
C41	FR JCT BDO	AMP CPC	14	560585	560584
C42	UNDER DASH-RH SW PANEL	AMP CPC	9	560636	560637
C43	UNDER DASH-RH CONSOLE	AMP CPC	24	560642	560643
C44	UNDER DASH-RH ACCESSORIES	AMP CPC	22	561995	561718
C45	UNDER DASH-RH ACCESSORIES	AMP CPC	22	561995	561718
C46	EVAPORATOR COMPARTMENT	AMP HML	2	561248	561249
C47	FR JCT BDO COMPT.-L.T.	AMP HML	2	561248	561247
C48	LUGGAGE COMPARTMENT LTS	AMP HML	2	561248	561247
C49	LUGGAGE COMPARTMENT LTS	AMP HML	2	561248	561247
C50	LUGGAGE COMPARTMENT LTS	AMP HML	2	561248	561247
C51	LUGGAGE COMPARTMENT LTS	AMP HML	2	561248	561247

CONNECTORS CODE ID Page G-1

No.	LOCATION	#WD TYPE	*PIN CAVITY	*SOCKET HOUSING	HOUSING
C52	LUGGAGE COMPARTMENT LTS	AMP HML	2	561248	561247
C53	LUGGAGE COMPARTMENT LTS	AMP HML	2	561248	561247
C54	LUGGAGE COMPARTMENT LTS	AMP HML	2	561248	561247
C55	LUGGAGE COMPARTMENT LTS	AMP HML	2	561248	561247
C56	ALARM JCT BDO COMPARTMENT	AMP CPC	24	560642	560643
C57	UNDER INSTRUMENT PANEL-LH	AMP CPC	37	560645	560646
C58	UNDER INSTRUMENT PANEL-CENT.	AMP CPC	16	560639	560640
C59	UNDER INSTRUMENT PANEL-CENT.	AMP CPC	37	560714	560713
C60	ALARM JCT BDO COMPARTMENT	PED WP	2	561610	561611
C61	LUGGAGE COMPT.-AIR RET.SENS.	AMP HML	2	561248	561247
C62	LUGGAGE COMPT.-AIR RET.SENS.	AMP HML	2	561248	561247
C63	FR JCT BDO COMPARTMENT	AMP CPC	22	561791	561718
C64	FR SERVICE COMPT.-UNDERNEATH	AMP CPC	37	560644	560646
C65	LUGGAGE COMPT.-AIR RET.SENS.	AMP HML	2	561248	561247
C66	LUGGAGE COMPT.-AIR RET.SENS.	AMP HML	2	561248	560898
C67	ENTRANCE DOOR	MODULE	6	562078	562069
C68	ENTRANCE DOOR-PRIORITY MOD.	MODULE	6	562078	561476
C69	ENTRANCE DOOR-PRESSURE SW.	PED WP	1	561605	561517
C70	UNDER INSTRUMENT PANEL-LH	AMP HTA-100	8	------	562248
C71	BATT.& RR JB,OPT.MARKER,LT	PED WP	2	561610	561611
C72	FR JCT BDO COMPT.-LTS	AMP HML	2	561248	561247
C73	RR JCT BDO	AMP CPC	16	560639	560640
C74	FR JCT BDO	AMP CPC	14	560585	560584
C75	RR JCT BDO	AMP CPC	16	560639	560640
C76	FR JCT BDO COMPT.-HATS SKID	AMP CPC	16	560639	560637
C77	FR JCT BDO COMPT.-HATS SKID	AMP CPC	16	560639	560637
C78	FR AXLE ACCESSORIES	AMP CPC	14	560585	560585
C79	FR AXLE ACC.-INSIDE PVC END	PED WP	6	561566	561578
C80	FR SERVICE COMPT.-ELCF PEDAL	PED WP	3	561782	561781
C81	FR SERVICE COMPT.LTS	AMP HML	2	561248	561247
C82	FR SERVICE COMPT.-CONDENSER	PED WP	2	561566	560690
C83	FR SERVICE COMPT.-ELEC.-HORNS	PED WP	2	561566	561690
C84	FR SERV.-ABS LH SENSOR	WABCO	3	------	561862
C85	FR SERV.& EQUIP.-HARNESS	ITT SS	2	561813	561812
C86	FR SERVICE COMPT.-ELEC.-HORNS	PED WP	2	561566	561690
C87	FR SERVICE COMPT.-CELS.WALVE	PED WP	2	561566	561690
C88	FR SERVICE COMPT.-WATER VALVE	PED WP	2	561566	561690
C89	FR SERVICE COMPT.-DAMPER	PED WP	2	561566	561690
C90	FR SERVICE COMPT.-KNEEL.SYS	PED WP	2	561566	561690
C91	FR SERVICE COMPT.-KNEEL.SYS	PED WP	2	561566	561690
C92	FR SERVICE COMPT.-KNEEL.SYS	PED WP	2	561566	561690
C93	EVAPORATOR COMPT.-DAMPER	ITT SS	2	561813	561812
C94	BATT.& RR JB,OPT.MARKER,LT	ITT SS	2	561813	561812
C95	BATT.& RR JB,OPT.MARKER,LT	ITT SS	2	561813	561812
C96	ENGINE COMPT.-HYD.PUMP	PED WP	2	561566	561690
C97	ENGINE COMPT.-LTS	PED WP	2	561566	561690
C98	ENGINE COMPT.-LAVATORY FAN	TC	2	561938	562997
C99	ENGINE CPT RR DOOR LH,O LAMP	PED WP	6	561606	561687
C100	ENGINE CPT RR DOOR LH,I LAMP	PED WP	6	561606	561687
C101	BATTERY CPT.-DOOR DR L.T.IN	ITT SS	2	561813	561812
C102	ENGINE CPT-CHAMBER DOOR	AMP HML	2	561566	561698
C103	ENGINE CPT-ETHER SW	PED WP	2	561566	561690

CONNECTORS CODE ID Page G-2

No.	LOCATION	#WD TYPE	*PIN CAVITY	*SOCKET HOUSING	HOUSING
C125	ENGINE CPT-BU.U.ALARM	PED WP	2	561566	561690
C126	ENGINE CPT-FLUSHING PUMP	PED WP	2	561566	561690
C127	ENGINE CPT-FUEL FILTER	PED WP	2	561566	561690
C128	ENGINE CPT-U-C COMPRO.UTCH	ITT SS	2	561813	561812
C129	ENGINE CPT-PRE-HEAT WATER	PED WP	2	561566	561690
C130	ENGINE CPT-UNLOADER	ITT SS	2	561813	561812
C131	ENGINE CPT-RR DOOR U.L.T.	ITT SS	2	561813	561812
C132	ENGINE CPT-W/C L.O.PRESS SW	PED WP	2	561566	561690
C133	ENGINE CPT-RR DOOR LH,CLS.LT	PED WP	6	561606	561687
C134	ENGINE CPT-RR DOOR LH,OPN.LT	PED WP	6	561606	561687
C135	FR JCT BDO-LUGGAGE DOOR ENG.	AMP HML	15	561987	561986
C136	W/C JCT BDO	AMP CPC	24	562281	562284
C137	W/C JCT BDO-TRANSMITTER	AMP HML	2	560920	560898
C138	W/C JCT BDO-CONTROL MODULE	AMP HML	2	560920	560898
C139	W/C JCT BDO-L.DOOC MODULE	AMP-HDP	15	562811	------
C140	RH HAT RACK-DOOR LAMP	AMP HML	2	561248	561247
C141	LAVATORY-DOOR WALL	AMP HML	3	560908	562086
C142	ENTRANCE DOOR-PRIORITY MOD.	MODULE	6	562078	561476
C143	ENTRANCE DOOR-PRESSURE SW	PED WP	1	561605	561517
C144	ENGINE CPT-MODULATOR VALVE	AMPHENOL	2	------	562412
C145	BATT.& RR JB,OPT.MARKER	PED WP	2	561566	561690
C146	FR JCT BDO COMPT.-LTS	AMP HML	2	561248	561247
C147	UNDER DASH-RH-LOCK SOL.	AMP CPC	4	561562	561580
C148	UNDER DASH-RH-LOCK SOL.	AMP CPC	4	561562	561581
C149	UNDER DASH-RH-LOCK SOL.	AMP CPC	4	561562	561582
C150	UNDER DASH-RH-LOCK SOL.	AMP CPC	4	561562	561583
C151	FR JCT BDO-LUGGAGE DOOR ENG.	AMP HML	15	561987	561986
C152	CONDENSER CPT-FUEL GAUGE	PED WP	4	561610	561611
C153	EVAPORATOR CPT-AIR SENSOR	PED WP	2	561248	561247
C154	EVAPORATOR CPT-FRESH AIR SENS	ITT SS	2	561813	561812
C155	EVAPORATOR CPT-AIR SENSOR	PED WP	2	561248	561247
C156	EVAPOR. CPT-EVPRATOR SENS.	PED WP	2	561566	561690
C157	EVAPORATOR CPT-WATER PUMP	PED WP	2	561566	561690
C158	CONDENSER CPT-A.C.H.E.TEMP.	PED WP	2	561566	561690
C159	CONDENSER CPT-A.C.H.E TEMP.	PED WP	2	561566	561690
C160	FR AXLE-ABS RH VALVE	WABCO	3	------	641098
C161	FR AXLE-ABS RH VALVE	WABCO	3	------	641098
C162	FR AXLE-ABS LH VALVE	WABCO	3	------	641098
C163	FR AXLE-ABS LH SENSOR	WABCO	3	641132	------
C164	FR AXLE-ABS LH VALVE	WABCO	3	------	641098
C165	FR AXLE-ABS LH VALVE	WABCO	3	------	641098
C166	FR AXLE-ABS RH VALVE	WABCO	3	------	641098
C167	EVAPORATOR CPT-DAMPER	DEUTSCH	2	562486	562485
C168	ENGLOPT.-FUEL PRIME PUMP	FEED DEUTSCH	2	562486	562485
C169	RR JCT BDO-FLASHER UNIT	TC	2	------	561948
C170	FR JCT BDO-FLASHER UNIT	TC	2	------	561948
C171	ALARM JCT BDO-LH CONSOLE	AMP CPC	37	560645	560646
C172	ENGINE CPT-WATER TANK HEAT.	PED WP	2	561566	561698
C173	ENGINE CPT-WATER TANK HEAT.	PED WP	2	561566	561698
C174	ENGINE CPT-RR DOOR LH,OPN.LT	PED WP	6	561606	561687
C175	UNDER DASH-RH-HTR MODULE	AMP HML	9	561678	561669
C176	UNDER DASH-RH-WIPER PULSE	AMP FF	6	------	561186
C177	UNDER DASH-RH-WIPER MOTOR	AMP FF	6	------	561186
C178	UNDER DASH-RH-LH FAN	TC	2	561938	562997
C179	UNDER DASH-RH-RH FAN	TC	2	561938	562997
C180	RR JCT BDO-CONTROL MODULE	AMP HML	2	561566	561698
C181	RR JCT BDO COMPT.-AT KYH	AMP CPC	16	560639	560640
C182	FR SERVICE CPT-HEADLAMP	ITT SS	2	561813	561812
C183	FR SERVICE CPT-HEADLAMP	ITT SS	2	561813	561812
C184	FR JCT BDO COMPT.-AT KYH	AMP CPC	16	560639	560640
C185	RR JCT BDO COMPT.-AT KYH	PED	30	------	561600

CONNECTORS CODE ID Page G-2

No.	LOCATION	#WD TYPE	*PIN CAVITY	*SOCKET HOUSING	HOUSING
C186	RR JCT BDO CPT.-SPEED SIGN.TR	PED WP	2	561566	561690
C186RH	RR JCT BDO CPT.-SPD SIGN.H.TR	PED WP	2	561566	561690
C186W	RR JCT BDO CPT.-SPD SIGN.WT	PED WP	2	561566	561690
C187	RR JCT BDO-RHM RESISTOR CON.	AMP HML	6	561552	561515
C189	ENGINE CPT-PRE-HEAT WATER	PED WP	2	561566	561690
C190	ENGINE CPT-RR DOOR TAIL L.T	PED WP	2	561566	561690
C191	ENGINE CPT-RR DOOR STOP L.T	PED WP	2	561566	561690
C192	ENGINE CPT-RR DOOR RH,CLS.LT	PED WP	2	561566	561690
C193	ENGINE CPT-RR DOOR RH,OPN.LT	PED WP	2	561566	561690
C194	ENGINE CPT-RR DOOR RH,CLS.LT	PED WP	2	561566	561690
C195	ENGINE CPT-RR DOOR RH,OPN.LT	PED WP	2	561566	561690
C196	ENGINE CPT-RR DOOR,CLOP.L.T	PED WP	2	561566	561690
C197	ENGINE CPT-W/C COMPRESSOR	PED WP	4	561889	561890
C198	ENGINE CPT-COMPRESSOR	PED WP	4	561889	561890
C199	ENGINE CPT RR DOOR L,ICENSE L.T	DOH AUTO	2	930210	------
C200	RH HAT RACK-DOOR LAMP	AMP HML	2	561248	561247
C201	RH HAT RACK-FLUORESCENT	AMP HML	4	561951	561666
C202	RH HAT RACK-BALLAST	AMP HML	4	560851	560852
C203	RH HAT RACK-BALLAST	AMP HML	4	560851	560852
C204	RH HAT RACK-GENERAL LT	AMP HML	3	561667	561550
C205	RH HAT RACK-PAX SPEAKER	AMP HML	4	561661	561662
C206	RH HAT RACK-READING LT	AMP HML	2	562480	562898
C207	LH HAT RACK-READING LT	AMP HML	2	562480	562898
C208	LH HAT RACK-BALLAST	AMP HML	4	560851	560852
C209	LH HAT RACK-PAX SPEAKER	AMP HML	4	561661	561662
C211	FR ROOF-STORE LTN	AMP HML	2	562480	562898
C212	FR ROOF-STORE LTN	AMP HML	2	562480	562898
C213	FR ROOF-CLEARANCE L.T	AMP HML	2	562480	562898
C216	UNDER DASH-LH-P.A.	AMP HML	9	561678	561669
C217	UNDER DASH-LH-P.A.	AMP HML	3	------	561550
C218	UNDER DASH-LH-P.A.	AMP HML	3	------	561550
C219	UNDER DASH-LH-P.A.	AMP HML	3	------	561550
C220	PRJCT.BDO-FUEL PRIME PUMP	TC	3	560878	560873
C222	ALARM JCT BDO CPT.-DOOR	MOLEX	4	561477	561476
C223	ALARM JCT BDO CPT.-DRVL.SPEAK.	AMP HML	3	561550	561668
C224	ALARM JCT BDO CPT.-DRVL.SPEAK.	AMP HML	3	561550	561668
C227	RH SW.PANEL-HEATER	AMP HML	2	561248	561247
C228	RH SW.PANEL-HEORG OUTLET	MOLEX	4	561477	561476
C229	RH SW.PANEL-PA VOL.CONT.	MOLEX	4	561477	561476
C230	ENGLOPT.-FUEL PRIME PUMP	FEED DEUTSCH	2	562486	562485
C231	RR JCT BDO-PUMP SW.	PED WP	2	561566	561690
C232	ENGLOPT.-FUEL PRIME PUMP	PED WP	2	561566	561690
C233	INSTRUMENT PANEL CENTER	MOLEX	4	561477	561476
C234	INSTRUMENT PANEL CENTER	MOLEX	4	561477	561476
C235	INSTRUMENT PANEL CENTER	MOLEX	4	561477	561476
C236	INSTRUMENT PANEL CENTER	AMP HML	2	560852	560852
C237	UNDER DASH-LH-JACOB CLUTCH SW	ITT SS	3	561111	561080
C238	A-C JCT BDO-DIODE CONNECTOR	AMP HML	3	561678	561669
C239	FR SERVICE CPT-HI BEUT VALVE	PED WP	2	561566	561690
C240	FR SERVICE CPT-KNEEL PRSS SW	PED WP	2	561566	561690
C241	FR SERVICE CPT-FOG RESISTOR	AMP CPC	3	561847	561862
C242	FR SERVICE CPT-HEADLAMP	TC	3	561871	------
C243	FR SERVICE CPT-HEADLAMP	TC	3	561871	------
C244	FR SERVICE CPT-RH-FOG LAMP	ITT SS	2	561813	561812
C245	FR SERVICE CPT-RH-FOG LAMP	ITT SS	2	561813	561812
C246	FR SERVICE CPT-HARN.& DR.L.T	ITT SS	3	561111	561080
C248	ALARM JCT BDO-WIPER PULSE SEN	AMP FF	6	------	561186
C249	ALARM JCT BDO-CONN.12V TO 5V	AMP HML	3	561667	561550

CONNECTORS CODE ID Page G-3

No.	LOCATION	#WD TYPE	*PIN CAVITY	*SOCKET HOUSING	HOUSING
C250	ALARM JCT BDO-DASH L.TS REGUL.	AMP HML	6	561552	561515
C251	LH SW.PANEL-F-EXT DLE	SWF	8	------	561187
C252	LH SW.PANEL-SWITCH-LT	SWF	2	------	561837
C253	LH SW.PANEL-EHEW	SWF	8	------	561187
C254	INST.PANEL RH-ENTRJDOOR SW.	TORRY	5	------	562018
C255	LH SW.PANEL-WIPER	SWF	2	------	561837
C257	INSTRUMENT PANEL CENT-SPEEDO	AMP HML	4	560851	560852
C258	LH SW.PANEL-MULTI FUNC. SW	AMP F	8	------	561188
C259	LH SW.PANEL-MULTI FUNC. SW	AMP F	8	------	561188
C260	UNDER DASH-RH-DOOR MODULE	AMP HML	9	561678	561669
C261	UNDER DASH-RH-DOOR MODULE	AMP HML	4	561951	561668
C262	UNDER DASH-RH-DOOR MODULE	AMP HML	3	561667	561550
C263	UNDER DASH-RH-DOOR MODULE	AMP HML	3	561667	561550
C264	UNDER DASH-RH-DOOR MODULE	AMP HML	3	561667	561550
C265	UNDER DASH-RH-DOOR MODULE	AMP HML	3	561667	561550
C267	UNDER DASH-RH	AMP CPC	24	561642	561643
C268	UNDER DASH-RH-MIRROR	AMP HML	4	561552	561515
C269	UNDER DASH-RH-MIRROR	AMP HML	4	561552	561515
C270	RH MIRROR POST	MOLEX	4	561477	561476
C271	RH MIRROR POST	MOLEX	4	561477	561476
C272	LH MIRROR	SPARTAN	6	990158	------
C273	RH MIRROR	SPARTAN	6	990158	------
C274	RADIO	AMP HML	9	561678	561669
C275	UNDER DASH-RH-LOCK SOL.VLVE	AMP HML	2	561248	561247
C276	RH SW.PANEL-A/C & HEAT	SWF	8	------	561187
C277	RH SW.PANEL-PA ON/OFF	SWF	8	------	561187
C278	RH SW.PANEL-FRESH AIR	SWF	8	------	561187
C279	RH SW.PANEL-CENT.TAC & SPG.L	SWF	8	------	561187
C280	LH CONSOLE-CONT-VIDEO SYST.	AMP HML	6	560671	560668
C281	LH CONSOLE-CONT-VIDEO SYST.	AMP HML	6	560671	560668
C282	LH CONSOLE-CONT-VIDEO SYST.	AMP HML	6	560671	560668
C283	LH CONSOLE-SW.VIDEO SYST.	SWF	8	------	561187
C284	UNDER DASH-LH-P.A.	AMP HML	3	561667	561550
C285	UNDER DASH-LH-P.A.	AMP HML	3	------	561550
C286	UNDER DASH-LH-P.A.	AMP HML	3	------	561550
C287	UNDER DASH-LH-P.A.	AMP HML	3	------	561550
C288	LH CONSOLE-CONT-VIDEO SYST.	AMP HML	6	560671	560668
C289	LH CONSOLE-CONT-VIDEO SYST.	AMP HML	6	560671	560668
C290	LH CONSOLE-VIDEO SYST.	AMP HML	6	560671	560668
C291	LH CONSOLE-LCD VIDEO SYST.	AMP HML	6	560671	560668
C292	LH CONSOLE-LCD VIDEO SYST.	AMP HML	6	560671	560668
C293	LH CONSOLE-SW.VIDEO SYST.	SWF	8	------	561187
C294	LH CONSOLE-SW.VIDEO SYST.	SWF	8	------	561187
C295	LH CONSOLE-SW.VIDEO SYST.	SWF	8	------	561187
C296	LH CONSOLE-SW.VIDEO SYST.	SWF	8	------	561187
C297	LH CONSOLE-CENT-VIDEO SYST.	AMP HML	6	560671	560668
C298	LH CONSOLE-CONT-VIDEO SYST.	AMP HML	6	560671	560668
C299	LH CONSOLE-CONT-VIDEO SYST.	AMP HML	6	560671	560668
C300	INVERTER CONPT.	AMP CPC	16	561639	561640
C301	INSTRUMENT PANEL CENT-MAIN	AMP HML	4	560851	560852
C302	INVERTER COMPT-GALLEY STR.	AMP HML	9	561661	561662
C303	LH CONSOLE-SW.PRESSTAT	SWF	8	------	561187
C304	LH CONSOLE-SW.PRESSTAT	SWF	8	------	561187
C305	LH CONSOLE-SW.HREOSTAT	AMP HML	2	561248	561247
C306	LH CONSOLE-SW.CONTROL	AMP HML	2	561248	561247
C307	LH CONSOLE-SW.LUGG.DOOR LOK	DEUTSCH	2	562486	562485
C308	LH CONSOLE-SW.HREOSTAT	AMP HML	2	561248	561247
C309	LH CONSOLE-SW.CONTROL	AMP HML	2	561248	561247
C310	LH CONSOLE-SW.HEADING L.TS	SWF	8	------	561187
C311	LH CONSOLE-SW.HEADING L.TS	SWF	8	------	561187
C312	LH CONSOLE-SW.CEN & FLOOR L.TS	SWF	8	------	561187
C313	LH CONSOLE-SW.FR DECS.SIGN	SWF	8	------	561187
C314	LH CONSOLE-SW.FR DECS.SIGN	SWF	8	------	561187
C315	LH SW.PANEL-SW.CPN WINDOW	SWF	8	------	561187
C316	LH CONSOLE-SW.CPN WINDOW LIFT	SWF	8	------	561187
C317	LH CONSOLE-SW.DRIVER'S LTS	SWF	8	------	561187
C318	LH CONSOLE-SW.WIND.LIFT NOT.	PED PO	2	------	561848
C319	LH CONSOLE-CRUISE CTR SW.PAN.	AMP CPC	9	561636	561637
C320	LH CONSOLE-RH-REFRIGERATOR	AMP HML	2	561248	561247
C325	LH CONSOLE-SW.KNEELING	SWF	8	------	561187
C326	LH CONSOLE-SW.DRVWL	SWF	8	------	561187
C327	ENGINE COMPT-RH START SW.BOX	AMP CPC	9	561636	561637

CONNECTORS CODE ID Page G-3

No.	LOCATION	#WD TYPE	*PIN CAVITY	*SOCKET HOUSING	HOUSING
C328	GALLEY-LAMP	AMP HML	2	561248	561247
C329	ENGINE TACHO SIGNAL	PED WP	2	561566	561689
C330	GALLEY-MICROWAVE SW.L.T	SWF	2	------	561837
C331	GALLEY-MICROWAVE SW	SWF	8	------	561187
C332	GALLEY-RH CONTAINER SW.L.T	SWF	2	------	561837
C333	GALLEY-RH CONTAINER SW	SWF	8	------	561187
C334	GALLEY-LH CONTAINER SW	SWF	8	------	561187
C335	GALLEY-LH CONTAINER SW.L.T	SWF	2	------	561837
C336	INSTRUMENT PANEL RH-DEF.SW.	AMP HML	3	561667	561550
C337	INSTR.PANEL-LH-DEFROSTER SW	SWF	8	------	561187
C338	INSTR.PANEL-LH-DEFROSTER SW	SWF	8	------	561187
C339	INSTR.PANEL-LH-UP WASHER SW	SWF	8	------	561187
C263	UNDER DASH-RH-DOOR MODULE	AMP HML	3	561667	560898
C264	UNDER DASH-RH-DOOR MODULE	AMP HML	3	561667	561558
C343	INSTR.PANEL-LH-HEADLAMP SW	SWF	8	------	561187
C344	INSTR.PANEL-LH-HAZARD L.T SW	SWF	8	------	561187
C345	INSTR.PANEL-LH-P.O.L.T SW	SWF	8	------	561187
C346	INSTR.PANEL-LH-SWITCH LTS	SWF	8	------	561837
C347	INSTR.PANEL-LH-SWITCH LTS	SWF	8	------	561837
C348	INSTRUMENT PANEL-FRT-HAZARD L	AMP HML	3	561667	561558
C349	RH CONSOLE-RED LED HTR	AMP HML	2	561248	561247
C350	RH CONSOLE-CE THERMOR	AMP HML	3	561667	561558
C351	LH HAT RACK-FLUOR 110V	MOLEX	4	561477	561476
C352	RH CONSOLE-OPN TEMP SENSOR	BURNDY	1	------	561518
C353	INSTR.PANEL-RH-OPN FAN RHEOST	AMP HML	6	561552	561515
C354	INSTR.PANEL-RH-OPN TEMP SW.	AMP HML	6	561552	561515
C355	INSTR.PANEL-RH-FR TEMP CTR	AMP HML	3	561667	561558
C356	INSTR.PANEL-RH-FR TEMP CTR	AMP HML	3	561667	561558
C357	INSTR.PANEL-RH-FUEL LEVEL GA	AMP HML	6	561552	561515
C358	INSTR.PANEL CENT-TAC & SPG.L T	AMP HML	2	562480	562898
C359	INSTRUMENT PANEL-RH-DEF.SW.	AMP HML	3	561667	561241
C360	RH CONSOLE-WIPER MOTOR	AMP FF	6	------	561186
C362	RH ROOF-LAVATORY OCCUPIED L	AMP HML	2	561248	561247
C363	FR ROOF-WATCH YOUR STEP L.T	AMP HML	2	561248	561247
C364	FR ROOF-WINDSHIELD DEFROST	AMP HML	3	561667	561558
C365	FR ROOF-UP WINDSHIELD DEFROST	AMP HML	3	561667	561558
C366	FR ROOF-DEST.SIGN L.T	AMP HML	2	562480	562898
C367	ENGINE COMPT-DOOR COL. L.T	AMP HML	2	561566	561698
C368	FR ROOF-DEST.SIGN BALLAST	AMP HML	3	561667	561558
C369	FR ROOF-DEST.SIGN OPEN.SW	TORRY	5	------	562018
C370	FR ROOF-DEST.SIGN FLUOR.	AMP HML	2	562480	562898
C371	FR ROOF-DEST.SIGN FLUOR.	AMP HML	2	562480	562898
C372	FR ROOF-DEST.SIGN SPEED SW.	MOLEX	4	561477	561476
C374	ALARM JCT BDO-CONT-MASTER SW	AMP HML	6	561552	561515
C375	ALARM JCT BDO CONPT-LH CONSOL	AMP HML	6	561552	561515
C376	ALARM JCT BDO-CONT-LH CONSOL	AMP HML	3	561667	561550
C377	LH SW.PANEL-SW.CPN WINDOW	SWF	8	------	561187
C380	LH CONSOLE-CONT-DOOR CONTROL	DEUTSCH	6	562366	------
C383	ALARM JCT BDO-CPT.-W/O WIRE	DEUTSCH	2	562486	562247
C385	FR SERV