LAZER FORMAT "A" CHOICE 8.2

CONNECTORS CODE ID) Page G-1

No.	LOCATION	#NB TYPE	*PIN CAVITY	*SOCKET HOUSING	HOUSING
C1	FR JCT BDI COMPARTMENT	AMP CPC	37	560644	560646
C2	FR JCT BDI COMPARTMENT	AMP CPC	24	560641	560643
C3	FR JCT BDI COMPARTMENT	AMP CPC	37	560714	560713
C4	FR JCT BDI COMPARTMENT	AMP CPC	16	560793	560795
C5	FR SERVICE COMPT.-UNDERHEATH	AMP CPC	37	560644	560646
C6	FR SERVICE COMPT.-UNDERHEATH	AMP CPC	24	560641	560643
C7	FR JCT BDI COMPT.-UNDERHEATH	AMP CPC	37	560714	560716
C8	FR SERVICE COMPT.-UNDERHEATH	AMP CPC	37	560714	560713
C9	ALARM JCT BDI	AMP CPC	37	560644	560646
C10	ALARM JCT BDI	AMP CPC	37	560644	560646
C11	FR SERVICE COMPARTMENT	AMP CPC	24	560642	560643
C12	FR SERVICE COMPARTMENT	AMP CPC	24	560642	560643
C13	LH CONSOLE-HEATER MON.	AMP HML	2	561248	561247
C13	FR SERVICE COMPT.	AMP HML	3	560552	560515
C13	LH CONSOLE-CE TH.MIRROR	AMP HML	6	561552	561515
C14	UNDER DASH-LH MIRROR	AMP HML	3	560552	560515
C15	RR JCT BDI	AMP CPC	24	560641	560643
C16	UNDER DASH-RH MIRROR	AMP HML	6	561552	561562
C16	LH CONSOLE-SW-CRUISE ON-OFF	SWF	8	-------	561087
C17	LH CONSOLE-SW-CRUISE RESUME	SWF	8	-------	561087
C17	LH CONSOLE-SW-CRUISE SET	SWF	8	-------	561087
C20	RR JCT BDI	AMP CPC	37	560644	560646
C21	RR JCT BDI	AMP CPC	24	560641	560643
C26	HYD & HAN TRANSM.-NEUT.& B-U	PED WP	4	561610	561611
C27	HYD & HAN TRANSM.-SPEED SENS.	PED WP	2	561766	561768
C30	DDEC ENGINE-ECM	PED	30	-------	561600
C35	RR JCT BDI	AMP CPC	37	560644	560646
C36	EMERGENCY-EXIT LTS	AMP HML	2	562600	562898
C37	RR SECTION-LH-HAT RACK	AMP HML	5	561661	561662
C38	RR SECTION-RH-HAT RACK	AMP HML	5	561661	561662
C40	RR JCT BDI	AMP CPC	16	560639	560640
C41	LAVATORY-ROOF FLOORS.SECT	AMP HML	2	562600	562898
C42	LAVATORY-BACK WALL-WTR TANK	AMP HML	2	562600	562898
C43	LAVATORY-BACK WALL-ACCESS.	AMP HML	5	561661	561662
C45	ALARM JCT BDI COMPARTMENT	AMP CPC	24	560642	560643
C47	FR SERVICE COMPT.-UNDERHEATH	AMP CPC	37	560714	560713
C49	WATERE COMPT.-LOW BLOCK	AMP HML	1	561605	561517
C50	FR SERVICE COMPT.-LOW BLOCK	PED WP	1	561605	561517
C52	RR JCT BDI	AMP CPC	22	560718	560717
C53	RR JCT BDI	AMP CPC	14	560585	560584
C54	UNDER DASH-PA UNIT	AMP HML	6	561552	561515
C55	UNDER DASH-RH SW PANEL	AMP CPC	9	560636	560637
C56	UNDER DASH-RH CONSOLE	AMP CPC	24	560642	560643
C57	UNDER DASH-RH ACCESSORIES	AMP CPC	22	561995	561718
C58	UNDER DASH-RH ACCESSORIES	AMP CPC	22	561995	561718
C59	EVAPORATOR COMPARTMENT	AMP HML	2	562600	562898
C60	RR JCT BDI COMPT.-L/T	AMP HML	2	561248	561247
C61	LUGGAGE COMPARTMENT-LTS	AMP HML	2	561248	561247
C62	LUGGAGE COMPARTMENT-LTS	AMP HML	2	561248	561247
C63	LUGGAGE COMPARTMENT-LTS	AMP HML	2	561248	561247
C64	LUGGAGE COMPARTMENT-LTS	AMP HML	2	561248	561247
C65	LUGGAGE COMPARTMENT-LTS	AMP HML	2	561248	561247

CONNECTORS CODE ID) Page G-1

No.	LOCATION	#NB TYPE	*PIN CAVITY	*SOCKET HOUSING	HOUSING
C66	LUGGAGE COMPARTMENT-LTS	AMP HML	2	561248	561247
C67	LUGGAGE COMPARTMENT-LTS	AMP HML	2	561248	561247
C68	LUGGAGE COMPARTMENT-LTS	AMP HML	2	561248	561247
C69	LUGGAGE COMPARTMENT-LTS	AMP HML	2	561248	561247
C70	ALARM JCT BDI COMPARTMENT	AMP CPC	24	560642	560643
C71	UNDER INSTRUMENT PANEL-LH	AMP CPC	37	560645	560646
C72	UNDER INSTRUMENT PANEL-CENT.	AMP CPC	37	560645	560646
C73	UNDER INSTRUMENT PANEL-CENT.	AMP CPC	16	560639	560640
C74	ALARM JCT BDI COMPARTMENT	AMP CPC	24	560642	560643
C75	ALARM JCT BDI COMPARTMENT	PED WP	2	561610	561611
C76	LUGGAGE COMPT.-AIR RET.SENS.	AMP HML	2	561248	561247
C77	LUGGAGE COMPT.-AIR RET.SENS.	AMP HML	2	561248	561247
C78	FR JCT BDI COMPARTMENT	AMP CPC	22	561789	561718
C79	FR SERVICE COMPT.-UNDERHEATH	AMP CPC	37	560644	560646
C80	LUGGAGE COMPT.-AIR RET.SENS.	AMP HML	2	561248	561247
C81	PASSENGER COMPT.-HOLE L.TS	AMP HML	2	562600	562898
C82	ENTRANCE DOOR	HOLEX	6	562878	562869
C83	ENTRANCE DOOR-PRESSURE SW.	AMP HML	2	561248	561476
C84	ENTRANCE DOOR-PRESSURE SW.	PED WP	1	561610	561611
C85	UNDER INSTRUMENT PANEL-LH	AMP HTA-100	8	-------	562248
C87	BATT.& RR JUNCPT.CONNECT.	AMP CPC	9	560636	560637
C88	RR END ROOF-CLEARANCE LTS	AMP HML	2	562600	562898
C89	RR END ROOF-B-U HONITOR	AMP CPC	1	561562	561561
C90	RR JCT BDI	AMP CPC	15	561987	561986
C91	RR JCT BDI	AMP CPC	37	560714	560713
C92	RR JCT BDI COMPT.-HATI SKID	AMP CPC	5	561635	561637
C93	RR JCT BDI COMPT.-HATI SKID	AMP CPC	5	561635	561637
C94	FR AXLE ACCESSORIES	AMP HML	14	560585	560585
C97	RR AXLE ACC.-INSIDE PVC END	PED WP	6	561560	561578
C98	FR SERVICE COMPT.-ELCF PEDAL	PED WP	3	561780	561781
C99	FR SERVICE COMPT.-LTS	AMP HML	2	562248	562247
C100	FR SERVICE COMPT.-CONNECTS	PED WP	2	561560	562098
C101	FR SERVICE COMPT.-ELEC.-HORNS	PED WP	2	561566	561569
C102	FR SERV.& SIDE CPT.-FLUORS.L.TS	AMP HML	5	561661	561662
C103	FR SERV.& SIDE CPT.-MIRRORS	ITT SS	2	561813	561812
C104	FR SERVICE COMPT.-CELS.WALKT	PED WP	2	561566	561569
C105	FR SERVICE COMPT.-CELS.WALKT	PED WP	2	561566	561569
C106	FR SERVICE COMPT.-WATER VALVE	PED WP	2	561566	561569
C107	FR SERVICE COMPT.-DUMPER	PED WP	2	561566	561569
C108	FR SERVICE COMPT.-KNEELSYS	PED WP	2	561566	561569
C109	FR SERVICE COMPT.-KNEELSYS	PED WP	2	561566	561569
C110	FR SERVICE COMPT.-KNEELSYS	PED WP	2	561566	561569
C111	EVAPORATOR COMPT.-DAMPER	ITT SS	2	561813	561812
C113	BATT.& RR JUCPT.MARKER.LT	ITT SS	2	561813	561812
C114	BATT.& RR JUCPT.MARKER.LT	ITT SS	2	561813	561812
C115	ENGINE COMPT.-HYDROMIR	AMP HML	2	561248	561247
C116	ENGINE COMPT.-LTS	PED WP	2	561566	561569
C117	ENGINE COMPT.-LAVATORY FAN	TC	2	561268	562997
C121	ENGINE CPT RH DOOR-HL.O LAMP	PED WP	6	561606	561687
C122	ENGINE CPT RH DOOR-HL.O LAMP	PED WP	6	561606	561687
C123	BATTERE CPT.-DOOR SW.L.T RH	ITT SS	2	561813	561812
C124	ENGINE CPT-CHANGE DOOR VALVE	PED WP	2	561566	561569
C124	ENGINE CPT-ETHER SW	PED WP	2	561566	561569

CONNECTORS CODE ID) Page G-2

No.	LOCATION	#NB TYPE	*PIN CAVITY	*SOCKET HOUSING	HOUSING
C125	ENGINE CPT-B-U ALARM	PED WP	2	561566	561569
C126	ENGINE CPT-FLUSHING PUMP	PED WP	2	561566	561569
C127	ENGINE CPT-FUEL FILTER	PED WP	2	561566	561569
C128	ENGINE CPT-I/C COMPRO.LUTCH	ITT SS	2	561813	561812
C129	ENGINE CPT-PRE-HEAT WATER	AMP CPC	2	561612	561608
C131	UNDER INSTRUMENT PANEL-LH	AMP CPC	37	560645	560646
C132	UNDER INSTRUMENT PANEL-CENT.	AMP CPC	16	560639	560640
C133	UNDER INSTRUMENT PANEL-CENT.	AMP CPC	16	560639	560640
C134	ALARM JCT BDI COMPARTMENT	PED WP	2	561610	561611
C136	FR JCT BDI-LUGGAGE DOOR CONS.	AMP HML	15	561987	561986
C137	R-C JCT BDI	AMP CPC	48	562286	562284
C137	ENGINE CPT-I/C TRANSMITTER	AMP HML	2	562600	562898
C138	R-C JCT BDI-CONTROL MODULE	AMP CPC	37	560644	560646
C139	R-C JCT BDI-L.DOOC MODULE	AMP-HDP	35	562811	-------
C142	LUGGAGE COMPT.-HOLE L.TS	AMP HML	2	561248	561247
C143	LAVATORY-DOOR WALL	AMP HML	3	560808	562086
C200	RH-HAT RACK-FLUORESCENT	AMP HML	5	561661	561662
C203	RH-HAT RACK-BALLAST	AMP HML	5	561661	561662
C204	RH-HAT RACK-GENERAL LT	AMP HML	3	561667	561550
C205	RH-HAT RACK-SPEAKER JMP.	AMP HML	5	561661	561662
C206	RH-HAT RACK-READING LT	AMP HML	2	562600	562898
C207	LH-HAT RACK-READING LT	AMP HML	2	562600	562898
C208	LH-HAT RACK-BALLAST	AMP HML	4	560851	560852
C209	LH-HAT RACK-SPEAKER JMP.	AMP HML	5	561661	561662
C211	FR ROOF-STORE LIN	AMP HML	2	562600	562898
C212	FR ROOF-CLEARANCE L.T	AMP HML	2	562600	562898
C213	FR ROOF-CLEARANCE L.T	AMP HML	2	562600	562898
C216	UNDER DASH-LH-P.A.	AMP HML	5	561678	561687
C217	UNDER DASH-LH-P.A.	AMP HML	3	-------	561550
C218	UNDER DASH-LH-P.A.	AMP HML	3	-------	561550
C220	INJECT.BDI-FUEL PRIME PUMP	TC	3	560878	560873
C222	ALARM JCT BDI-CHT-DRYS.SW	HOLEX	4	561477	561476
C223	RH-AXLE-ABS LH SENSOR	W&BCO	3	-------	561550
C224	RH-AXLE-ABS LH SENSOR	W&BCO	2	641132	-------
C225	RH-AXLE-LH WHEEL	W&BCO	3	-------	561550
C226	RH-AXLE-RH WHEEL	W&BCO	3	-------	561550
C227	RH-AXLE-RH WHEEL	W&BCO	2	641132	-------
C228	RH SW.PANEL-HIGRO.OUTLET	HOLEX	4	561477	561476
C229	ENGCPT.-PA RH DOOR	DEUTSCH	2	562486	562475
C230	ENGCPT.-FUEL PRIME PUMP FEED	DEUTSCH	2	562486	562495
C231	ENGCPT.-FUEL PUMP SW.	PED WP	2	561566	561569
C232	ENGCPT.-FUEL PRIME PUMP	PED WP	2	561566	561569
C233	INSTRUMENT PANEL CENTER	HOLEX	4	561477	561476
C234	INSTRUMENT PANEL CENTER	H.DUL.	6	-------	562844
C235	INSTRUMENT PANEL CENTER	H.DUL.	6	-------	562844
C236	INSTRUMENT PANEL CENTER	AMP HML	3	560808	560852
C237	UNDER DASH-LH-JACOB CLUTCH SW	ITT SS	3	561111	561080
C238	A-C JCT BDI-DODGE CONNECTOR	AMP HML	5	561678	561669
C239	FR SERVICE CPT-HI BUOY VALVE	PED WP	2	561566	561569
C240	FR SERVICE CPT-KNEEL PRO SW	PED WP	2	561566	561569
C241	FR SERVICE CPT-FOG RESISTOR	AMP CPC	3	560847	561862
C242	FR SERVICE CPT-DOOR SW.L.T	PED WP	2	561566	561569
C243	FR SERVICE CPT-HEADLAMPS	TC	3	561871	-------
C244	FR SERVICE CPT-RH FOG LAMP	ITT SS	2	561813	561812
C245	FR SERVICE CPT-RH FOG LAMP	ITT SS	2	561813	561812
C246	FR SERVICE CPT-HARN & DR.L.T	ITT SS	3	561111	561080
C248	FR SERVICE CPT-WIPER PULSE GEN	AMP FF	6	-------	561189
C249	ALARM JCT BDI-CONN.12V TO 5V	AMP HML	3	561667	561550

CONNECTORS CODE ID) Page G-2

No.	LOCATION	#NB TYPE	*PIN CAVITY	*SOCKET HOUSING	HOUSING
C196	RR JCT BDI-CPT.-SPED SIGN.TR	PED WP	2	561566	561569
C198	RR JCT BDI-CPT.-SPD SIGN.W.TR	PED WP	2	561566	561569
C199	RR JCT BDI-CPT.-SPD SIGN.W.T	PED WP	2	561566	561569
C187	RR JCT BDI-RPM RESISTOR CON.	AMP HML	6	561552	561515
C189	ENGINE CPT-PRE-HEAT WATER	AMP CPC	2	561612	561608
C190	ENGINE CPT RH DOOR TAIL L.T	PED WP	2	561566	561569
C191	ENGINE CPT RH DOOR-TAIL L.T	PED WP	2	561566	561569
C192	ENGINE CPT RH DOOR-RH.STOP.L	PED WP	2	561566	561569
C193	ENGINE CPT RH DOOR-RH.STOP.L	PED WP	2	561566	561569
C194	ENGINE CPT RH DOOR-CLOP.L.T	PED WP	2	561566	561569
C195	ENGINE CPT RH DOOR-CLOP.L.T	PED WP	2	561566	561569
C197	ENGINE CPT-I/C COMPRESSOR	PED WP	4	561889	561890
C198	ENGINE CPT-COMPRESSOR	PED WP	4	561889	561890
C199	ENGINE CPT RH DOOR-LICENCE L.T	DOH-AUTO	2	930210	-------
C200	RH-HAT RACK-BALLAST	AMP HML	4	560851	560852
C201	RH-HAT RACK-FLUORESCENT	AMP HML	3	561951	561666
C202	RH-HAT RACK-BALLAST	AMP HML	4	560851	560852
C203	RH-HAT RACK-BALLAST	AMP HML	3	561667	561550
C204	RH-HAT RACK-GENERAL LT	AMP HML	3	561667	561550
C205	RH-HAT RACK-SPEAKER JMP.	AMP HML	5	561661	561662
C206	RH-HAT RACK-READING LT	AMP HML	2	562600	562898
C207	LH-HAT RACK-READING LT	AMP HML	2	562600	562898
C208	LH-HAT RACK-BALLAST	AMP HML	4	560851	560852
C209	LH-HAT RACK-SPEAKER JMP.	AMP HML	5	561661	561662
C211	FR ROOF-STORE LIN	AMP HML	2	562600	562898
C212	FR ROOF-CLEARANCE L.T	AMP HML	2	562600	562898
C213	FR ROOF-CLEARANCE L.T	AMP HML	2	562600	562898
C216	UNDER DASH-LH-P.A.	AMP HML	5	561678	561687
C217	UNDER DASH-LH-P.A.	AMP HML	3	-------	561550
C218	UNDER DASH-LH-P.A.	AMP HML	3	-------	561550
C220	INJECT.BDI-FUEL PRIME PUMP	TC	3	560878	560873
C222	ALARM JCT BDI-CHT-DRYS.SW	HOLEX	4	561477	561476
C223	RH-AXLE-ABS LH SENSOR	W&BCO	3	-------	561550
C224	RH-AXLE-ABS LH SENSOR	W&BCO	2	641132	-------
C225	RH-AXLE-LH WHEEL	W&BCO	3	-------	561550
C226	RH-AXLE-RH WHEEL	W&BCO	3	-------	561550
C227	RH-AXLE-RH WHEEL	W&BCO	2	641132	-------
C228	RH SW.PANEL-HIGRO.OUTLET	HOLEX	4	561477	561476
C229	ENGCPT.-PA RH DOOR	DEUTSCH	2	562486	562475
C230	ENGCPT.-FUEL PRIME PUMP FEED	DEUTSCH	2	562486	562495
C231	ENGCPT.-FUEL PUMP SW.	PED WP	2	561566	561569
C232	ENGCPT.-FUEL PRIME PUMP	PED WP	2	561566	561569
C233	INSTRUMENT PANEL CENTER	HOLEX	4	561477	561476
C234	INSTRUMENT PANEL CENTER	H.DUL.	6	-------	562844
C235	INSTRUMENT PANEL CENTER	H.DUL.	6	-------	562844
C236	INSTRUMENT PANEL CENTER	AMP HML	3	560808	560852
C237	UNDER DASH-LH-JACOB CLUTCH SW	ITT SS	3	561111	561080
C238	A-C JCT BDI-DODGE CONNECTOR	AMP HML	5	561678	561669
C239	FR SERVICE CPT-HI BUOY VALVE	PED WP	2	561566	561569
C240	FR SERVICE CPT-KNEEL PRO SW	PED WP	2	561566	561569
C241	FR SERVICE CPT-FOG RESISTOR	AMP CPC	3	560847	561862
C242	FR SERVICE CPT-DOOR SW.L.T	PED WP	2	561566	561569
C243	FR SERVICE CPT-HEADLAMPS	TC	3	561871	-------
C244	FR SERVICE CPT-RH FOG LAMP	ITT SS	2	561813	561812
C245	FR SERVICE CPT-RH FOG LAMP	ITT SS	2	561813	561812
C246	FR SERVICE CPT-HARN & DR.L.T	ITT SS	3	561111	561080
C248	FR SERVICE CPT-WIPER PULSE GEN	AMP FF	6	-------	561189
C249	ALARM JCT BDI-CONN.12V TO 5V	AMP HML	3	561667	561550

CONNECTORS CODE ID) Page G-3

No.	LOCATION	#NB TYPE	*PIN CAVITY	*SOCKET HOUSING	HOUSING
C250	ALARM JCT BDI-DASH L.TS RELOC.	AMP HML	4	561552	561515
C251	LH SW.PANEL-FAST IDLE	SWF	8	-------	561837
C252	LH SW.PANEL-SWITCH-LT	SWF	2	-------	561837
C253	LH SW.PANEL-ETHER	SWF	8	-------	561087
C254	INST.PANEL RH-ENTRADOOR SW.	TORRY	5	-------	562010
C255	LH SW.PANEL-PRIME PUMP	SWF	8	-------	561087
C257	INSTRUMENT PANEL CENT-SPEEDO	AMP HML	4	560851	560852
C258	LH SW.PANEL-MULTI FUNC. SW	AMP FF	6	-------	561088
C259	LH SW.PANEL-MULTI FUNC. SW	AMP FF	6	-------	561088
C260	UNDER DASH-RH-DOOR HOOLE	AMP HML	4	560851	560852
C261	UNDER DASH-RH-DOOR CLOP.L.T	AMP HML	4	560851	560852
C262	UNDER DASH-RH-DOOR HOOLE	AMP HML	4	560851	560852
C263	UNDER DASH-RH-DOOR CLOP.L.T	AMP HML	4	560851	560852
C264	UNDER DASH-RH-DOOR HOOLE	AMP HML	3	561667	561550
C265	UNDER DASH-RH-DOOR CLOP.L.T	AMP HML	3	561667	561550
C267	UNDER DASH-RH	AMP CPC	24	560642	560643
C268	UNDER DASH-LH-MIRROR	AMP HML	6	561552	561515
C269	UNDER DASH-RH-MIRROR	AMP HML	3	560552	560515
C270	RH-MIRROR POST	HOLEX	6	562878	562869
C271	RH-MIRROR POST	HOLEX	6	562878	562869
C272	LH-MIRROR	SPARTAN	6	990158	-------
C273	RH-MIRROR	SPARTAN	6	990158	-------
C274	RADIO	AMP HML	9	561678	561669
C275	UNDER DASH-RH-DOOR HOOLE	AMP HML	3	561667	561550
C276	UNDER DASH-RH-LOCK SOL.VALVE	AMP HML	2	561248	561247
C280	RH SW.PANEL-HI-DOUT	AMP HML	6	561552	561515
C281	DEPART COMPT.-LTS SW	PED WP	2	561566	561569
C282	LH SW.PANEL-SWITCH-LT	SWF	2	-------	561837
C283	RH SW.PANEL-SWITCH-LT	SWF	2	-------	561837
C292	LH CONSOLE COMPT.-VIDEO SYST.	AMP HML	4	560671	560669
C293	LH CONSOLE-EQUIP.SYS.T.	AMP HML	2	561248	561247
C297	INSTRUMENT PANEL RH-L.TS	AMP HML	2	562600	562898
C362	FR ROOF-LAVATORY OCCUPIED	AMP HML	2	561248	561247
C363	FR ROOF-WATCH YOUR STEP L.T	AMP HML	2	561248	561247
C364	FR ROOF-INVERTER CONT.	AMP HML	5	561661	561662
C365	FR ROOF-UP WINDSHIELD DEFROST	AMP HML	5	561667	561550
C366	FR ROOF-DEST.SIGN FLUOR.	AMP HML	2	562600	562898
C367	FR ROOF-DEST.SIGN FLUOR.	AMP HML	2	562600	562898
C368	FR ROOF-DEST.SIGN BALLAST	AMP HML	3	561667	561550
C369	FR ROOF-DEST.SIGN DRIV.SW	TORRY	1	-------	562018
C370	DDEC ENGINE-ECM POWER CON.	PED WP	5	-------	562345
C371	FR ROOF-DEST.SIGN FLUOR.	AMP HML	2	562600	562898
C372	FR ROOF-DEST.SIGN SPEED SW.	HOLEX	4	561477	561476
C374	ALARM JCT BDI-CONT-MASTER SW	AMP HML	6	561552	561515
C375	ALARM JCT BDI-CONT-LH CONSOL	AMP HML	6	561552	561515
C376	ALARM JCT BDI-CONT-LH CONSOL	AMP HML	3	561667	561550
C377	LH CONSOLE-SW-ENGINE STOP	HOLEX	4	561477	561476
C380	LH CONSOLE-ODM CONNECTOR	DEUTSCH	6	562366	-------
C383	ALARM JCT BDI-CPT.-HIC W WIRE	DEUTSCH	2	562486	562475
C385	FR SERV.COMPT.-UNDERHEATH.WL	AMP HML	9	561667	561662
C386	LH CONSOLE-WCL POWER SYSTEM	SWF	8	-------	561087
C387	RR JCT BDI-WCL	AMP HML	5	561661	561662

CONNECTORS CODE ID) Page G-3

No.	LOCATION	#NB TYPE	*PIN CAVITY	*SOCKET HOUSING	HOUSING
C328	GALLEY-LAMP	AMP HML	2	561248	561247
C329	ENGINE TACHO SIGNAL	PED WP	2	561566	561569
C330	GALLEY HICROWAVE SW.L.T	SWF	2	-------	561837
C331	GALLEY HICROWAVE SW	SWF	8	-------	561087
C332	GALLEY LH CONTAINER SW.L.T	SWF	2	-------	561837
C333	GALLEY RH CONTAINER SW.L.T	SWF	2	-------	561837
C334	GALLEY LH CONTAINER SW	SWF	8	-------	561087
C335	GALLEY LH CONTAINER SW	SWF	8	-------	561837
C336	INSTRUMENT PANEL RH-DEF.SOL	AMP HML	3	561667	561550
C337	INSTRUMENT PANEL-DEFROSTER	SWF	8	-------	561087
C338	INSTRUMENT PANEL-DEFROSTER	SWF	8	-------	561087
C339	INSTR.PANEL LH-UP WASHER SW	SWF	8	-------	561087
C340	INSTR.PANEL-LH-HEAT MIRROR	AMP HML	2	560808	560809
C342	INSTR.PANEL-LH-HEAT MIRROR SW	SWF	8	-------	561087
C343	INSTR.PANEL-LH-HEADLAMP SW	SWF	8	-------	561837
C344	INSTR.PANEL-LH-HAZARD.L.T SW	SWF	8	-------	561087
C345	INSTR.PANEL-LH-FOG L.T SW	SWF	8	-------	561087
C346	INSTR.PANEL-LH-SWITCH LTS	SWF	2	-------	561837
C347	INSTR.PANEL-LH-SWITCH LTS	SWF	8	-------	561087
C348	INSTR.PANEL CENT-HADLO.AMP.HML	3	561667	561550
C349	RH CONSOLE-RED LED HITR	AMP HML	2	561248	561247
C350	RH CONSOLE-THERMOSTAT	AMP HML	5	561667	561550
C351	LH HAT RACK-FLUOR 110V	HOLEX	4	561477	561476
C352	RH CONSOLE-DEM TEMP SENSOR	BURNDY	1	561678	-------
C353	INSTR.PANEL RH-DIM FAN RHEOST	AMP HML	6	561552	561515
C354	INSTR.PANEL RH-DIM TOP LIGHT	AMP HML	6	561552	561515
C355	INSTR.PANEL RH-STOP LTS	AMP HML	3	561667	561550
C356	INSTR.PANEL RH-PARK LTS	AMP HML	3	561667	561550
C357	INSTR.PANEL RH-FUEL LEVEL	AMP HML	3	561667	561550
C358	INSTR.PANEL CENT-TAC.& SPD.L.T	AMP HML	2	562600	562898
C359	INSTR.PANEL CENT-TAC.& SPD.L.T	AMP HML	2	562600	562898
C360	INSTRUMENT PANEL RH-WIPER MOTOR	AMP FF	6	-------	561186
C361	FR ROOF-LAVATORY OCCUPIED L.T	AMP HML	2	561248	561247
C362	FR ROOF-WATCH YOUR STEP L.T	AMP HML	2	561248	561247
C363	FR ROOF-INVERTER CONT.	AMP HML	5	561661	561662
C364	FR ROOF-UP WINDSHIELD DEFROST	AMP HML	3	561667	561550
C365	FR ROOF-DEST.SIGN FLUOR.	AMP HML	2	562600	562898
C366	FR ROOF-DEST.SIGN FLUOR.	AMP HML	2	562600	562898
C367	FR ROOF-DEST.SIGN BALLAST	AMP HML	3	561667	561550
C368	FR ROOF-DEST.SIGN DRIV.SW	TORRY	1	-------	562018
C369	FR ROOF-DEST.SIGN FLUOR.	AMP HML	2	562600	562898
C370	FR ROOF-DEST.SIGN FLUOR.	AMP HML	2	562600	562898
C371	FR ROOF-DEST.SIGN SPEED SW.	HOLEX	4	561477	561476
C373	ALARM JCT BDI-CONT-MASTER SW	AMP HML	6	561552	561515
C374	ALARM JCT BDI-CONT-LH CONSOL	AMP HML	6	561552	561515
C375	ALARM JCT BDI-CONT-LH CONSOL	AMP HML	3	561667	561550
C376	LH CONSOLE-SW-ENGINE STOP	HOLEX	4	561477	561476
C379	LH CONSOLE-OBD CONNECTOR	DEUTSCH	6	562366	-------
C380	ALARM JCT BDI-CPT.-HIC W WIRE	DEUTSCH	2	562486	562475
C382	LH CONSOLE-SW-WINDOW LIFT	SWF	8	-------	561087
C383	LH CONSOLE-SW-DRIVER'S LTS	SWF	2	-------	561837
C384	LH CONSOLE-DRV.WIND.LIFT HOT	PED PO	2	-------	561848
C385	FR SERV.COMPT.-UNDERHEATH.WL	AMP HML	3	561667	561550
C386	LH CONSOLE-WCL POWER SYSTEM	SWF	8	-------	561087
C387	RR JCT BDI-WCL	AMP HML	5	561661	561662

CONNECTORS CODE ID) Page G-2

No.	LOCATION	#NB TYPE	*PIN CAVITY	*SOCKET HOUSING	HOUSING
C389	RR JCT BDI-WCL	AMP HML	12	561735	561734
C389	WCL REAR DOOR	HOLEX	4	561477	561476
C390	LAVATORY WALL-WCL REMOTE CTR	SWF	8	-------	561087
C391	LAVATORY WALL-WCL LAMP	SWF	8	-------	561087
C392	LAVATORY WCL SW.L.T.	SWF	2	-------	561835
C393	LAVATORY WALL-WCL REMOTE S/S.	AMP CPC	4	560686	560687
C394	UNDER INSTRUMENT PANEL-MONITOR	AMP HML	4	560851	560852
C395	DRIVER'S COMPT.-B-U MONITOR	AMP	8	-------	561485
C396	DRIVER'S COMPT.-B-U MONITOR	AMP	8	-------	561485
C397	ENGINE COMPT.-CINDLE ELEC.	PED WP	2	561566	562284
C398	FR SECT.LH-HAT RACK AMPL1