LAZER FORMAT A1 CHELLE 8.2

CONNECTORS CODE ID Page G-1

No.	LOCATION	#ND TYPE	*PIN CAVITY	*SOCKET HOUSING	HOUSING
C1	FR JCT BDI COMPARTMENT	AMP CPC	37	560644	560646
C2	FR JCT BDI COMPARTMENT	AMP CPC	24	560641	560643
C3	FR JCT BDI COMPARTMENT	AMP CPC	37	560714	560713
C4	FR JCT BDI COMPARTMENT	AMP CPC	16	560693	560695
C5	FR SERVICE COMPT.-UNDERHEATH	AMP CPC	37	560644	560646
C6	FR SERVICE COMPT.-UNDERHEATH	AMP CPC	24	560641	560643
C7	FR JCT BDI COMPT.-UNDERHEATH	AMP CPC	37	560714	560716
C8	FR SERVICE COMPT.-UNDERHEATH	AMP CPC	37	560714	560713
C9	ALARM JCT BDI	AMP CPC	37	560644	560646
C10	ALARM JCT BDI	AMP CPC	37	560644	560646
C11	FR SERVICE COMPARTMENT	AMP CPC	24	560642	560643
C12	FR SERVICE COMPARTMENT	AMP CPC	24	560642	560643
C13	LH CONSOLE-HEATER MOR.	AMP HNL	2	561248	561247
C13	FR SERVICE COMPT.	AMP HNL	2	561248	561247
C13	LH CONSOLE-CER.HORROR	AMP HNL	6	561552	561555
C14	UNDER DASH-LH HORROR	AMP HNL	6	561552	561555
C15	RR JCT BDI	AMP CPC	24	561410	561643
C16	LH CONSOLE-CER.HORROR	AMP HNL	6	561552	561555
C16	LH CONSOLE SW-CRUISE ON-OFF	SWF	8	------	561087
C17	LH CONSOLE SW-CRUISE RESUME	SWF	8	------	561087
C18	LH CONSOLE SW-CRUISE SET	SWF	8	------	561087
C20	RR JCT BDI	AMP CPC	37	560644	560646
C21	RR JCT BDI	AMP CPC	24	560641	560643
C26	HYD & HVAC TRANSM.+NEUT.& B-U	PED WP	4	561610	561611
C27	HYD & HVAC TRANSM.-SPEED SENS.	PED WP	2	561566	561569
C30	DDEC ENGINE-ECM	PED	30	------	561600
C35	RR JCT BDI	AMP CPC	24	561642	561643
C36	EMERGENCY-EXIT LTS	AMP HNL	2	561248	561247
C37	RR SECTION-LH HAT RACK	AMP HNL	9	561661	561662
C38	RR SECTION-RH HAT RACK	AMP HNL	9	561661	561662
C40	RR JCT BDI	AMP CPC	16	560639	560640
C41	LAVATORY-ROOF FLUORESCENT	AMP HNL	2	560908	560898
C42	LAVATORY-BACK WALL-WTR TANK	AMP HNL	2	560908	560898
C43	LAVATORY-BACK WALL-ACCESS.	AMP HNL	9	561661	561662
C45	ALARM JCT BDI COMPARTMENT	AMP CPC	24	561642	561643
C46	FR SERVICE COMPT.-LOW BLOC	PED WP	11	561605	561517
C49	WATERE COMPT.-LOW BLOC	AMP HNL	2	561248	561247
C50	FR SERVICE COMPT.-LOW BLOC	PED WP	11	561605	561517
C52	RR JCT BDI	AMP CPC	22	561678	561718
C53	RR JCT BDI	AMP CPC	14	561585	561584
C54	UNDER DASH-LH HALT	HNL	6	561552	561555
C55	UNDER DASH-RH SW PANEL	AMP CPC	9	560636	560637
C56	UNDER DASH-RH CONSOLE	AMP CPC	24	561642	561643
C57	UNDER DASH-RH ACCESSORIES	AMP CPC	22	561678	561718
C58	UNDER DASH-RH ACCESSORIES	AMP CPC	22	561678	561718
C59	EVAPORATOR COMPARTMENT	AMP HNL	2	561248	561247
C60	RR JCT BDI COMPT.-L/T	AMP HNL	2	561248	561247
C61	LUGGAGE COMPARTMENT LTS	AMP HNL	2	561248	561247
C62	LUGGAGE COMPARTMENT LTS	AMP HNL	2	561248	561247
C63	LUGGAGE COMPARTMENT LTS	AMP HNL	2	561248	561247
C64	LUGGAGE COMPARTMENT LTS	AMP HNL	2	561248	561247
C65	LUGGAGE COMPARTMENT LTS	AMP HNL	2	561248	561247

CONNECTORS CODE ID Page G-1

No.	LOCATION	#ND TYPE	*PIN CAVITY	*SOCKET HOUSING	HOUSING
C66	LUGGAGE COMPARTMENT LTS	AMP HNL	2	561248	561247
C67	LUGGAGE COMPARTMENT LTS	AMP HNL	2	561248	561247
C68	LUGGAGE COMPARTMENT LTS	AMP HNL	2	561248	561247
C69	RH AVLE ACC-DISPOSE PVC END	PED WP	6	561568	561578
C70	ALARM JCT BDI COMPARTMENT	AMP CPC	14	561642	561643
C71	UNDER INSTRUMENT PANEL-LH	AMP CPC	37	561645	561646
C72	UNDER INSTRUMENT PANEL-CENT.	AMP CPC	37	561645	561646
C73	UNDER INSTRUMENT PANEL-CENT.	AMP CPC	16	560639	560640
C74	LUGGAGE COMPT.-AIR RET.SENS.	AMP HNL	2	561248	561247
C75	ALARM JCT BDI COMPARTMENT	PED WP	4	561610	561611
C76	LUGGAGE COMPT.-AIR RET.SENS.	AMP HNL	2	561248	561247
C77	LUGGAGE COMPT.-AIR RET.SENS.	AMP HNL	2	561248	561247
C78	FR JCT BDI COMPARTMENT	AMP CPC	22	561678	561718
C79	FR SERVICE COMPT.-UNDERHEATH	AMP CPC	37	560644	560646
C80	LUGGAGE COMPT.-AIR RET.SENS.	AMP HNL	2	561248	561247
C81	PASSENGER COMPT.-HOLE L/T	AMP HNL	6	560908	560898
C82	ENTRANCE DOOR	HOLEX	6	562079	562069
C83	ENTRANCE DOOR-MIDSHIFT HOLE	HOLEX	6	562079	561476
C84	ENTRANCE DOOR-PRESSURE SW	PED WP	2	561566	561569
C85	UNDER INSTRUMENT PANEL-LH	AMP HTA-100 B	8	------	562248
C87	RR JCT BDI	AMP CPC	9	560636	560637
C88	RR END ROOF-CLEARANCE LTS	AMP HNL	2	560908	560898
C89	RR END ROOF-B-U HOINTER	AMP CPC	14	561582	561581
C90	RR JCT BDI	AMP CPC	15	561587	561586
C91	RR JCT BDI	AMP CPC	37	561566	561569
C92	RR JCT BDI COMPT.-WATI SKID	AMP CPC	9	561635	561637
C93	RR JCT BDI COMPT.-WATI SKID	AMP CPC	9	561635	561637
C94	FR AVLE ACCESSORIES	AMP CPC	14	561585	561585
C97	RH AVLE ACC-DISPOS PVC END	PED WP	6	561568	561578
C98	FR SERVICE COMPT.-ELC.F.SPEDAL	PED WP	3	561782	561781
C99	FR SERVICE COMPT.LTS	AMP HNL	2	561248	561247
C100	FR SERVICE COMPT.-CONDENSER	AMP HNL	2	561248	561247
C101	FR SERVICE COMPT.-ELEC.-HORNS	PED WP	2	561566	561569
C102	FR SERVICE COMPT.-F.I.-GEN.L.T	HNL	9	561661	561662
C103	FR SW & SERV.ELC.COMPT.-HARNESS	ITT SS	2	561813	561812
C104	FR SERVICE COMPT.-CIGL.& WLHT	PED WP	2	561566	561569
C105	FR SERVICE COMPT.-WATER VALVE	PED WP	2	561566	561569
C106	FR SERVICE COMPT.-CHMPER	PED WP	2	561566	561569
C107	FR SERVICE COMPT.-KNEEL.SYS	PED WP	2	561566	561569
C108	FR SERVICE COMPT.-KNEEL.SYS	PED WP	2	561566	561569
C109	FR SERVICE COMPT.-KNEEL.SYS	PED WP	2	561566	561569
C110	EVAPORATOR COMPT.-DAMPER	ITT SS	2	561813	561812
C113	BATT.& RH J&JCPT.MARKER.L.T	ITT SS	2	561813	561812
C114	BATTERY CPT.-DOOR SW.L.T RH	ITT SS	2	561813	561812
C115	ENGINE COMPT.-LTS	PED WP	2	561566	561569
C116	ENGINE COMPT.-LAVATORY FAN	TC	2	561268	562997
C117	UNDER DASH-RH WIPER MOTOR	AMP FF	6	------	561186
C118	UNDER DASH-RH L/H FAN	TC	2	561268	562997
C119	UNDER DASH-RH RH FAN	TC	2	561268	562997
C120	RR JCT BDI-COOLER CONNECTOR	AMP HNL	2	561248	561247
C121	RR JCT BDI COMPT.-AT KYH	AMP CPC	16	560639	560640
C122	RR JCT BDI COMPT.-AT KYH	AMP CPC	16	560639	560640
C124	FR SERVICE COMPT.-KNEELING	ITT SS	3	561811	561880
C125	RR JCT BDI COMPT.-AT KYH	PED	30	------	561600

CONNECTORS CODE ID Page G-2

No.	LOCATION	#ND TYPE	*PIN CAVITY	*SOCKET HOUSING	HOUSING
C125	ENGINE COMPT-BU-U.ALARM	PED WP	2	561566	561569
C126	ENGINE COMPT-FLUSHING PUMP	PED WP	2	561566	561569
C127	ENGINE COMPT-FUEL FILTER	PED WP	2	561566	561569
C128	ENGINE COMPT-U-C COMPRES.LUTION	ITT SS	2	561813	561812
C129	ENGINE COMPT-FUEL PUMP	PED WP	2	561566	561569
C130	ENGINE COMPT-UN.DOOR	ITT SS	2	561813	561812
C131	ENGINE COMPT-UN.DOOR	ITT SS	2	561813	561812
C132	ENGINE COMPT-W/C L.O.PRESS SW	PED WP	2	561566	561569
C133	ENGINE COMPT-W/C L.O.PRESS SW	PED WP	2	561566	561569
C134	ALARM JCT BDI COMPARTMENT	PED WP	4	561610	561611
C136	FR JCT BDI-LUGGAGE DOOR CON.	AMP HNL	15	561587	561586
C137	RR JCT BDI	AMP CPC	37	561566	561569
C138	W/C JCT BDI-TRANSMITTER	AMP HNL	2	560908	560898
C139	W/C JCT BDI-CONTROL MODULE	AMP HNL	2	560908	560898
C139	W/C JCT BDI-L-DOOC MODULE	AMP HOP	15	562811	------
C142	LAVATORY-DOOR WALL	AMP HNL	2	561248	561247
C143	LAVATORY-DOOR WALL	AMP HNL	3	560908	562086
C144	ENGINE CPT-RH-DIFF.PRESS.SW	PED WP	2	561566	561569
C200	RH SECT.-RH HAT RACK-BALLAST	AMP HNL	9	561661	561662
C201	ENGINE CPT-MODULATOR VALVE	AMPHENOL	2	------	561412
C202	RH SECT.-RH HAT RACK SPEAKER	AMP HNL	9	561661	561662
C203	RH HAT RACK-READING L.T	AMP HNL	2	561248	561247
C204	RH HAT RACK-GENERAL L.T	AMP HNL	9	561661	561662
C205	RH SECT.-RH HAT RACK SPEAKER	AMP HNL	9	561661	561662
C206	RH HAT RACK-READING L.T	AMP HNL	2	560908	560898
C207	RH HAT RACK-READING L.T	AMP HNL	2	560908	560898
C208	LH HAT RACK-BALLAST	AMP HNL	4	560951	560952
C209	RH SECT.-LH HAT RACK SPEAKER	AMP HNL	9	561661	561662
C211	EVAPORATOR-CPT-FRESH AIR SENS	ITT SS	2	561813	561812
C212	EVAPORATOR-CPT-FRESH AIR SENS	ITT SS	2	561813	561812
C213	FR ROOF-CLEARANCE L.T	AMP HNL	2	560908	560898
C216	UNDER DASH-LH-P.A.	AMP HNL	9	561678	561678
C217	UNDER DASH-LH-P.A.	AMP HNL	3	------	561558
C218	UNDER DASH-LH-P.A.	AMP HNL	3	------	561558
C219	UNDER DASH-LH-P.A.	AMP HNL	3	------	561558
C220	RR JCT BDI-FUEL PRIME PUMP	TC	1	561818	561873
C222	ALARM JCT BDI COMPT.-AT KYH	AMP CPC	14	561677	561678
C223	RH AVLE-LH-DIST-TACHO	AMP HNL	4	561551	561661
C224	ENGINE CPT-FUEL PRIME PUMP	PED WP	2	561566	561569
C227	RH AVLE-RH-LH WHEEL	W48CD	3	------	641098
C228	RH SW PANEL-HIGRO OUTLET	HOLEX	4	561477	561476
C229	RH AVLE-LH-DIST-DRIV.SPEAK.	AMP HNL	4	561551	561661
C230	ENGOPT.-FUEL PRIME PUMP FEED	DEUTSCH	2	562495	562495
C231	RH AVLE-RH-LH WHEEL	W48CD	3	------	641098
C232	ENGOPT.-FUEL PRIME PUMP	PED WP	2	561566	561569
C233	INSTRUMENT PANEL CENTER	AMP HNL	2	561248	561247
C234	INSTRUMENT PANEL CENTER	VJOL	6	------	562844
C235	INSTRUMENT PANEL CENTER	VJOL	6	------	562844
C236	INSTRUMENT PANEL CENTER	AMP HNL	4	560951	560952
C237	UNDER DASH-LH-JACOB CLUTCH SW	ITT SS	3	561111	561880
C238	W/C JCT BDI-DDEC CONNECTOR	AMP HNL	9	561678	561678
C239	FR SERVICE CPT-HI BUZZ VALVE	PED WP	2	561566	561569
C240	FR SERVICE CPT-KNEEL PRSD SW	PED WP	2	561566	561569
C241	FR SERVICE CPT-FOG RESISTOR	AMP CPC	3	561847	561862
C242	FR SERVICE CPT-FOG RESISTOR	AMP CPC	3	561847	561862
C243	FR SERVICE CPT-HEADLAMPS	TC	1	------	561871
C244	FR SERVICE CPT-HI-FOG LAMP	ITT SS	2	561813	561812
C245	FR SERVICE CPT-HI-FOG LAMP	ITT SS	2	561813	561812
C246	FR SERVICE CPT-HARN & DRL'S	ITT SS	3	561111	561880
C248	ALARM JCT BDI-WIPER PULSE DEV	AMP FF	6	------	561189
C249	ALARM JCT BDI-CONN.12V TO 5V	AMP HNL	3	561667	561550

CONNECTORS CODE ID Page G-3

No.	LOCATION	#ND TYPE	*PIN CAVITY	*SOCKET HOUSING	HOUSING
C250	ALARM JCT BDI-DASH LTS REGUL.	AMP HNL	4	561952	561515
C251	LH SW PANEL-F.VENT IDLE	SWF	8	------	561837
C252	LH SW PANEL-SWITCH L.T	SWF	2	------	561837
C253	LH SW PANEL-ETHER	SWF	2	------	561837
C254	INST. PANEL-RH ENTR.DOOR SW. TORR1	5	------	562108
C255	LH SW PANEL-SPEED SW	SWF	8	------	561837
C257	INSTRUMENT PANEL CENT-SPEEDO	AMP HNL	4	560951	560952
C258	LH SW PANEL-MULTI FUNC. SW	AMP FF	8	------	561188
C259	LH SW PANEL-MULTI FUNC. SW	AMP FF	6	------	561188
C260	LH SW PANEL-MULTI FUNC. SW	AMP FF	6	------	561188
C264	UNDER DASH-RH DOOR CIR.L.T	AMP HNL	4	561551	561668
C265	UNDER DASH-RH DOOR CIR.L.T	AMP HNL	4	561551	561668
C266	UNDER DASH-RH DOOR CIR.L.T	AMP HNL	4	561551	561668
C267	ENGINE CPT-U-C COMPRESSOR	AMP HNL	4	561889	561892
C268	ENGINE CPT-U-C COMPRESSOR	AMP HNL	4	561889	561892
C269	ENGINE CPT RR DOOR LICENCE L.T	DOH-AUTO	2	930210	------
C270	RH SW PANEL-RADIO	AMP HNL	4	561551	561668
C271	RH HAT RACK-FLUORESCENT	AMP HNL	4	561551	561668
C272	RH HAT RACK-BALLAST	AMP HNL	4	561551	561668
C273	RH HAT RACK-BALLAST	AMP HNL	4	561551	561668
C274	RH HAT RACK-GENERAL L.T	AMP HNL	4	561667	561550
C275	RH SECT.-RH HAT RACK SPEAKER	AMP HNL	4	561551	561668
C276	RH HAT RACK-READING L.T	AMP HNL	2	560908	560898
C277	RH HAT RACK-READING L.T	AMP HNL	2	560908	560898
C278	LH HAT RACK-BALLAST	AMP HNL	4	560951	560952
C279	RH SECT.-LH HAT RACK SPEAKER	AMP HNL	4	561551	561668
C280	LH SW PANEL-SWITCH L.T	AMP HNL	2	561248	561247
C281	LH SW PANEL-SWITCH L.T	AMP HNL	2	561248	561247
C282	LH CONSOLE COMPT-VIDEO SYST.	AMP HNL	4	561671	561668
C283	LH CONSOLE COMPT-VIDEO SYST.	AMP HNL	4	561671	561668
C284	INSTRUMENT PANEL RH -LTS	AMP HNL	2	560908	560898
C285	LH DASH-CONTROL-SWITCH L.T	AMP HNL	3	561667	561558
C299	LH CONSOLE SW-GALLEY	SWF	8	------	561087
C300	INVERTER-CENTER	AMP HNL	4	561551	561668
C301	INSTRUMENT PANEL CENT-TACHO	AMP HNL	4	560951	560952
C302	LH CONSOLE SW-GALLEY	AMP HNL	9	561661	561662
C305	GALLEY	AMP HNL	9	561661	561662
C306	LH CONSOLE SW-PHEDISTAL	SWF	8	------	561087
C309	DDEC ENGINE-ECM POWER CON.	PED HP	5	------	562345
C310	LH CONSOLE SW-CIGL.& WLHT	SWF	8	------	561087
C311	LH CONSOLE SW-HDS & PAS CHME	SWF	8	------	561087
C312	LH CONSOLE SW-WIPER	SWF	8	------	561087
C313	LH CONSOLE SW-CEN & FLOOR LTS	SWF	8	------	561087
C314	LH CONSOLE SW-CEN & FLOOR LTS	SWF	8	------	561087
C315	LH CONSOLE SW-SWITCH	SWF	8	------	561087
C316	LH CONSOLE SW-SWITCH	SWF	8	------	561087
C318	LH CONSOLE SW-DRIV WINDOW LIFT	SWF	8	------	561087
C320	LH CONSOLE SW-DRIVER'S LTS	SWF	8	------	561087
C321	LH CONSOLE-DRV WIND LIFT HOT.	PED PO	2	------	561848
C322	LH CONSOLE SW-DAWN,WIND.WIPER	SWF	8	------	561087
C324	GALLEY-REFRIGERATOR	AMP HNL	9	561661	561662
C325	LH CONSOLE SW-WIPER	SWF	8	------	561087
C326	LH CONSOLE SW-SPARE	SWF	8	------	561087
C327	ENGINE COMPT-MR-START SW BDY	AMP CPC	9	560636	560637

CONNECTORS CODE ID Page G-3

No.	LOCATION	#ND TYPE	*PIN CAVITY	*SOCKET HOUSING	HOUSING
C328	GALLEY-LAMP	AMP HNL	2	561248	561247
C329	ENGINE TACHO SIGNAL	PED WP	2	561566	561569
C330	GALLEY-MICROWAVE SW.L.T	SWF	2	------	561837
C331	GALLEY-MICROWAVE SW	SWF	2	------	561837
C332	GALLEY-RH CONTAINER SW.L.T	SWF	2	------	561837
C333	GALLEY-RH CONTAINER SW	SWF	2	------	561837
C334	GALLEY-LH CONTAINER SW	SWF	2	------	561837
C335	GALLEY-LH CONTAINER SW.L.T	SWF	2	------	561837
C337	INSTR.PANEL-LH-UP WIPER SW	SWF	8	------	561087
C338	INSTR.PANEL-LH-WASHER SW	SWF	8	------	561087
C339	INSTR.PANEL-LH-WASHER SW.L	SWF	2	------	561837
C340	ALARM JCT BDI-COMP.	AMP HNL	2	560908	560898
C341	INSTR.PANEL-LH-HORNS SW	SWF	8	------	561087
C342	INSTR.PANEL-LH-HEADLAMP SW	SWF	8	------	561087
C343	INSTR.PANEL-LH-HORNS,L.T SW	SWF	8	------	561087
C344	INSTR.PANEL-LH-F.IDLE SW	SWF	8	------	561087
C345	INSTR.PANEL-LH-HORNS SW	SWF	2	------	561837
C346	INSTR.PANEL-LH-DASHLT SW	SWF	2	------	561837
C347	LH CONSOLE-RADIO-SPEAKER	AMP HNL	9	561661	561662
C348	RH CONSOLE-RELEVISEUR	AMP HNL	2	561248	561247
C350	RH CONSOLE-THERMOMETER	AMP HNL	3	561667	561550
C351	LH HAT RACK-FLUOR.CIR.	HOLEX	4	561477	561476
C352	RH CONSOLE-CRY TEMP SENSOR	BURNDY	4	561184	------
C353	INSTR.PANEL RH-DRV FAN RHEOST	AMP HNL	5	561552	561555
C354	INSTR.PANEL RH-DRV TEMP CTR	AMP HNL	6	561552	561555
C355	INSTR.PANEL RH-FRT DEFR CTR	AMP HNL	5	561667	561558
C357	INSTR.PANEL RH-WATER TEMP SW	AMP HNL	3	561667	561558
C358	INSTR.PANEL RH-DRV FAN SW	AMP HNL	3	561667	561558
C359	INSTR.PANEL CENT-FAC & SPEL	AMP HNL	2	561248	561247
C360	RH ROOF-WIPER MOTOR	AMP FF	6	------	561186
C361	RH ROOF-WIPER OCCUPIED SW	AMP HNL	2	561248	561247
C362	RH ROOF-WATCH-YOUR STEP L.T	AMP HNL	2	561248	561247
C364	RH ROOF-DOOR-STRATOS SW	AMP HNL	3	561667	561558
C365	RH ROOF-UP WINDSHIELD DEFROST	AMP HNL	3	561667	561558
C366	RH CONSOLE-TRANSMITTER	AMP HNL	3	561667	561558
C367	RH CONSOLE-DSP.CTL.T SENSOR	PED WP	2	561566	561569
C368	RH CONSOLE-DSP.CTL.T SENSOR	PED WP	2	561566	561569
C369	RH ROOF-DEST.SIGN OPER. TORR1	4	------	562108
C370	RH ROOF-DEST.SIGN FLUOR.	AMP HNL	2	560908	560898
C371	RH ROOF-DEST.SIGN FLUOR.	AMP HNL	2	560908	560898
C372	RH ROOF-DEST.SIGN SPEED SW	HOLEX	4	561477	561476
C374	ALARM JCT BDI COMPT-MASTER SW	AMP HNL	6	561552	561555
C375	ALARM JCT BDI COMPT-LH CONSOL	AMP HNL	6	561552	561555
C376	ALARM JCT BDI COMPT-LH CONS.	AMP CPC	37	561714	561205
C377	LH SW PANEL-STOP ENGOPERDE	SWF	8	------	561087
C378	LH SW PANEL-STOP ENGOPERDE	SWF	2	------	561837
C379	ALARM JCT BDI-MIC W/ SWITCH	DEUTSCH	2	562248	562247
C380	FR SERVICE COMPT-UNDERHEATH	AMP HNL	9	561661	561662
C381	LH CONSOLE-W/C POWER SYSTEM	SWF	8	------	561087
C387	RR JCT BDI -W/C	AMP HNL	9	561661	561662

CONNECTORS CODE ID Page G-2

No.	LOCATION	#ND TYPE	*PIN CAVITY	*SOCKET HOUSING	HOUSING
C388	RR JCT BDI-W/C	AMP HNL	12	561735	561734
C389	W/C REAR DOOR	HOLEX	4	561477	561476
C390	LAVATORY WALL-W/C REMOTE CTR	SWF	8	------	561087
C391	LAVATORY WALL-W/C LAMP	SWF	8	------	561087
C392	LAVATORY-W/C WL SW.L.T.	SWF	2	------	561837
C393	LAVATORY WALL-W/C REMOTE STS.	AMP CPC	4	561686	561687
C394	UNDER INSTRUMENT PANEL-LH	AMP HNL	4	560951	560952
C395	DRIVER'S COMPT.-B-U MONITOR	AMP	5	------	561465
C396	FR SERVICE COMPT.-ENGINE	DEUTSCH	2	562495	562495
C397	ENGINE COMPT.-CINDLL.ALC	DEUTSCH	2	562495	562284
C398	FR SECT.-LH HAT RACK-AMPL1	HOLEX	6	------	562464
C399	FR SECT.-LH HAT RACK-AMPL1	HOLEX	6	------	562464
C400	ENGINE COMPT.-BLOCK HEATER	PED HP	3	561781	561782
C401	FR SECT.-LH HAT RACK-AMPL1	HOLEX	6	------	562464
C402	RR DRIVE AXLE-AIR DRYER	PED HP	2	------	562251
C403	CALLEY-FWD.HOOD	AMP HNL	2	562248	561247
C406	FR JCT BDI COMPT.-WATI SKID	AMP HNL	2	560908	560898
C407	FR SERVICE COMPT.	AMP HNL	2	561248	561247
C408	ENGINE COMPT.-SIGNAL	PED HP	4	561606	561607
C409	ENGINE CPT.-LOW COOL.LEVEL	PED HP	2	562358	------
C410	FR JCT BDI-DDDE CONNECTOR	AMP HNL	15	561587	561586
C411	FR JCT BDI-DDDE CONNECTOR	AMP HNL	15	561587	561586
C412	LH SW.PANEL-MASTER SWITCH	SWF	8	------	561087
C413	ENG.CPT-U-C HE UNLOAD.RYS SW	PED WP	2	561566	561569
C414	FR JCT BDI	AMP CPC	14	561678	561649
C415	ENGINE CPNDLE-FAN SIGNAL	PED WP	3	561781	561782
C416	ENGINE CPT-FAN SIGNAL	PED WP	3	561781	561782
C417	FRONT JCT BDI-DDDE	AMP HNL	15	561587	561586
C418	INSTR.PANEL LH-HTR WINDSHIELD	SWF	8	------	561087
C419	FR JCT BDI-DDDE CONN.FOR JACOB	AMP HNL	3	561667	561558
C420	ENGINE COMPT.-WEBASTO WATER HTR	TC	2	561597	------
C421	ENGINE COMPT.-WEBASTO WATER HTR	TC	1	561873	------
C422	ENGINE COMPT.-WEBASTO WATER HTR	TC	2	561597	------
C423	UNDER DASH-CENTER-AMP.HNL	3	561667	561558
C425	ALARM JCT BDI-DIODES	AMP HNL	15	561587	561586
C426	ALARM JCT BDI-DIODES	AMP HNL	15	561587	561586
C427	ALARM JCT BDI-DIODES	AMP HNL	6	561552	561555
C430	ALARM JCT BDI COMPT.-TIMER	AMP FF	8	561188	561363
C431	ALARM JCT BDI-DIODES-REL.TAB	AMP HNL	2	561248	561247
C432	ENGINE CPT.-PROV.SW.DOOR AJAR	DEUTSCH	4	562479	562477
C433	FRONT JCT.BDI-DIODES	AMP HNL	15	561587	561586
C434	FRONT JCT.BDI-DIODES	AMP HNL	15	561587	561586
C435	FR SERVICE CPT.-RH KNEEL.PRSD SW	PED WP	2	560908	560898
C436	RH HAT RACK-W/C CENTER ROOF.AC	AMP CPC	16	560639	560640
C437	RH HAT RACK-W/C CENTER ROOF.AC	AMP CPC	16	560639	560640
C450	WORLD TRANSM.-TURBINE SENSOR	PED HP	2	------	562431
C457	WORLD TRANSM.-MAIN CONNECTOR	DEUTSCH	31	562572	562536
C458	WORLD TRANSM.-TURBINE SENSOR	PED HP	2	------	562426
C459	WORLD TRANSM.-ENGINE SPS.SENS.	PED HP	2	------	562426
C460	WORLD TRANSM.-SPEED SENSOR	ITT	2	------	562541
C461	WORLD TRANSM.-RETARDER TEMP.	PED HP	2	561566	561569
C462	WORLD TRANSM.-SOL.VALVE	PED HP	2	------	562432
C463	WORLD TRANSM.-SENSOR CONN.	DEUTSCH	36	562578	562573
C464	RR JCT BDI-ODL CONN w.C.	PED HP	12	------	562574

CONNECTORS CODE ID Page G-2

No.	LOCATION	#ND TYPE	*PIN CAVITY	*SOCKET HOUSING	HOUSING
C465	LH CONSOLE-SHIFTER SELECTOR	T & BET	18	------	562429
C466	FR SERVICE CPT.-RESIS.HOO.	PED WP	3	------	562428
C467	FR SERVICE CPT.-RESIS.HOO.	PED WP	3	------	562428
C468	FRONT JCT.BDI-W/C SW.L.T.	PED HP	1	------	562873
C470	FR SERVICE CPT.-SILENT 1000	AMP HNL	2	561248	561247
C471	FR SERVICE CPT.-SILENT 1000	AMP HNL	2	561248	561247
C472	FR SERVICE CPT.-SILENT 1000	PED HP	2	561566	561569
C473	ENGINE CPT.-PROV.SW.DOOR AJAR	DEUTSCH	4	562479	562477
C474	ALARM JCT BDI-PROPEVER	HOLEX	6	561678	562069
C501	LH CONSOLE-PROPEVER HOLDER	PED HP	3	562433	------
C502	LH CONSOLE-PRE HEATER SW.	SWF	8	------	561087
C503	LH CONSOLE-PRE HEATER SW.	SWF	8	------	561087
C504	ALARM JCT BDI COMPT.-WELTEMP	AMP	8	561688	562363
C505	ALARM JCT BDI COMPT.&TRAM TIMER AMP		3	------	562934
C506	AL