CONNECTORS CODE (C) Page G : 1

No.	LOCATION	(NB) TYPE	#PIN CAVITY	#SOCKET HOUSING	HOUSING
C1	FR JCT BOX COMPARTMENT	AMP CPC	37	561644	561646
C2	FR JCT BOX COMPARTMENT	AMP CPC	24	561641	561643
C3	FR JCT BOX COMPARTMENT	AMP CPC	37	561714	561713
C4	FR JCT BOX COMPARTMENT	AMP CPC	16	561693	561695
C5	FR SERVICE COMPT.-UNDERNEATH	AMP CPC	37	561644	561646
C6	FR SERVICE COMPT.-UNDERNEATH	AMP CPC	24	561641	561643
C7	FR JCT BOX COMPT.-UNDERNEATH	AMP MNL	15	561987	561986
C8	FR SERVICE COMPT.-UNDERNEATH	AMP CPC	37	561714	561713
C9	ALARM JCT BOX	AMP CPC	16	561693	561695
C10	ALARM JCT BOX	AMP CPC	37	561644	561646
C11	FR SERVICE COMPARTMENT	AMP CPC	24	561642	561643
C12	FR SERVICE COMPARTMENT	AMP CPC	16	561639	561640
C12	LH CONSOLE-HEATER MIR.	AMP MNL	2	561248	561247
C13	FR SERVICE COMPT.	AMP MNL	6	561552	561515
C13	LH CONSOLE-CTR MIRROR	AMP MNL	6	561552	561515
C14	UNDER DASH-LH MIRROR	AMP MNL	9	561661	561662
C15	RR JCT BOX	AMP CPC	24	561641	561643
C15	UNDER DASH-RH MIRROR	AMP MNL	9	561661	561662
C16	LH CONSOLE SW-CRUISE ON OFF	SWF	8	------	561107
C17	LH CONSOLE SW-CRUISE RESUME	SWF	8	------	561107
C18	LH CONSOLE SW-CRUISE SET	SWF	8	------	561107
C20	RR JCT BOX	AMP CPC	37	561644	561646
C21	RR JCT BOX	AMP CPC	24	561641	561643
C26	HYD & MAN TRANSM.-NEUT.& B/U	PED WP	4	561610	561611
C27	HYD & MAN TRANSM.-SPEED SENS.	PED WP	2	561566	561690
C32	DDEC ENGINE-ECM	PED	30	------	561600
C35	RR JCT BOX	AMP CPC	24	561642	561643
C36	EMERGENCY EXIT LTS	AMP MNL	2	560900	560898
C37	RR SECTION-LH HAT RACK	AMP MNL	9	561661	561662
C38	RR SECTION-RH HAT RACK	AMP MNL	9	561661	561662
C40	RR JCT BOX	AMP CPC	16	561639	561640 PRIOR R021
C41	LAVATORY ROOF FLUORESCENT	AMP MNL	2	560900	560898
C42	LAVATORY BACK WALL-WTR TANK	AMP MNL	2	560900	560898
C43	LAVATORY BACK WALL-ACCES.	AMP MNL	9	561661	561662
C45	ALARM JCT BOX COMPARTMENT	AMP CPC	24	561642	561643
C47	FR SERVICE COMPARTMENT	AMP CPC	16	561694	561695
C49	BATTERIE COMPT.-LT	AMP MNL	2	561248	561247
C50	FR SERVICE COMPT.-LOW BUOY	PED WP	1	561605	561577
C52	RR JCT BOX	AMP CPC	22	561709	561710
C53	RR JCT BOX	AMP CPC	14	561585	561584 PRIOR R021
C54	UNDER DASH-PA UNIT	AMP MNL	6	561552	561515
C55	UNDER DASH-RH SW PANEL	AMP CPC	9	561636	561637
C56	UNDER DASH-RH CONSOLE	AMP CPC	24	561642	561643
C57	UNDER DASH-RH ACCESSORIES	AMP CPC	22	561989	561710
C58	EVAPORATOR COMPARTMENT	AMP CPC	14	561585	561583
C59	EVAPORATOR COMPARTMENT	AMP CPC	16	561639	561640
C60	RR JCT BOX COMPT.-LT	AMP MNL	2	561248	561247
C61	LUGGAGE COMPARTMENT LTS	AMP MNL	2	561248	561247
C62	LUGGAGE COMPARTMENT LTS	AMP MNL	2	561248	561247
C63	LUGGAGE COMPARTMENT LTS	AMP MNL	2	561248	561247
C64	LUGGAGE COMPARTMENT LTS	AMP MNL	2	561248	561247
C65	LUGGAGE COMPARTMENT LTS	AMP MNL	2	561248	561247
C66	LUGGAGE COMPARTMENT LTS	AMP MNL	2	561248	561247
C67	LUGGAGE COMPARTMENT LTS	AMP MNL	2	561248	561247
C68	LUGGAGE COMPARTMENT LTS	AMP MNL	2	561248	561247
C69	RR AXLE ACC-INSIDE PVC END	PED WP	6	561568	561578

CONNECTORS CODE (C) Page G : 1

No.	LOCATION	(NB) TYPE	#PIN CAVITY	#SOCKET HOUSING	HOUSING
C70	ALARM JCT BOX COMPARTMENT	AMP CPC	24	561642	561643
C71	UNDER INSTRUMENT PANEL-LH	AMP CPC	37	561645	561646
C72	UNDER INSTRUMENT PANEL-CENT.	AMP CPC	37	561645	561646
C73	UNDER INSTRUMENT PANEL-CENT.	AMP CPC	16	561639	561640
C74	UNDER INSTRUMENT PANEL-RH	AMP CPC	24	561642	561643
C75	ALARM JCT BOX COMPARTMENT	PED WP	4	561610	561611
C76	LUGGAGE COMPT.-AIR RET.SENS.	AMP MNL	2	561248	561247
C77	LUGGAGE COMPT.-AIR RET.SENS.	AMP MNL	2	561248	561247
C78	FR JCT BOX COMPARTMENT	AMP CPC	22	561709	561710
C79	FR SERVICE COMPT.-UNDERNEATH	AMP CPC	37	561644	561646
C80	LUGGAGE COMPT.-AIR RET.SENS.	AMP MNL	2	561248	561247
C81	PASSENGER COMPT.-AISLE LTS	AMP MNL	2	560900	560898
C82	ENTRANCE DOOR	MOLEX	6	562070	562069
C83	ENTRANCE DOOR-PROIMITY SW	MOLEX	4	561477	561476
C84	ENTRANCE DOOR-PRESSURE SW	PED WP	2	561566	561690
C85	UNDER INSTRUMENT PANEL LH	AMP MTA-100	8	------	562248
C87	RR END ROOF	AMP CPC	9	561636	561637
C88	RR END ROOF-CLEARANCE LTS	AMP MNL	2	560900	560898
C89	RR END ROOF-B/U NONITOR	AMP CPC	4	561582	561581
C90	RR JCT BOX	AMP CPC	15	561987	561986
C91	RR JCT BOX	AMP CPC	37	561714	561713
C92	FR JCT BOX COMPT-ANTI SKID	AMP CPC	9	561635	561637
C93	FR JCT BOX COMPT-ANTI SKID	WABCO	35	------	641094
C96	FR AXLE ACCESSORIES	AMP CPC	14	561585	561585
C97	RR AXLE ACC-INSIDE PVC END	PED WP	6	561568	561578
C98	FR SERVICE COMPT-EL.FT.PEDAL	PED WP	3	561782	561781
C99	FR SERVICE COMPT LTS	AMP MNL	2	561248	561247
C100	FR SERVICE COMPT-CORNERING LT	PED WP	2	561566	561690
C101	FR SERVICE COMPT-ELEC. HORNS	PED WP	2	561566	561690
C102	FR SERV & SIDE CPT-FLASH. LH	ITT SS	2	561813	561812
C103	FR SERV & SIDE CPT-MARKERS	ITT SS	2	561813	561812 PRIOR R021
C103	FR SERV & SIDE CPT-MARKERS	GROTE	2	------	562155
C104	FR SERV & SIDE CPT-FLASH. RH	ITT SS	2	561813	561812 PRIOR R021
C104	FR SERV & SIDE CPT-FLASH. RH	GROTE	2	------	562155
C105	FR SERVICE COMPT-LIQ.S.VALVE	PED WP	2	561566	561690
C106	FR SERVICE COMPT-WATER VALVE	PED WP	2	561566	561690
C107	EVAPORATOR COMPT-DAMPER	PED WP	2	561566	561690
C108	FR SERVICE COMPT-KNEEL.SYS	PED WP	2	561566	561690
C109	FR SERVICE COMPT-KNEEL.SYS	PED WP	2	561566	561690
C110	FR SERVICE COMPT-KNEEL.SYS	PED WP	2	561566	561690
C111	EVAPORATOR COMPT-DAMPER	ITT SS	2	561813	561812
C113	BATT. & RR J.B.CPT.MARKER LT	ITT SS	2	561813	561812 PRIOR R021
C113	BATT. & RR J.B.CPT.MARKER LT	GROTE	2	------	562155
C114	RR J. BOX CPT DOOR DIR LT LH	ITT SS	2	561813	561812 PRIOR R021
C114	RR J. BOX CPT DOOR DIR LT LH	GROTE	2	------	562155
C115	ENGINE COMPT-AIR DRYER	PED WP	2	561566	561690
C116	ENGINE COMPT. LTS	PED WP	2	561566	561690 PRIOR R021
C116	ENGINE COMPT. LTS	PED WP	1	561605	561577
C118	ENGINE COMPT-LAVATORY FAN	TC	2	561030	560997
C119	ENGINE CPT RR DOOR RH LO LAMP	PED WP	6	561606	561607
C120	ENGINE CPT RR DOOR LH LO LAMP	PED WP	6	561606	561607
C121	BATTERIE CPT. DOOR DIR LT RH	ITT SS	2	561813	561812 PRIOR R021
C121	BATTERIE CPT. DOOR DIR LT RH	GROTE	2	------	562155
C122	ENGINE CPT-CAMERA DOOR VALVE	PED WP	2	561566	561690
C124	ENGINE CPT-ETHER SW	PED WP	2	561566	561690

PREVOST CAR inc.	WIRING DIAGRAM	NO: D060869	P. G/$^{1}_{4}$	REVISION 021

CONNECTORS CODE (C) Page G : 2

No.	LOCATION	TYPE	(NB) CAVITY	#PIN HOUSING	#SOCKET HOUSING	
C125	ENGINE CPT-B/U ALARM	PED WP	2	561566	561690	
C126	ENGINE CPT-FLUSHING PUMP	PED WP	2	561566	561690	
C127	ENGINE CPT-FUEL FILTER	PED WP	2	561566	561690	
C128	ENGINE CPT-A/C COMPR.CLUTCH	ITT SS	2	561813	561812	
C129	ENGINE CPT-PRE-HEAT WATER	AMP FF	6	561672	561186	
C130	ENGINE CPT-UNLOADER	ITT SS	2	561813	561812	
C131	ENGINE CPT-UNLOADER	ITT SS	2	561813	561812	
C132	ENGINE CPT-A/C LO PRESS SW	PED WP	2	561566	561690	
C133	ENGINE CPT-A/C HI PRESS SW	PED WP	2	561566	561690	
C134	FR JCT BOX-LUGGAGE DIODE CON.	AMP MNL	15	561987	561986	
C135	FR JCT BOX-LUGGAGE DIODE CON.	AMP MNL	15	561987	561986	
C136	A/C JCT BOX	DEUTSCH	40	562281	562284	
C137	A/C JCT BOX-TRANSMITTER	AMP MNL	2	560900	560898	
C138	A/C JCT BOX-CONTROL MODULE	AMP HDP	15	------	562012	
C139	A/C JCT BOX-LOGIC MODULE	AMP HDP	15	562011	------	
C142	LAVATORY DOOR WALL	AMP MNL	2	561248	561247	
C143	LAVATORY DOOR WALL	AMP MNL	3	560908	562006	
C144	UNDER LH SEAT-AISLE LTS	AMP MNL	4	560851	560852	
C145	RR JCT BOX CPT-RR SIDE LTS	AMP MNL	9	561670	561669	
C146	ENGINE CPT-MODULATOR VALVE	AMPHENOL	2	------	560412	
C147	BATT & RR J.B.CPT-DOCK.LTS	PED WP	2	561566	561690	
C148	FR.JCT BOX COMPT. LTS	AMP MNL	2	561248	561247	
C149	CONDENSER CPT-FAN MOTOR	ORDNANCE	3	562555	562001	
C152	CONDENSER CPT-FUEL GAUGE	PED WP	4	561610	561611	
C153	EVAPORATOR CPT-AIR AMB. SENS	AMP MNL	2	561248	561247	
C154	EVAPORATOR CPT-FRESH AIR SENS	ITT SS	2	561813	561812	
C155	EVAPORATOR CPT-WATER VALVE	PED WP	4	561610	561611	
C156	EVAPOR. CPT-BYPASS WATER VAL.	PED WP	2	561566	561690	
C157	EVAPORATOR CPT-WATER PUMP	PED WP	2	561566	561690	
C158	CONDENSER CPT-A/C LO TEMP.	PED WP	2	561566	561690	
C159	CONDENSER CPT-A/C HI TEMP.	PED WP	2	561566	561690	
C160	FR AXLE-ABS RH SENSOR	WABCO	2	641132	------	
C161	FR AXLE-ABS RH VALVE	WABCO	3	------	641098	
C162	FR AXLE-ABS LH VALVE	WABCO	3	------	641098	
C163	FR AXLE-ABS LH SENSOR	WABCO	2	641132	------	
C164	RR AXLE-ABS LH SENSOR	DEUTSCH	2	562486	562485	
C165	RR AXLE-ABS LH VALVE	WABCO	3	------	641098	
C166	RR AXLE-ABS RH VALVE	WABCO	3	------	641098	
C167	RR AXLE-ABS RH SENSOR	DEUTSCH	2	562486	562485	
C168	RR AXLE-ABS OPT ATC	PED WP	4	561610	561611	
C169	RR JCT BOX-SPEED SW	AMP HDP	15	------	562012	
C170	FR JCT BOX-FLASHER UNIT	TC	2	------	561940	
C171	ALARM JCT BOX CPT-LH CONSOLE	AMP CPC	37	561645	561646	
C172	ENGINE COMPT-WATER TANK HEAT.	PED WP	2	561566	561690	
C173	LAV.POTABLE-WATER TANK HEAT.	AMP MNL	2	560900	560898	
C174	UNDER DASH RH-HTR MODULE	AMP MNL	9	561670	561669	
C175	UNDER DASH RH-HTR MODULE	AMP MNL	9	561670	561669	
C176	UNDER DASH RH-WIPER PULSE	AMP FF	6	------	561186	
C177	UNDER DASH RH-WIPER MOTOR	AMP FF	6	------	561186	
C178	UNDER DASH RH-LH FAN	TC	2	561030	560997	
C179	UNDER DASH RH-RH FAN	TC	2	561030	560997	
C181	RR JCT BOX-DIODE CONNECTOR	AMP MNL	15	561987	561986	
C182	RR JCT BOX COMPT.-WT VIW	AMP CPC	16	561639	561640	
C183	FR SERVICE CPT-KNEELING PAN.	PED WP	4	561610	561611	
C184	FR SERVICE CPT-KNEELING SW	ITT SS	3	561111	561080	
C185	RR JCT BOX COMPT.-WT VIM	PED	30	------	561600	PRIOR R021

CONNECTORS CODE (C) Page G : 2

No.	LOCATION	TYPE	(NB) CAVITY	#PIN HOUSING	#SOCKET HOUSING	
C186	RR JCT BOX CPT.-SPEED SIGN.TR	PED WP	2	561566	561690	
C186M	RR JCT BOX CPT.-SPD SIGN. M.TR	PED WP	2	561566	561690	
C186W	RR JCT BOX CPT.-SPD SIGN. WT	PED WP	2	561566	561690	
C187	FR JCT BOX-RPM RESISTOR CON.	AMP MNL	6	561552	561515	
C189	ENGINE CPT RR DOOR B/U LT	PED WP	2	561566	561690	
C190	ENGINE CPT RR DOOR TAIL LT	PED WP	2	561566	561690	
C191	ENGINE CPT RR DOOR RH STOP LT	PED WP	2	561566	561690	
C192	ENGINE CPT RR DOOR RH DIR. LT	PED WP	2	561566	561690	
C193	FR SECT. LH HAT RACK-FLUOR.	AMP MNL	2	561248	561247	
C194	ENGINE CPT RR DOOR LH DIR. LT	PED WP	2	561566	561690	
C195	ENGINE CPT RR DOOR LH STOP LT	PED WP	2	561566	561690	
C196	ENGINE CPT RR DOOR CYCLOP LT	PED WP	2	561566	561690	
C197	ENGINE CPT-A/C COMPRESSOR	PED WP	4	561889	561890	PRIOR R021
C198	ENGINE CPT-A/C COMPRESSOR	PED WP	4	561889	561890	PRIOR R021
C199	ENGINE CPT RR DOOR LICENCE LT	DOM AUTO	2	930210	------	
C200	RH HAT RACK-FLUORESCENT	AMP MNL	4	561551	561668	
C201	RH HAT RACK-FLUORESCENT	AMP MNL	4	561551	561668	
C202	RH HAT RACK-BALLAST	AMP MNL	4	560851	560852	
C203	RH HAT RACK-BALLAST	AMP MNL	6	561552	561515	
C204	RH HAT RACK-GENERAL LT	AMP MNL	3	561667	561550	
C205	FR SECT.-RH HAT RACK SPEAKER	AMP MNL	9	561661	561662	
C206	RH HAT RACK-READING LT	AMP MNL	2	560900	560898	
C207	LH HAT RACK-READING LT	AMP MNL	2	560900	560898	
C208	LH HAT RACK-BALLAST	AMP MNL	4	560851	560852	
C210	FR SECT.-LH HAT RACK SPEAKER	AMP MNL	9	561661	561662	
C211	FR ROOF-STORE LH	AMP MNL	2	560900	560898	
C212	FR ROOF-STORE RH	AMP MNL	2	560900	560898	
C213	FR ROOF-CLEARANCE LT	AMP MNL	2	560900	560898	
C216	UNDER DASH LH-P.A.	AMP MNL	9	561670	561669	
C217	UNDER DASH LH-P.A.	AMP MNL	3	------	561550	
C218	UNDER DASH LH-P.A.	AMP MNL	3	------	561550	
C219	UNDER DASH LH-P.A.	AMP MNL	4	------	561668	
C220	RR.JCT.BOX-FUEL PRIME PUMP	TC	1	561070	561073	
C222	ALARM JCT BOX CPT-MICRO	MOLEX	4	561477	561476	
C223	ALARM JCT BOX CPT-DRIV.SPEAK	AMP MNL	4	561551	561668	
C225	FR SECT. RH HAT RACK-FLUOR.	AMP MNL	2	561248	561247	
C227	RH SW PANEL-SPEAKER	SWF	8	------	561107	
C228	RH SW PANEL-MICRO OUTLET	MOLEX	4	561477	561476	
C229	RH SW PANEL-PA VOLUME	MOLEX	4	561477	561476	
C230	ENG.CPT.-FUEL PRIME PUMP FEED	DEUTSCH	2	562486	562485	
C231	ENG.CPT.-FUEL PRIME PUMP SW.	PED WP	2	561566	561690	
C232	ENG.CPT.-FUEL PRIME PUMP	PED WP	2	561566	561690	
C233	INSTRUMENT PANEL CENTER	V.D.O.	8	------	562043	
C234	INSTRUMENT PANEL CENTER	V.D.O.	4	------	562044	
C235	INSTRUMENT PANEL CENTER	V.D.O.	8	------	562041	
C236	INSTRUMENT PANEL CENTER	AMP MNL	4	560851	560852	
C237	UNDER DASH LH-JACOB CLUTCH SW	ITT SS	3	561111	561080	
C238	A/C JCT BOX-DIODE CONNECTOR	AMP MNL	9	561670	561669	
C239	FR SERVICE CPT-HI BUOY VALVE	PED WP	2	561566	561690	
C240	FR SERVICE CPT-KNEEL PROX SW	PED WP	2	561566	561690	
C241	FR SERVICE CPT-FOG RESISTOR	AMP CPC	3	561847	561862	
C242	FR SERVICE CPT-MARK & DIR LT	ITT SS	3	561111	561080	
C243	FR SERVICE CPT-HEADLAMPS	TC	3	------	561071	
C244	FR SERVICE CPT-LH FOG LAMP	ITT SS	2	561813	561812	
C245	FR SERVICE CPT-RH FOG LAMP	ITT SS	2	561813	561812	
C246	FR SERVICE CPT-MARK & DIR LT	ITT SS	3	561111	561080	
C248	ALARM JCT BOX-WIPER PULSE GEN	AMP FF	6	------	561108	
C249	ALARM JCT BOX-CONV. 12V TO 5V	AMP MNL	3	561667	561550	

No.	LOCATION	(NB) TYPE	#PIN CAVITY	#SOCKET HOUSING	HOUSING
C250	ALARM JCT BOX-DASH LTS REGUL.	AMP MNL	6	561552	561515
C251	LH SW PANEL-FAST IDLE	SWF	8	------	561107
C252	LH SW PANEL-SWITCH LT	SWF	2	------	561837
C253	LH SW PANEL-ETHER	SWF	8	------	561107
C254	INST. PANEL RH-ENTR.DOOR SW.	TORRIX	5	------	562110
C255	LH SW PANEL-JACOB	SWF	8	------	561107
C257	INSTRUMENT PANEL CENT-SPEEDO	AMP MNL	4	560851	560852 PRIOR REV. 018
C257	INSTRUMENT PANEL CENT-TACHO	AMP FF	8	------	562363
C258	LH SW PANEL-MULTI FUNC. SW	AMP FF	8	561188	------
C259	LH SW PANEL-MULTI FUNC. SW	AMP FF	6	------	561108
C260	FR SERVICE CPT-LUG DOOR LCK	PED WP	6	561606	561607
C261	UNDER DASH RH-DOOR MODULE	AMP MNL	9	561670	561669
C262	UNDER DASH RH-DOOR MODULE	AMP MNL	4	561551	561668
C263	UNDER DASH RH-DOOR MODULE	AMP MNL	3	561667	561550
C264	UNDER DASH RH-DOOR MODULE	AMP MNL	3	561667	561550
C265	UNDER DASH RH-DOOR MODULE	AMP HDP-20	15	562011	562012
C267	UNDER DASH RH	AMP CPC	24	561642	561643
C268	UNDER DASH LH-MIRROR	AMP MNL	6	561552	561515
C269	UNDER DASH RH-MIRROR	AMP MNL	6	561552	561515
C270	LH MIRROR POST	MOLEX	6	562070	562069
C271	RH MIRROR POST	MOLEX	6	562070	562069
C272	LH MIRROR	SPARTAN	6	------	990158
C273	RH MIRROR	SPARTAN	6	------	990158
C274	RADIO	AMP MNL	9	561670	561669
C275	UNDER DASH RH-DOOR MODULE	AMP MNL	9	561670	561669
C276	UNDER DASH RH-LOCK SOL.VALVE	AMP MNL	2	561248	561247
C286	RH SW PANEL-A/C & HEAT	SWF	8	------	561107
C287	ENGINE COMPT-LTS SW	PED WP	2	561566	561690
C288	RH SW PANEL-FRESH AIR	SWF	8	------	561107
C289	RH SW PANEL-SWITCH LT	SWF	2	------	561837
C292	LH CONSOLE COMPT-VIDEO SYST.	AMP MNL	4	561671	561668
C293	LH CONSOLE SW-VIDEO SYST.	SWF	8	------	561107
C297	INSTRUMENT PANEL RH -LTS	AMP MNL	2	560900	560898
C299	LH CONSOLE SW-GALLEY	SWF	8	------	561107
C300	INVERTER COMPT.	AMP CPC	16	561639	561640
C301	INSTRUMENT PANEL CENT-TACHO	AMP MNL	4	560851	560852 PRIOR REV. 018
C301	INSTRUMENT PANEL CENT-TACHO	AMP FF	8	------	562363
C303	INVERTER COMPT-GALLEY CTR	AMP MNL	9	561661	561662
C305	GALLEY	AMP CPC	3	561862	561847
C306	GALLEY	AMP MNL	9	561661	561662
C308	LH CONSOLE SW-RHEOSTAT	TC	2	561030	560997
C309	DDEC ENGINE-ECM POWER CON.	PED MP	5	------	562345
C310	LH CONSOLE SW-LUG. DOOR LCK	SWF	8	------	561107
C311	LH CONSOLE SW-HOS & PAS CHIME	SWF	8	------	561107
C312	LH CONSOLE SW-READING LTS	SWF	8	------	561107
C313	LH CONSOLE SW-GEN & FLUOR LTS	SWF	8	------	561107
C314	LH CONSOLE SW-FR DEST. SIGN	SWF	8	------	561107
C315	LH CONSOLE SW-LH STORE	SWF	8	------	561107
C316	LH CONSOLE SPARE SWITCH	SWF	8	------	561107
C317	LH CONSOLE SW-RH STORE	SWF	8	------	561107
C318	LH CONSOLE SW-DRV WINDOW LIFT	SWF	8	------	561107
C320	LH CONSOLE SW-DRIVER'S LTS	SWF	8	------	561107
C322	LH CONSOLE DRV WIND LIFT MOT	PED PO	2	------	561848
C323	LH CONSOLE CRUISE CTR SW PAN.	AMP CPC	9	561636	561637
C324	GALLEY-REFRIGERATOR	AMP MNL	2	561247	561248

No.	LOCATION	(NB) TYPE	#PIN CAVITY	#SOCKET HOUSING	HOUSING
C325	LH CONSOLE SW-KNEELING	SWF	8	------	561107
C326	LH CONSOLE SW-SPARE	SWF	8	------	561107
C327	ENGINE COMPT-RR START SW BOX	DEUTSCH	5	562565	562566 PRIOR R021
C327	ENGINE CONTROL RR START SW	DEUTSCH	6	562583	562581
C328	GALLEY-LAMP	AMP MNL	2	561248	561247
C329	ENGINE TACHO SIGNAL	PED WP	3	561781	561789
C330	GALLEY MICROWAVE SW LT	SWF	2	------	561837
C331	GALLEY MICROWAVE SW	SWF	8	------	561107
C332	GALLEY RH CONTAINER SW LT	SWF	2	------	561837
C333	GALLEY RH CONTAINER SW	SWF	8	------	561107
C334	GALLEY LH CONTAINER SW	SWF	8	------	561107
C335	GALLEY LH CONTAINER SW LT	SWF	2	------	561837
C337	INSTR PANEL LH-UP WIPER SW	SWF	8	------	561107
C338	INSTR PANEL LH-UP DEFROST SW	SWF	8	------	561107
C339	INSTR PANEL LH-UP WASHER SW	SWF	8	------	561107
C340	ALARM JCT. BOX COMP.	AMP MNL	2	560900	560898
C341	INSTR PANEL LH-HEAT MIRROR SW	SWF	8	------	561107
C342	ENGINE RR START SW	DEUTSCH	2	562586	562585
C343	INSTR PANEL LH-HEADLAMP SW	SWF	8	------	561107
C344	INSTR PANEL LH-HAZARD LT SW	SWF	8	------	561107
C345	INSTR PANEL LH-FOG LT SW	SWF	8	------	561107
C346	INSTR PANEL LH-SWITCH LTS	SWF	2	------	561837
C347	INSTR PANEL LH-DASH LT SW	AMP MNL	2	560900	560898
C348	INSTR PANEL CENT-RACOR MODULE	AMP MNL	3	561667	561550
C349	RH CONSOLE-RED LED HTR	AMP MNL	2	561248	561247
C350	RH CONSOLE-THERMOMETER	AMP MNL	3	561667	561550
C351	LH HAT RACK-FLUOR 110V	MOLEX	4	561477	561476
C352	RH CONSOLE-DRV TEMP SENSOR	BURNDY	4	------	561104
C353	INSTR PANEL RH-DRV FAN RHEOST	AMP MNL	6	561552	561515
C354	INSTR PANEL RH-DRV TEMP CTR	AMP MNL	6	561552	561515
C355	INSTR PANEL RH-FR TEMP CTR	AMP MNL	3	561667	561550
C357	INSTR PANEL RH-WATER TEMP GA	AMP MNL	3	561667	561550
C358	INSTR PANEL RH-FUEL LEVEL GA	AMP MNL	3	561667	561550
C359	INSTR PANEL CENT-TAC & SPD LT	AMP MNL	2	560900	560898 PRIOR R.018
C361	FR ROOF-WIPER MOTOR	AMP FF	6	------	561186
C362	FR ROOF-LAVATORY OCCUPIED LT	AMP MNL	2	561248	561247
C363	FR ROOF-WATCH YOUR STEP LT	AMP MNL	2	561248	561247
C364	FR ROOF-DESTINATION SIGN	AMP MNL	3	561667	561550
C365	FR ROOF-UP WINDSHIELD DEFROST	AMP MNL	3	561667	561550
C366	RH CONSOLE-GRN LED	AMP MNL	2	561248	561247
C367	ENGINE COMPT-DIF OIL T SENSOR	PED WP	2	561566	561690
C368	FR ROOF-DEST. SIGN BALLAST	AMP MNL	3	561667	561550
C369	FR ROOF-DEST. SIGN OPER. SW	TORRIX	5	------	562110
C370	FR ROOF-DEST. SIGN FLUOR.	AMP MNL	2	560900	560898
C371	FR ROOF-DEST. SIGN FLUOR.	AMP MNL	2	560900	560898
C372	FR ROOF-DEST. SIGN SPEED SW	MOLEX	4	561477	561476
C374	ALARM JCT BOX COMPT-MASTER SW	AMP MNL	6	561552	561515
C375	ALARM JCT BOX COMPT-LH CONSOL	AMP MNL	6	561552	561515
C376	ALARM JCT BOX COMPT-LH CONS.	AMP CPC	37	561714	562005
C377	LH SW PANEL-STOP ENG.OVERIDE	SWF	8	------	561107
C380	LH CONCOLE-DDR CONNECTOR	DEUTSCH	6	562360	------
C383	ALARM J.B. CPT.-MIC W/O WIRE	DEUTSCH	6	561248	561247
C385	FR.SERV.COMPT-UNDERNEAT(WCL)	AMP MNL	9	561661	561662
C386	LH CONCOLE-WCL POWER SYSTEM	SWF	8	------	561107
C387	RR JCT BOX (WCL)	AMP MNL	9	561661	561662

PREVOST CAR inc.

WIRING DIAGRAM

NO: D060869

P. G/$^{3}_{4}$

REVISION
021

CONNECTORS CODE (C) Page G : 2

		(NB)	#PIN	#SOCKET	
No.	LOCATION	TYPE	CAVITY	HOUSING	HOUSING
C388	RR JCT BOX (WCL)	AMP MNL	12	561735	561734
C389	WCL REAR DOOR	MOLEX	4	561477	561476
C390	LAVATORY WALL-WCL REMOTE CTR	SWF	8	------	561107
C391	LAVATORY WALL-WCL LAMP	SWF	8	------	561107
C392	LAVATORY WALL-WCL SW. LT.	SWF	2	------	561835
C393	LAVATORY WALL-WCL REMOTE SYS.	AMP CPC	4	561686	561687
C394	UNDER INSTR. PANEL- B/U MONITOR	AMP MNL	4	560851	560852
C395	DRIVER'S COMPT. - B/U MONITOR	AMP	5	------	------
C396	FR SECT. LH HAT RACK AMPLI	MOLEX	8	------	562465
C397	ENGINE COMPT. CRADLE ACC.	DEUTSCH	40	562281	562284
C398	FR SECT. LH HAT RACK AMPLI	MOLEX	6	------	562464
C399	FR SECT. LH HAT RACK AMPLI	MOLEX	8	------	562465
C400	ENGINE COMPT. BLOCK HEATER	PED MP	3	561781	561782
C401	FR SECT. LH HAT RACK AMPLI	MOLEX	6	------	562464
C402	RR DRIVE AXLE-AIR DRYER	PED MP	2	------	562251
C403	GALLEY FRIGO NORCOLD	AMP MNL	2	561248	561247
C406	FR JCT BOX COMPT.-ANTI-SKID	AMP MNL	2	560900	560898
C407	ENGINE COMPT. -SIGNAL	PED WP	6	561606	561607
C408	ENGINE COMPT. -SIGNAL	PED WP	6	561606	561607
C409	ENGINE CPT -LOW COOL. LEVEL	PED MP	2	------	562350
C410	FR JCT BOX-DIODE CONNECTOR	AMP MNL	15	561987	561986
C411	FR JCT BOX-DIODE CONNECTOR	AMP MNL	15	561987	561986
C412	LH SW PANEL-MASTER SWITCH	SWF	8	------	561107
C413	ENG CPT-A/C HI UNLOAD PRS SW	PED WP	2	561566	561690
C414	RR JCT BOX	AMP MNL	9	561670	561669
C415	ENGINE CRADLE-FAN SIGNAL	PED WP	3	561781	561782
C416	ENGINE CRADLE-FAN SIGNAL	PED P-C	3	562237	------
C417	FRONT JCT BOX-DIODES	AMP MNL	15	561987	561986
C418	INSTR. PANEL LH-HTR WINDSH.SW	SWF	8	------	561107
C419	FR JCT BOX-RETARDER OR JACOB	AMP MNL	3	561667	561550
C420	ENGINE COMPT. WEBASTO WATER HTR	TC	2	561597	------
C421	ENGINE COMPT. WEBASTO WATER HTR	TC	1	561073	------
C422	ENGINE COMPT. WEBASTO WATER HTR	TC	2	561597	------
C424	UNDER INSTRUMENT PANEL CENTER	AMP MNL	3	561667	561550
C425	ALARM JCT BOX-DIODES	AMP MNL	15	561987	561986
C426	ENGINE COMPT. CLUTCH CTR FAN	PED MP	3	561781	561782
C429	ALARM JCT BOX COMPT.	AMP MNL	6	561552	561515
C430	ALARM JCT BOX COMPT-TIMER	AMP FF	8	561188	562363
C431	ALARM JCT. BOX COMPT. PRE HEAT.	TAB AMP	1	561540	561539
C432	ENGINE CPT.-PROX. SW. DOOR AJAR	DEUTSCH	4	562479	562477
C433	FR SERVICE CPT. KNEEL. PRESS. SW	PED WP	2	561566	561690
C434	FRONT JCT. BOX-DIODES	AMP MNL	15	561987	561986
C435	FR SERVICE CPT.(RH) KNEEL. PIEZO	AMP MNL	2	560900	560898
C436	RH HAT RACK-WCL CENTER ROOF ACC	AMP CPC	16	561639	561640
C437	RH HAT RACK-WCL FR & RR SECT.	AMP CPC	24	561642	561643
C450	SOUND SYS. JCT. PANEL	MOLEX	4	562507	562503
C451	WIRELESS MICRO-FIRST CPT BAG	MOLEX	2	562550	562549
C452	UNDER DASH INSTR. PANEL	MOLEX	2	562550	562549
C453	SOUND SYS. JCT.PANEL-VCP	PED WP	2	561566	561590
C454	SOUND SYS.JCT.PAN.-FILT. VCP	PED WP	2	561566	561590
C455	WIRELESS MICRO-LH HAT-RACK	CINCH	2	562554	562551
C456	WORLD TRANSM.-RETARDER ACCUM.	PED MP	2	------	562427
C457	WORLD TRANSM.-MAIN CONNECTOR	DEUTSCH	31	562572	562536
C458	WORLD TRANSM.-TURBINE SP.SENS	PED MP	2	------	562426
C459	WORLD TRANSM.-ENGINE SP.SENS.	PED MP	2	------	562426
C460	WORLD TRANSM.-SPEED SENSOR	ITT	2	------	562541
C461	WORLD TRANSM.-RETARDER TEMP.	PED MP	2	561566	561590

CONNECTORS CODE (C) Page G : 2

		(NB)	#PIN	#SOCKET	
No.	LOCATION	TYPE	CAVITY	HOUSING	HOUSING
C462	WORLD TRANSM.-RETARD SOL."K"	PED MP	2	------	562426
C463	WORLD TRANSM.-SENSOR CONN.	DEUTSCH	16	562570	562571
C464	RR JCT BOX-DDL CONN W.T.	PED MP	12	------	562574
C465	LH CONSOLE-SHIFTER SELECTOR	T & BET	10	------	562429
C466	FR SERVICE CPT.-RESIS. MOD.	PED WP	3	------	562428
C467	FR SERVICE CPT.-RESIS. MOD.	PED WP	3	------	562428
C468	RR JCT BOX-VIM MOD. W.T.	PED MP	18	------	562573
C470	FR SERVICE CPT.-SILENT 1000	AMP MNL	2	561248	561247
C471	FR SERVICE CPT.-SILENT 1000	AMP MNL	2	561248	561247
C472	FR SERVICE CPT.-SILENT 1000	PED WP	2	561566	561690
C473	FR SERVICE CPT.-SILENT 1000	AMP MNL	3	561667	561550
C474	LUGGAGE CPT.-TEMP. SENSOR	AMP MNL	2	561247	561248
C475	RR JCT BOX-SPEED SIGN CONNECTOR	AMP MNL	2	561248	561247
C475	RR JCT BOX-SPEED SIGN CONNECTOR	MOLEX	6	562070	562069
C475M	RR JCT BOX-SPEED SIGN MANUAL TR.	MOLEX	6	562070	562069
C475W	RR JCT BOX-SPEED SIGN WORLD TR.	MOLEX	6	562070	562069
C476	RR JCT BOX-VIM WORLD TRANSM.	AMP CPC	16	561639	561640
C477	RR JCT BOX-WORLD TR. SHIFT.&RET.	AMP CPC	9	561636	561637
C478	ELECTRONIC DESTINATION SIGN	AMP CPC	9	561636	561637
C500	ALARM JCT BOX CPT-PRODRIVER	MOLEX	6	562070	562069
C501	LH CONSOLE-PRODRIVER MODULE	PED MP	7	562433	------
C502	LH CONSOLE-PRE HEATER SW.	SWF	8	------	561107
C503	LH CONSOLE-PRE HEATER SW.	SWF	2	------	561837
C504	ALARM JCT. BOX COMPT.WEB.TIMER	AMP	8	561188	562363
C505	ALARM JCT. BOX COMPT.ESPAR TIMER	AMP	3	------	562034
C506	ALARM JCT BOX CPT. DIGITAL CLOCK	AMP	4	561685	561687
C507	FR SECT. LH HAT-RACK DIG. CLOCK	MOLEX	4	561477	561476
C508	RR JCT BOX-FAN CLUTCH RETARDER	AMP MNL	6	561552	561515
C509	ALARM JCT BOX-DATA LOGGER	PED MP	16	------	562530
C510	ALARM JCT BOX-DATA LOGGER	DEUTSCH	9	562531	------
C511	ALARM JCT BOX-DATA LOGGER	PED MP	4	562532	------
C512	ALARM JCT BOX-DATA LOGGER	PED MP	10	562533	------
C513	ALARM JCT BOX-DATA LOGGER	AMP MNL	3	561667	561550
C514	ALARM JCT BOX-DATA LOGGER	PED MP	6	562433	562417
CA	RR JCT BOX-ECU WORLD TR.	T & BET	34	------	562419
CB	RR JCT BOX-ECU WORLD TR.	T & BET	34	------	562420
FB1	RR JCT BOX-WORLD TR. FUSE BLOCK	PED	8	------	562610

PREVOST CAR inc.	WIRING DIAGRAM	NO: D060869	P. G 4/4	REVISION 021