RELAYS LIST

No	Location	Part #	Function	Page					
R1	RJB	562364	24vIgn&AccRelay	3.1					
R3	RJB	563348	12vIgn&AccRelay	3.1					
R10	Evap.Cmpt.	563348	CondensorRelay1stSpeed	18.2					
R11	RJBVECR	563332	24V_Ign	5.1					
R12	Evap.Cmpt.	563348	EvaporatorRelay	18.2					
R17	FJB	564218	12vRrWup	3.3					
R18	FJB	564218	24vFrWUpRelay	3.3					
R19	FJB	564218	12vFrWUpRelay	3.3					
R21	RJB	563269	EmergencyCutoutRelay	3.2					
R22	FJB	563269	12_WakeUp_To_CPC	3.3					
R23	RHConsole	563332	LowerWiperRelay	31.1					
R25	RJBVECR	563332	EcmIgn	5.1					
R29	RJB	563348	Preheater_Volvo	14.2					
R30	RJB	563332	Luggage_Door_LockUnlock	24.2					
R31	RJB	563332	Luggage_Door_LockUnlock	24.2					
R32	RJB	563332	Luggage_Door_LockUnlock	24.2					
R33	RJB	563332	Luggage_Door_LockUnlock	24.2					
R34	FJB	564218	12v_Rr_Engine_Ecu	3.3					
R41	FJB	563332	SunVisor_Relay	32.1					
R42	FJB	563332	SunVisor_Relay	32.1					
R43	FJB	563332	SunVisor_Relay	32.1					
R_Starter	RJB	564095	Starter_Relay	3.2					
RLock	Front	563332	Keyless	29.1					
RSo1	Slide_Out_Jct_Box	563445	SlideOut_Relay	20.1					
RSo2	Slide_Out_Jct_Box	563445	SlideOut_Relay	20.1					
RSo3	Slide_Out_Jct_Box	563445	SlideOut_Relay	20.1					
RSo4	Slide_Out_Jct_Box	563445	SlideOut_Relay	20.1					
RUnlock	Front	563332	Keyless	29.1					