C571
1 0-0CS-18 MASTER SW. ON SIGNAL TO PAGE 1.1
2 24-86T-18 STARTER SIGNAL FROM P. 4.1 OR 4.2
3 NOT USED
4 0-93-20 BATTERY LO/HI SIGNAL TO PAGE 4.1
5 24-25A-18 DELCO ALT. SIGNAL FROM R33(87) P. 4.1
BOSCH ALT. SIGNAL FROM RA1(87) P. 4.2
6 24-28T-18 LO A/C PRESS SIGNAL FROM PAGE 15.2 OR 15.3
7 24-28H-18 HI A/C PRESS SIGNAL FROM PAGE 15.2 OR 15.3
8 0-540-20 SIGNAL CRUISE ENABLE TO PAGE 5.1
10 0-85Z-18 TO TRAILER ABS SIGNAL PAGE 22.1
11 0-115W-18 CHECK TRANSM. SIGNAL TO PAGE 6.1
12 0-123B-18 FIRE ALARM SIGNAL TO PAGE 7.2
13 0-105W-18 TRANSMISSION HOT OIL SIGNAL TO PAGE 21.1
14 OPT. 4
15 24-25K-18 NOT GEN. (2) SIGNAL FROM PAGE 4.2 (NOT USED)
16 0-92-18 BATTERY MONITOR BALANCE SIGNAL TO PAGE 4.1
17 0-76C-18 LO FUEL SIGNAL TO PAGE 7.1
18 12-197A-18 FUEL WATER FILTER SIGNAL FROM PAGE 8.1
19 24-126F-18 LEVEL-LOW SIGNAL FROM PAGE 18.1
20 12-23-18 RH FLASHER SIGNAL FROM PAGE 9.2

C572
1 NOT USED
2 NOT USED
3 24-SO-18 OPTION : SLIDE OUT INPUT SIGNAL
4 0-170C-18 LUGGAGE DOOR UNLOCK SIGNAL TO PAGE 12.1
5 OPT.1
6 0-85Y-18 TO ABS SIGNAL TO PAGE 22.1
7 0-45W-20 A/C DOOR AJAR SIGNAL TO PAGE 11.1
8 0-419-18 CHECK ENGINE SIGNAL TO PAGE 5.1
9 24-82-18 STOP LTS. SIGNAL FROM PAGE 9.3
10 12-21-18 LH FLASHER SIGNAL FROM PAGE 9.2
11 NOT USED
12 0-10R-20 LUGGAGE DOOR AJAR SIGNAL TO PAGE 11.1
13 12-98-20 ENGINE DOOR AJAR SIGNAL FROM PAGE 11.1
14 0-181-20 OUTSIDE FREESE POINT SIGNAL TO P. 15.1 OR 15.4
15 0-160-16 TAG AXLE SIGNAL TO PAGE 7.2
16 24-91B-16 PARKING BRAKE SIGNAL FROM PAGE 8.1
17 0-509-18 STOP ENGINE SIGNAL TO PAGE 5.1
18 24-55-16 HI BEAM SIGNAL FROM PAGE 9.2

C571 1 2 3 4 5 6 7 8 10 11 12 13 14 15 16 17 18 19 20
C572 1 2 3 4 5 6 7 8 9 10 11 12 13 14 15 16 17 18
•2 •2 •2 •2 •2 •2 •2 •2 •2 •2 •2 •2 •2 •2 •2 •2 •2 •1 •2 •2 •2 •2 •2 •2 •2 •2 •1 •2 •2
12V PWR 12V IGN 12V IGN 12V PWR 12V IGN 12V IGN 12V IGN 12V IGN
12V IGN 12V IGN 12V IGN 12V IGN 12V IGN 12V IGN

EXT. TEMP DISPLAY
ENABLE CLK DATA GND
C573 8 7 6 5 4 3 2 1

•1 • 12V PWR MUST BE TURNED ON
•2 • 12V IGN MUST BE TURNED ON

POWER SUPPLY
SIGNAL_GND TEST IN CHS GRD 12V IGN 12V PWR

NOR
PIEZO PARK BRAKE NOT APPLY

C570 1 2 3 4 5 6

180-20
180A-20 OUTSIDE TEMPERATURE SIGNAL
180B-20 FROM HVAC DASH MODULE
180C-20 C540 SEE P 15.1 OR 15.3

FBG FS
0-00A-18 0-RT-18 0-0T1-18
C548 12B 3 7 9
REMOTE TEST SW.

0-00A-18 FBG
0-0T2-18 FS
12-12H-18

12-12DT-18 TO LED INSIDE SWITCH
SEE P. 1.1,5.1,9.3,11.2,16.1,16.2,16.3,24SP1

C71 12
CB130
12-12DT-18 6A 12-12D-14 12V HOT WIRE FROM FJB
SEE PAGE 2.1

12-12H-18 12V IGNITION FROM CB28
SEE PAGE 7.1

12-114A-18 FROM DASH LTS RHEOSTAT SEE P 11.2

TELL TALE LIGHTS MODULE