ENTRANCE DOOR OPEN SIGNAL FROM DOOR RELAY MODULE RLT(30) SEE P.16

24VI 5 MPH NC SIGNAL FROM RR. JCT. BOX SPEED CON. C475 (5) SEE P. 15.1

FROM DASH LTS RHEOST. SEE P 11.2

24V POWER FROM FR.JCT.BOX SEE P.1.1

WCL DOOR AJAR SIGNAL FROM RR JCT BOX RLY R97(87) SEE P. 25.1

TO RH FR. SIDE DIRECT. LT R37 (86) SEE P.10.1

24V HOT WIRE POWER FROM FR. JCT BOX CB85 SEE P. 22.1

TO KNEELING T.T.L.T. MODULE C516 (11) SEE P. 28.1

KNEEL. WARN. AUDIBLE

PIEZO

F33 5A

RKD

R43

R44

D15

D21

D16

D58

D70

D77

D73

D72

D71

D82

D81

PRESS.SW 15-30

EXHAUST SOL.VAL.

PARK.BRAKE SOL.VAL.

BELLOWS CTR.SOL.VAL.

REAR HIGH BUOY SOL. VALVE

LOW BUOY CONTROL VALVE

KNEELING SW.

DW

UP

N.O. PROXIMITY SWITCH
OPENED·NORMAL
CLOSED· DOWN

KNEELING OPERATE WHEN THE ENTRANCE DOOR IS CLOSE | HI BUOY | LOW BUOY

PREVOST	WIRING DIAGRAM	NO: D060902	PAGE: 18.1 sp1	REVISION 08