CIRCUIT NUMBER CODE Page E : 1

No.	SYSTEM
0	IC - INVERTER CPT GRD
0	GALLEY GRD
0	BC - BAT. CPT GRD
0	CONDENSER CPT GRD
0	A/C - A/C JCT BOX GRD
0	GALLEY GRD
0	FJB - FR JCT BOX GRD
0	GALLEY GRD
0	VIDEO GRD
0A	A/C - A/C JCT BOX GRD
0A	FRS - FR ROOF ACCES. GRD
0A	RS - LUG. CPT ACCES. GRD
0A	AJB - ALARM JCT BOX GRD
0A	FJB - FR JCT BOX GRD
0AA	RS - VOLTAGE REGULATOR GRD
0B	EC - ENGINE GRD
0B	FRS - FR ROOF HEAT WIND GRD
0B	FS - FR ROOF ACCES. GRD
0B	RS - LUG. CPT ACCES. GRD
0B	A/C - A/C JCT BOX GRD
0B	FJB - FR JCT BOX GRD
0BE	RJB - BAT. EQUAL. BAT GRD
0C	EC - STARTER MOTOR GRD
0C	BAT. EQUALIZER GRD
0C	FS - SERV. CPT ACCES. GRD
0C	RS - ENGINE ACCES. GRD
0C	RJB - SPEED SW. BATT. GRD
0CR	24V DISC. SW. RLY GRD SIGNAL
0CS	24V DISC. SW. RLY GRD SIGNAL
0D	FS - SERV. CPT ACCES. GRD
0D	RS - HAT RACK ACCES. LH GRD
0DF	RS - RR SIDE FLASH & MARK GRD
0E	FS - FR LAMPS GRD
0E	RS - HAT RACK ACCES. LH GRD
0E2	FRS - HEAD & CORNERING LTS GRD
0EE	FRS - HEAD & CORNERING LTS GRD
0F	RS - HAT RACK ACCES. RH GRD
0G	RS - HAT RACK ACCES. RH GRD
0G	FS - INSTR. PANEL LH GRD
0H	FS - INSTR. PANEL CENT GRD
0H	RS - LAVATORY ACCES. GRD
0I	FS - INSTR. PANEL RH GRD
0J	FS - SW CONSOLE LH GRD
0J	RS - RR ROOF ACCES. GRD
0K	RS - RR ROOF ACCES. GRD
0L	RS - ENGINE CPT ACCES. GRD
0L	FS - UNDER DASH RH GRD
0LA	ENTRANCE DOOR (SEDAN) GRD
0LH	RS - RR END LAMPS LH GRD
0M	RS - ENGINE CPT ACCES. GRD
0M	FS - UNDER DASH RH GRD
0MR	24V DISC. SW. RLY GRD SIGNAL
0MS	24V DISC. SW. RLY GRD SIGNAL
0N	FS - UNDER DASH RH GRD
0N	RS - ENGINE CPT ACCES. GRD
0P	FS - ALARM JCT BOX GRD
0P	RS - ENGINE CPT ACCES. GRD
0R	FS - UNDER DASH LH GRD
0R	RS - ENGINE CPT ACCES. GRD
0R	FS - SOUND SYS. JCT PANEL GRD
0RE	RADIO &CTRL HEAD CHASSIS GRD

No.	SYSTEM
0RH	RS - RR END LAMPS RH GRD
0S2	SOUND SYSTEM RADIO GRD
0S3	SOUND SYSTEM VIDEO GRD
0SS	SOUNS SYSTEM BATT. GRD
00SS	SOUND SYSTEM BATT. GRD
0T	FS - LUG. CPT ACCES. GRD
0V	RR JCT BOX CPT GRD STUD
0V	FS - FR JCT BOX CPT GRD STUD
0VA	BATTERY TO EQUALISER 0V
0W	FS - UNDER DASH CENT GRD
0W	RS - RR JCT BOX GRD
0W	FS - FR JCT BOX CPT GRD STUD
0WC	RS - RR JCT BOX GRD (WCL)
0X	FS - TO LH CONS. C483 NOT USED
0X	FR JCT BOX CPT GRD STUD
0X	RS - RR JCT BOX GRD
0X2	FR JCT BOX CPT GRD STUD
0Y	RR JCT BOX GRD
0Y	FR JCT BOX CPT GRD STUD
0Y	ABS FR JCT BOX CPT GRD STUD
0Y1	ABS FR JCT BOX CPT GRD STUD
0Z	FR JCT BOX CPT GRD STUD
0Z	RR JCT BOX CPT GRD STUD
00	RR JCT BOX CPT BATT. GRD
1	TACHO SYSTEM
2B	A/C & HEAT SYSTEM-COOL 1 SIGN
2C	A/C & HEAT SYSTEM-LO PRESS SW
2D	A/C & HEAT SYSTEM-LO PRESS TT LT
4	HOSTESS & PASSENGER CHIME
4A	HOSTESS & PASSENGER CHIME
4B	PASSENGER CHIME
4C	HOSTESS CHIME
5	INTERIOR LTS-AISLE & EMERG. EXIT
5	UPPER WINDSHIELD DEFROSTER
5D	UPPER WINDSHIELD DEFROSTER
5E	UPPER WINDSHIELD DEFROSTER
5N	INTERIOR LTS-EMERGENCY EXIT
6	INTERIOR LTS-AISLE
7A	SPEED SW 5 MPH N/O
7B	ENTRANCE DOOR (SEDAN)
7C	ENTRANCE DOOR (SEDAN)
7D	ENTRANCE DOOR (SEDAN)
7DA	ENTRANCE DOOR (SEDAN)
7DB	ENTRANCE DOOR (SEDAN)
8	TACHOMETER GRD SHIELD
9	INTERIOR LTS-ENGINE CPT
9A	INTERIOR LTS-ENGINE CPT
9B	ENGINE DOOR AJAR T.T.LT.
9E	INTERIOR LTS-FR SERVICE CPT
9F	INTERIOR LTS-FR SERVICE CPT
10	INTERIOR LTS-LUGGAGE CPT
10A	INTERIOR LTS-LUGGAGE CPT
10B	INTERIOR LTS-LUGGAGE CPT
10D	INTERIOR LTS-LUGGAGE CPT
10F	INTERIOR LTS-LUGGAGE CPT
10H	INTERIOR LTS-LUGGAGE CPT
10K	INTERIOR LTS-LUGGAGE CPT
10R	INTERIOR LTS-LUGGAGE DOOR AJAR
11	FR DESTINATION SIGN
11A	FR DESTINATION SIGN
11B	FR DESTINATION SIGN

CIRCUIT NUMBER CODE Page E : 1

No.	SYSTEM
11C	FR DESTINATION SIGN
11D	FR DESTINATION SIGN
11E	FR DESTINATION SIGN
11K	FR DESTINATION SIGN
12	BAT CPT 12V BATTERY
12	FR JCT BOX 12V DISC SW
12	12V BAT CPT JCT BLOCK
12A	FR JCT BOX 12V DISC SW
12A	RR JCT BOX 12V DISC SW
12B	FR JCT BOX 12V DISC SW
12B	12V BAT CPT JCT BLOCK
12BE	BAT. EQUALIZER MONITOR
12C	FR JCT BOX 12V DISC SW
12D	BAT CPT 12V BATTERY
12E	FR JCT BOX 12V DISC SW
12E	RR JCT BOX 12V DISC SW
12F	FR JCT BOX 12V DISC SW
12F	RR JCT BOX 12V DISC SW
12F	BAT CPT 12V FJB & IC
12I	RR JCT BOX 12V IGNITION
12I	12V IGNITION DISTRIBUTION
12IA	FR JCT BOX 12V IGNITION
12IA	12V IGNITION DISTRIBUTION
12IB	FR JCT BOX 12V IGNITION
12IF	FR JCT BOX 12V IGNITION
12P	INVERTER CPT 12V DISC SW
12PV	INVERTER CPT 12V DISC SW
12R	BAT CPT 12V DISC RLY TO RJB
12R	MEMORY BATTERY RADIO
12S	SOUND SYSTEM 12V RADIO
12S1	SOUND SYSTEM 12V RADIO
12S2	SOUND SYSTEM 12V RADIO
12SB	SOUND SYSTEM 12V FEEDING
12SS	SOUND SYSTEM 12V FEEDING
12VA	BATTERY TO EQUALIZER 12V
12VD	12V HOT WIRE DISTRIBUTION
12VF	BAT CPT 12V FJB & IC
12VG	INVERTER CPT 12V DISC SW
12VI	12V IGNITION DISTRIBUTION
12VR	BAT CPT 12V DISC RLY TO RJB
12W	12V BATTERY DDEC III
12WA	ENTRANCE DOOR (SEDAN)
12X	FR JCT BOX 12V DISC SW
12X2	FR JCT BOX 12V DISC SW
12Y	FR JCT BOX 12V DISC SW
13A	ALARM & SIGNAL-LO AIR PRIM.
13B	ALARM & SIGNAL-LO AIR SEC.
14	LAVATORY-FLUSHING PUMP
14A	LAVATORY-FLUSHING PUMP
15	EXTERIOR LTS-MULTI FUNC LEVEL
15A	WIPER & WASHER UPPER WINDSHIELD
16	SPEEDO - SIGN
16S	SPEEDO - TRANSMITTER
16T	SPEEDO - TRANSMITTER
17	EXTERIOR LTS-FLASHER UNIT
17A	EXTERIOR LTS-FLASHER UNIT
19	DIFFERENTIAL OIL TEMP
20	SPEEDO - NEGATIVE SIGN
20T	SPEEDO - NEGATIVE SIGN
21	EXTERIOR LTS-DIRECTIONNAL LH
21A	EXTERIOR LTS-DIRECTIONNAL LH

No.	SYSTEM
21B	EXTERIOR LTS-HAZARD
21C	EXTERIOR LTS-CORNERING LH
21H	EXTERIOR LTS-DIRECTIONNAL LH
21K	EXTERIOR LTS-CORNERING
21N	EXTERIOR LTS-CORNERING LH
21P	EXTERIOR LTS-CORNERING LH
23	EXTERIOR LTS-DIRECTIONNAL RH
23	EXTERIOR LTS-DIRECTIONNAL RH
23A	EXTERIOR LTS-DIRECTIONNAL RH
23B	EXTERIOR LTS-DIRECTIONNAL RH
23C	EXTERIOR LTS-CORNERING RH
23N	EXTERIOR LTS-CORNERING RH
23P	EXTERIOR LTS-CORNERING RH
24	BAT CPT 24V BATTERY
24	FR JCT BOX 24V DISC SW
24A	BOOSTER BLOCK 24V DISC SW
24A	RR JCT BOX 24V DISC SW
24A	FR JCT BOX 24V DISC SW
24B	RR JCT BOX 24V DISC SW
24B	FR JCT BOX 24V DISC SW
24B	24V STARTER RLY FEEDING
24BE	RJB CPT-BAT EQ MONITOR HOT WIRE
24C	FR JCT BOX 24V DISC SW
24D	BAT CPT 24V HOT WIRE
24D	FR JCT BOX 24V HOT WIRE
24D	RR JCT BOX 24V HOT WIRE
24DP	A/C JCT BOX 24V HOT WIRE
24E	BAT CPT 24V DISC SW
24E	FR JCT BOX 24V DISC SW
24E	RR JCT BOX 24V DISC SW
24F	FR JCT BOX 24V DISC SW
24F	RR JCT BOX 24V DISC SW
24G	FR JCT BOX 24V DISC SW
24G	RR JCT BOX 24V DISC SW
24H	FR JCT BOX 24V DISC SW
24H	RR JCT BOX 24V DISC SW
24I	FR JCT BOX 24V IGNITION
24I	RR JCT BOX 24V IGNITION
24IA	FR JCT BOX 24V IGNITION
24IA	RR JCT BOX 24V IGNITION
24IB	FR JCT BOX 24V IGNITION
24IB	RR JCT BOX 24V IGNITION
24IC	FR JCT BOX 24V IGNITION
24ID	FR JCT BOX 24V IGNITION
24IF	FR JCT BOX 24V IGNITION
24J	FR JCT BOX 24V DISC SW
24K	FR JCT BOX 24V DISC SW
24P	FR JCT BOX 24V DISC SW
24PV	INVERTER CPT 24V DISC SW
24S	24V DISC SW RLY SIGNAL
24S1	SOUND SYSTEM 24V AMPLIFIER
24S2	SOUND SYSTEM 24V AMPLIFIER
24S3	SOUND SYSTEM 24V VIDEO
24S4	SOUND SYSTEM 24V VIDEO
24SB	SOUND SYSTEM 24V FEEDING
24SS	SOUND SYSTEM 24V FEEDING
24T	RR JCT BOX 24V DISC SW
24V2	RR JCT BOX 24V DISC SW
24V3	RR JCT BOX 24V DISC SW
24V4	RR JCT BOX 24V DISC SW
24V5	RR JCT BOX 24V DISC SW

PREVOST CAR inc.	WIRING DIAGRAM	NO: D060869	P.E / 1/4	REVISION 014

CIRCUIT NUMBER CODE Page E : 2

No.	SYSTEM	No.	SYSTEM
24VD	24V HOT WIRE DISTRIBUTION	45D	A/C & HEAT SYSTEM-WATER VALVE
24VF	BAT CPT 24V SW TO FJB & IC	45E	A/C & HEAT SYSTEM-HEAT 1 SIGN
24VF	INVERTER CPT 24V DISC SW	45G	A/C & HEAT SYSTEM-DRIVER'S HTR
24VA	BATTERY TO EQUALIZER 24V	45H	A/C & HEAT SYSTEM-DRIVER'S HTR
24VI	RR JCT BOX 24V IGNITION	45W	A/C & HEAT SYSTEM-DRIVER'S HTR
24VR	BAT CPT 24V DISC SW TO RJB	46	EXTERIOR LTS-MARKER
24W	RR JCT BOX 24V DISC SW (WCL)	46A	EXTERIOR LTS-MARKER
24WC	BATT. CPT TO HYD. PUMP (WCL)	46B	EXTERIOR LTS-MARKER
24WL	24V BATTERY-HYD.PUMP (WCL)	46B	EXTERIOR LTS-MARKER
24X	FR JCT BOX 24V DISC SW	46C	EXTERIOR LTS-MARKER
24X2	FR JCT BOX 24V DISC SW	47	A/C & HEAT SYSTEM-DRIVER'S HTR
24Y	FR JCT BOX 24V DISC SW	48	ENTRANCE DOOR (SEDAN)
24Y2	FR JCT BOX 24V DISC SW	48A	ENTRANCE DOOR (SEDAN)
25	12VAC GEN RLY ON SIGNAL	48B	ENTRANCE DOOR (SEDAN)
25A	NOT GENERATOR-WARNING LT	48C	ENTRANCE DOOR (SEDAN)
25B	EXTERIOR LTS-DAYTIME RUN LTS	48D	ENTRANCE DOOR (SEDAN)
26	DRIVER'S WINDOW LIFTER	49	ENTRANCE DOOR (SEDAN)
26	CIGAR LIGHTER	49A	ENTRANCE DOOR (SEDAN)
26B	DRIVER'S WINDOW LIFTER	49B	ENTRANCE DOOR (SEDAN)
26C	DRIVER'S WINDOW LIFTER	50	AIR DRYER
27	LAVATORY-EMERGENCY SONALERT	52	ALARM & SIGNAL-ELEC. HORN
28A	A/C & HEAT SYSTEM-HI PRESSURE	52A	ALARM & SIGNAL-ELEC. HORN
29	A/C & HEAT SYSTEM-DRIVER'S HTR	53	ALARM & SIGNAL-ELEC. HORN
29A	A/C & HEAT SYSTEM-DRIVER'S HTR	53A	WIPER & WASHER SYSTEM
29B	A/C & HEAT SYSTEM-DRIVER'S HTR	53B	WIPER & WASHER SYSTEM
30A	GALLEY	53C	WIPER & WASHER SYSTEM
31A	A/C & HEAT SYSTEM-UNLOADER	53E	WIPER & WASHER SYSTEM
31B	A/C & HEAT SYSTEM-UNLOADER	53J	WIPER & WASHER SYSTEM
31B	WIPER & WASHER SYSTEM	55	EXTERIOR LTS-HI BEAM
31C	WIPER & WASHER SYSTEM	57	EXTERIOR LTS-HI BEAM
31D	WIPER & WASHER SYSTEM	57A	EXTERIOR LTS-HI BEAM
31E	WIPER & WASHER SYSTEM	57A	A/C & HEAT SYSTEM-WATER PUMP
31J	WIPER & WASHER SYSTEM	57B	A/C & HEAT SYSTEM-WATER PUMP
31X	WIPER & WASHER SYSTEM	57C	PRE-HEAT WATER HEATER
32	EXTERIOR LTS-BACK-UP	57E	EXTERIOR LTS-HEAD LTS
32B	EXTERIOR LTS-BACK-UP	58	EXTERIOR LTS-LO BEAM
32C	BACK-UP PWR & SIGNAL	58A	EXTERIOR LTS-LO BEAM
32D	BACK-UP ALARM	58B	EXTERIOR LTS-LO BEAM
32F	BACK-UP MONITOR	58E	EXTERIOR LTS-LO BEAM
35	ENTRANCE DOOR (SEDAN)	59A	JACOB BRAKE SYSTEM
35B	ENTRANCE DOOR (SEDAN)	61	EXTERIOR LTS-24V FEED SW
35BB	ENTRANCE DOOR (SEDAN)	61A	EXTERIOR LTS-HEAD SIGNAL
35D	ENTRANCE DOOR (SEDAN)	62	LAVATORY-OCCUPIED LT
36	JACOB BRAKE SYSREM	62A	LAVATORY-FLUOR LT
36A	JACOB BRAKE SYSREM	62B	LAVATORY-FLUOR LT
38	INTERIOR LTS-24V FLUORESCENT	62E	LAVATORY-OCCUP & FLUOR LT
38A	INTERIOR LTS-24V FLUORESCENT	63	EXTERIOR LTS-CLEARANCE
38C	INTERIOR LTS-24V FLUORESCENT	63A	EXTERIOR LTS-CLEARANCE
38D	INTERIOR LTS-24V FLUORESCENT	63B	EXTERIOR LTS-CLEARANCE
39	INTERIOR LTS-24V LH CONSOLE SW	63C	EXTERIOR LTS-MARKER SIGNAL
39A	INTERIOR LTS-DRIVER"S LTS	63D	EXTERIOR LTS-MARKER & TAIL
41	A/C & HEAT SYSTEM-COND FAN MOT	63E	EXTERIOR LTS-CLEARANCE
41A	A/C & HEAT SYSTEM-COND FAN MOT	63F	EXTERIOR LTS-MARKER BLINKER
41B	A/C & HEAT SYSTEM-COND FAN MOT	63H	EXTERIOR LTS-TAIL
42	A/C & HEAT SYSTEM-COND FAN MOT	67	A/C & HEAT SYSTEM
42A	A/C & HEAT SYSTEM-COND FAN MOT	67A	A/C & HEAT SYSTEM
44	EXTERIOR LTS-FOG	67B	A/C & HEAT SYSTEM
44A	EXTERIOR LTS-FOG	67C	A/C & HEAT SYSTEM & HEAT WINDS.
44B	EXTERIOR LTS-FOG	67K	A/C & HEAT SYSTEM-COND FAN CTR
44C	EXTERIOR LTS-FOG & HAZARD	67L	A/C & HEAT SYSTEM-COND FAN CTR
45B	A/C & HEAT SYSTEM-HEAT 3 SIGN	67V	A/C & HEAT SYSTEM-WATER VALVE

CIRCUIT NUMBER CODE Page E : 2

No.	SYSTEM	No.	SYSTEM
70	INTERIOR LTS-HAT RACK & RR RUN.	91A	DDEC-FAST IDLE SIGNAL
71	EXTERIOR LTS-DOCKING	91W	PARK. BRAKE SW. SIGN. (WCL)
71C	DOCKING LTS & ENGINE CPT LTS	92	BATTERY EQUALIZER-CHECK BALANCE
71D	EXTERIOR LTS-DOCKING	93	BATTERY EQUALIZER-CHECK LO/HI
71R	EXTERIOR LTS-DOCKING	95A	ENGINE BRAKE & RETARDER SYSTEM
71G	EXTERIOR LTS-DOCKING	97	TACHOMETER (-)
71L	EXTERIOR LTS-DOCKING	100	INTERIOR LTS-GENERAL
72	SUN VISOR-FEEDING	100A	INTERIOR LTS-GENERAL
72A	SUN VISOR-RH	100B	INTERIOR LTS-GENERAL
72B	SUN VISOR-RH	101	24V STARTER SOL FEEDING
72C	SUN VISOR-LH	101	WORLD TRANSM-LO SIGNAL SOL. LO
72D	SUN VISOR-LH	102	24V STARTER TO GENERATOR
73	LAVATORY-FEEDING	102	WORLD TRANSM-SOL. GRD 1
74	INTERIOR LTS-READING RH	102	WORLD TRANSM-SOL. C3
74A	INTERIOR LTS-READING RH	103	LOW BUOY
74D	INTERIOR LTS-READING SIGNAL	104	WORLD TRANSM-SOL. FORWARD
75	INTERIOR LTS-READING LH	105	WORLD TRANSM-RETARDER & SUMP
75A	INTERIOR LTS-READING LH	105W	WORLD TRANSM-RETARDER & SUMP
76	FUEL TANK GAUGE	106	WORLD TRANSM-OIL LEVEL HI
76B	LOW FUEL LT & ETHER COLD START	107	CHARG SYST-VOLTAGE REGUL. "F"
76C	LOW FUEL LT	107	WORLD TRANSM-LOCKUP SOL. HI
76M	FUEL PRIME PUMP	108	WORLD TRANSM-REMOTE PWR WAKE UP
76P	FUEL PRIME PUMP	109	WORLD TRANSM-RET. SOL. LO
77	A/C & HEAT SYSTEM-HI PRESSURE	110	ALARM & SIGNAL-WATER TEMP
77A	A/C & HEAT SYSTEM-DRIVER'S HTR	110	WORLD TRANSM-LOCKUP SOL. LO
77B	A/C & HEAT SYSTEM-COMPRESSOR	111	WORLD TRANSM-SOL. C6
77C	A/C & HEAT SYSTEM-COMPRESSOR	112	WORLD TRANSM-SPARE OUTPUT (+)
77H	A/C & HEAT SYSTEM-COMPRESSOR	113	ALARM & SIGNAL-OIL PRESS
81	EXTERIOR LTS-STOP SW	113	WORLD TRANSM-REVERSE WARNING
82	EXTERIOR LTS-STOP SIGNAL	114	WORLD TRANSM-SPARE OUTPUT (-)
82A	EXTERIOR LTS-STOP SIGNAL	114	INTERIOR LTS-DASH LT REGUL.
82B	EXTERIOR LTS-STOP LTS	114A	INTERIOR LTS-DASH LT
82K	EXTERIOR LTS-STOP PARK BRK	114B	INTERIOR LTS-DASH LT REGUL.
82L	EXTERIOR LTS-LH STOP	114D	INTERIOR LTS-DASH LT REGUL.
82R	EXTERIOR LTS-LH STOP	114E	INTERIOR LTS-DASH LT REGUL.
83	ENGINE CTR-KEY SW ACCES SIGN	115	ALARM & SIGNAL-TAG PRESS
84	ENGINE CTR-KEY SW START SIGN	115	DDEC III-COOLANT LEVEL
85	ENGINE CTR-KEY SW IGNITION SIGN	115	WORLD TRANSM-DO NOT SHIFT SIGNAL
85	24V IGNITION SIGNAL	115C	DDEC III-COOLANT LEVEL
85A	24V IGN DASH INSTRUMENTATION	115W	WORLD TRANSM-DO NOT SHIFT SIGNAL
85B	ENGINE CTR-24V IGNITION	116	WORLD TRANSM-LO SIGNAL SOL. HI
85C	PARKING BRAKE SWITCH	116B	A/C & HEAT SYSTEM-DRIVER'S HTR
85F	LO AIR SONALERT	117	WORLD TRANSM-SPARE INPUT (-)
85F	ENGINE CTR-ENGINE CTRL SW IGN	117A	ALARM & SIGNAL-TRANSM OIL TEMP
85W	24V IGN ANTI SKID	117A	ALARM & SIGNAL-TRANSM OIL TEMP
85X	24V IGN ANTI SKID	118	WORLD TRANSM-SPARE INPUT (+)
85Y	ANTI SKID-WARNING LT	119	WORLD TRANSM-ENG BRK INPUT (+)
86	ENGINE CTR-STARTER SOL SIGN	120	WORLD TRANSM-SOL. C1
86A	ENGINE CTR-STARTER SOL SIGN	121	WORLD TRANSM-SOL. GRD 2
88	ENGINE CTR-RR START SIGNAL	122	WORLD TRANSM-SOL. GRD 4
89	ENGINE CTR-RR START SIGNAL	122	A/C & HEAT SYSTEM-DRIVER'S HTR
90A	A/C & HEAT SYSTEM-COND FAN MOT	122	A/C & HEAT SYSTEM-FRESH AIR
90B	A/C & HEAT SYSTEM-COND FAN MOT	122A	A/C & HEAT SYSTEM-FRESH AIR
90B	ENGINE CTR-MAST KEY SW FEED	123	WORLD TRANSM-NEUTRAL START
90C	A/C & HEAT SYSTEM-COND FAN MOT	123A	ALARM & SIGNAL-FIRE DETECTOR
90D	A/C & HEAT SYSTEM-EVAP FAN MOT	123B	ALARM & SIGNAL-FIRE DETECTOR
90F	CHARG SYST-VOLTAGE REGUL. "B"	124	WORLD TRANSM-THROTTLE (HI)
90G	A/C & HEAT SYSTEM-COND FAN MOT	125	WORLD TRANSM-RETARDER INDICATOR
90H	A/C & HEAT SYSTEM-EVAP FAN MOT	125	LAVATORY-FAN
90J	A/C & HEAT SYSTEM-COND FAN MOT	125	GALLEY-LAMP
91	PARKING BRAKE SW SIGNAL	125W	WORLD TRANSM-RETARDER INDICATOR

PREVOST CAR inc.

WIRING DIAGRAM

NO: D060869

P. E / 2 4

REVISION 021

CIRCUIT NUMBER CODE Page E : 3

No.	SYSTEM
126	WORLD TRANSM-LUBE PRESS SW.
126	KNEELING SYSTEM
126A	KNEELING SYSTEM
126B	KNEELING SYSTEM
126C	KNEELING SYSTEM
126D	KNEELING SYSTEM
126E	KNEELING SYSTEM
126F	KNEELING SYSTEM
126G	KNEELING SYSTEM
126H	KNEELING SYSTEM
126K	KNEELING SYSTEM
126P	KNEELING SYSTEM
126R	KNEELING SYSTEM
126S	KNEELING SYSTEM
126T	KNEELING SYSTEM
126W	5 MPH N.C. SIGNAL (WCL)
127	WORLD TRANSM-RETARDER FEED SOL.
127	PRE-HEAT WATER HEATER
127A	PRE-HEAT WATER HEATER
127B	PRE-HEAT WATER HEATER
127S	PRE-HEAT WATER HEATER
127W	PRE-HEAT WATER HEATER
128	WORLD TRANSM-SOL. C2
128	PRE-HEAT WATER HEATER
128A	PRE-HEAT WATER HEATER
128B	PRE-HEAT WATER HEATER
128W	PRE-HEAT WATER HEATER
129	PRE-HEAT WATER HEATER
129	WORLD TRANSM-SOL. C5
130	WORLD TRANSM-SOL. GRD 3
131	WORLD TRANSM-SOL. C4
132	WORLD TRANSM-ENG BRK OUTPUT (-)
132W	WORLD TRANSM-ENG BRK OUTPUT (-)
133	WORLD TRANSM-RET. ACTUATOR HI
133	GALLEY-HEAT CONTAINERS
133A	GALLEY-HEAT CONTAINERS
133B	GALLEY-HEAT CONTAINERS
133C	GALLEY-HEAT CONTAINERS
134	WORLD TRANSM-RET. APPLY SOL. HI
134	GALLEY-HEAT CONTAINERS
134A	GALLEY-HEAT CONTAINERS
135	A/C & HEAT SYSTEM-AIR SENSOR
135	WORLD TRANSM-ANALOG GRD
135A	A/C & HEAT SYSTEM-AIR SENSOR
135C	WORLD TRANSM-RETARDER TEMP
135C	A/C & HEAT SYSTEM-AIR SENSOR
135D	WORLD TRANSM-RETARDER RES MOD
135D	A/C & HEAT SYSTEM-AIR SENSOR
136	GALLEY-ACCESSORIES
136	WORLD TRANSM-ECU POWER
136V	WORLD TRANSM-12V BATTERY
136W	WORLD TRANSM-12V BATTERY
136X	WORLD TRANSM-12V BATTERY
137	WORLD TRANSM-RETARDER
137	MIRROR (SPARTAN & RAMCO)
137A	MIRROR (SPARTAN & RAMCO)
137B	RR VIEW MIRROR (SPARTAN)
137C	RR VIEW MIRROR (SPARTAN)
137D	RR VIEW MIRROR (SPARTAN)
137E	RR VIEW MIRROR (SPARTAN)
137F	RR VIEW MIRROR (SPARTAN)
137G	RR VIEW MIRROR (SPARTAN)
138	WORLD TRANSM-RETARDER TEMP
138	ABS SYSTEM
138A	ABS SYSTEM
139	WORLD TRANSM-OUTPUT SPEED HI
139	ABS SYSTEM
140	WORLD TRANSM-OUTPUT SPEED LO
140	ABS SYSTEM
141	ABS SYSTEM
141	WORLD TRANSM-ENGINE SPEED HI
142	ABS SYSTEM
142	WORLD TRANSM-SERIAL COM. A
143	ABS SYSTEM
143	WORLD TRANSM-ECU BATTERY GRD
143A	ABS SYSTEM
143W	WORLD TRANSM-BATTERY GRD
143X	WORLD TRANSM-BATTERY GRD
144	WORLD TRANSM-ECU CHASSIS GRD
144	ABS SYSTEM
144A	ABS SYSTEM
145	ABS SYSTEM
146	ABS SYSTEM
146	WORLD TRANSM-IGNITION SENSE
146W	WORLD TRANSM-12V IGNITION
146X	WORLD TRANSM-12V IGNITION
147	WORLD TRANSM-OIL TEMP
147	ABS SYSTEM
147	ETHER COLD START
147C	ETHER COLD START
148	WORLD TRANSM-OUTPUT SPEED LO
148	ABS SYSTEM
149	WORLD TRANSM-TURBINE SPEED HI
149	ABS SYSTEM
149A	ABS SYSTEM
150	WORLD TRANSM-ENGINE SPEED LO
150	DDEC III-ECM BATTERY GRD
150A	DDEC III-ECM BATTERY GRD
151	DDEC III-ECM BATTERY GRD
151	WORLD TRANSM-SERIAL COM. B
151	ABS SYSTEM
151A	ABS SYSTEM
152	ABS SYSTEM
152A	ABS SYSTEM
153	WORLD TRANSM-SPARE INPUT (-)
153	ABS SYSTEM
154	WORLD TRANSM-ABS RETARDER INPUT
154	ABS SYSTEM
155	WORLD TRANSM-SPARE INPUT (-)
155	ABS SYSTEM
156	WORLD TRANSM-THROTTLE POS.
156	ABS SYSTEM
156A	ABS SYSTEM
157	WORLD TRANSM-SPEEDOMETER SIGNAL
157	ABS SYSTEM
157A	ABS SYSTEM
157B	ABS SYSTEM
158	WORLD TRANSM-DIMMER
160	ALARM & SIGNAL-TAG PRESS SW
160	WORLD TRANSM-SER. INTERFACE (-)
161	WORLD TRANSM-SIGNAL GRD
161B	WORLD TRANSM-SIGNAL GRD

CIRCUIT NUMBER CODE Page E : 3

No.	SYSTEM
162	WORLD TRANSM-PRESS. SW C3
163	WORLD TRANSM-RETARDER ENABLE
164	WORLD TRANSM-RET. ACTUATOR SIGN
165	WORLD TRANSM-OIL LEVEL SIGNAL
165	A/C & HEAT SYSTEM-TRANSMITER
165A	A/C & HEAT SYSTEM-TRANSMITER
165B	A/C & HEAT SYSTEM-TRANSMITER
165C	A/C & HEAT SYSTEM-TRANSMITER
165D	A/C & HEAT SYSTEM-TRANSMITER
166B	A/C & HEAT SYSTEM-EVAP. MOD.
167	A/C & HEAT SYSTEM-TEMP. CTR
167A	A/C & HEAT SYSTEM-TEMP. CTR
168	WORLD TRANSM-SER. INTERFACE (+)
168	A/C & HEAT SYSTEM-HUMIDISTAT
168A	A/C & HEAT SYSTEM-HUMIDISTAT
170	LUGGAGE DOOR LOCK
170C	LUGGAGE DOOR LOCK
170E	LUGGAGE DOOR LOCK
170H	LUGGAGE DOOR LOCK
180	DIGITAL THERMOMETER
181	DIGITAL THERMOMETER
181A	THERMOMETER INSIDE SENSOR
181B	THERMOMETER INSIDE SENSOR
197	FUEL WATER FILTER
197A	FUEL WATER FILTER
197B	FUEL WATER FILTER
201	WORLD TRANSM-SPARE
202	WORLD TRANSM-SPARE
203	WORLD TRANSM-SPARE
204	WORLD TRANSM-SPARE
205	WORLD TRANSM-SPARE
206	WORLD TRANSM-SPARE
214	WORLD TRANSM-BACK UP SIGNAL
231	NEUTRAL SIGNAL GRD
231A	NEUTRAL COIL RELAY FEED SIGNAL
231W	NEUTRAL SIGNAL GRD (WCL)
240	DDEC III-ECM 12V FEEDING
241	DDEC III-ECM 12V FEEDING
251	DDEC III - PRODRIVER 12V H.W.
253	GALLEY-MICROWAVE
254	GALLEY-12V FRIGO NORCOLD
254A	GALLEY-FRIGO
255	GALLEY-COFEEMAKER
255A	GALLEY-COFEEMAKER
257	WINDSHIELD HEATED
257A	WINDSHIELD HEATED
257B	WINDSHIELD HEATED
257C	WINDSHIELD HEATED
257D	WINDSHIELD HEATED SPARE
257E	WINDSHIELD HEATED SPARE
258	WINDSHIELD HEATED
258A	WINDSHIELD HEATED
259	WINDSHIELD HEATED
259A	WINDSHIELD HEATED
290	FAN CLUTCH RADIATOR
290A	FAN CLUTCH RADIATOR
291	FAN CLUTCH RADIATOR SPD 1
292	FAN CLUTCH RADIATOR SPD 2
300	DOOR AJAR MAGN.SW. (WCL)
300A	POWER SYSTEM SW. (WCL)
300B	DOOR AJAR ALARM (WCL)
301	POWER SYSTEM SW. (WCL)
302	DOOR AJAR T.T.L.T. (WCL)
302A	DOOR AJAR ALARM SIGN.(WCL)
302B	DOOR AJAR MAGN.SW. (WCL)
303	REMOTE WALL SW. DWN (WCL)
304	REMOTE WALL SW. UP (WCL)
305	PARK. BRAKE SOL. VALVE (WCL)
305A	PARK. BRAKE SAFETY SW. (WCL)
306	CONTROL SYSTEM (WCL RICON)
307	CONTROL SYSTEM (WCL RICON)
308	CONTROL SYSTEM (WCL RICON)
309	CONTROL SYSTEM (WCL RICON)
417	DDEC III-LIMIT SPEED GOVERNOR
419	DDEC III-CHECK ENGINE LIGHT
439	DDEC III-12V IGNITION
440	DDEC III-12V IGNITION
440A	DDEC III-12V IGNITION
451	DDEC III-A/C FAN CLUTCH
505	DDEC III-TACHOMETER DRIVE
509	DDEC III-STOP ENGINE LIGHT
510	DDEC III-FAST IDLE SIGNAL
524	DDEC III-ENGINE BRAKE DISABLE
525	DDEC III-FAST IDLE SIGNAL
528	DDEC III-STOP ENG. OVERRIDE
531	DDEC III-CRUISE CLUTCH RELEASE
541	DDEC III-CRUISE SET SW
543	DDEC III-CRUISE STOP SW CUT IN
544	DDEC III-CRUISE ON/OFF SW
545	DDEC III-CRUISE RESUME SW
555	DDEC III-FAN CLUTCH SPEED# 1
556	DDEC III-VEHICLE SPEED (+)
557	DDEC III-VEHICLE SPEED (-)
563	DDEC III-FAN CLUTCH SPEED# 2
564	DDEC III-DIGITAL OUTPUT
565	DDEC III-ENGINE BRAKE ACTIVE
583	DDEC III-ENGINE BRAKE 4 CYL.
900	DDEC III-DATA LINK (+)
901	DDEC III-DATA LINK (-)
908	DDEC III-HYDRAULIC PWM#1 OUTPUT
916	DDEC III-SENSOR SUPPLY (5VDC)
952	DDEC III-SENSOR RETURN
953	DDEC III-BATTERY GRD
979	DDEC III-ENGINE BRAKE 2 CYL.
B00	RR JCT BOX CPT BATT GRD
B000	RR JCT BOX CPT BATT GRD
BA	INTERIOR LTS-110V FLUORESCENT
BB	INTERIOR LTS-110V FLUORESCENT
D1	SOUND SYSTEM-FR RH SPEAKER
D2	SOUND SYSTEM-FR RH SPEAKER
D3	SOUND SYSTEM-FR RH SPEAKER
D4	SOUND SYSTEM-RR RH SPEAKER
D5	SOUND SYSTEM-RR RH SPEAKER
D6	SOUND SYSTEM-RR RH SPEAKER
D9	SOUND SYSTEM-DRIVER SPEAKER
D10	SOUND SYSTEM-DRIVER SPEAKER

PREVOST CAR inc.	WIRING DIAGRAM	NO: D060869	P. E / 3/4	REVISION 021

CIRCUIT NUMBER CODE Page E : 4

No.	SYSTEM
G1	SOUND SYSTEM-FR LH SPEAKER
G2	SOUND SYSTEM-FR LH SPEAKER
G3	SOUND SYSTEM-FR LH SPEAKER
G4	SOUND SYSTEM-RR LH SPEAKER
G5	SOUND SYSTEM-RR LH SPEAKER
G6	SOUND SYSTEM-RR LH SPEAKER
G9	SOUND SYSTEM-DRIVER SPEAKER
G10	SOUND SYSTEM-DRIVER SPEAKER
L1A	INTERIOR LTS-110V FLUORESCENT
L1B	INTERIOR LTS-110V FLUORESCENT
L2	INTERIOR LTS-110V FLUORESCENT
L2A	INTERIOR LTS-110V FLUORESCENT
L2B	INTERIOR LTS-110V FLUORESCENT
L3A	GALLEY-110V FRIGO
L4	GALLEY-110V FRIGO
LL0	110V RECEPTACLE
LL1	110V RECEPTACLE
LL2	110V RECEPTACLE
LL3	GALLEY-110V FRIGO
L7	GALLEY-110V MICROWAVE OVEN
L8	ENG. BLK & WATER TANK-HEATER
L9	ENG. BLK & WATER TANK-HEATER
N1	VIDEO SYSTEM-110V INVERTER
N7	GALLEY-110V MICROWAVE OVEN
RA	INTERIOR LTS-110V FLUORESCENT
RB	INTERIOR LTS-110V FLUORESCENT
YC	INTERIOR LTS-110V FLUORESCENT
YD	INTERIOR LTS-110V FLUORESCENT
WC	A/C & HEAT SYST-EVAP CTR SIGN
SH2	SPEEDOMETER-SHIELD GRD
SH4	SPEEDOMETER-SHIELD GRD
SP2	SPARE-FJB TO FR SERV CPT
SP3	SPARE-FJB TO CENTER DASH
SP4	SPARE-FJB TO CENTER DASH
SP5	SPARE-RJB TO LUGG CPT #2
SP6	SPARE-RJB TO LUGG CPT #1
SP7	SPARE-RJB TO LUGG CPT #1
SP8	SPARE-RJB TO LUGG CPT #1
SP9	SPARE-RJB TO LUGG CPT #2
SP10	SPARE-RJB TO LUGG CPT #1
SP11	SPARE-RJB TO ENGINE
SP12	SPARE-RJB TO ENGINE
SP13	SPARE-RJB TO ENGINE
SP14	SPARE-FJB TO FR SERV CPT
SP15	SPARE-RJB TO ENGINE
SP16	SPARE-RJB TO ENGINE
SP17	SPARE-RJB TO ENGINE
SP18	SPARE-FJB TO FR SERV CPT
SP24	SPARE-RJB TO LH HAT RACK
SP25	SPARE-RJB TO LH HAT RACK
SP26	SPARE-RJB TO LH HAT RACK
SP27	SPARE-RJB TO LH HAT RACK
SP28	SPARE-RJB TO LH HAT RACK
SP31	SPARE-RJB TO RH HAT RACK
SP32	SPARE-RJB TO RH HAT RACK
SP33	SPARE-FJB TO RJB
SP36	BACK-UP MONITOR
SP37	SPARE-ALARM JCT BOX
SP38	SPARE-ALARM JCT BOX TO RJB
SP39	SPARE-ALARM JCT BOX TO FJB
SP40	SPARE-ALARM JCT BOX TO FJB
SP43	SPARE-FJB TO RJB
SP45	SPARE-FJB TO RJB
SP46	SPARE-RJB TO LH FR ROOF
SP48	SPARE-RJB TO RH FR ROOF
SP56	SPARE-FJB TO RH SW PANEL
SP57	SPARE-FJB TO ENGINE
SP58	SPARE-FJB TO ENGINE
SP59	SPARE-FJB TO ENGINE
SP61	SPARE-FJB TO RH CONSOLE
SP68	SPARE-FJB TO ENGINE ECM
SP69	SPARE-FJB TO FR AXLE
SP70	SPARE-FJB TO FR AXLE
SP71	SPARE-FJB TO RH SW PANEL
SP72	SPARE-FJB TO FR SERV CPT
SP74	SPARE-FJB TO LH CONSOLE
SP77	SPARE-FJB TO A/C JB CPT
SP78	SPARE-FJB TO A/C JCT BOX
SP79	SPARE-FJB TO A/C JCT BOX
SP80	SPARE-TO A/C JCT BOX CPT
SP82	SPARE-FJB TO LH CONSOLE
SP83	SPARE-FJB TO RH CONSOLE
SP84	SPARE-FJB TO RH CONSOLE
SP85	SPARE-FJB TO LH CONS & SW PAN
SP86	SPARE-FJB TO LH CONS & SW PAN
SP87	SPARE-RJB TO LH HAT RACK
SP88	SPARE-RJB TO RH HAT RACK
SP92	SPARE-RJB TO A/C JCT BOX
SP93	SPARE-RJB TO EVAPORATOR CPT
SP94	SPARE-RJB TO RR ROOF
SP95	SPARE-RJB TO RR ROOF
SP96	SPARE-RJB TO LUGG CPT #2
SP97	SPARE-RJB TO LUGG CPT #3
SP98	SPARE-RJB TO LUGG CPT #3
SP100	SPARE-DATA LOGGER
SP101	SPARE-DATA LOGGER
SP104	SPARE-RJB TO ENGINE CPT
SP105	SPARE-DASH TO ENGINE CRADLE ACCES.
SP106	SPARE-RJB TO BATT. CPT.
SP107	SPARE-RJB TO BATT. CPT.
SP108	SPARE-RJB TO BATT. CPT.
SP109	SPARE-RJB TO ENGINE CPT.
SP110	SPARE-RJB TO ENGINE CPT.
SP111	SPARE-RJB TO ENGINE CPT.
SP112	SPARE-RJB TO ENGINE CPT.
SP113	SPARE-RJB TO WCL JCT BOX RICON

CIRCUIT NUMBER CODE Page E : 4

No.	SYSTEM	No.	SYSTEM

PREVOST CAR inc.	WIRING DIAGRAM	NO: D060869	P. E / 4 4	REVISION 021