CIRCUIT NUMBER CODE		Page E : 1
No.	SYSTEM	No. SYSTEM
0	EC - INVERTER CPT GRD	0RH RS - RR END LAMPS RH GRD
0I	GALLEY GRD	0SS SOUNS SYSTEM BATT. GRD
0J	BC - BAT. CPT GRD	0SA SOUND SYSTEM BATT. GRD
0J	CONDENSER CPT GRD	0T FS - LUG. CPT ACCES. GRD
0J	A/C - A/C JCT BOX GRD	0W RR JCT BOX CPT GRD STUD
0J	GALLEY GRD	0W FS - RR JCT BOX CPT GRD
0J	A/C - A/C JCT BOX GRD	0W RS - RR JCT BOX CPT GRD
0J	GALLEY GRD	0W FS - UNDER DASH CENT GRD
0J	VIDEO GRD	0W RS - RR JCT BOX
0JA	A/C - A/C JCT BOX GRD	0WA FS - FR JCT BOX CPT GRD STUD
0JA	FRS - FR ROOF ACCES. GRD	0WC RS - RR JCT BOX GRD WCL
0JA	RS - LUG. CPT ACCES. GRD	0Y FS - FR CONS. CARD NOT USED
0JA	AJB - ALARM JCT BOX GRD	0Y FR JCT BOX CPT GRD STUD
0JA	FS - FR ROOF ACCES. GRD	0Y FR JCT BOX CPT GRD
0JAA	RS - VOLTAGE REGULATOR GRD	0YC FR JCT BOX GRD WCL
0JB	EC - ENGINE GRD	0Y FR JCT BOX CPT GRD
0JB	FRS - FR ROOF HEAT JKN GRD	0Y FR JCT BOX CPT GRD
0JB	FS - FR ROOF ACCES. GRD	0Y ABS FR JCT BOX CPT GRD STUD
0JB	RS - LUG. CPT ACCES. GRD	0Y 12V IGNITION DISTRIBUTION
0JB	A/C - A/C JCT BOX GRD	12A FR JCT BOX 12V IGNITION
0JB	FS - FR ROOF ACCES. GRD	12B FR JCT BOX 12V IGNITION
0JBE	RJB - BATT.EQUAL.,BAT GRD	12B FR JCT BOX 12V IGNITION
0JC	EC - STARTER MOTOR GRD	12F FR JCT BOX 12V IGNITION
0JC	BAT.EQUAL.SYSTEM GRD	12P INVERTER CPT 12V DISC SW
0JC	FS - SERV. CPT ACCES. GRD	2C A/C & HEAT SYSTEM-L.O PRESS SW
0JC	RS - ENGINE ACCES. GRD	12R BAT CPT 12V DISC SW - TO RJB
0JC	RJB - SPEED SW, BATT.GRD	12S FJB TO BAT. 12V HOT WIRE
0JC	FS - FR ROOF ACCES. GRD	12T FR JCT BOX 12V IGNITION
0JCS	24V DISC.SW.,RL/ GRD SIGNAL	12VD 12V HOT WIRE DISTRIBUTION
0JD	FS - SERV. CPT ACCES. GRD	12VF BAT CPT 12V F.B & JC
0JD	RS - HAT RACK ACCES.,LH GRD	12VG INVERTER CPT 12V DISC SW
0JDF	RS - RR SIDE FLASH & MARK GRD	12VI 12V IGNITION DISTRIBUTION
0JE	FS - FR LAMPS GRD	12VR BAT CPT 12V DISC.RL/ TO RJB
0JE	RS - HAT RACK ACCES.LH GRD	12W UPPER WINDSHIELD DEFROSTER
0JE	FRS - HAT RACK ACCES.,RH GRD	12X FR JCT BOX 12V IGNITION
0JEE	FRS - HEAD & GROUND,LTS GRD	12Y FR JCT BOX 12V IGNITION
0JF	RS - HAT RACK ACCES.,RH GRD	12Y FR JCT BOX 12V IGNITION
0JG	RS - HAT RACK ACCES.,RH GRD	12Z FR JCT BOX 12V IGNITION
0JG	FS - INSTR.PANEL LH GRD	13A ALARM & SIGNAL-LO AIR PRES.
0JH	FS - INSTR.PANEL CENT GRD	13B ALARM & SIGNAL-CENT SEC.
0JH	RS - LAVATORY ACCES.,GRD	13C LAVATORY-FLUSHING PUMP
0JI	FS - LAVATORY ACCES.,GRD	13D ALARM & SIGNAL-FUEL PUMP
0JJ	FS - SW CONSOLE LH GRD	13E EXTERIOR,LTS-HIGH LEVEL
0JJ	RS - RR ROOF ACCES. GRD	13F WIPER & WASHER UPPER WINDSHIELD
0JK	RS - RR ROOF ACCES. GRD	13G SPEEDO - SIGNAL
0JL	RS - ENGINE CPT ACCES.,GRD	13H SPEEDO - TRANSMITTER
0JL	FS - UNDER DASH RH GRD	13J INTERIOR,LTS-FR SERVICE CPT
0JLA	ENTRANCE DOOR (SEDAN) GRD	13K INTERIOR,LTS-FR FLASHER UNIT
0JM	FS - UNDER DASH RH GRD	13L INTERIOR,LTS-LUGGAGE CPT
0JM	RS - ENGINE CPT ACCES.,GRD	13M INTERIOR,LTS-LUGGAGE CPT
0JM	FS - UNDER DASH RH GRD	13N INTERIOR,LTS-LUGGAGE CPT
0JMR	24V DISC.SW.,RL/ GRD SIGNAL	13P INTERIOR,LTS-LUGGAGE CPT
0JNS	FS - UNDER DASH RH GRD	13R INTERIOR,LTS-LUGGAGE CPT
0JN	RS - ENGINE CPT ACCES.,GRD	13M INTERIOR,LTS-LUGGAGE CPT
0JP	RS - ENGINE CPT ACCES.,GRD	13T INTERIOR,LTS-LUGGAGE CPT
0JP	RS - ENGINE CPT ACCES.,GRD	13U INTERIOR,LTS-LUGGAGE CPT
0JR	FS - UNDER DASH LH GRD	13V INTERIOR,LTS-LUGGAGE CPT
0JR	RS - ENGINE CPT ACCES.,GRD	13W INTERIOR,LTS-LUGGAGE CPT
		13X INTERIOR,LTS-LUGGAGE CPT
		13Y INTERIOR,LTS-LUGGAGE CPT
		13Z DOOR AJAR
		1E FR DESTINATION SIGN
		1H FR DESTINATION SIGN
		1J FR DESTINATION SIGN
		1K SOUNS SYSTEM BATT. GRD
		1L BAT CPT 12V BATTERY
		1Z FR JCT BOX 12V DISC SW
		12A 12V BAT CPT JCT BLOCK
		12A FR JCT BOX 12V DISC SW
		12B FR JCT BOX 12V DISC SW
		12B FR JCT BOX 12V DISC SW
		12B 12V BAT CPT JCT BLOCK
		12BE BAT.EQUAL.LIER MONITOR
		12C FR JCT BOX 12V DISC SW
		12D BAT CPT 12V BATTERY
		12E FR JCT BOX 12V DISC SW
		12F FR JCT BOX 12V DISC SW
		12G FR JCT BOX 12V DISC SW
		12H FR JCT BOX 12V DISC SW
		12J FR JCT BOX 12V DISC SW
		12K FR JCT BOX 12V DISC SW
		12L FR JCT BOX 12V DISC SW
		12M FR JCT BOX 12V DISC SW
		12N FR JCT BOX 12V DISC SW
		12P FR JCT BOX 12V DISC SW
		12Q FR JCT BOX 12V DISC SW
		12R FR JCT BOX 12V DISC SW
		12S FR JCT BOX 12V DISC SW
		12T FR JCT BOX 12V DISC SW
		12U FR JCT BOX 12V DISC SW
		12V FR JCT BOX 12V DISC SW
		12W FR JCT BOX 12V DISC SW
		12X FR JCT BOX 12V DISC SW
		12Y FR JCT BOX 12V DISC SW
		12Z FR JCT BOX 12V DISC SW
		13 LAVATORY-FLUSHING PUMP
		13A ALARM & SIGNAL-LO AIR PRES.
		13B ALARM & SIGNAL-CENT SEC.
		13C LAVATORY-FLUSHING PUMP
		13D ALARM & SIGNAL-FUEL PUMP
		13E EXTERIOR,LTS-HIGH LEVEL
		13F WIPER & WASHER UPPER WINDSHIELD
		13G SPEEDO - SIGNAL
		13H SPEEDO - TRANSMITTER
		13J INTERIOR,LTS-FR SERVICE CPT
		13K INTERIOR,LTS-FR FLASHER UNIT
		13L INTERIOR,LTS-LUGGAGE CPT
		13M INTERIOR,LTS-LUGGAGE CPT
		13N INTERIOR,LTS-LUGGAGE CPT
		13P INTERIOR,LTS-LUGGAGE CPT
		13R INTERIOR,LTS-LUGGAGE CPT
		13M INTERIOR,LTS-LUGGAGE CPT
		13T INTERIOR,LTS-LUGGAGE CPT
		13U INTERIOR,LTS-LUGGAGE CPT
		13V INTERIOR,LTS-LUGGAGE CPT
		13W INTERIOR,LTS-LUGGAGE CPT
		13X INTERIOR,LTS-LUGGAGE CPT
		13Y INTERIOR,LTS-LUGGAGE CPT
		13Z DOOR AJAR
		21B FR DESTINATION SIGN
		21H FR DESTINATION SIGN
		21K FR DESTINATION SIGN
		21L FR DESTINATION SIGN
		21P EXTERIOR,LTS-CORNERING LH
		23 EXTERIOR,LTS-DIRECTIONAL RH
		23 EXTERIOR,LTS-DIRECTIONAL RH
		23A EXTERIOR,LTS-DIRECTIONAL RH
		23B EXTERIOR,LTS-DIRECTIONAL RH
		23C EXTERIOR,LTS-CORNERING RH
		23D EXTERIOR,LTS-CORNERING RH
		23P EXTERIOR,LTS-CORNERING RH
		24 BAT CPT 24V BATTERY
		24A FR JCT BOX 24V DISC SW
		24A BOOSTER BLOCK 24V DISC SW
		24A FR JCT BOX 24V DISC SW
		24A FR JCT BOX 24V DISC SW
		24A FR JCT BOX 24V DISC SW
		24B FR JCT BOX 24V DISC SW
		24B 24V STARTER RL-1 FEEDING
		24B RJB OFF-BAT.24V DISC SW
		24C FR JCT BOX 24V DISC SW
		24D BAT CPT 24V HOT WIRE
		24E BAT CPT 24V HOT WIRE
		24F A/C JCT BOX 24V HOT WIRE
		24G BAT CPT 24V DISC SW
		24H FR JCT BOX 24V DISC SW
		24J FR JCT BOX 24V DISC SW
		24K FR JCT BOX 24V DISC SW
		24L FR JCT BOX 24V DISC SW
		24M FR JCT BOX 24V DISC SW
		24N FR JCT BOX 24V DISC SW
		24P FR JCT BOX 24V DISC SW
		24Q FR JCT BOX 24V DISC SW
		24R FR JCT BOX 24V DISC SW
		24S FR JCT BOX 24V DISC SW
		24T FR JCT BOX 24V DISC SW
		24U FR JCT BOX 24V DISC SW
		24V FR JCT BOX 24V DISC SW
		24W FR JCT BOX 24V DISC SW
		24X FR JCT BOX 24V DISC SW
		24Y FR JCT BOX 24V DISC SW
		24Z FR JCT BOX 24V DISC SW
		24X 24V HOT WIRE DISTRIBUTION
		24Y BAT CPT 24V SW TO FJB & JC
		24Z INVERTER CPT 24V DISC SW
		24W BATTERY EQUALIZER 24V
		24X BAT CPT 24V DISC SW TO RJB
		24Y BAT CPT 24V DISC SW NCL1
		24Z BAT.L.CPT TO H/DL PUMP WCL1

PREVOST CAR inc. | WIRING DIAGRAM | NO: D060869 | P. E / 1/4 | REVISION 020

CIRCUIT NUMBER CODE		Page E : 2
No.	SYSTEM	No. SYSTEM
24AL	24V BATTERY-HYDUPUMP (WCL)	46A EXTERIOR,LTS-MARKER
24A	FR JCT BOX 24V DISC SW	46B EXTERIOR,LTS-MARKER
24A2	FR JCT BOX 24V DISC SW	46C EXTERIOR,LTS-MARKER
24Y	FR JCT BOX 24V DISC SW	46E EXTERIOR,LTS-MARKER
24Y2	FR JCT BOX 24V DISC SW	47 A/C & HEAT SYSTEM-DRIVER'S HTR
25	12VAC ON RL-1 ON SIGNAL	48 EXTERIOR DOOR (SEDAN)
25A	12V BAT CPT 12V DISC SW	49 ALARM & SIGNAL-LO T
25B	EXTERIOR,LTS-DAYTIME RUN LTS	50 AIR DRYER
26	DRIVER'S WINDOW LIFTER	52 ALARM & SIGNAL-ELEC. HORN
26	CIGAR LIGHTER	52A ALARM & SIGNAL-ELEC.,HORN
26B	DRIVER'S WINDOW LIFTER	56 LOW FUEL LT
26C	DRIVER'S WINDOW LIFTER	56C LOW FUEL LT
27	LAVATORY-EMERGENCY SIGNALLIGHT	56P FUEL PRIME PUMP
27A	A/C & HEAT SYSTEM-DRIVER'S HTR	56R FUEL PRIME PUMP
27B	A/C & HEAT SYSTEM-DRIVER'S HTR	57 A/C & HEAT SYSTEM-HI PRESSURE
27C	A/C & HEAT SYSTEM-DRIVER'S HTR	57A ALARM & SIGNAL-WATER TEMP
27D	A/C & HEAT SYSTEM-COMPRESSOR	53J WIPER & WASHER SYSTEM
27E	A/C & HEAT SYSTEM-COMPRESSOR	55 EXTERIOR,LTS-HEBEAM
27F	A/C & HEAT SYSTEM-COMPRESSOR	57 EXTERIOR,LTS-HEBEAM
30	GALLEY	57A EXTERIOR,LTS-HEBEAM
31A	A/C & HEAT SYSTEM-UNLOADER	57A A/C & HEAT SYSTEM-WATER PUMP
31B	A/C & HEAT SYSTEM-UNLOADER	57B A/C & HEAT SYSTEM-WATER PUMP
31C	WIPER & WASHER SYSTEM	57C PRE-HEAT WATER-HEATER
31D	WIPER & WASHER SYSTEM	57E EXTERIOR,LTS-HEAD LTS
31E	WIPER & WASHER SYSTEM	58 EXTERIOR,LTS-LO BEAM
31F	WIPER & WASHER SYSTEM	58A EXTERIOR,LTS-LO BEAM
32	EXTERIOR,LTS-BACK-UP	58E EXTERIOR,LTS-LO BEAM
32A	BACK-UP ALARM-SIGNAL	58F EXTERIOR,LTS-LO BEAM
32D	BACK-UP PWR & SIGNAL	61 EXTERIOR,LTS-24V FEED SW
32D	BACK-UP ALARM	61A EXTERIOR,LTS-HEAD SIGNAL
32F	BACK-UP MONITOR	62 LAVATORY-DOCKING LT
35	ENTRANCE DOOR (SEDAN)	62A LAVATORY-FLOOR LT
35B	ENTRANCE DOOR (SEDAN)	62B LAVATORY-FLOOR LT
35BB	ENTRANCE DOOR (SEDAN)	62E LAVATORY-OCCUP & FLUOR.LT
35C	DOOR AJAR-SIGNAL	63 EXTERIOR,LTS-CLEARANCE
35D	DOOR AJAR-SIGNAL	63A EXTERIOR,LTS-CLEARANCE
36A	JACOB BRAKE SYSTEM	63B EXTERIOR,LTS-CLEARANCE
38	INTERIOR,LTS-24V FLUORESCENT	63C EXTERIOR,LTS-HARKER SIGNAL
38A	INTERIOR,LTS-24V FLUORESCENT	63D EXTERIOR,LTS-MARKER & TAIL
38C	INTERIOR,LTS-24V FLUORESCENT	63E EXTERIOR,LTS-MARKER
38D	INTERIOR,LTS-24V FLUORESCENT	63F EXTERIOR,LTS-MARKER BLOWER
38E	INTERIOR,LTS-24V FLUORESCENT	63G A/C & HEAT SYSTEM
39	INTERIOR,LTS-DRIVING LIGHT	63H A/C & HEAT SYSTEM
41	A/C & HEAT SYSTEM-COND FAN HOT	67A A/C & HEAT SYSTEM
41A	A/C & HEAT SYSTEM-COND FAN HOT	67B A/C & HEAT SYSTEM & HEAT WINDS.
41B	A/C & HEAT SYSTEM-COND FAN HOT	67C A/C & HEAT SYSTEM-COND FAN CTR
42A	A/C & HEAT SYSTEM-COND FAN HOT	67L A/C & HEAT SYSTEM-EVAP FAN HOT
42B	A/C & HEAT SYSTEM-COND FAN HOT	67M A/C & HEAT SYSTEM-EVAP FAN HOT
44	EXTERIOR,LTS-FOG	67N A/C & HEAT SYSTEM-COND FAN HOT
44A	EXTERIOR,LTS-FOG	67P A/C & HEAT SYSTEM-COND FAN HOT
45	EXTERIOR,LTS-FOG & HAZARD	67R A/C & HEAT SYSTEM-COND FAN CTR
45B	A/C & HEAT SYSTEM-HEAT 3 SIGN	70 A/C & HEAT SYSTEM-EVAP FAN HOT
45C	A/C & HEAT SYSTEM-WATER VALVE	70J A/C & HEAT SYSTEM-COND FAN HOT
45E	A/C & HEAT SYSTEM-HEAT 1 SIGN	71 EXTERIOR,LTS-DOCKING
45G	A/C & HEAT SYSTEM-DRIVER'S HTR	71A EXTERIOR,LTS-DOCKING
45H	A/C & HEAT SYSTEM-DRIVER'S HTR	71B EXTERIOR,LTS-DOCKING
45K	A/C & HEAT SYSTEM-DRIVER'S HTR	71F EXTERIOR,LTS-DOCKING
46	EXTERIOR,LTS-MARKER	71G EXTERIOR,LTS-DOCKING
		71H EXTERIOR,LTS-DOCKING
		72 SUN VISOR-FEEDING
		72A SUN VISOR-RH
		72B SUN VISOR-RH
		72C SUN VISOR-LH
		72D SUN VISOR-LH
		73 LAVATORY-FEEDING
		74 INTERIOR,LTS-READING RH
		74A INTERIOR,LTS-READING RH
		74D INTERIOR,LTS-READING SIGNAL
		74E INTERIOR,LTS-READING LH
		74F INTERIOR,LTS-READING LH
		76 FUEL TANK GAUGE
		76B LOW FUEL L & ETHER COLD START
		76C LOW FUEL LT
		76P FUEL PRIME PUMP
		76R FUEL PRIME PUMP
		77 A/C & HEAT SYSTEM-HI PRESSURE
		77A A/C & HEAT SYSTEM-DRIVER'S HTR
		77B A/C & HEAT SYSTEM-COMPRESSOR
		77C A/C & HEAT SYSTEM-COMPRESSOR
		77H A/C & HEAT SYSTEM-COMPRESSOR
		81 EXTERIOR,LTS-STOP SIGNAL
		82 EXTERIOR,LTS-STOP SIGNAL
		82A EXTERIOR,LTS-STOP SIGNAL
		82B EXTERIOR,LTS-STOP LTS
		82K EXTERIOR,LTS-STOP PARK BRK
		83 EXTERIOR,LTS-LH STOP
		82R EXTERIOR,LTS-LH STOP
		84 ENGINE CTR-KEY SW ACCES SIGN
		84 ENGINE CTR-KEY SW START SIGN
		85 ENGINE CTR-SW IGNITION SIGN
		85 IGNITION SIGNAL
		85A 24V SGN DASH INSTRUMENTATION
		85F ENGINE CTR-24V IGNITION
		85G PARKING BRAKE SWITCH
		85P LO AIR SIGNALERT
		85P ENGINE CTR-ENGINE CTRL SW JKN
		86 24V IGN-AIR DRYER
		87 24V START SIGN
		87A LT. SKID-WARNING LT
		88 ENGINE CTR-STARTER SOL SIGN
		86A ENGINE CTR-STARTER SOL. SIGN
		88 ENGINE CTR-START SIGNAL
		89 ENGINE CTR-HR START SIGNAL
		90 A/C & HEAT SYSTEM-COND FAN HOT
		90 A/C & HEAT SYSTEM-FRESH AIR
		90B ENGINE CTR-INSTRUMENT ON-FEED
		90C A/C & HEAT SYSTEM-EVAP FAN HOT
		90D A/C & HEAT SYSTEM-EVAP FAN HOT
		90F CHARG SYST-VOLTAGE REGUL.,"B"
		90G A/C & HEAT SYSTEM-COND FAN HOT
		90H A/C & HEAT SYSTEM-EVAP FAN HOT
		90J A/C & HEAT SYSTEM-COND FAN HOT
		90K A/C & HEAT SYSTEM-COND FAN HOT
		90L DOOC-FAST IDLE SIGNAL
		90M PARK. BRAKE SW., SIGN. WCL1
		92 BATTERY EQUALIZER-CHECK BALANCE
		93 BATTERY EQUALIZER-CHECK LO-HI
		95 ENGINE BRAKE & RETARDER SYSTEM
		96 TACHOMETER
		102 SUN VISOR-LH
		102A INTERIOR,LTS-GENERAL
		102B INTERIOR,LTS-GENERAL
		101 24V STARTER SOL FEEDING
		101 WORLD TRANSM-LO SIGNAL SOL.,LO
		102 24V STARTER SOLENOID
		102 WORLD TRANSM-SOL.-ORD.1
		102 WORLD TRANSM-SOL.-C3
		103 LOW BOOT
		103 WORLD TRANSM-SOL.-FORWARD
		105 WORLD TRANSM-RETARDER & SUMP
105W	WORLD TRANSM-RETARDER & SUMP	
106	WORLD TRANSM-OIL LEVEL HI	
107	TACHOMETER-VOL.LEVEL HI	
107	WORLD TRANSM-LOCKUP SOL.	
108	WORLD TRANSM-REMOTE PWR WAKE UP	
109	WORLD TRANSM-SOL.-C4	
110	WORLD TRANSM-WATER TEMP	
110	WORLD TRANSM-LOCKUP SOL.,LO	
111	WORLD TRANSM-SOL.-C5	
112	WORLD TRANSM-SPARE OUTPUT (+)	
113	ALARM & SIGNAL-OIL PRESS	
113	WORLD TRANSM-REVERSE WARNING	
114	WORLD TRANSM-SPARE OUTPUT (+)	
114	INTERIOR,LTS-DASH-LT REGUL.	
114A	INTERIOR,LTS-DASH-L	
114B	INTERIOR,LTS-DASH-LT REGUL.	
114D	INTERIOR,LTS-DASH-LT REGUL.	
115	WORLD TRANSM-SOL.,OUT	
115	ALARM & SIGNAL-TAC PRESS	
115	WORLD TRANSM-SOL.-C6	
115	WORLD TRANSM-SOLENOID SHIFT SIGNAL	
115C	DOO-ELL-COOLANT LEVEL	
115V	WORLD TRANSM-SHIFT SOL.	
116	WORLD TRANSM-LO SIGNAL SOL.,HI	
116B	A/C & HEAT SYSTEM-DRIVER'S HTR	
117	WORLD TRANSM-SPARE INPUT (+)	
117	ALARM & SIGNAL-HIGH OIL TEMP	
118	WORLD TRANSM-SPARE INPUT (+)	
118	WORLD TRANSM-SPARE INPUT (+)	
119	WORLD TRANSM-ENG.BRK INPUT (+)	
120	WORLD TRANSM-SOL.-C1	
121	WORLD TRANSM-SOL.,ORD	
122	WORLD TRANSM-SOL.-ORD.4	
123	A/C & HEAT SYSTEM-DRIVER'S HTR	
123	A/C & HEAT SYSTEM-FRESH AIR	
123A	A/C & HEAT SYSTEM-FRESH AIR	
123A	ALARM & SIGNAL-FINE DETECTOR	
123B	ALARM & SIGNAL-FINE DETECTOR	
123C	WORLD TRANSM-THROTTLE (HI)	
125	WORLD TRANSM-RETARDER INDICATOR	
125	LAVATORY-FAN	
125	WORLD TRANSM-C2	
125W	WORLD TRANSM-RETARDER INDICATOR	
126	WORLD TRANSM-LUBE PRESS SW.	
126A	KNEELING SYSTEM	
126B	KNEELING SYSTEM	
126C	KNEELING SYSTEM	

PREVOST CAR inc. | WIRING DIAGRAM | NO: D060869 | P. E 3/4 | REVISION 020

CIRCUIT NUMBER CODE		Page E : 3
No.	SYSTEM	No. SYSTEM
126D	KNEELING SYSTEM	13R ABS SYSTEM
126E	KNEELING SYSTEM	13T WORLD TRANSM-OUTPUT SPEED LO
126F	KNEELING SYSTEM	14B ABS SYSTEM
126G	KNEELING SYSTEM	14D ABS SYSTEM
126H	KNEELING SYSTEM	14I WORLD TRANSM-ENGINE SPEED HI
126K	KNEELING SYSTEM	14J ABS SYSTEM
126P	KNEELING SYSTEM	14Q WORLD TRANSM-SERIAL COM.A
126Q	KNEELING SYSTEM	14R ABS SYSTEM
126R	KNEELING SYSTEM	14S WORLD TRANSM-ECU BATTERY ORD
126T	KNEELING SYSTEM	14Sb ABS SYSTEM
126W	S-PIN ELC. SIGNAL (WCL)	14W WORLD TRANSM-BATTERY ORD
127	WORLD TRANSM-RETARDER FEED SOL.	14X WORLD TRANSM-BATTERY ORD
127A	PRE-HEAT WATER-HEATER	14Y WORLD TRANSM-ECU CHASSIS ORD
127A	PRE-HEAT WATER-HEATER	144 ABS SYSTEM
127B	PRE-HEAT WATER-HEATER	144 ABS SYSTEM
127B	PRE-HEAT WATER-HEATER	145 ABS SYSTEM
127E	PRE-HEAT WATER-HEATER	146 ABS SYSTEM
128	WORLD TRANSM-SOL.,C3	146 WORLD TRANSM-IGNITION SENSE
128	PRE-HEAT WATER-HEATER	146W WORLD TRANSM-12V IGNITION
128A	PRE-HEAT WATER-HEATER	146 WORLD TRANSM-12V IGNITION
129	WORLD TRANSM-OIL TEMP	147B FUEL WATER FILTER
129	WORLD TRANSM-C7	147 FUEL WATER FILTER
129	PRE-HEAT WATER-HEATER	147 ETHER COLD START
129	WORLD TRANSM-SOL.,C5	147C ETHER COLD START
130	WORLD TRANSM-SOL.,ORD.3	148 WORLD TRANSM-OUTPUT SPEED LO
131	WORLD TRANSM-SOL.,C4	148 ABS SYSTEM
132	WORLD TRANSM-ENGINE OUTPUT (+)	200 WORLD TRANSM-TURBINE SPEED HI
132W	WORLD TRANSM-ENG.BRK OUTPUT (+)	149 ABS SYSTEM
133	WORLD TRANSM-SOL.,ORD.2	150 WORLD TRANSM-SOL.,C1
133	GALLEY-HEAT CONTAINERS	150 WORLD TRANSM-ENGINE SPEED LO
133A	GALLEY-HEAT CONTAINERS	150 DOO-ELL-ECH BATTERY ORD
133B	GALLEY-HEAT CONTAINERS	150 DOO-ELL-ECH BATTERY ORD
133C	GALLEY-HEAT CONTAINERS	151 DOO-ELL-ECH BATTERY ORD
134	WORLD TRANSM-RET.,APPL.T. SOL.,HI	151 WORLD TRANSM-SERIAL COM.B
134	GALLEY-HEAT CONTAINERS	151 ABS SYSTEM
134	GALLEY-HEAT CONTAINERS	152 ABS SYSTEM
135	WORLD TRANSM-SOL.,C2	152 ABS SYSTEM
135	WORLD TRANSM-ANALOG ORD	152A ABS SYSTEM
135A	A/C & HEAT SYSTEM-AIR SENSOR	152 WORLD TRANSM-SPARE INPUT (+)
135Q	WORLD TRANSM-RETARDER TEMP	153 ABS SYSTEM
135Q	WORLD TRANSM-RETARDER TEMP	153 WORLD TRANSM-ABS RETARDER INPUT
135Q	WORLD TRANSM-RETARDER RES HOD	154 ABS SYSTEM
135Q	WORLD TRANSM-RETARDER TEMP	154 WORLD TRANSM-SPARE INPUT (+)
136	GALLEY-ICE DISPENSER	155 ABS SYSTEM
136	WORLD TRANSM-ECU POWER	156 WORLD TRANSM-THROTTLE POS.
136A	WORLD TRANSM-12V BATTERY	156 ABS SYSTEM
136H	WORLD TRANSM-12V BATTERY	156A ABS SYSTEM
136K	WORLD TRANSM-12V BATTERY	157 ABS SYSTEM
137	RR VIEW MIRROR (SPARTAN)	157 ABS SYSTEM
137A	RR VIEW MIRROR (SPARTAN)	157B ABS SYSTEM
137B	RR VIEW MIRROR (SPARTAN)	157B ABS SYSTEM
137C	RR VIEW MIRROR (SPARTAN)	158 WORLD TRANSM-DIMMER
137D	RR VIEW MIRROR (SPARTAN)	160 ALARM & SIGNAL-TAC PRESS SW
137E	RR VIEW MIRROR (SPARTAN)	160 WORLD TRANSM-SERIL INTERFACE (+)
137F	RR VIEW MIRROR (SPARTAN)	160A WORLD TRANSM-SIGNAL ORD
137G	RR VIEW MIRROR (SPARTAN)	160B WORLD TRANSM-SIGNAL ORD
137H	RR VIEW MIRROR (SPARTAN)	162 WORLD TRANSM-RESS. SW C3
138	WORLD TRANSM-RETARDER TEMP	163 WORLD TRANSM-RETARDER ENABLE
138A	ABS SYSTEM	164 WORLD TRANSM-RET.,ACTUATOR SIGN
139	ABS SYSTEM	165 WORLD TRANSM-SOL.LEVEL SIGNAL
139	WORLD TRANSM-OUTPUT SPEED HI	165 A/C & HEAT SYSTEM-TRANSMITTER
		165A A/C & HEAT SYSTEM-TRANSMITTER
		165B A/C & HEAT SYSTEM-TRANSMITTER
		165C A/C & HEAT SYSTEM-TRANSMITTER
		166B A/C & HEAT SYSTEM-EXHP.MOD.
		167 A/C & HEAT SYSTEM-TEMP.CTR
		167A A/C & HEAT SYSTEM-TEMP.CTR
		168 WORLD TRANSM-SERL INTERFACE (+)
		169W A/C & HEAT SYSTEM-HUMIDISTAT
		169A A/C & HEAT SYSTEM-HUMIDISTAT
		170 LUGGAGE DOOR LOCK
		170C LUGGAGE DOOR LOCK
		170D LUGGAGE DOOR LOCK
		170F LUGGAGE DOOR LOCK
		172 DIGITAL THERMOMETER
		172 DIGITAL THERMOMETER
		197 FUEL WATER FILTER
		197A FUEL WATER FILTER
		197B FUEL WATER FILTER
		200 WORLD TRANSM-SPARE
		202 WORLD TRANSM-SPARE
		203 WORLD TRANSM-SPARE
		204 WORLD TRANSM-SPARE
		205 WORLD TRANSM-SPARE
		204 WORLD TRANSM-SPARE
		214 WORLD TRANSM-BACK UP SIGNAL
		215 WORLD TRANSM-SPARE
		223W NEUTRAL SIGNAL ORD WCL1
		248 DOO-ELL-ECM 12V FEEDING
		249 DOO-ELL-ECM 12V FEEDING
		250 VIDEO SYSTEM & TV RECEIVER
		250Z DOO-ELL-SENSOR BATTERY
		251 DOO-ELL-BATTERY ORD
		252 DOO-ELL-BATTERY ORD
		253 ABS SYSTEM
		254 ABS SYSTEM
		254A GALLEY-FRIDGE
		255 GALLEY-COFFEEMAKER
		255A GALLEY-COFFEEMAKER
		257 WINDSHIELD HEATED
		257A WINDSHIELD HEATED
		257B WINDSHIELD HEATED
		257D WINDSHIELD HEATED
		257G WINDSHIELD HEATED SPARE
		258 WINDSHIELD HEATED
		258 WINDSHIELD HEATED
		258A WINDSHIELD HEATED
		259 WINDSHIELD HEATED
		259 WINDSHIELD HEATED
		261 FAN CLUTCH RADIATOR
		261 FAN CLUTCH RADIATOR SPD 1
		262 FAN CLUTCH RADIATOR SPD 2
		300 DOOR AJAR HADLSW. (WCL)
		300A POWER SYSTEM SW. (WCL)
		300B DOOR AJAR AL.ARM (WCL)
		302 POWER SYSTEM SW. (WCL)
		302A DOOR AJAR T.I.,T.L. (WCL)
		302B DOOR AJAR ALARM (WCL)
		302D DOOR AJAR HADLSW. (WCL)
		303 REMOTE WALL SW.(BATV WCL)
		304 REMOTE WALL SW.(P. WCL)
		305 PARK.BRAKE SOL.,VAL.VE WCL1
		305A PARK.BRAKE SAFETY SW.(WCL)
		417 DOO-ELL-SHIT SPEED GOVERNOR
		419 DOO-ELL-CHECK ENGINE LIGHT