LAZER FORMAT "A" CHALLE 2:

CONNECTORS CODE ID Page G-1

No.	LOCATION	#HD TYPE	*PIN CAVITY	*SOCKET HOUSING	HOUSING
C1	FR JCT BDI COMPARTMENT	AMP CPC	37	560644	560646
C2	FR JCT BDI COMPARTMENT	AMP CPC	24	560641	560643
C4	FR JCT BDI COMPARTMENT	AMP CPC	37	560714	560713
C4	FR JCT BDI COMPARTMENT	AMP CPC	16	560693	560695
C5	FR SERVICE COMPT.-UNDERHEATH	AMP CPC	37	560644	560646
C6	FR SERVICE COMPT.-UNDERHEATH	AMP CPC	24	560641	560643
C7	FR JCT BDI COMPT.-UNDERHEATH	AMP CPC	37	560787	560786
C8	FR SERVICE COMPT.-UNDERHEATH	AMP CPC	37	560714	560713
C9	ALARM JCT BDI	AMP CPC	37	560644	560646
C10	ALARM JCT BDI	AMP CPC	37	560644	560646
C11	FR SERVICE COMPARTMENT	AMP CPC	24	560642	560643
C12	FR SERVICE COMPARTMENT	AMP CPC	16	560639	560640
C12	LH CONSOLE-HEATER MOR.	AMP HML	2	561248	561247
C13	FR SERVICE COMPT.	AMP HML	8	560552	560515
C13	LH CONSOLE-C.ETR.HORROR	AMP HML	6	561552	561515
C14	UNDER DASH-LH HORROR	AMP HML	6	561552	561515
C15	RR JCT BDI	AMP CPC	24	560641	560643
C15	UNDER DASH-RH HORROR	AMP HML	6	561552	561662
C16	LH CONSOLE-E.SW-CRUISE ON-OFF	SWF	8	------	561037
C17	LH CONSOLE-E.SW-CRUISE RESUME	SWF	8	------	561037
C18	LH CONSOLE-E.SW-CRUISE SET	SWF	8	------	561037
C20	RR JCT BDI	AMP CPC	37	560644	560646
C21	RR JCT BDI	AMP CPC	24	560641	560643
C26	HYD & HVAC TRANSDS.-NEUT.& B-U	PED WP	4	561610	561611
C31	HYD & HVAC TRANSDS.-SPEED SENS.	PED WP	2	561766	561767
C32	DDEC ENGINE-ECM	PED	30	------	561600
C34	RR JCT BDI	AMP CPC	24	560641	560643
C36	EMERGENCY-EXIT LTS	AMP HML	2	561248	561247
C37	RR SECTION-LH-HAT RACK	AMP HML	9	561661	561662
C38	RR SECTION-RH-HAT RACK	AMP HML	9	561661	561662
C40	RR JCT BDI	AMP CPC	16	560639	560640
C41	LAVATORY-ROOF FLUORESCENT	AMP HML	2	560908	560898
C42	LAVATORY-BACK WALL-WTR TANK	AMP HML	2	560908	560898
C43	LAVATORY-BACK WALL-ACCESS.	AMP HML	9	561661	561662
C45	ALARM JCT BDI COMPARTMENT	AMP CPC	24	560642	560643
C46	FR SERVICE COMPT.-UNDERHEATH	AMP CPC	37	560644	560646
C49	WATERER COMPT.-LOW BLOCK	AMP HML	2	561248	561247
C50	FR SERVICE COMPT.-LOW BLOCK	PED WP	1	561605	561517
C52	RR JCT BDI	AMP CPC	22	560718	560717
C53	RR JCT BDI	AMP CPC	14	560585	560584
C54	UNDER DASH-LH HUT	AMP HML	6	561552	561515
C55	UNDER DASH-RH SW PANEL	AMP CPC	9	560636	560637
C56	UNDER DASH-RH CONSOLE	AMP CPC	24	560642	560643
C57	UNDER DASH-RH ACCESSORIES	AMP CPC	22	561995	561718
C58	UNDER DASH-RH ACCESSORIES	AMP CPC	22	561995	561718
C59	EVAPORATOR COMPARTMENT	AMP HML	2	561248	561249
C60	RR JCT BDI COMPT.-L.T.	AMP HML	2	561248	561247
C61	LUGGAGE COMPARTMENT LTS	AMP HML	2	561248	561247
C62	LUGGAGE COMPARTMENT LTS	AMP HML	2	561248	561247
C63	LUGGAGE COMPARTMENT LTS	AMP HML	2	561248	561247
C64	LUGGAGE COMPARTMENT LTS	AMP HML	2	561248	561247
C65	LUGGAGE COMPARTMENT LTS	AMP HML	2	561248	561247

CONNECTORS CODE ID Page G-1

No.	LOCATION	#HD TYPE	*PIN CAVITY	*SOCKET HOUSING	HOUSING
C66	LUGGAGE COMPARTMENT LTS	AMP HML	2	561248	561247
C67	LUGGAGE COMPARTMENT LTS	AMP HML	2	561248	561247
C68	LUGGAGE COMPARTMENT LTS	AMP HML	2	561248	561247
C69	RH AVLE ACC-INSIDE PVC END	PED WP	6	561568	561578
C70	ALARM JCT BDI COMPARTMENT	AMP CPC	24	560642	560643
C71	UNDER INSTRUMENT PANEL-LH	AMP CPC	37	560645	560646
C72	UNDER INSTRUMENT PANEL-CENT.	AMP CPC	37	560645	560646
C73	UNDER INSTRUMENT PANEL-CENT.	AMP CPC	16	560639	560640
C74	UNDER INSTRUMENT PANEL-CENT.	AMP CPC	16	560639	560640
C75	ALARM JCT BDI COMPARTMENT	AMP CPC	37	560644	560646
C76	LUGGAGE COMPT.-AIR RET.SENS.	AMP HML	2	561248	561247
C77	LUGGAGE COMPT.-AIR RET.SENS.	AMP HML	2	561248	561247
C78	FR JCT BDI COMPARTMENT	AMP CPC	22	561791	561718
C79	FR SERVICE COMPT.-UNDERHEATH	AMP CPC	37	560644	560646
C80	LUGGAGE COMPT.-AIR RET.SENS.	AMP HML	2	561248	561247
C81	PASSENGER COMPT.-HOLE L.T.S	AMP HML	2	561248	560898
C82	ENTRANCE DOOR	HDLEX	6	562079	562069
C83	ENTRANCE DOOR-PRESSURE SWITCH	AMP HML	2	561248	561476
C84	ENTRANCE DOOR-PRESSURE SW.	PED WP	1	561605	561517
C85	UNDER INSTRUMENT PANEL-LH	AMP HTA-100	8	------	562248
C87	BATT.& RR JUL.CPT.-SWITCH	PED WP	1	561605	561517
C88	FR JCT BDI COMPT.-L.T.S	AMP HML	2	561248	561247
C90	RR END ROOF-CLEARANCE LTS	AMP HML	2	560908	560898
C91	RR END ROOF-BLU.NONITOR	AMP CPC	14	561582	561581
C92	RR JCT BDI	AMP CPC	15	561587	561586
C93	RR JCT BDI	AMP CPC	37	561714	561713
C94	FR JCT BDI COMPT.-WATI SKID	AMP CPC	15	561635	561637
C95	FR JCT BDI COMPT.-WATI SKID	AMP CPC	15	561635	561637
C96	FR AVLE ACCESSORIES	AMP CPC	14	560585	560584
C97	RH AVLE ACC-INSIDE PVC END	PED WP	6	561568	561578
C98	FR SERVICE COMPT.-ELLIP.PEDAL	PED WP	3	561782	561781
C99	FR SERVICE COMPT.LTS	AMP HML	2	561248	561247
C100	FR SERVICE COMPT.-CONDENSER	AMP HML	2	561568	560298
C101	FR SERVICE COMPT.-ELEC.-HORNS	PED WP	2	561566	561569
C102	FR SERV.& EQ.COMPT.-FLUORES.	LH TL	9	561661	561662
C103	FR SERV.& EQ.COMPT.-INVERERS	ITT SS	2	561813	561812
C104	FR SERVICE COMPT.-CLS.& VALVE	PED WP	2	561566	561569
C105	FR SERVICE COMPT.-CLS.& VALVE	PED WP	2	561566	561569
C106	FR SERVICE COMPT.-WATER VALVE	PED WP	2	561566	561569
C107	EVAPORATOR COMPT.-DAMPER	PED WP	2	561566	561569
C108	FR SERVICE COMPT.-KNEEL.SYS	PED WP	2	561566	561569
C109	FR SERVICE COMPT.-KNEEL.SYS	PED WP	2	561566	561569
C110	FR SERVICE COMPT.-KNEEL.SYS	PED WP	2	561566	561569
C111	EVAPORATOR COMPT.-DAMPER	ITT SS	2	561813	561812
C113	BATT.& RR JUL.CPT.-MARKER L.T	ITT SS	2	561813	561812
C114	BATT.& RR JUL.CPT.-MARKER L.T	ITT SS	2	561813	561812
C115	ENGINE COMPT.-HYD.DRIVER	PED WP	2	561566	561569
C116	ENGINE COMPT.LTS	PED WP	2	561566	561569
C117	ENGINE COMPT.-LAVATORY FAN	TC	5	561938	562997
C118	ENGINE CPT RH DOOR-RH LO.LAMP	PED WP	6	561606	561607
C119	ENGINE CPT RH DOOR-LH LO.LAMP	PED WP	6	561606	561607
C120	BATTERE CPT.-DOOR SW.L.T.RH	ITT SS	2	561813	561812
C121	ENGINE CPT-CHAIRS DOOR CONNECTOR	AMP HML	2	561566	561678
C124	ENGINE CPT-ETHER SW	PED WP	2	561566	561678

CONNECTORS CODE ID Page G-2

No.	LOCATION	#HD TYPE	*PIN CAVITY	*SOCKET HOUSING	HOUSING
C125	ENGINE CPT-B.U.ALARM	PED WP	2	561566	561678
C126	ENGINE CPT-FLUSHING PUMP	PED WP	2	561566	561678
C127	ENGINE CPT-FUEL FILTER	PED WP	2	561566	561678
C128	ENGINE CPT-L+C COMPRO.LUTCH	ITT SS	2	561813	561812
C129	ENGINE CPT-WAT.W.LVLT	PED WP	2	561566	561678
C130	ENGINE CPT-UNLOADER	ITT SS	2	561813	561812
C131	ENGINE CPT-UNLOADER	ITT SS	2	561813	561812
C132	ENGINE CPT-W.C.L.O.PRESS SW	PED WP	2	561566	561678
C133	ENGINE CPT-W.C.L.O.PRESS SW	PED WP	2	561566	561678
C134	ENGINE CPT RH DOOR-LH COL.LT	AMP HML	6	561606	561607
C135	FR JCT BDI-LUGGAGE DOOR CONS.	AMP HML	15	561787	561786
C136	A-/C JCT BDI	AMP CPC	18	562285	562284
C137	A-/C JCT BDI-TRANSMITTER	AMP HML	2	560908	560898
C138	A-/C JCT BDI-CONTROL MODULE	AMP HML	2	560908	560898
C139	A-/C JCT BDI-L.DOOC MODULE	AMP-HDP	15	562811	------
C140	RH-HAT RACK-DOOR LAMP	AMP HML	9	561661	561662
C141	LAVATORY-DOOR WALL	AMP HML	3	560908	560886
C142	ENGINE CPT-RH DOOR-LO.LAMP	PED WP	6	561606	561607
C203	RH-HAT RACK-BALLAST	AMP HML	9	561661	561662
C204	RH-HAT RACK-GENERAL LT	AMP HML	9	561661	561662
C205	RH-HAT RACK-SPEAKER AMP HML	9	561661	561662
C206	RH-HAT RACK-READING LT	AMP HML	2	560908	560898
C207	LH-HAT RACK-READING LT	AMP HML	2	560908	560898
C208	LH-HAT RACK-BALLAST	AMP HML	4	560851	560852
C209	FR SECT.-LH-HAT RACK SPEAKER	AMP HML	9	561661	561662
C211	FR ROOF-STORE LTH	AMP HML	2	560908	560898
C212	FR ROOF-CLEARANCE L.T	AMP HML	2	560908	560898
C213	FR ROOF-CLEARANCE L.T	AMP HML	2	560908	560898
C216	UNDER DASH-LH-P.A.	AMP HML	9	561678	561687
C217	UNDER DASH-LH-P.A.	AMP HML	3	------	561550
C218	UNDER DASH-LH-P.A.	AMP HML	3	------	561550
C219	UNDER DASH-LH-P.A.	AMP HML	3	------	561550
C220	PALJCT.BDI-FUEL PRIME PUMP	TC	1	560878	560873
C222	ALARM JCT BDI CPT.-SPD SIGN.	HDLEX	4	561477	561476
C223	ALARM JCT BDI CPT.-DRIVL.SPD.SIG.	AMP HML	4	560550	560468
C224	ALARM JCT BDI CPT.-SPD SIGN.WT	PED WP	2	561566	561569
C227	RH SW.PANEL-SPEAKER	AMP HML	9	561661	561662
C228	RH SW.PANEL-MICRO DUTLET	HDLEX	4	561477	561476
C229	RH SW.PANEL-PA VOL.CONTROL	HDLEX	4	561477	561476
C230	ENGLOPT.-FUEL PRIME PUMP FEED	DEUTSCH	2	562486	562495
C231	RR JCT BDI-PUMP SW.	PED WP	15	------	561762
C232	ENGLOPT.-FUEL PRIME PUMP	PED WP	2	561566	561569
C233	INSTRUMENT PANEL CENTER	VJDL	8	------	561643
C234	INSTRUMENT PANEL CENTER	VJDL	4	------	562844
C235	INSTRUMENT PANEL CENTER	VJDL	4	------	562844
C236	INSTRUMENT PANEL CENTER	AMP HML	2	560908	560852
C237	UNDER DASH-LH-JACOB CLUTCH SW	ITT SS	3	561111	561080
C238	A-/C JCT BDI-DIODE CONNECTOR	AMP HML	9	561678	561687
C239	FR SERVICE CPT-HI BUOY VALVE	PED WP	2	561566	561569
C240	FR SERVICE CPT-KNEEL PRSD SW	PED WP	2	561566	561569
C241	FR SERVICE CPT-FOG RESISTOR	AMP CPC	3	561847	561862
C242	FR SERVICE CPT-HEADLAMPS	TC	5	561938	562997
C243	FR SERVICE CPT-HEADLAMPS	TC	3	561871	------
C244	FR SERVICE CPT-RH FOG LAMP	ITT SS	2	561813	561812
C245	FR SERVICE CPT-RH FOG LAMP	ITT SS	2	561813	561812
C246	FR SERVICE CPT-HARN.& DIR.L.T	ITT SS	3	561111	561080
C248	ALARM JCT BDI-WIPER PULSE GEN.HVF	TC	6	------	561189
C249	ALARM JCT BDI-CONN.12V TO 5V HVF	HML	3	561667	561650

CONNECTORS CODE ID Page G-2

No.	LOCATION	#HD TYPE	*PIN CAVITY	*SOCKET HOUSING	HOUSING
C286	RR JCT BDI CPT.-SPEED SIGN.TR.PED	AMP	2	561566	561678
C288	RR JCT BDI CPT.-SPD SIGN.W.TR.PED	AMP	2	561566	561678
C289	RR JCT BDI CPT.-SPD SIGN.WT PED	AMP	2	561566	561678
C287	RR JCT BDI-RRH RESISTOR CON.	AMP HML	6	561552	561515
C291	ENGINE CPT RH DOOR-LLS T	PED WP	2	561566	561678
C292	ENGINE CPT RH DOOR TAIL LS T	PED WP	2	561566	561678
C293	ENGINE CPT RH DOOR-RH DIR.L.T	PED WP	2	561566	561678
C294	ENGINE CPT RH DOOR-LH DIR.L.T	PED WP	2	561566	561678
C295	ENGINE CPT RH DOOR-RH STOP.L.T	PED WP	2	561566	561678
C296	ENGINE CPT RH DOOR-LH STOP.L.T	PED WP	2	561566	561678
C297	ENGINE CPT RH DOOR-C.O.P.L.T	PED WP	2	561566	561678
C298	ENGINE CPT-A/C COMPRESSOR	PED WP	4	561889	561890
C299	ENGINE CPT-A/C COMPRESSOR	PED WP	4	561889	561890
C300	RH-HAT RACK-DOOR LIGHT	AMP HML	9	561661	561662
C301	ENGINE CPT RH DOOR-L.ICENSE L.T	DOH-AUTO	2	930210	------
C302	RH-HAT RACK-DOOR LIGHT	AMP HML	9	561661	561662
C303	RH-HAT RACK-FLUORESCENT	AMP HML	4	561551	561666
C304	RH-HAT RACK-GENERAL LT	AMP HML	9	561661	561662
C305	RH-HAT RACK-BALLAST	AMP HML	4	560851	560852
C306	RH-HAT RACK-READING LT	AMP HML	2	560908	560898
C307	LH-HAT RACK-READING LT	AMP HML	2	560908	560898
C308	LH-HAT RACK-BALLAST	AMP HML	4	560851	560852
C309	FR SECT.-LH-HAT RACK SPEAKER	AMP HML	9	561661	561662
C311	FR ROOF-STORE LTH	AMP HML	2	560908	560898
C312	FR ROOF-CLEARANCE L.T	AMP HML	2	560908	560898
C313	FR ROOF-CLEARANCE L.T	AMP HML	2	560908	560898
C316	UNDER DASH-LH-P.A.	AMP HML	9	561678	561687
C317	UNDER DASH-LH-P.A.	AMP HML	3	------	561550
C318	UNDER DASH-LH-P.A.	AMP HML	3	------	561550
C319	UNDER DASH-LH-P.A.	AMP HML	3	------	561550
C320	RR JCT BDI-FUEL PRIME PUMP	TC	1	560878	560873
C322	ALARM JCT BDI CPT.-SPD SIGN.W.TR	HDLEX	4	561477	561476
C323	ALARM JCT BDI CPT.-DRIVL.SPD.SIG.	AMP HML	4	560550	560468
C324	ALARM JCT BDI CPT.-SPD SIGN.WT	PED WP	2	561566	561569
C327	RH SW.PANEL-SPEAKER	AMP HML	9	561661	561662
C328	RH SW.PANEL-MICRO DUTLET	HDLEX	4	561477	561476
C329	RH SW.PANEL-PA VOL.CONTROL	HDLEX	4	561477	561476
C330	ENGLOPT.-FUEL PRIME PUMP FEED	DEUTSCH	2	562486	562495
C331	RR JCT BDI-PUMP SW.	PED WP	15	------	561762
C332	ENGLOPT.-FUEL PRIME PUMP	PED WP	2	561566	561569
C333	INSTRUMENT PANEL CENTER	VJDL	8	------	561643
C334	INSTRUMENT PANEL CENTER	VJDL	4	------	562844
C335	INSTRUMENT PANEL CENTER	VJDL	4	------	562844
C336	INSTRUMENT PANEL CENTER	AMP HML	2	560908	560852
C337	UNDER DASH-LH-JACOB CLUTCH SW	ITT SS	3	561111	561080
C338	A-/C JCT BDI-DIODE CONNECTOR	AMP HML	9	561678	561687
C339	FR SERVICE CPT-HI BUOY VALVE	PED WP	2	561566	561569
C340	FR SERVICE CPT-KNEEL PRSD SW	PED WP	2	561566	561569
C341	FR SERVICE CPT-FOG RESISTOR	AMP CPC	3	561847	561862
C342	FR SERVICE CPT-HEADLAMPS	TC	5	561938	562997
C343	FR SERVICE CPT-HEADLAMPS	TC	3	561871	------
C344	FR SERVICE CPT-RH FOG LAMP	ITT SS	2	561813	561812
C345	FR SERVICE CPT-RH FOG LAMP	ITT SS	2	561813	561812
C346	FR SERVICE CPT-HARN.& DIR.L.T	ITT SS	3	561111	561080
C348	ALARM JCT BDI-WIPER PULSE GEN.HVF	TC	6	------	561189
C349	ALARM JCT BDI-CONN.12V TO 5V HVF	HML	3	561667	561650

CONNECTORS CODE ID Page G-3

No.	LOCATION	#HD TYPE	*PIN CAVITY	*SOCKET HOUSING	HOUSING
C250	ALARM JCT BDI-DASH L.TS REGUL.	AMP HML	6	561552	561515
C251	LH SW.PANEL-F.AST DLE	SWF	8	------	561837
C252	LH SW.PANEL-SWITCH L.T	SWF	2	------	561837
C253	LH SW.PANEL-ETHER	SWF	8	------	561837
C254	INST.PANEL RH-ENTRADOOR SW.	TORRIX	5	------	562102
C255	LH SW.PANEL-HYD.PUMP	SWF	8	------	561837
C257	INSTRUMENT PANEL CENT-SPEEDO	AMP HML	4	560851	560852
C258	LH SW.PANEL-MULTI.FUNC.SW	AMP	8	------	561837
C259	LH SW.PANEL-MULTI.FUNC.SW	AMP	3	561667	561558
C260	UNDER DASH-RH DOOR MODULE	AMP HML	9	------	561037
C261	UNDER DASH-RH DOOR MODULE	AMP HML	9	561678	561687
C262	UNDER DASH-RH DOOR MODULE	AMP HML	4	561551	561668
C263	UNDER DASH-RH DOOR MODULE	AMP HML	3	561667	561558
C264	UNDER DASH-RH DOOR MODULE	AMP HML	3	561667	561558
C265	UNDER DASH-RH DOOR MODULE	AMP HML	2	560908	560852
C267	UNDER DASH-RH	AMP CPC	24	561642	561643
C268	UNDER DASH-RH-HORROR	AMP HML	4	561552	561515
C269	UNDER DASH-RH-HORROR	AMP HML	6	561552	561515
C270	RH-HORROR POST	HDLEX	4	561477	561476
C271	RH-HORROR POST	HDLEX	4	561477	561476
C272	LH HORROR	SPARTAN	6	990158	------
C273	RH-HORROR	SPARTAN	6	990158	------
C274	RADIO	AMP HML	9	561678	561687
C276	UNDER DASH-RH-LOCK SOL.VLVE	AMP HML	2	561248	561247
C286	RH SW.PANEL-A/C & HEAT	SWF	8	------	561837
C287	RH SW.PANEL-FRESH-AIR	SWF	8	------	561837
C288	RH SW.PANEL-FRESH-AIR	SWF	3	561667	561558
C289	RH SW.PANEL-FRESH-AIR	SWF	3	561667	561558
C290	LH CONSOLE-CONT-VIDEO SYST.	AMP HML	9	561678	561687
C293	LH CONSOLE-CONT-VIDEO SYST.	SWF	8	------	561837
C297	UNDER DASH-LH-L.TS	AMP HML	2	560908	560898
C298	LH CONSOLE-CONT-VIDEO SYST.	AMP HML	9	561678	561687
C299	UNDER DASH-LH-L.TS	AMP HML	2	560908	560898
C300	INVERTER CONT.	AMP CPC	16	561639	561640
C301	INSTRUMENTS CENT.-WATER	AMP HML	4	560851	560852
C303	INVERTER CONT.-GALLEY CTR.	AMP HML	9	561661	561662
C304	LH CONSOLE-SW.PRESET	TC	2	561838	560997
C305	LH CONSOLE-SW.PRESET	TC	2	561838	560997
C306	LH CONSOLE-SW.PRESET	TC	2	561838	560997
C307	DDEC ENGINE-ECM POWER	PED	30	------	561600
C308	LH CONSOLE-SW.RHEOSTAT	TC	2	561838	560997
C309	DDEC ENGINE-ECM POWER	PED	30	------	561600
C310	LH CONSOLE-SW.LUGG.DOOR LOK	DEUTSCH	2	562486	562495
C311	LH CONSOLE-SW.READING L.TS	SWF	8	------	561837
C312	LH CONSOLE-SW.CEN & FLOOR L.TS	SWF	8	------	561837
C313	LH CONSOLE-SW.PRESET.SIGN	SWF	8	------	561837
C314	LH CONSOLE-SW.PRESET.SIGN	SWF	8	------	561837
C315	LH CONSOLE-SW.STOP SIGN	SWF	8	------	561837
C316	LH CONSOLE-SW.OPN WINDOW LIFT	SWF	8	------	561837
C317	LH CONSOLE-SW.DRIVER'S L.TS	SWF	8	------	561837
C318	LH CONSOLE-SW.WIND.LIFT NOT PED	PED	2	------	561848
C320	LH CONSOLE-CRUISE CTR SW.PANEL	AMP CPC	9	561636	561637
C321	LH CONSOLE-T.-REFRIGERATOR	SWF	8	------	561837
C325	LH CONSOLE-SW.KNEELING	SWF	8	------	561837
C326	LH CONSOLE-SW.DRVMR	SWF	8	------	561837
C327	ENGINE COMPT-RH START SW.BOX	AMP CPC	9	561636	561637

CONNECTORS CODE ID Page G-3

No.	LOCATION	#HD TYPE	*PIN CAVITY	*SOCKET HOUSING	HOUSING
C328	GALLEY-LAMP	AMP HML	2	561248	561247
C329	ENGINE TACHO SIGNAL	PED WP	2	561566	561569
C330	GALLEY HICROWAVE SW.L.T	SWF	2	------	561837
C331	GALLEY HICROWAVE SW	SWF	8	------	561837
C332	GALLEY RH CONTAINER SW.L.T	SWF	2	------	561837
C333	GALLEY RH CONTAINER SW	SWF	8	------	561837
C334	GALLEY LH CONTAINER SW	SWF	8	------	561837
C335	GALLEY LH CONTAINER SW.L.T	SWF	2	------	561837
C336	INSTRUMENT PANEL RH-DIR.SIG.	AMP HML	3	561667	561558
C337	INSTRUMENT PANEL-DIR.SIG.	SWF	8	------	561837
C338	UNDER DASH-RH-DOOR MODULE	AMP HML	9	561678	561687
C362	UNDER DASH-RH-DOOR MODULE	AMP HML	4	561551	561668
C363	UNDER DASH-RH-DOOR MODULE	AMP HML	3	561667	561558
C364	UNDER DASH-RH-DOOR MODULE	AMP HML	3	561667	561558
C365	UNDER DASH-RH-DOOR MODULE	AMP HML	2	560908	560898
C366	UNDER DASH-RH-DOOR MODULE	AMP HML	2	560908	560898
C367	UNDER DASH-RH-DOOR MODULE	AMP HML	2	560908	560898
C368	UNDER DASH-RH-DOOR MODULE	AMP HML	2	560908	560898
C369	UNDER DASH-RH-DOOR MODULE	AMP HML	2	560908	560898
C370	RH-HORROR POST	HDLEX	4	561477	561476
C371	RH-HORROR POST	HDLEX	4	561477	561476
C372	RH-HORROR POST	HDLEX	4	561477	561476
C373	ALARM JCT BDI-CONT-MASTER SW.HVF	TC	6	561552	561515
C374	ALARM JCT BDI-CONT-LH CONSOL.HVF	HML	6	561552	561515
C375	ALARM JCT BDI-CONT-RH CONSOL.HVF	HML	6	561552	561515
C376	LH SW.PANEL-DIR.SIG.CONT.LEVER	SWF	8	------	561837
C380	LH CONSOLE-DDR CONNECTOR	DEUTSCH	6	562366	------
C383	ALARM JCT BDI-CPT.-HIC W/O WIRE	DEUTSCH	2	562486	562247
C385	FR SERV.COMPT-UNDERHEATH(C)	AMP HML	9	561661	561662
C386	LH CONSOLE-WCL POWER SYSTEM	SWF	8	------	561837
C387	RR JCT BDI-WCL	AMP HML	9	561661	561662

CONNECTORS CODE ID Page G-2

No.	LOCATION	#HD TYPE	*PIN CAVITY	*SOCKET HOUSING	HOUSING
C388	RR JCT BDI-WCL	AMP HML	12	561735	561734
C389	WCL REAR DOOR	HDLEX	4	561477	561476
C390	LAVATORY WALL-WCL REMOTE CTR	SWF	8	------	561187
C391	LAVATORY WALL-WCL	SWF	8	------	561187
C392	LAVATORY WCL SW.L.T.	SWF	2	------	561835
C393	LAVATORY WALL-WCL REMOTE S.TS.	AMP CPC	4	560686	560687
C394	UNDER INSTRUMENT PANEL-RH	AMP HML	4	560851	560852
C395	DRIVER'S COMPT.-B.U.MONITOR	AMP	8	------	561485
C396	DRIVER'S COMPT.-B.U.MONITOR	AMP	8	------	561485
C397	ENGINE COMPT.-CRANKS.ELEC.	DEUTSCH	2	562285	562284
C398	FR SECT.-LH-HAT RACK AMPL1	HDLEX	6	------	562464
C399	FR SECT.-LH-HAT RACK AMPL1	HDLEX	6	------	562465
C400	ENGINE COMPT.-BLOCK HEATER	PED WP	3	561783	561782
C401	FR SECT.-LH-HAT RACK AMPL1	HDLEX	6	------	562464
C402	RR DRIVE AXLE-AIR DRYER	PED WP	2	------	562251
C403	GALLEY FRIDGE-MOTOR	AMP HML	2	561248	561247
C404	FR JCT BDI COMPT.-WATI SKID	AMP HML	2	560908	560898
C405	FR JCT BDI COMPT.-WATI SKID	AMP HML	2	560908	560898
C408	ENGINE COMPT.-SIDING	PED WP	4	561626	561627
C409	ENGINE CPT.-LOW COOL.LEVEL	PED WP	2	562358	------
C410	FR JCT BDI-DIODE CONNECTOR	AMP HML	15	561787	561786
C411	FR JCT BDI-DIODE CONNECTOR	AMP HML	15	561787	561786
C412	LH SW.PANEL-MASTER SWITCH	SWF	8	------	561837
C413	ENG CPT-A/C HI UNLOAD RRS SW	PED WP	2	561566	561678
C414	FR SERVICE COMPT.	AMP HML	9	561678	561687
C415	ENGINE CMOOLE-FAN SIGNAL	PED WP	3	561781	561782
C416	ENGINE COMPT.-FAN SIGNAL	PED WP	3	561781	561782
C417	FRONT JCT BDI-CONN.PRESS.	AMP HML	15	561787	561786
C418	INSTR.PANEL LH-HTR WINDOW.SW	SWF	8	------	561037
C419	FR JCT BDI-FRONT DOOR JACOB	AMP HML	3	561667	561558
C420	ENGINE COMPT.-WEBASTO WATER-HTR	TC	2	561597	------
C421	ENGINE COMPT.-WEBASTO WATER-HTR	TC	1	561873	------
C422	ENGINE COMPT.-WEBASTO WATER-HTR	TC	2	561597	------
C423	LAVATORY-WATER CENTER	AMP HML	3	561667	561558
C424	FR JCT BDI-DIODES	AMP HML	15	561787	561786
C425	FR JCT BDI-DIOD