LAZER FORMAT A1 CUTE 1.2:

CONNECTORS CODE (C) Page G:1

No.	LOCATION	#@ TYPE	*PIN CAVITY	*SOCKET HOUSING	HOUSING
C1	FR JCT BOX COMPARTMENT	AMP CPC	37	560644	560646
C2	FR JCT BOX COMPARTMENT	AMP CPC	24	560641	560643
C3	FR JCT BOX COMPARTMENT	AMP CPC	37	560714	560713
C4	FR JCT BOX COMPARTMENT	AMP CPC	16	560493	560495
C5	FR SERVICE COMPT.-UNDERNEATH	AMP CPC	37	560644	560646
C6	FR SERVICE COMPT.-UNDERNEATH	AMP CPC	24	560641	560643
C7	FR SERVICE COMPT.-UNDERNEATH	AMP CPC	37	560714	560716
C8	FR SERVICE COMPT.-UNDERNEATH	AMP CPC	37	560714	560713
C9	ALARM JCT BOX	AMP CPC	37	560644	560646
C10	ALARM JCT BOX	AMP CPC	37	560644	560646
C11	FR SERVICE COMPARTMENT	AMP CPC	24	560642	560643
C12	FR SERVICE COMPARTMENT	AMP CPC	24	560641	560643
C13	LH CONSOLE-HEATER MDL	AMP HNL	2	561248	561247
C13	FR SERVICE COMPT.	AMP HNL	3	560552	560555
C13	LH CONSOLE-C.ETR.HORROR	AMP HNL	6	561552	561555
C14	UNDER DASH-LH HORROR	AMP HNL	9	560692	560698
C15	RR JCT BOX	AMP CPC	24	560641	560643
C16	UNDER DASH-RH HORROR	AMP HNL	9	560692	560662
C16	LH CONSOLE-S.W-CRUISE ON/OFF	SWF	8	------	561087
C17	LH CONSOLE-S.W-CRUISE RESUME	SWF	8	------	561087
C18	LH CONSOLE-S.W-CRUISE SET	SWF	8	------	561087
C20	RR JCT BOX	AMP CPC	37	560644	560646
C21	RR JCT BOX	AMP CPC	24	560641	560643
C26	HYD & HAN TRANSM.-NEUT.& R-U	PED WP	4	561610	561611
C27	HYD & HAN TRANSM.-SPEED SENS.	PED WP	2	561566	561690
C30	DOOC ENGINE-ECM	PED	30	------	561600
C35	RR JCT BOX	AMP CPC	37	560644	560646
C36	EMERGENCY-EXIT LTS	AMP HNL	2	561248	561247
C37	RR SECTION-LH HAT RACK	AMP HNL	9	560661	560662
C38	RR SECTION-RH HAT RACK	AMP HNL	9	560661	560662
C40	RR JCT BOX	AMP CPC	16	560493	560494
C41	LAVATORY-ROOF FLOOR/CEILING	AMP HNL	2	560908	560898
C42	LAVATORY-BACK WALL-WTR TANK	AMP HNL	2	560908	560898
C43	LAVATORY-BACK WALL-ACCESS.	AMP HNL	18	560666	560667
C45	ALARM JCT BOX COMPARTMENT	AMP CPC	24	560642	560643
C47	FR SERVICE COMPT.-UNDERNEATH	AMP CPC	37	560714	560716
C49	BATTERY CHG.-LH	AMP HNL	2	561248	561247
C50	FR SERVICE COMPT.-LOW BLOC	PED WP	11	560685	561517
C52	RR JCT BOX	AMP CPC	22	560718	560717
C53	RR JCT BOX	AMP CPC	14	560585	560584
C54	UNDER DASH-LH VNT	HNL	6	560552	560555
C55	UNDER DASH-RH SW PANEL	AMP CPC	9	560636	560637
C56	UNDER DASH-RH CONSOLE	AMP CPC	24	560642	560643
C57	UNDER DASH-RH ACCESSORIES	AMP CPC	22	560769	560718
C58	UNDER DASH-RH ACCESSORIES	AMP CPC	22	560769	560718
C59	EVAPORATOR COMPARTMENT	AMP HNL	2	560908	560898
C60	RR JCT BOX COMPT.-L/T	AMP HNL	2	561248	561247
C61	LUGGAGE COMPARTMENT-LTS	AMP HNL	2	561248	561247
C62	LUGGAGE COMPARTMENT-LTS	AMP HNL	2	561248	561247
C63	LUGGAGE COMPARTMENT-LTS	AMP HNL	2	561248	561247
C64	LUGGAGE COMPARTMENT-LTS	AMP HNL	2	561248	561247
C65	LUGGAGE COMPARTMENT-LTS	AMP HNL	2	561248	561247

CONNECTORS CODE (C) Page G:1

No.	LOCATION	#@ TYPE	*PIN CAVITY	*SOCKET HOUSING	HOUSING
C66	LUGGAGE COMPARTMENT-LTS	AMP HNL	2	561248	561247
C67	LUGGAGE COMPARTMENT-LTS	AMP HNL	2	561248	561247
C68	LUGGAGE COMPARTMENT-LTS	AMP HNL	2	561248	561247
C69	RH AXLE ACC-DIODE PVC END	PED WP	6	561568	561578
C70	ALARM JCT BOX COMPARTMENT	AMP CPC	24	560642	560643
C71	UNDER INSTRUMENT PANEL-LH	AMP CPC	37	560645	560646
C72	UNDER INSTRUMENT PANEL-CENT.	AMP CPC	37	560645	560646
C73	UNDER INSTRUMENT PANEL-CENT.	AMP CPC	16	560639	560640
C74	ALARM JCT BOX COMPARTMENT	AMP CPC	24	560642	560643
C75	ALARM JCT BOX COMPARTMENT	PED WP	4	561608	561611
C76	LUGGAGE COMPT.-AIR RET.SENS.	AMP HNL	2	561248	561247
C77	LUGGAGE COMPT.-AIR RET.SENS.	AMP HNL	2	561248	561247
C78	FR JCT BOX COMPARTMENT	PED WP	22	561709	561718
C79	FR SERVICE COMPT.-UNDERNEATH	AMP CPC	37	560644	560646
C80	LUGGAGE COMPT.-AIR RET.SENS.	AMP HNL	2	561248	561247
C81	PASSENGER COMPT.-HOLE L/T	AMP HNL	2	560908	560898
C82	ENTRANCE DOOR	HOLEX	6	562078	562069
C83	ENTRANCE DOOR-PRESSURE SW.	AMP HNL	2	561476	561476
C84	ENTRANCE DOOR-PRESSURE SW.	PED WP	2	561566	561690
C85	UNDER INSTRUMENT PANEL-LH	AMP HTA-100	8	------	562248
C86	RR END ROOF	AMP CPC	9	560636	560637
C87	RR END ROOF-CLEARANCE LTS	AMP HNL	2	560908	560898
C88	RR END ROOF-B.U.HORN/STAR	CONNINCE	3	562565	562680
C90	RR JCT BOX	AMP CPC	15	561987	561986
C91	RR JCT BOX	AMP CPC	37	560644	560646
C92	FR JCT BOX COMPT.-VNT1 SKID	AMP CPC	9	560635	560637
C93	FR JCT BOX COMPT.-VNT2 SKID	AMP CPC	9	560635	560637
C94	FR AXLE-ACCESSORIES	AMP HNL	14	560585	560585
C97	RH AXLE ACC-DIODE PVC END	PED WP	6	561568	561578
C98	FR SERVICE COMPT.-ELC.F.PEDAL	PED WP	3	561566	561690
C99	FR SERVICE COMPT.-LTS	AMP HNL	2	561248	561247
C100	FR SERVICE COMPT.-CONNECTING	AMP HNL	2	560908	560898
C101	FR SERVICE COMPT.-ELEC.HORNS	PED WP	2	561566	561690
C102	FR SERV.-RH WIPER PULSE	AMP FF	6	560186	560187
C103	FR SERV.& SERV.COMPARTMENTS	FFT SS	2	561813	561812
C104	FR SERVICE COMPT.-LTS.& HAL.HT	PED WP	2	561566	561690
C105	FR SERVICE COMPT.-LTS.& HAL.HT	PED WP	2	561566	561690
C106	FR SERVICE COMPT.-WATER VALVE	PED WP	2	561566	561690
C107	EVAPORATOR-TOP COMPT.-DAMPER	PED WP	2	561566	561690
C108	FR SERVICE COMPT.-KNEELSYS	PED WP	2	561566	561690
C109	FR SERVICE COMPT.-KNEELSYS	PED WP	2	561566	561690
C110	FR SERVICE COMPT.-KNEELSYS	PED WP	2	561566	561690
C111	EVAPORATOR COMPT.-DAMPER	FFT SS	2	561813	561812
C113	BATT.& RH JUEJOT.MARKER.L/T	FFT SS	2	561813	561812
C114	BATT.& RH JUEJOT.MARKER.L/T	FFT SS	2	561813	561812
C115	ENGINE COMPT.-LTS	PED WP	2	561566	561690
C116	ENGINE COMPT.-LTS	PED WP	2	561566	561690
C117	ENGINE COMPT.-LAVATORY FAN	TC	2	561938	562997
C118	ENGINE CPT RH DOOR-HL O LAMP	FED WP	6	561686	561687
C119	ENGINE CPT RH DOOR-LH L.O.LAMP	PED WP	6	561686	561687
C120	BATTERY CPT.-DOOR SW.L.T.RH	FFT SS	2	561813	561812
C121	ENGINE CPT-CHAMBER DOOR VALVE	PED WP	2	561566	561690
C124	ENGINE CPT-ETHER SW	PED WP	2	561566	561690

CONNECTORS CODE (C) Page G:2

No.	LOCATION	#@ TYPE	*PIN CAVITY	*SOCKET HOUSING	HOUSING
C125	ENGINE CPT-BU.U.ALARM	PED WP	2	561566	561690
C126	ENGINE CPT-FLUSHING PUMP	PED WP	2	561566	561690
C127	ENGINE CPT-FUEL FILTER	PED WP	2	561566	561690
C128	ENGINE CPT-U.K COMPUL.LOTH	FFT SS	2	561813	561812
C129	ENGINE CPT-RH WIPER	AMP FF	6	560186	560187
C130	ENGINE CPT-UN.DOOR	FFT SS	2	561813	561812
C131	ENGINE CPT-HL O.C.PRESS SW	PED WP	2	561566	561690
C132	ENGINE CPT-HL O.C.PRESS SW	PED WP	2	561566	561690
C133	ALARM JCT BOX COMPARTMENT	PED WP	4	561608	561611
C136	FR JCT BOX-LUGGAGE DOOR CON.	AMP HNL	15	561987	561986
C137	RH JCT BOX	AMP CPC	37	560644	560646
C138	H.C JCT BOX-TRANSMITTER	AMP HNL	2	560908	560898
C139	H.C JCT BOX-L.DOOR MODULE	AMP HDP-20	15	562811	------
C140	H.C JCT BOX-L.DOOR MODULE	AMP HNL	2	561248	561247
C143	LAVATORY-DOOR WALL	AMP HNL	3	560908	560886
C144	ENGINE CPT-HOD.LAMP-L.T.L	AMP HNL	6	561476	561476
C203	RH HAT RACK-BALLAST	AMP HNL	9	560661	560662
C204	RH HAT RACK-GENERAL L.T	AMP HNL	9	560667	560662
C205	FR SECT.-RH HAT RACK SPEAKER	AMP HNL	9	560661	560662
C206	RH HAT RACK-READING L.T	AMP HNL	2	560908	560898
C207	RH HAT RACK-READING L.T	AMP HNL	2	560908	560898
C208	LH HAT RACK-BALLAST	AMP HNL	4	560851	560852
C210	FR SECT.-LH HAT RACK SPEAKER	AMP HNL	9	560661	560662
C211	FR ROOF-STORE LH	AMP HNL	2	560908	560898
C212	FR ROOF-STORE LH	AMP HNL	2	560908	560898
C213	FR ROOF-CLEARANCE L.T	AMP HNL	2	560908	560898
C216	UNDER DASH-LH P.A.	AMP HNL	9	560636	560637
C217	UNDER DASH-LH P.A.	HNL	3	------	561552
C218	UNDER DASH-LH P.A.	AMP HNL	3	------	561552
C219	UNDER DASH-LH P.A.	AMP HNL	3	------	561552
C220	INJECT.-FUEL PRIME PUMP	TC	1	561878	561873
C222	ALARM JCT BOX-CPT.-DRS.SW.	HDLEX	4	561477	561476
C223	ALARM JCT BOX-CPT.-DRS.SW.	AMP HNL	4	560851	560852
C224	FR SERV.& SERV.COMPARTMENTS	FFT SS	2	561813	561812
C227	RH SW.PANEL-SPEAKER	AMP HNL	9	560661	560662
C228	RH SW.PANEL-HIGRO.OUTLET	HDLEX	4	561477	561476
C229	RH SW.PANEL-PA W.MIC	HDLEX	4	561477	561476
C230	ENGCPT.-FUEL PRIME PUMP FEED	DEUTSCH	2	562498	562495
C231	ENGCPT.-FUEL PRIME PUMP	PED WP	2	561566	561690
C232	ENGCPT.-FUEL PRIME PUMP	PED WP	2	561566	561690
C233	INSTRUMENT PANEL-WATER	VJOL	8	------	560643
C234	INSTRUMENT PANEL-CENTER	VJOL	4	------	562844
C235	INSTRUMENT PANEL-CENTER	VJOL	4	------	562844
C236	INSTRUMENT PANEL-CENTER	AMP HNL	2	560908	560892
C237	UNDER DASH-LH-JACOB CLUTCH SW	FFT SS	3	561111	561080
C238	H.C JCT BOX-DOOR CONNECTOR	AMP HNL	9	560678	560669
C239	FR SERVICE CPT-HI BUZZ VALVE	PED WP	2	561566	561690
C240	FR SERVICE CPT-KNEEL PRSS SW	PED WP	2	561566	561690
C241	FR SERVICE CPT-FOG RESISTOR	AMP CPC	3	561847	561862
C242	FR SERVICE CPT-HEADLAMPS	TC	1	561878	561873
C243	FR SERVICE CPT-HEADLAMPS	TC	1	561878	561873
C244	FR SERVICE CPT-RH FOG LAMP	FFT SS	2	561813	561812
C245	FR SERVICE CPT-RH FOG LAMP	FFT SS	2	561813	561812
C246	FR SERVICE CPT-HARN.& DIR.L.T	FFT SS	3	561111	561080
C248	ALARM JCT BOX-WIPER PULSE GEN	AMP FF	6	560186	560187
C249	ALARM JCT BOX-CONV.12V TO 5V	AMP HNL	3	561667	561550

CONNECTORS CODE (C) Page G:3

No.	LOCATION	#@ TYPE	*PIN CAVITY	*SOCKET HOUSING	HOUSING
C250	ALARM JCT BOX-DASH L.TS REGUL.	AMP HNL	6	561552	561515
C251	LH SW.PANEL-F.VENT IDLE	SWF	8	------	561087
C252	LH SW.PANEL-SWITCH L.T	SWF	2	------	561837
C253	LH SW.PANEL-ETHER	SWF	8	------	561087
C254	INST.PANEL-RH ENTR.DOOR SW.	TORRIT	5	------	562110
C255	LH SW.PANEL-DOOR L.T	SWF	2	------	561837
C257	INSTRUMENT PANEL-CENT-SPEEDO	AMP HNL	4	560851	560852 PRIOR REV. B18
C258	INSTRUMENT PANEL-CENT-SW.T	AMP HNL	2	------	562363
C258	LH SW.PANEL-HOLT.FUNC.SW	AMP FF	8	561088	------
C259	LH SW.PANEL-HOLT.FUNC.SW	AMP FF	8	561088	------
C264	FR SERVICE CPT-LUG.DOOR L.T	PED WP	4	561686	561687
C265	UNDER DASH-RH DOOR MODULE	AMP HNL	9	560678	560669
C266	UNDER DASH-RH DOOR MODULE	AMP HNL	9	560678	560669
C267	ENGINE CPT-A/C COMPRESSOR	PED WP	4	561889	561892
C268	ENGINE CPT-COMPRESSOR	AMP HNL	2	560908	560898
C269	ENGINE CPT RH DOOR-LICENCE L.T	DOH-AUTO	2	930210	------
C270	RH HAT RACK-FLUORESCENT	AMP HNL	4	560851	560852
C271	RH HAT RACK-FLUORESCENT	AMP HNL	4	560851	560852
C272	RH HAT RACK-BALLAST	AMP HNL	4	560851	560852
C273	RH HAT RACK-BALLAST	AMP HNL	4	560851	560852
C274	RH HAT RACK-GENERAL L.T	AMP HNL	9	560667	560662
C275	RH HAT RACK-SPEAKER	AMP HNL	9	560661	560662
C276	RH HAT RACK-READING L.T	AMP HNL	2	560908	560898
C277	RH HAT RACK-READING L.T	AMP HNL	2	560908	560898
C278	LH HAT RACK-BALLAST	AMP HNL	4	560851	560852
C279	FR SECT.-LH HAT RACK SPEAKER	AMP HNL	9	560661	560662
C280	FR ROOF-STORE LH	AMP HNL	2	560908	560898
C281	FR ROOF-STORE LH	AMP HNL	2	560908	560898
C282	FR ROOF-CLEARANCE L.T	AMP HNL	2	560908	560898
C283	EVAPORATOR-CPT-WATER PUMP	PED WP	2	561566	561690
C284	EVAPORATOR-CPT-A/C.& HT.SW	PED WP	2	561566	561690
C285	EVAPORATOR-CPT-A/C.& HT.SW	PED WP	2	561566	561690
C286	EVAPORATOR-CPT-WATER PUMP	PED WP	2	561566	561690
C287	EVAPORATOR-CPT-A/C.& HT.SW	PED WP	2	561566	561690
C288	EVAPORATOR-CPT-A/C.& HT.SW	PED WP	2	561566	561690
C289	CONDENSER CPT-A/C.& HT.TEMP.	PED WP	2	561566	561690
C290	CONDENSER CPT-A/C.& HT.TEMP.	PED WP	2	561566	561690
C291	RH AXLE-ABS RH VALVE	W48CD	3	------	641098
C292	RH AXLE-ABS RH VALVE	W48CD	3	------	641098
C293	RH AXLE-ABS LH VALVE	W48CD	3	------	641098
C294	RH AXLE-ABS LH VALVE	W48CD	3	------	641098
C295	RH AXLE-ABS RH SENSOR	W48CD	3	641132	------
C296	RH AXLE-ABS RH VALVE	W48CD	3	------	641098
C297	RH AXLE-ABS LH VALVE	W48CD	3	------	641098
C298	RH AXLE-ABS RH VALVE	W48CD	3	------	641098
C299	FR SERVICE CPT-PA W.MIC	HDLEX	4	561477	561476
C300	ENGCPT.-FUEL PRIME PUMP FEED	DEUTSCH	2	562498	562495
C301	ENGCPT.-FUEL PRIME PUMP	PED WP	2	561566	561690
C302	ENGCPT.-FUEL PRIME PUMP	PED WP	2	561566	561690
C303	INSTRUMENT PANEL-CENTER	VJOL	4	------	562844
C304	INSTRUMENT PANEL-CENTER	VJOL	4	------	562844
C305	INSTRUMENT PANEL-CENTER	AMP HNL	2	560908	560892
C306	LH CONSOLE-S.W-KNEELING	SWF	8	------	561087
C307	LH CONSOLE-S.W-SPARE	SWF	8	------	561087
C308	LH CONSOLE-S.W-SPARE	SWF	8	------	561087
C309	LH CONSOLE-S.W-SPARE	SWF	8	------	561087
C310	LH CONSOLE-S.W-CRUISE ON/OFF	SWF	8	------	561087
C311	LH CONSOLE-S.W-CRUISE RESUME	SWF	8	------	561087
C312	LH CONSOLE-S.W-CRUISE SET	SWF	8	------	561087
C313	LH CONSOLE-S.W-SPARE	SWF	8	------	561087
C314	LH CONSOLE-S.W-SPARE	SWF	8	------	561087
C315	LH CONSOLE-S.W-KNEELING	SWF	8	------	561087
C316	LH CONSOLE-S.W-SPARE	SWF	8	------	561087
C317	LH CONSOLE-CPT-RR START SW.BOX	DEUTSCH	5	562565	562566
C318	LALLEY-LAMP	AMP HNL	2	562248	562141
C319	ENGINE TACHO SIGNAL	AMP FF	3	561786	561789
C320	LH SW.PANEL-DOOR L.T	SWF	2	------	561837
C321	LH SW.PANEL-HORDWARE SW.L.T	SWF	2	------	561837
C330	GALLEY-RH CONTAINER SW.L.T	SWF	2	------	561837
C331	GALLEY-RH CONTAINER SW	SWF	8	------	561087
C332	GALLEY-RH CONTAINER SW.L.T	SWF	2	------	561837
C333	GALLEY-LH CONTAINER SW.L.T	SWF	2	------	561837
C334	GALLEY-LH CONTAINER SW.L.T	SWF	2	------	561837
C337	INSTR.PANEL-LH-UP WOFER SW	SWF	8	------	561087
C338	INSTR.PANEL-LH-UP WOFER SW	SWF	8	------	561087
C339	INSTR.PANEL-LH-UP WASHER SW	SWF	8	------	561087
C340	INSTR.PANEL-LH-HEAT MIRROR	SWF	8	------	561087
C341	INSTR.PANEL-LH-HEAT MIRROR SW	SWF	8	------	561087
C342	INSTR.PANEL-LH-HAZARD L.T SW	SWF	2	------	561837
C344	INSTR.PANEL-LH-HAZARD L.T SW	SWF	2	------	561837
C345	INSTR.PANEL-LH-SWITCH L.T	SWF	2	------	561837
C346	INSTR.PANEL-LH-SWITCH L.T	SWF	2	------	561837
C347	INSTR.PANEL-LH-SWITCH L.T	SWF	2	------	561837
C348	INSTR.PANEL-LH-SWITCH L.T	SWF	2	560920	560918
C349	INSTR.PANEL-EXT-HORN-DOOLE	AMP HNL	3	561667	561550
C350	RH CONSOLE-RED LED HTR	AMP HNL	15	561987	561986
C351	LH HAT RACK-THERMOSTER	AMP HNL	3	561667	561550
C351	LH HAT RACK-FLUOR DISP.	HDLEX	4	561477	561476
C352	RH CONSOLE-LH-HORN TEMP.CONTROL	SWF	8	------	561087
C353	INSTR.PANEL-RH-DRV FAN INHEIST	AMP HNL	6	561552	561515
C354	INSTR.PANEL-RH-DRV FAN INHEIST	AMP HNL	6	561552	561515
C355	INSTR.PANEL-RH-WATER TEMP CTR	AMP HNL	3	561667	561550
C357	INSTR.PANEL-RH-WATER TEMP SW	AMP HNL	3	561667	561550
C358	INSTR.PANEL-RH-CONSOLE SYST.	AMP HNL	3	561667	561550
C359	INSTR.PANEL-CENT-TAC.& SPD.L.T	AMP HNL	2	560908	560898 PRIOR R.B18
C361	FR ROOF-WIPER MOTOR	SWF	2	------	561837
C362	FR ROOF-LAVATORY OCCUPIED L.T	AMP HNL	2	562148	562147
C363	FR ROOF-WATER LEVEL L.T	AMP HNL	2	562148	562147
C364	FR ROOF-DESTINATION SIGN	AMP HNL	3	561667	561558
C365	FR ROOF-DESTINATION SIGN	AMP HNL	3	561667	561558
C366	DIVERTER-CAMERA SW.L.T	AMP HNL	4	561476	562147
C367	ENGINE COMPT-EGF COL.T SENSOR	PED WP	2	561566	561690
C368	ENGINE COMPT-EGF COL.T SENSOR	PED WP	2	561566	561690
C369	LH CONSOLE-SW.RHEOSTAT	TC	2	562380	562997
C370	FR ROOF-DEST.SIGN FLUOR.	AMP HNL	2	560920	560918
C371	FR ROOF-DEST.SIGN FLUOR.	AMP HNL	2	560920	560918
C372	FR ROOF-DEST.SIGN SPEED SW.	HDLEX	4	561477	561476
C374	ALARM JCT BOX COMPT-MASTER SW.AMP	HNL	6	561552	561515
C375	ALARM JCT BOX COMPT-MASTER SW.AMP	HNL	6	561552	561515
C376	ALARM JCT BOX COMPT-LH-PARKING	HDLEX	4	561714	562505
C377	LH SW.PANEL-STOP ENGLEVERDE SWF	8	------	561087
C381	LH CONSOLE-CPT-DIVERTER	DEUTSCH	5	562260	------
C383	ALARM JCB.CPT.-MIC W/O WIRE DEUTSCH	6	562240	562247
C385	FR.SERV.COMPT-UNDERNEATH(C)	AMP HNL	9	560661	560662
C386	LH CONSOLE-MCL POWER SYSTEM	SWF	8	------	561087
C387	RH JCT BOX-VCL	AMP HNL	9	560661	560662

CONNECTORS CODE (C) Page G:2

No.	LOCATION	#@ TYPE	*PIN CAVITY	*SOCKET HOUSING	HOUSING
C388	RR JCT BOX-VCL	AMP HNL	12	561735	561734
C389	WCL REAR DOOR	HOLEX	4	561477	561476
C390	LAVATORY WALL-WCL REMOTE CTR	SWF	8	------	561087
C391	LAVATORY-WALL-WCL LAMP	SWF	8	------	561087
C392	LAVATORY-WCL WL SW.L.T	AMP HNL	2	560835	------
C393	LAVATORY-WALL-WCL REMOTE SYS.	AMP CPC	4	561686	561687
C394	UNDER INSTRUMENT PANEL-LH	AMP HNL	4	560851	560852
C395	DRIVER'S COMPT.-B.U.HORN	AMP HNL	2	------	562573
C396	FR SERV.COMPT-CHAMBER DOOR	PED WP	2	561566	561690
C397	ENGINE COMPT.-CHAN.L.ALARM	PED WP	2	561566	561690
C398	FR SECT.-LH HAT RACK-AMPL1	HDLEX	6	------	562464
C399	FR SECT.-LH HAT RACK-AMPL1	HDLEX	6	------	562464
C400	ENGINE COMPT.-BLOCK HEATER	PED WP	3	561780	561782
C401	FR SECT.-LH HAT RACK-AMPL1	HDLEX	6	------	562464
C402	RR DRIVE AXLE-AIR DRYER	PED WP	2	------	562251
C403	GALLEY-TRANS.MODULE	AMP HNL	2	562248	562147
C406	FR JCT BOX COMPT.-VNT1-SKID	AMP HNL	2	560908	560898
C407	FR JCT BOX COMPT.-VNT2	AMP HNL	2	560908	560898
C408	ENGINE COMPT.-SIGNAL	PED WP	4	561686	561687
C409	ENGINE CPT.-LOW COOL.LEVEL	PED WP	2	------	562350
C410	FR JCT BOX-DOOR CONNECTOR	AMP HNL	15	561987	561986
C411	FR JCT BOX-DOOR CONNECTOR	AMP HNL	15	561987	561986
C412	LH SW.PANEL-MASTER SWITCH	SWF	8	------	561087
C413	ENG.CPT-A/C HI UNLOAD.PRS SW	PED WP	2	561566	561690
C414	RR JCT BOX	AMP HNL	9	560678	560669
C415	ENGINE CNOOLE-FAN SIGNAL	AMP FF	3	561781	561782
C416	ENGINE CNOOLE-FAN SIGNAL	AMP FF	3	561781	561782
C417	FRONT JCT BOX-DIODES	AMP HNL	15	561987	561986
C418	INSTR.PANEL-LH-HTR WINDPISLEW	SWF	8	------	561087
C419	FR JCT BOX-DOOR CONNECTOR JUCJOB	AMP HNL	3	561667	561558
C420	ENGINE COMPT.-WEBASTO WATER HTR	TC	2	561597	------
C421	ENGINE COMPT.-WEBASTO WATER HTR	TC	2	561597	------
C422	ENGINE COMPT.-WEBASTO WATER HTR	TC	2	561597	------
C423	UNDER DASH-CENTER CENTER-AMP	HNL	3	561667	561558
C425	ALARM JCT BOX-DIODES	AMP HNL	15	561987	561986
C426	ALARM JCT BOX-DIODES	AMP HNL	15	561987	561986
C427	ALARM JCT BOX-DIODES	AMP HNL	4	560852	560853
C430	ALARM JCT BOX COMPT.-TIMER	AMP FF	8	561088	561363
C431	ALARM JCT.BOX COMPT.-PRE.WL.TAB	AMP HNL	2	561248	561529
C432	ENGINE CPT.-PROV.SW.DOOR AJAR	DEUTSCH	4	562479	562477
C433	ALARM JCT BOX-PRESS.DO.PRE.W	AMP HNL	2	561248	561529
C434	FRONT JCT.BOX-DIODES	AMP HNL	15	561987	561986
C435	FR SERV.COMPT-CHAMBER DOOR	PED WP	2	561566	561690
C436	RH HAT RACK-WCL CENTER ROOF ACC	AMP CPC	24	560639	560640
C437	RH HAT RACK-WCL CENTER ROOF ACC	AMP CPC	24	560639	560640
C438	GRAPHIC CPT-WCL-LH-PANEL	AMP HNL	2	561248	561529
C439	WIRELESS MICRO-FIRST CPT BAG	HOLEX	2	562558	562549
C440	UNDER DASH-DIOD PANEL	HOLEX	2	562558	562549
C441	SOUND SYS.JCT.PANEL-VCP	PED WP	2	561566	561690
C442	SOUND SYS.JCT.PANEL-FTL.T.VCP	PED WP	2	561566	561690
C443	WIRELESS MICRO-LH HAT-RACK	CINCH	2	562554	562555
C444	FR JCT BOX-DOOR CONNECTOR	AMP HNL	2	------	562427
C447	WORLD TRANSM.-MAIN CONNECTOR	DEUTSCH	31	562572	562536
C448	WORLD TRANSM.-ENGINE SPEEDSNL	HDP-20	15	562811	------
C449	WORLD TRANSM.-ENGINE SPEEDSNL	HDP-20	15	562811	------
C450	WORLD TRANSM.-SPEED SENSOR	FFT	2	------	562541
C451	WORLD TRANSM.-RETARDER TEMP.	PED WP	2	561566	561690

CONNECTORS CODE (C) Page G:2

No.	LOCATION	#@ TYPE	*PIN CAVITY	*SOCKET HOUSING	HOUSING
C452	WORLD TRANSM.-RETARD SOL.N	PED WP	2	------	562426
C453	WORLD TRANSM.-SENSOR CONN.	DEUTSCH	31	562572	562571
C454	RH JCT BOX-DOO CONN.W.T.	PED WP	12	------	562574
C455	LH CONSOLE-SW.RHEOSTAT	TC	2	562380	562429
C456	FR SERVICE CPT.-PRESS.HOOL	PED WP	3	------	562428
C457	FR SERVICE CPT.-