RESISTORS LIST

No	Location	Part #	Function	Page					
Res1	Front_Service_Pane	563593	TPMS	39.1					
Res2	Dashboard	563205	PullDownResistor	18.1					
Res3	RJB	563593	EndoflineresistanceBBUSnetwork120ohms4W	6.1					
Res4	FJB	563593	EndoflineresistanceBBUS1	6.1					
Res6	FJB	563593	EndoflineresistanceDBUSnetwork120ohms4W	6.2					
Res7	FJB	563593	EndoflineresistanceDBUSnetwork120ohms4W	6.2					
Res8	ParcelRack	563205	PullDownPrackFan	18.3					
Res9	Dashboard	563205	PullDownResistor	18.1					
Res10	Dashboard	563205	PullDownResistor	18.1					
Res11	RJB	563205	PullDownRes	4.2					
Res12	Dashboard	562498	ReduceMirrorSpeedResistor	31.1					
Res13	Dashboard	562498	ReduceMirrorSpeedResistor	31.1					
Res14	RJB	563205	Evaporatorfans620ohms2W	18.2					
Res15	Engine_Cmpt	563587	EndoflineresistanceFlamedetec.device10kohms	38.1					
Res16	FJB	563593	EndoflineresistanceDBUSnetwork120ohms4W	6.1					
Res17	FJB	563593	EndoflineresistanceDBUSnetwork120ohms4W	6.1					
Res21	RJB	563205	RJBcompartementlights620ohms2W	25.1					
Res22	RJB	563205	Luggagecmpt.lighting620ohms2W	25.1					
Res31	Cmpt_fuel_tank	41123	Ureatankheatingelement(Heatedhose)	14.2					
Res32	Cmpt_fuel_tank	41123	Ureatankheatingelement(Heatedhose)	14.2					
Res53	FJB	563593	EndoflineresistanceDBUSnetwork120ohms4W	6.2					
Res99	Dashboard	563593	CANNetwork	42.4					