SOUND DISTRIBUTION

A64
CD_Changer
Right_Channel
Left_Channel
Audio_Common
Shield
Cchgr
10 11 12 9
Ana−Chgr_R−18
Ana−Chgr_L−18
Ana−Chgr_C−18
gnd−SHLD−18
C
16 13 19 17

A63
H1_VR−300
Cd_Chgr_Right_Channel
Cd_Chgr_Left_Channel
Cd_Chgr_Audio_Common
Cd_Chgr_Shield
L_AUX_IN
AUX_COM
R_AUX_IN
AUX_ON_OFF
RR_+_Speaker
RR_−_Speaker
LR_+_Speaker
LR_−_Speaker
Line_Out_RR+
Line_Out_RR−
Line_Out_LR+
Line_Out_LR−
B
1 2 7 8
Ana−R_DRIVER−24
Ana−R_DRIVER−24
Ana−L_DRIVER−24
Ana−L_DRIVER−24
C764:1
C764:2
C765:1
C765:2
D
3 4 7 8
Ana−H1_R+−24
Ana−H1_R−−24
Ana−H1_L+−24
Ana−H1_L−−24

A67
VSS_03
VSE
10 1
Radio_H1_R+
Radio_H1_R−
VSD
24 16
Radio_H1_L+
Radio_H1_L−
VSD
8 17 1
Vhs_R+
Vhs_Gnd
Vhs_L+
VSB
4 22 12 3 21 11 20 10
Rear_Right_Signal+_To_Va400
Rear_Right_Signal−_ToVa400
Rear_Left_Signal+_To_Va400
Rear_Left_Signal−_To_Va400
Front_Right_Signal+_To_Va400
Front_Right_Signal−To_Va400
Front_Left_Signal+_To_Va400
Front_Left_Signal−_To_Va400
Ana−RR+−24
Ana−RR−−24
Ana−LR+−24
Ana−LR−−24
Ana−RF+−24
Ana−RF−−24
Ana−LF+−24
Ana−LF−−24

A39
Ampli_VA_400
P101
10 11 14 13 16 17 15 18
Input_RR+
Input_RR−
Input_LR+
Input_LR−
Input_RF+
Input_RF−
Input_LF+
Input_LF−
Output_RR_+
Output_RR_−
Output_LR_+
Output_LR_−
Sub_1_+
Sub_1_−
Sub_2_+
Sub_2_−
4 1 6 5 3 2 9 8
Ana−RR+−16
Ana−RR−−16
Ana−LR+−16
Ana−LR−−16
Ana−Sub1+−14
Ana−Sub1−−14
Ana−Sub2+−14
Ana−Sub2−−14
C766:1
C766:2
C766:3
C766:4
35.2_Speakers_Arrangement:1 B
35.2_Speakers_Arrangement:1 B
35.2_Speakers_Arrangement:1 A
35.2_Speakers_Arrangement:1 A
35.2_Speakers_Arrangement:4 G
35.2_Speakers_Arrangement:4 G
35.2_Speakers_Arrangement:4 F
35.2_Speakers_Arrangement:4 F
P901
Output_RF_+
Output_RF_−
Output_LF_+
Output_LF_−
4 1 5 6
Ana−RF+−16
Ana−RF−−16
Ana−LF+−16
Ana−LF−−16
C766:5
C766:6
C766:7
C766:8
35.2_Speakers_Arrangement:1 E
35.2_Speakers_Arrangement:1 E
35.2_Speakers_Arrangement:1 F
35.2_Speakers_Arrangement:1 F

VSA
Driver_Speaker_R+
Driver_Speaker_R−
Driver_Speaker_L+
Driver_Speaker_L−
3 2 4 5
CVSA:1
CVSA:2
CVSA:3
CVSA:4
Ana−DSR+++−18
Ana−DSR−−−−18
Ana−DSL+++−18
Ana−DSL−−−−18
35.2_Speakers_Arrangement:1 G
35.2_Speakers_Arrangement:1 G
35.2_Speakers_Arrangement:1 G
35.2_Speakers_Arrangement:1 G

Open CVSA circuit with GPS option
Ana−DSR+++−18
Ana−DSR−−−−18
Ana−DSL+++−18
Ana−DSL−−−−18
35.4_Navigation_System:3 D
35.4_Navigation_System:3 D
35.4_Navigation_System:3 D
35.4_Navigation_System:3 D
Ana−DSR+++−18
Ana−DSR−−−−18
Ana−DSL+++−18
Ana−DSL−−−−18
35.4_Navigation_System:3 D
35.4_Navigation_System:3 D
35.4_Navigation_System:3 D
35.4_Navigation_System:3 D

A60
Dvd 1
Audio_Out_R
Gnd_Audio_R
Gnd_Audio_L
Audio_Out_L
D 1 2
C 2 1
Ana−DVD1_R+−24
Ana−DVD1_Gnd−24
Ana−DVD1_L+−24
C750:1
C750:2
C751:1
C751:2
Ana−H2_R+−24
Ana−H2_R−−24
Ana−H2_L+−24
Ana−H2_L−−24
14 22 5
Dvd1_R+
Dvd1_Gnd
Dvd1_L+
7 23 15 6
Radio_H2_R+
Radio_H2_R−
Radio_H2_L+
Radio_H2_L−

A68
Add.Radio (H2)
RR_+_Speaker
RR_−_Speaker
RF_+_Speaker
RF_−_Speaker
B 1 2 3 4
Ana−H2_R+−24
Ana−H2_R−−24
Ana−H2_L+−24
Ana−H2_L−−24

Add.Radio (Cd1)
RR_+_Speaker
RR_−_Speaker
RF_+_Speaker
RF_−_Speaker
B 1 2 3 4
Ana−Cd1_R+−24
Ana−Cd1_Gnd−24
Ana−Cd1_L+−24
Ana−Cd1_Gnd−24
C752:1
C752:2
C753:1
C753:2

Add.Radio (Cd2)
RR_+_Speaker
RR_−_Speaker
RF_+_Speaker
RF_−_Speaker
B 1 2 3 4
Ana−Cd2_R+−24
Ana−Cd2_Gnd−24
Ana−Cd2_L+−24
Ana−Cd2_Gnd−24
C754:1
C754:2
C755:1
C755:2

Add.Radio (Cd3)
RR_+_Speaker
RR_−_Speaker
RF_+_Speaker
RF_−_Speaker
B 1 2 3 4
Ana−CD3_R+−24
Ana−CD3_Gnd−24
Ana−CD3_L+−24
Ana−CD3_Gnd−24
C762:1
C762:2
C763:1
C763:2

A71
Dvd 2
OR TV SAT
Audio_Out_R
Gnd_Audio_R
Gnd_Audio_L
Audio_Out_L
D 1 2
C 2 1
Ana−Dvd2_R+−24
Ana−Dvd2_Gnd−24
Ana−Dvd2_Gnd−24
Ana−Dvd2_L+−24

Ana−Cd1_Gnd−24
Ana−Cd1_R+−24
Ana−Cd1_Gnd−24
Ana−Cd1_L+−24
Ana−Cd2_Gnd−24
Ana−Cd2_R+−24
Ana−Cd2_Gnd−24
Ana−Cd2_Gnd−24
Ana−Cd2_L+−24
Ana−CD3_Gnd−24
Ana−CD3_R+−24
Ana−CD3_Gnd−24
Ana−CD3_L+−24
Ana−Dvd2_Gnd−24
19 3 10 9 18 2 21 13 12
Cd1_R+
Cd1_Gnd
Cd1_L+
Cd2_R+
Cd2_Gnd
Cd2_L+
Cd3_R+
Cd3_Gnd
Cd3_L+
Dvd2_R+
Dvd2_Gnd
Dvd2_L+

JACK_1
Ana−RED−20
Ana−SHIELD−20
Ana−WHITE−20
VSE 14 Hos
VSC
Ana−Aux1_R+−24
Ana−Aux1_Gnd−24
Ana−Aux1_L+−24
12 17 6
Aux1_R+
Aux1_Signal_Gnd
Aux1_L+
Ana−Aux2_Gnd−24
Ana−Aux_R+−24
Ana−Aux2_L+−24
11 16 5
Aux2_R_+
Aux2_Signal_Gnd
Aux2_L+
RED1 3
BLK1 14
RED2 8
BLK2 2
Driver_Mic+
Driver_Mic−
Guide_Mic+
Guide_Mic−
VSE
WHT1 5
WHT2 4
Driver_Mic
Guide_Mic
Contol_Guide_Mic_Gnd
Control_Driver_Mic_Gnd
VSE 15 16
GRN2
GRN1

22.1_IntLts_Reading_lamps_Chimes:3 B
35.0_SS_Pwr_Distribution:3 F
HOSTESS
SHD2
C758:1
C758:2
C759:1
C759:2
C760:1
C760:2
C761:1
C761:2

A61
WIRELESS RECEIVER
GRN2
WHT2
BLK2
RED2
SHD2
2 3 4 5
SIGNAL−
SIGNAL+
AUDIO−
AUDIO+

L.H.MODESTY PANEL
C564:4
C564:1
C564:3
C564:2
Micro

R.H.MODESTY PANEL
C465:4
C465:1
C465:3
C465:2
C465:5
C39:4
C39:1
C39:3
C39:2
Micro

GUIDE
SPARE
C564−Sp:4
C564−Sp:1
C564−Sp:3
C564−Sp:2
Micro

R.H.CONSOLE
C558:4
C558:1
C558:3
C558:2
Micro

L.H.CONSOLE
C567:4
C567:1
C567:3
C567:2
Micro

DRIVER
BOOM
C566:4
C566:1
C566:3
C566:2
Micro

REVOST®
WIRING DIAGRAM
Rev:22
Page:35.1
No:D061020