FROM DVD (VIDEO OUT) SEE P.20.8, 20.9
FRON RELAY RCA (VIDEO OUT) SEE P.20.10

WITH DVD ONLY

VIDEO DISTRIBUTION AMPLIFIER (VDA)

VCP AUDIO OUT TO SEAT AUDIO SYSTEM SEE P 20.7

12V POWER FROM DR'S LTS SW. SEE P. 11.3

FROM DR'S LTS SW. SEE P. 11.3

VCP SWITCH

VCP 9 7 3 2B 1 6 5B 4 8 10

12-39-16

YEL ORA BLK

0-011-18

FROM CONTROL HEAD CONNECTION VCP #18 SEE P 20.1

C562 12C

C562 9C

TAB

OUT

VIDEO MODULE

VCPA VCPB

C562 9C

C562 9C

C5 RED A16 SHLD A8 WTH CLR C11 GRN C12 WHT C9 BLU C14 BRN C13 RED C10 BLK

C562 10 6 11 3 2 4 7 8 1

(VCP A) VIDEO CASSETTE PLAYER

AUDIO OUT VIDEO OUT AUDIO IN VIDEO IN POWER IN

C5 RED A16 SHLD A8 WTH CLR C11 GRN C12 WHT C9 BLU C14 BRN C13 RED C10 BLK

C562 10 6 11 3 2 4 7 8 1

(VCP B) VIDEO CASSETTE PLAYER

AUDIO OUT VIDEO OUT AUDIO IN VIDEO IN POWER IN

C579 4 2

+24V GND

(WITH DVD PLAYER)

FROM DVD PLAYER SEE P 20.8

FROM AUDIO OUT DVD

0-0S3-16

24-24S3-16

C579 2 4

C295 2 1

C285 16 17

RH MONITOR 4

RH MONITOR 2

CENTRAL MONITOR 1

LH MONITOR 3

LH MONITOR 5

RED BLK

C292 4 2 1

C284 B C A

24-24S3-16 0-0S3-16 24-24SI-16

0-0S3-16

24-24S3-16

24V BATTERY POWER FROM SOUND SYS. JCT. PANEL BREAKER CB96 SEE P 20.1

BATTERY GROUND FROM SOUND SYS. JCT. PANEL OSS JCT BLOCK SEE P 20.1

CONTROL HEAD SIGNAL FROM CONTROL HEAD SEE P 20.1

RED BLK

VIDEO FILTER

C454 B A

24-24S4-12

30 86 87A 87 85

R66

SPARE WIRE AMPLI PANEL

C453 B A

0-0S3-12 24-24S3-12

24-24SI-16

TO FRONT CAMERA SEE P. 20.9, 20.10

VIDEO SYSTEM 2 VCP