CIRCUIT NUMBER CODE — Page E : 1

No.	SYSTEM
0	GRD BATTERY 1 TO BATTERY 2
0	GRD BATTERY 1 TO GRD STUD
0	GRD STARTER MOTOR TO GRD STUD
0	FJP - INSIDE GRD
0	RJB - INSIDE GRD
0	ATECI TEST SW GRD
0A	A/C - A/C JCT BOX GRD
0A	FJP - GRD
0A	RJB - GRD
0AA	VOLTAGE REGULATOR GRD
0B	FJP - GRD
0B	RJB - GRD
0BE	0V BATTERY MONITOR
0C	FJP - GRD
0C	RJB - GRD
0D	FJP - GRD
0D	RJB - GRD
0E	FJP - GRD
0E	RJB - GRD
0G	FJP - GRD
0J	FJP - GRD
0P	RJB - GRD
0S	FJB - SUN VISOR GRD
0T	RJB - UNLOAD TAG GRD
0U	FR SERVICE CPT-GRD
0VA	GRD BATTERY 2 TO BAT.EQUALIZER
0W	FJP - GRD
0W	WORLD TRANSM. VIM CHASSIS GRD
0WA	PRE-HEAT WATER HEATER
0WB	PRE-HEAT WATER HEATER
0X	DDEC II-COOLANT MODULE GRD
0Y	ABS SYSTEM-GRD
0Y1	ABS SYSTEM-GRD
0Z	DDEC II-COOLANT MODULE GRD
0D	BATTERY GRD
2	A/C & HEAT SYSTEM-CONSENSER
2A	A/C & HEAT SYSTEM-CONSENSER
2D	A/C & HEAT SYSTEM-CONSENSER
3	A/C & HEAT SYSTEM-EVAPORATOR
3	A/C & HEAT SYSTEM-CLUTCH SW
3A	A/C & HEAT SYSTEM-EVAPORATOR
5	EXTERIOR LTS-DOCKING
6A	EXTERIOR LTS-CORNERING
6B	EXTERIOR LTS-CORNERING
6B1	EXTERIOR LTS-CORNERING RH
6C	EXTERIOR LTS-CORNERING
6C1	EXTERIOR LTS-CORNERING LH
6D	EXTERIOR LTS-DOCKING
6E	EXTERIOR LTS-CORNERING LH
6F1	EXTERIOR LTS-CORNERING RH
7	ENTRANCE DOOR
8A	DDEC III-STP ENG.OVERRIDE
9	INTERIOR LTS-ENGINE CPT
9	INTERIOR LTS-RR JCT BOX
9	INTERIOR LTS-FR SERVICE CPT
9A	INTERIOR LTS-FR JCT PANEL
9B	INTERIOR LTS-FR JCT PANEL
9C	INTERIOR LTS-FR SERVICE CPT
9E	INTERIOR LTS-LUGGAGE CPT.
10	A/C & HEAT SYSTEM-LO PRES.

No.	SYSTEM
10	INTERIOR LTS-LUGGAGE CPT
10A	INTERIOR LTS-LUGGAGE CPT
10A	A/C & HEAT SYSTEM-HI PRES.
10B	INTERIOR LTS-LUGGAGE CPT
10D	INTERIOR LTS-LUGGAGE CPT
10E	INTERIOR LTS-LUGGAGE CPT
12	12V CUT OUT SW. TO BATTERY
12	FR JCT PANEL 12V DISC SW
12A	ENTRANCE DOOR AIR LOCK
12A	FR JCT PANEL 12V DISC SW
12A	RR JCT BOX 12V DISC SW
12A	ENTRANCE DOOR AIR LOCK
12B	FR JCT PANEL 12V DISC SW
12B	RR JCT BOX 12V DISC SW
12B	12V BATTERY MONITOR
12C	FR JCT PANEL 12V DISC SW
12C	RR JCT BOX 12V DISC SW
12D	FR JCT PANEL 12V DISC SW
12D	RR JCT BOX 12V DISC SW
12E	FR JCT PANEL 12V DISC SW
12E	RR JCT BOX 12V DISC SW
12F	FR JCT PANEL 12V DISC SW
12G	FR JCT PANEL 12V DISC SW
12I	RR JCT BOX 12V IGNITION
12I	FR JCT PANEL 12V IGNITION
12A	FR JCT PANEL 12V IGNITION
12F	FR JCT PANEL 12V IGNITION
12F	RR JCT BOX 12V DISC SW
12I	FR JCT BOX 12V DISC SW
12V	RR JCT BOX 12V DISC SW
12VA	12V BATTERY POST TO EQUALIZER
12VD	12V HOT WIRE
12VDR	12V HOT WIRE RJB
12VF	12V FR JCT PANEL
12VF	FR JCT PANEL 12V IGNITION
12VR	RR JCT BOX 12V IGNITION
12VR	12V RR JCT BOX
12W	12V HOT WIRE DDEC II FEED
13A	ALARM & SIGNAL-LO AIR PRM.
13B	ALARM & SIGNAL-LO AIR SEC.
15	EXTERIOR LTS-MULTIFUNC.LEVEL
15	ALARM & SIGNAL-OIL TEMP
15	WIPER & WASHER SYSTEM
15A	ALARM & SIGNAL-DIF. OIL TEMP
16	SPEEDOMETER SIGNAL (+)
16T	SPEED SW SIGNAL IN (+)
17	EXTERIOR LTS-FLASHER UNIT
17A	EXTERIOR LTS-FLASHER UNIT
18	ETHER COLD START SYST.
19	SPARE - RJB TO RR ROOF RH
20	SPEEDOMETER SIGNAL (-)
20T	SPEED SW SIGNAL IN (-)
21	EXTERIOR LTS-DIRECTIONAL LH
21A	EXTERIOR LTS-DIRECTIONAL LH
21B	EXTERIOR LTS-DIRECTIONAL LH
21C	EXTERIOR LTS-DIRECTIONAL LH
21H	EXTERIOR LTS-HAZARD SIGNAL
23	EXTERIOR LTS-DIRECTIONAL RH

No.	SYSTEM
23A	EXTERIOR LTS-DIRECTIONAL RH
23B	EXTERIOR LTS-DIRECTIONAL RH
23C	EXTERIOR LTS-DIRECTIONAL RH
23H	EXTERIOR LTS-HAZARD SIGNAL
24	BATTERY 3 TO BATTERY 4
24	BATTERY 4 TO 24V DISC SW
24A	RR JCT BOX 24V DISC SW
24A	FR JCT PANEL 24V DISC SW
24B	RR JCT BOX 24V DISC SW
24B	FR JCT PANEL 24V DISC SW
24BE	BATTERY MONITOR
24C	RR JCT BOX 24V DISC SW
24C	FR JCT PANEL 24V DISC SW
24E	FR JCT PANEL 24V DISC SW
24E	RR JCT BOX 24V DISC SW
24F	FR JCT PANEL 24V DISC SW
24G	FR JCT PANEL 24V DISC SW
24I	FR JCT PANEL 24V IGNITION
24I	RR JCT BOX 24V IGNITION
24IA	FR JCT PANEL 24V IGNITION
24IA	RR JCT BOX 24V IGNITION
24IB	FR JCT PANEL 24V IGNITION
24IB	RR JCT BOX 24V IGNITION
24IF	FR JCT PANEL 24V IGNITION
24IF	RR JCT BOX 24V DISC SW
24R	24V RR JCT BLK TO STARTER
24S	FJP 24V DISC SW-SUN VISOR
24T	FR JCT PANEL 24V DISC SW
24VA	24V BATTERY POST TO EQUALIZER
24VI	FR JCT PANEL 24V IGNITION
24VIF	FR JCT PANEL 24V IGNITION
24VIR	RR JCT BOX 24V IGNITION
24VD	24V HOT WIRE
24VF	FR JCT PANEL 24V DISC SW
24VF	RR JCT BOX 24V DISC SW
24X	24V SPEED SW & LEVEL LOW
25	12VAC GEN RLY ON SIGNAL
25A	NOT GENERATOR-WARNING LT
25B	EXTERIOR LTS-DAYTIME RUN LTS
25C	12VAC GEN RLY ON SIGNAL
25K	12VAC GEN RLY ON SIGNAL
25L	12VAC GEN RLY ON SIGNAL
26A	ATECI-NEUTRAL SIGNAL
28	A/C & HEAT SYSTEM-WARNING LT
28A	A/C & HEAT SYSTEM-WARNING LT
29	A/C & HEAT SYSTEM-DRIVER'S HTR
29A	A/C & HEAT SYSTEM-DRIVER'S HTR
29B	A/C & HEAT SYSTEM-DRIVER'S HTR
31	A/C & HEAT SYSTEM-WARNING LT
31A	A/C & HEAT SYSTEM-WARNING LT
31B	A/C & HEAT SYSTEM-PRESSURE SW
31B	WIPER & WASHER SYSTEM
32	EXTERIOR LTS-BACK-UP
32B	EXTERIOR LTS-BACK-UP
32D	BACK-UP ALARM
34	A/C & HEAT SYSTEM-CONDENSER
35	INTERIOR LTS-ENTRANCE DOOR
36	ENGINE BRAKE SYSTEM & RETARDER
36A	ENGINE BRAKE SYSTEM

No.	SYSTEM
36C	ENGINE BRAKE SYSTEM
38	FUEL WATER FILTER
39	INTERIOR LTS-DRIVER'S LTS
39A	INTERIOR LTS-DRIVER'S LTS
39B	INTERIOR LTS-DRIVER'S LTS
39C	INTERIOR LTS-DRIVER'S LTS
40	SPARE - F.J.PANEL TO F.SERV CPT
43	A/C & HEAT SYSTEM-FULL AIR
44	EXTERIOR LTS-FOG
44A	EXTERIOR LTS-FOG
44B	EXTERIOR LTS-FOG
44C	EXTERIOR LTS-FOG & HAZARD SW
45	A/C & HEAT SYSTEM-DRIVER'S CTRL
45	A/C & HEAT SYSTEM-FULL AIR
45A	A/C & HEAT SYSTEM-FULL AIR
45C	A/C & HEAT SYSTEM-DRIVER'S HTR
46	EXTERIOR LTS-MARKER
46A	EXTERIOR LTS-MARKER
46B	EXTERIOR LTS-MARKER
46C	EXTERIOR LTS-MARKER
47	A/C & HEAT SYSTEM
47	A/C & HEAT SYSTEM-FULL AIR
50	AIR DRYER
52	ALARM & SIGNAL-ELEC. HORN
52A	ALARM & SIGNAL-ELEC. HORN
53	ALARM & SIGNAL-ELEC. HORN
53B	WIPER & WASHER SYSTEM
53C	WIPER & WASHER SYSTEM
53E	WIPER & WASHER SYSTEM
53F	WIPER & WASHER SYSTEM
53J	WIPER & WASHER SYSTEM
54	SPARE-F.J.B. TO FR ROOF
55	EXTERIOR LTS-HIBEAM
56	TRANSM. OIL TEMP. GAUGE
57	EXTERIOR LTS-HIBEAM
57	A/C & HEAT SYSTEM-WATER PUMP
57A	A/C & HEAT SYSTEM-HIBEAM
57B	A/C & HEAT SYSTEM-WATER PUMP
57C	PRE-HEAT WATER HEATER
57C	A/C & HEAT SYSTEM-WATER PUMP
57D	PRE-HEAT WATER HEATER
57E	PRE-HEAT WATER PUMP
57F	PRE-HEAT WATER HEATER
58	EXTERIOR LTS-LO BEAM
58A	EXTERIOR LTS-LO BEAM
58B	EXTERIOR LTS-LO BEAM
58E	EXTERIOR LTS-LO BEAM
59A	ENGINE BRAKE SYSTEM
59B	EXTERIOR LTS-R & FR ROOF GRD
60	EXTERIOR LTS-24V FEED SW.
61A	EXTERIOR LTS-HEAD SIGNAL
62	LEVEL-LOW SYSTEM
63	EXTERIOR LTS-CLEARANCE
63A	EXTERIOR LTS-CLEARANCE
63B	EXTERIOR LTS-CLEARANCE
63C	EXTERIOR LTS-MARKER SIGNAL
63D	EXTERIOR LTS-MARKER & TAIL
63E	EXTERIOR LTS-CLEARANCE
63F	EXTERIOR LTS-MARKER BLINKER

PREVOST CAR inc. | WIRING DIAGRAM | NO: D060874 | P.E1/3 | REVISION 000

CIRCUIT NUMBER CODE — Page E : 2

No.	SYSTEM
63H	EXTERIOR LTS-TAIL
63K	EXTERIOR LTS-TAIL
64	DIFFERENTIAL OIL TEMP GAUGE
65A	CENTER DOOR AIR LOCK
65A	LOW FUEL T.T.L.T.
67	A/C & HEAT SYSTEM
67A	A/C & HEAT SYSTEM
67B	A/C & HEAT SYSTEM
67C	A/C & HEAT SYSTEM
70B	ENGINE CONTROL SW - 24V IGN.
71	BACK-UP CANCEL SW
71B	BACK-UP CANCEL SW
72	BACK-UP CANCEL SW
72	SPARE F.J.B. TO R.J.B.
72	SPARE F.J.B. TO R.J.B.
72B	SUN VISOR
72C	SUN VISOR
72D	SUN VISOR
72E	SUN VISOR
72S	SUN VISOR
76	FUEL TANK GAUGE
76A	CENTER DOOR AJAR LT
76L	LOW FUEL LT
76M	FUEL PRIME PUMP
76P	FUEL PRIME PUMP
77	A/C & HEAT SYSTEM
77B	A/C & HEAT SYSTEM
77C	A/C & HEAT SYSTEM-COMPRESSOR
77H	A/C & HEAT SYSTEM-FAN CLUTCH
80	WORLD TRANSM-NEUTRAL SIGNAL GRD
81	EXTERIOR LTS-STOP SW
82	EXTERIOR LTS-STOP SIGNAL
82A	EXTERIOR LTS-STOP SIGN
82B	EXTERIOR LTS-STOP LTS
82K	EXTERIOR LTS-STOP RETARDER
82L	EXTERIOR LTS-STOP LTS
82R	EXTERIOR LTS-STOP LTS
83	ENGINE CRT-MAST KEY SW ACCES
83A	DDEC II-COOLANT LEVEL PROBE
84	ENGINE CRT-MAST KEY SW START
84A	ENGINE CTR-MAST KEY SW START
85	ENGINE CTR-MAST KEY SW IGN
85A	24V IGN DASH INSTRUMENTATION
85B	ENGINE CTR-24V IGNITION
85C	PARKING BRAKE SWITCH
85F	LO AIR SONALERT
85L	LEVEL LOW SYSTEM
85W	ABS-24V IGN
85X	ABS-24V IGN
85Y	ABS-24V IGN
86	ENGINE CTR-STARTER SOL SIGN
86A	ENGINE CTR-STARTER SOL SIGN
87B	ENGINE CTR-24V IGNITION
88	ENGINE CTR-RR START SIGNAL
89	ENGINE CTR-RR START SIGNAL
90	A/C & HEAT SYSTEM-WATER PUMP
90A	ENGINE CTR-MAST KEY SW FEED
90B	A/C & HEAT SYSTEM-COND FAN MOT
90B	ENGINE CTR-MAST KEY SW FEED
90E	FR JCT PANEL 24V DISC SW
90C	ALARM & SIGNAL-FIRE DETECTOR

No.	SYSTEM
90F	CHARG SYST-VOLTAGE REGUL."B"
91	PARKING BRAKE SW SIGNAL
91A	PARKING BRAKE SW SIGNAL
91B	DDEC III-FAST IDLE SIGNAL
91B	EXTERIOR LTS-RUN LTS CANCEL
91M	PARKING BRAKE ALARM
91N	PARKING BRAKE ALARM
92	BATTERY EQUALIZER-CHECK BALANCE
93	BATTERY EQUALIZER-CHECK LO/HI
95	ENGINE BRAKE & RETARDER SYSTEM
95A	ENGINE BRAKE & RETARDER SYSTEM
95B	ENGINE BRAKE & RETARDER SYSTEM
97	TACHOMETER-NOT USE
99	UNLOAD TAG SYSTEM
99A	FR SERVICE CPT-24V 12V HOT WIRE
100B	BACK-UP CANCEL SW
101	24V DISC SW TO A/C JCT BOX
101	WORLD TRANSM-LO SIGNAL SOL.-LO
102	24V STARTER-TO GENERATOR
102	24V DISC SW TO A/C JCT BOX
102	WORLD TRANSM-SOL. GRD 1
102	WORLD TRANSM-SOL. GRD 3
104	LEVEL-LOW SYSTEM
104	WORLD TRANSM-SOL. FORWARD
105	WORLD TRANSM-RETARDER & SUMP
106	WORLD TRANSM-OIL LEVEL HI
107	CHARG SYST-VOLTAGE REGUL."F"
107	WORLD TRANSM-LOCKUP SOL. HI
108	WORLD TRANSM-DIAGNOSTIC WAKE UP
109	WORLD TRANSM-RET. SOL. LO
110	ALARM & SIGNAL-TAG PRESS
110	WORLD TRANSM-LOCKUP SOL. LO
111	BATTERY GRD
111	WORLD TRANSM-SOL. C6
112	WORLD TRANSM-SPARE OUTPUT (+)
112	BACK-UP SIGNAL
113	ALARM & SIGNAL-OIL PRESS
113	WORLD TRANSM-DIAGNOSTIC WARNING
113	WORLD TRANSM-SPARE OUTPUT (-)
114	INTERIOR LTS-DASH LT REGUL.
114A	INTERIOR LTS-DASH LT
114B	INTERIOR LTS-DASH LT REGUL.
114C	INTERIOR LTS-DASH LT
115	ALARM & SIGNAL-TAG PRESS
115	DDEC III-COOLANT LEVEL
115	WORLD TRANSM-DO NOT SHIFT SIGNAL
115A	ALARM & SIGNAL-TAG PRESS
115B	ALARM & SIGNAL-TAG PRESS
115C	DDEC III-COOLANT LEVEL
116	WORLD TRANSM-LO SIGNAL SOL. HI
116A	A/C & HEAT SYSTEM-DRIVER'S HTR
116B	A/C & HEAT SYSTEM-DRIVER'S HTR
117	WORLD TRANSM-SPARE INPUT (+)
117	ALARM & SIGNAL-TRANSM OIL TEMP
117A	ALARM & SIGNAL-TRANSM OIL TEMP
118	WORLD TRANSM-SPARE INPUT (+)
118	DRIVER'S & CO-PILOT SEAT HTR
118A	DRIVER'S & CO-PILOT SEAT HTR
119	WORLD TRANSM-ENGINE BRAKE

No.	SYSTEM
120	12V HOT WIRE-DISC SW TO FJP
120	WORLD TRANSM-SOL. C1
121	WORLD TRANSM-SOL. GRD 2
121	CIGAR LIGHTER
122	A/C & HEAT SYSTEM-DRIVER'S HTR
122	A/C & HEAT SYSTEM-FRESH AIR
123	WORLD TRANSM-SOL. GRD 4
123	WORLD TRANSM-NEUTRAL START
123	ALARM & SIGNAL-FIRE DETECTOR
123A	ALARM & SIGNAL-FIRE DETECTOR
124	WORLD TRANSM-THROTTLE (HI)
125	WORLD TRANSM-RETARDER INDICATOR
125W	WORLD TRANSM-RETARDER INDICATOR
126	WORLD TRANSM-LUBE PRESS SW.
126	CENTER DOOR AIR LOCK
127	WORLD TRANSM-RETARDER FEED SOL.
127	PRE-HEAT WATER HEATER
127A	PRE-HEAT WATER HEATER
127W	PRE-HEAT WATER HEATER
127X	PRE-HEAT WATER HEATER
128	WORLD TRANSM-SOL. C2
128A	PRE-HEAT WATER HEATER
128B	PRE-HEAT WATER HEATER
128C	PRE-HEAT WATER HEATER
128D	PRE-HEAT WATER HEATER
128W	PRE-HEAT WATER HEATER
128X	PRE-HEAT WATER HEATER
129	WORLD TRANSM-SOL. C5
129	PRE-HEAT WATER HEATER
129A	PRE-HEAT WATER HEATER
129B	PRE-HEAT WATER HEATER
130	WORLD TRANSM-SOL. GRD 3
130	A/C & HEAT SYSTEM-EVAPORATOR
131	24V DISC SW TO FR JCT PANEL
131	WORLD TRANSM-SOL. C4
132	WORLD TRANSM-ENGINE BRAKE
132	LEVEL LOW SYSTEM
132A	LEVEL-LOW SYSTEM
132B	LEVEL-LOW SYSTEM
132C	LEVEL-LOW SYSTEM
132D	LEVEL-LOW SYSTEM
132E	LEVEL-LOW SYSTEM
132W	WORLD TRANSM-ENGINE BRAKE
133	WORLD TRANSM-RET. ACTUATOR HI
134	WORLD TRANSM-PLO APPLY SOL. HI
135	WORLD TRANSM-ANALOG GRD
135	A/C & HEAT SYSTEM-AIR SENSOR
135A	A/C & HEAT SYSTEM-AIR SENSOR
135C	A/C & HEAT SYSTEM-AIR SENSOR
135D	A/C & HEAT SYSTEM-AIR SENSOR
136	GALLEY-ACCESSORIES
136	WORLD TRANSM-ECU POWER
136V	WORLD TRANSM-12V BATTERY
136W	WORLD TRANSM-12V BATTERY

No.	SYSTEM
136X	WORLD TRANSM-12V BATTERY
137	WORLD TRANSM-RETARDER
137	RR VIEW MIRROR
137A	RR VIEW MIRROR
138	WORLD TRANSM-RETARDER TEMP
138	ABS SYSTEM
138A	ABS SYSTEM
139	ABS SYSTEM
139	WORLD TRANSM-OUTPUT SPEED HI
140	WORLD TRANSM-OUTPUT SPEED LO
140	ABS SYSTEM
141	ABS SYSTEM
141	WORLD TRANSM-ENGINE SPEED HI
142	WORLD TRANSM-SERIAL COM. A
142	ABS SYSTEM
143	ABS SYSTEM
143A	ABS SYSTEM
143	WORLD TRANSM-ECU BATTERY GRD
143W	WORLD TRANSM-BATTERY GRD
143X	WORLD TRANSM-BATTERY GRD
144	WORLD TRANSM-ECU CHASSIS GRD
144A	ABS SYSTEM
144A	ABS SYSTEM
145	ABS SYSTEM
145	ABS SYSTEM
146	WORLD TRANSM-IGNITION SENSE
146W	WORLD TRANSM-12V IGNITION
146X	WORLD TRANSM-12V IGNITION
147	WORLD TRANSM-OIL TEMP
147	ABS SYSTEM
147	ETHER COLD START
147C	ETHER COLD START
148	ABS SYSTEM
148	WORLD TRANSM-OUTPUT SPEED LO
149	WORLD TRANSM-TURBINE SPEED HI
149	ABS SYSTEM
149A	ABS SYSTEM
150	ABS SYSTEM-SPARE
150	WORLD TRANSM-ENGINE SPEED LO
150	DDEC III-BATTERY GRD
150A	DDEC III-ECM BATTERY GRD
151	DDEC III-ECM BATTERY GRD
151	WORLD TRANSM-SERIAL COM. B
151	ABS SYSTEM-SPARE
152	ABS SYSTEM-SPARE
153	ABS SYSTEM
153	ELECTRICAL DRIVER'S SEAT
153	WORLD TRANSM-SPARE INPUT (-)
154	WORLD TRANSM-ABS INPUT
155	WORLD TRANSM-SPARE INPUT (-)
155	ABS SYSTEM
156	WORLD TRANSM-THROTTLE POS. SIGNAL
156	ABS SYSTEM
156A	ABS SYSTEM
156C	ABS SYSTEM
156W	ABS SYSTEM

PREVOST CAR inc. | WIRING DIAGRAM | NO: D060874 | P.E2/3 | REVISION 003

CIRCUIT NUMBER CODE — Page E : 3

No.	SYSTEM
157	WORLD TRANSM-SPEEDOMETER SIGNAL
157	ABS SYSTEM
157A	ABS SYSTEM
157B	ABS SYSTEM
157C	ABS SYST.-CANCEL SEC. BRK
158	WORLD TRANSM-DIMMER
160	WORLD TRANSM-SER. INTERFACE (+)
161	WORLD TRANSM-SIGNAL GRD
161	DDEC III-FAST IDLE SIGNAL
161B	WORLD TRANSM-SIGNAL GRD
162	WORLD TRANSM-PRESS. SW. C3
163	WORLD TRANSM-RETARDER ENABLE
164	WORLD TRANSM-RET. ACTUATOR SIGN
165	WORLD TRANSM-OIL LEVEL SIGNAL
168	WORLD TRANSM-SER. INTERFACE (+)
170C	LUGGAGE DOOR LOCK
170D	LUGGAGE DOOR LOCK
170E	LUGGAGE DOOR LOCK
170F	LUGGAGE DOOR LOCK
170G	LUGGAGE DOOR LOCK
170H	LUGGAGE DOOR LOCK
170J	LUGGAGE DOOR LOCK
170L	LUGGAGE DOOR LOCK
170M	LUGGAGE DOOR LOCK
170N	LUGGAGE DOOR LOCK
170O	LUGGAGE DOOR LOCK
170R	LUGGAGE DOOR LOCK
170S	LUGGAGE DOOR LOCK
170V	LUGGAGE DOOR LOCK
170W	LUGGAGE DOOR LOCK
170X	LUGGAGE DOOR LOCK
170Y	LUGGAGE DOOR LOCK
170Z	LUGGAGE DOOR LOCK
182	PYROMETER
182A	PYROMETER
185	UNLOAD TAG SYSTEM
185A	UNLOAD TAG SYSTEM
186	UNLOAD TAG SYSTEM
186A	UNLOAD TAG SYSTEM
187	UNLOAD TAG SYSTEM
187C	UNLOAD TAG SYSTEM
188	UNLOAD TAG SYSTEM
188A	UNLOAD TAG SYSTEM
188B	UNLOAD TAG SYSTEM
201	WORLD TRANSM-SPARE
202	WORLD TRANSM-SPARE
203	WORLD TRANSM-SPARE
204	WORLD TRANSM-SPARE
205	WORLD TRANSM-SPARE
206	WORLD TRANSM-SPARE
214	WORLD TRANSM-BACK UP SIGNAL
214A	WORLD TRANSM-BACK UP SIGNAL
231	WORLD TRANSM-NEUTRAL SIGNAL GRD
240	DDEC III-ECM 12V FEEDING
241	DDEC III-ECM 12V FEEDING
251	PROPRIVIM-12V HOT WIRE
260	WINDOW AJAR
290	FAN CLUTCH RADIATOR
291	FAN CLUTCH RADIATOR SPD 1

No.	SYSTEM
292	FAN CLUTCH RADIATOR SPD 2
417	DDEC III-LIMIT SPEED GOVERNOR
419	DDEC III-CHECK ENGINE LIGHT
439	DDEC III-12V IGNITION
440	DDEC III-12V IGNITION
505	DDEC III-TACHOMETER DRIVE
505	DDEC III-TACHOMETER DRIVE
509	DDEC III-STOP ENGINE LIGHT
510	DDEC III-FAST IDLE SIGNAL
524	DDEC III-ENGINE BRAKE DISABLE
525	DDEC III-FAST IDLE SIGNAL
528	DDEC III-STOP ENG.OVERRIDE
531	DDEC III-CRUISE CLUTCH CUT OUT
541	DDEC III-CRUISE SET SW
543	DDEC III-CRUISE STOP SW CUT OUT
544	DDEC III-CRUISE ON/OFF SW
545	DDEC III-CRUISE RESUME SW
555	DDEC III-CRUISE ARMED LIGHT
556	DDEC III-VEHICLE SPEED (+)
557	DDEC III-VEHICLE SPEED (-)
565	DDEC III-ENGINE BRAKE ACTIVE
583	DDEC III-ENGINE BRAKE 4 CYL.
750	PROPRIVER-ILLUMINATION LTS.
900	DDEC III-DATA LINK (+)
901	DDEC III-DATA LINK (-)
908	DDEC III-HYDRAULIC TRANSM. MODULATOR
916	DDEC III-SENSOR SUPPLY (5VDC)
952	DDEC III-SENSOR RETURN
953	DDEC III-BATTERY GRD
953C	DDEC III-BATTERY GRD
979	DDEC III-ENGINE BRAKE 2 CYL.
A	LEVEL-LOW SYSTEM
A	A/C & HEAT SYSTEM-HI PRES.
A1	A/C & HEAT SYSTEM-LO PRES.
A2	INTERIOR LTS-DRIVER'S LTS
B	LEVEL-LOW SYSTEM
B00	RR JCT BOX CPT BATT GRD
B000	RR JCT BOX CPT BATT GRD
C	LEVEL-LOW SYSTEM
J4	A/C & HEAT SYSTEM-DRIVER'S HTR
03	A/C & HEAT SYSTEM-DRIVER'S HTR
R1	A/C & HEAT SYSTEM-DRIVER'S HTR
R6	A/C & HEAT SYSTEM-DRIVER'S HTR
SH1	SHIELD WIRE GRD
SH2	SHIELD WIRE GRD
SH3	SHIELD WIRE GRD
V5	A/C & HEAT SYSTEM-DRIVER'S HTR
V7	A/C & HEAT SYSTEM-DRIVER'S HTR

PREVOST CAR inc. | WIRING DIAGRAM | NO: D060874 | P.E3/3 | REVISION 000