
RR. ROOF ACCESSORIES
062693
C87
C122
CAMERA DOOR SOLENOID
C124
ETHER
C126
C116 ENGINE CPT LT
C230
064101
C232 PRIME PUMP SW.
C231 FUEL PRIME PUMP
C127
063715
C127
FUEL WATER FILTER
C120
063209
RR RH LOWER LAMPS
C119
063210
RR LH LOWER LAMPS
064719
C342 RR START SW.
C327 RR CTRL START SW.
C125 BACK UP ALARM
C432 ENG. LTS RR DOOR SW.
C287 ENG. LTS RH DOOR SW.
PRE-HEATER CONNECTION
C159 PRESS SW. 2ND SPEED RAD. FAN
C133 HI-PRESS SW.
C132 LO-PRESS SW.
C128 COMPR. A/C
C409 COOLANT LEVEL PROBE
C116 ENGINE CPT LT
C115
063331
AIR DRYER
E.C.M.
DDEC III
C32
C309
064601
C415
C407
C408
C397
064728
ENGINE CRADLE ACCESSORIES
BAT. JCT. CPT
064729
063906
ENGINE DDEC3 HARNESS SENSOR
C594 DRIVER'S LTS
CLEARANCE LTS C213
RAMCO MIRROR
C590
SPARTAN RH MIRROR
062711
C269
3 WAY SWITCH
C276
WIPER MOTOR
C177
WIPER PULSE MODULE
C176
STEP LT
MARK & FLASH.
C243
RH HEADLAMPS
C246
KEYLESS ENTRY SYSTEM
064831
C266
064830
C267
RH FOG
C245
DEFROST UNIT
C480
C481
A/C CONTROL
C539
C540
T.T.LT. MODULE
AA1
AA2
C573
C572
C571
C570
R.H. SW. PANEL
L.H. SW. PANEL
RX
CY
LY
LX
CLUSTER
064736
C244
LH FOG
LO AIR PRESS SW
STOP PRESS. SW.
064736
C157 WATER PUMP
C106 WATER VALV
STEP LT
C105 LIQ.SOL. VALV
RH CORNERING
C104 RH FR SIDE FLASHER
C103 RH FR SIDE MARKER
C467
C466
C465
RESISTANCE MODULE
RESISTANCE MODULE
SHIFTER
063782
HAND LEVER RETARDER
2 PSI BRK (RET.)
4 PSI BRK (RET.)
7 PSI BRK (RET.)
064601
064733
AUX. SPEED CTR'L UNIT
C201
C202
C203 AUX MOTOR
C67 LUG. LT
C86 LUG. LOCK
C81 LUG. LOCK
C65 LUG. LT
C105 RH CENT. FLASHER
C103 RH CENT. MARKER
C82 LUG. LOCK
C63 LUG. LT
ESPAR PUMP & FUEL TANK G.A.
064116
C107
C152
C78
LUGG. LTS
C290 LUG. LOCK
C61 LUG. LT
AUX. LIQ. SOL.
C148
LUG. LT
LUG. LT C68
LUG. LOCK C85
LUG. LOCK C84
LUG. LT C66
LH CENT. FLASHER
C102
LH CENT. MARKER
C103
LUG. LOCK C83
LUG. LT C64
LUG. LT C79
LUG. LOCK C291
LUG. LT C62
C76
C243 LH HEADLAMPS
C242 LH FRONT MARKER & FLASHER
C102 LH FR SIDE FLASHER
C103 LH FR SIDE MARKER
DIGITAL THERMOMETER
OUTSIDE SENSOR
C538
C483 DRIVER'S ELECTRICAL SEAT
C98 ACCELERATOR
C380 DDR
064601
064733
064731
064596
RH SENSOR & SOLENOID
LH SENSOR & SOLENOID
C96
064588
064595
RH SENSOR & SOLENOID
LH SENSOR & SOLENOID
C97
C69
ECU ABS
C93
ABS BLINK CODE SW.
C406
C92
C8
C9
C6
C5
C4
C2
C3
C1
FR. JCT. BOX
064734
C74
C72
C71
C45
C11
C12
HORNS
LH CORNERING
SERVICE CPT LTS
WASHER PUMP
064177
LEVEL LOW PANEL
C172
064657
C281
064700 WEBASTO
C430
C171
064584 ESPARE
C70
064603
LH. CONSOLE
C323
CRUISE CTRL SW.
064732
C589
064656
LH MIRROR RAMCO
C589
062711
C268
LH MIRROR SPARTAN
064645
C594 DRIVER'S LTS
064731
064733
064869
064719
C477
064597
C457 TRANSM. MAIN. CONN.
C463
064716
C462 OUTPUT SPEED
C461 RETARDER TEMP
C460 RETARDER SOLENOID
C459 ENGINE SPEED
C458 TURBINE SPEED
C456 RETARDER ACCUMULATOR SOL.
C476 VIM
C182 VIW
C464 DDR
C414
C186
C220
C90
064128
C91
C52
C21
C20
C15
CA
CB
E.C.U. WORLD TR.
C58
C59
A/C & HEAT JUNCTION PANEL
064720
RR. JCT. BOX
064865
PRIME PUMP
C145
RH DOCKING LT
C121
RH FR SIDE FLASHER
C113
RH FR SIDE MARKER
C49
BATTERIES CPT LT
064399
C113
LH FR SIDE MARKER
C114
LH FR SIDE FLASHER
LH DOCKING LT
WITH A/C - HEAT DRIVER ONLY