LOC. DDR CONNECTOR
CENTER DASH PANEL
SP23-16
SP21-16
TW1-18
TW2-18
SP29-16
SP57-16
SP58-16
C8
SP59-16
SP68-16
SP105-18
C74
JONCTION BOX
FRONT
C2
C1
C4
C45
C3
C6
C74
C5
C92
C96
C415
C52
C397
C20
C91
C87
C35
C717
C702
C720
R.H. DASH PANEL
RH DASH PANEL
CENTER DASH PANEL
L.H. CONSOLE
FR. SERV. COMPT.
BEHIND TAG PANEL
U/DASH RH NEAR WIPER MOTOR
U/FLOOR NEAR RH HEADLAMP
FR. ROOF - LH ACCES.
FR. ROOF - LH ACCES.
FR. ROOF - RH ACCES.
FR. ROOF - RH ACCES.
CONDENSER COMPT.
EVAPAPORATOR COMPT.
FR. AXLE ACCES
RR. AXLE ACCES
L.H. LUGG. COMPT. NO:2
L.H. LUGG. COMPT. NO:1
R.H. LUGG. COMPT. NO:1
R.H. LUGG. COMPT. NO:2
L.H. LUGG. COMPT. NO:3
R.H. LUGG. COMPT. NO:3
NEAR STARTER SOL.
NEAR STARTER SOL.
NEAR C407 OR C408
NEAR FAN CLUTCH C426
NEAR FAN CLUTCH C426
NEAR FAN CLUTCH C426
RR. ROOF CENTER ACCES.
RR DOOR LOWER LTS C120
PRE-HEATER CONNECTION
PRE-HEATER CONNECTION
RR START SW C342
RR DOOR CPT LTS SW C432
ENGINE CPT LT C116
R.H. HAT RACK END C38
LAVATORY ROOF RR END C43
L.H. HAT RACK RR END C37
ONLY WITH ZF TRANSM. OPTION

PREVOST	WIRING DIAGRAM	NO: D060976	PAGE: D	REVISION 00