TO MASTER KEY SW.
ANTI-THEFT RLY R104
SEE P.4.1
0-294-18
TO DRIVER'S LTS
R64 (85) SEE P.11.2
REMOTE CTR (PANIC)
TO HORN SIGN. SEE P 7.2
0-53-18
12V IGNITION
FROM CB28 SEE P.7.1
12V HOT WIRE
FROM FR.JCT BOX
SEE P.2.1
12-12D-16
ENTRANCE DOOR SW.
LOCK
UNLOCK
0-0T1-18
FROM DASH LTS. RHEOST.
SEE P.10
CB115
8A
0-285-18
285A-18
UNLOCK
LOCK
C267
C12
C20
C5
C4
0-39K-18
0-284A-18
0-285-18
12-12H-18
ENTRANCE DOOR SW. SIGN.
NC-DOOR OPEN
0-0L-16
ENTRANCE DOOR KEY SW.
DISARM SIGN. NO-LOCK
N.O.
N.C. COM.
0-0L-18
ANTI-THEFT LED INDICATOR
0-0T2-18
C381
TO ENTRANCE DOOR LTS
R106 SEE P 11.2
12-270-16
0-285A-18
UNLOCK
R102
R105 LOCK
286-16
12-170R-16
0-0L-16
C266
C285
ENTRANCE DOOR
KEYBOARD
BLU/YEL
GRN/RED
YEL/BLK
YEL
RED
BRN
BLU
BLK
C264
C266
12-272-18
12-274-18
12-276-18
12-278-18
12-280-18
0-0L-18
12-277-18
KEYLESS BY PASS SW.
0-0C1-16
C267
KEYLESS MODULE
0-294-18
0-39K-18
0-53-18
0-283A-18
0-283-18
0-284A-18
0-285-18
UNLOCK
LOCK
12-277-18
12-270-16
0-285A-18
12-295-18
C310
0-0T1-18
12-114A-18
UNLOCK
LOCK
0-284A-18
0-285-18
LUGGAGE DOOR SW.
12V HOT WIRE
FROM RR. JCT. BOX
SEE P. 2.1
12-12B-12
CB118
20A
CB120
20A
12-170D-14
0-285-18
0-0Y2-14
0Y2
R70 UNLOCK
R69 LOCK
12-170W-14
12-170W-14
0-284A-18
0-285-18
COND. COMPT.
OPTIONAL
C52
C75
C81
C82
C86
C85
12-170F-14
12-170G-14
0-285-18
0-0Y1-14
0Y1-14
R75 UNLOCK
R74 LOCK
12-170W-14
EVAP. COMPT. WITHOUT
FAN ONLY
C77
C83
C84
C291
C290
12-170Y-14
12-170Z-14
0-0-18
C52
C75 170E-20
COND. COMPT.
OPTIONAL
C75 170K-20
C290
24 VI POWER
FROM AIR DRYER FUSE F5
SEE P. 8.1
C290
C291 170L-20
C291 170V-20
OR
C77
EVAP. COMPT.
WITHOUT FAN
C77 170T-20
C83
OR
C83
C84 170X-20
C84
C85 170M-20
C85
C86 170N-20
C86
C81 170P-20
C81
C82 170R-20
C82 170S-20
N.O. COM
TO LUGGAGE DOOR UNLOCK T.T.L.T.
MODULE C572 (4) SEE P. 23.1
0-170C-20
0-170C-18
24-50-16
170S-20
R71
0-0-18
C5
C20
C52

KEYLESS ENTRY SYSTEM

LUGGAGE DOOR LOCK

PREVOST	WIRING DIAGRAM	NO: D060912	PAGE: 12.1	REVISION 09