FROM STARTER RELAY
R4 SEE THIS PAGE

FROM 24V JCT. BLOCK
ENGINE WALL
SEE P.1.1

12V IGNITION
FROM RR.JCT.BOX
SEE P. 2.1

TO HVAC DASH MODULE
C540 (11) SEE P 15.1

TO DAYTIME RUN LTS
RELAY R18 (30)
SEE P 9.1

TO MASTER SW. CUT
OUT RLY R78 (86)
SEE P.1.1

24VI POWER
FROM FR.JCT.BOX
SEE P.1.1

TO HVAC MODULE
SEE C540 P. 15.1 , 15.3

TO PARK BRAKE ALARM
SEE P. 8.1

24V POWER
FROM FR.JCT.BOX
SEE P.1.1

TO 24V IGNITION RLY
R1 (86) SEE P. 1.1

TO 24V IGNITION RLY
R53 (86) SEE P. 1.1

TO ENG. BRK RLY
R87 (86) SEE P. 21.1

TO STOP & B/U RLY
R61 (86) R9 (86)
SEE P 9.3

TO LEVEL LOW
CONTROL SW. SEE P. 18.1

24V POWER
FROM FR.JCT.BOX
SEE P.1.1

24V POWER
FROM BATTERIES CPT
CB6 SEE P. 1.1

TO STARTER SOL.
SEE THIS PAGE OR 4.2

NEUTRAL SIGN.
FROM WORLD TR. RELAY
VIMN (30) SEE P.6.1

TO BATTERY BALANCET.T.L.T.
MODULE C571 (16) SEE P. 23.1

TO BATTERY LO/HI T.T.L.T.
MODULE C571 (4) SEE P. 23.1

24V H.W. POWER
FROM BATTERIES CPT
JCT" B SEE P. 1.1

12V H.W. POWER
FROM BATTERIES CPT
JCT" A SEE P. 1.1

BATTERY GROUND
FROM BATTERIES CPT
JCT" C SEE P. 1.1

160A
C397
24-86-10
24-101-4/0
F57
C532
1A
12-121-18
12-25B-18
A
C20
0-05-18
R100
RS
C5
C3
12-25-18
ENGINE RUN RLY
R33
0-0C4-18
FS
CB70
24-241A-14
24-67C-16
30
87A
24-67-16
24-25A-18
CB10
8A
C71
C12
24-24-14
24-90B-16
C267
24-85-18
C20
26
C5
CB18
6A
CB16
8A
24-24B-14
24-89-16
24-90F-12
24-231A-16
D75
R4
BAT
0-231-18
24-24B-8
24-86-10
0-92-18
0-93-18
24-24BE-16
12-12BE-16
0-0BE-16
24-85F-18
0-0B-2/0
0-0C-2/0
24-102-2/0
12-25-16
C397 C15
STARTER SOL.
S
HOLD IN
PULL IN
BATT.
M
G
BUS BAR
STARTER MOTOR
M
DC
+
RLY
24V ALTERNATOR
F2
F1
C397
16GA
13
14
24-107-12
24-90F-12
24-85F-18
ENGINE CPT GRD STUD
TO ENGINE BODY GROUND STUD
0-OAA-12
BC
G
F
B
IGN
VOLTAGE REGULATOR
TO NOT GEN. T.T.L.T. MODULE C571 (5) SEE P. 23.1
TO ETHER SWITCH SEE P.8.1
C71
27
5
24-83-18
C5
2
C21
22
C71
26
R104
86
30
87
87A
85
294
FROM KEYLESS MOD. SEE P 12.1
24-85-18
C267
21
C12
7
24-90A-16
BAT.
ACC
ST.
IGN.
MASTER KEY SW.
24-84-16
C90
1
C6
C583
24-84J-16
24-84A-16
24-85F-18
TO RADIAT. FAN CLUTCH
R99 (86) C5085 SEE P. 8.1
24-85F-18
D
C15
23
C15
20
C91
15
29
28
16
24-89-16
24-88-16
C327
24-85B-16
24-85F-18
24-84-16
24-231A-16
WH
BLK
GRY
ORA
RED
YEL
NORM.
RESTART
ENGINE CONTROL SW.
C342
RR START SW.
C5
27
28
C20
C15
21
22
BATT. BALAN.
BAT.HI
BAT.LO
24V
12V
GRD
24VI
BATTERY EQUALIZER MONITOR
TO 12V IGNITION RLY
R2 (86) SEE P. 2.1

STARTER & ALTERNATOR DELCO

ENGINE CONTROL

PREVOST	WIRING DIAGRAM	NO: D060912	PAGE: 4.1	REVISION 02