CIRCUIT NUMBER CODE — PAGE: 1

NO.	SYSTEM
0	GRD BATTERY A TO GRD STUD
0	GRD BATTERY A1 TO GRD STUD
0	GRD STARTER MOTOR TO GRD STUD
0	FJP - GRD
0	RJB - GRD
0	BJP - GRD
0A	RJB - GRD
0A	FR SERV JCT BOX - GRD
0B	FJP - GRD
0B	RJB - GRD
0BE	BV BATTERY MONITOR
0C	RJB - GRD
0D	FJP - GRD
0D	RJB - GRD
0E	RJB - GRD
0F	RJB - GRD
0H	FJP - GRD
0H	BACK-UP MONITOR
0P	RJB - GRD
0P	RJB - SOUND SYSTEM GRD
0S2	RADIO- BATTERY GRD
0S3	VIDEO- BATTERY GRD
0S5	SOUND SYSTEM - BATTERY GRD
0S5S	SOUND SYSTEM - BATTERY GRD
0T	FJP - GRD
0T	FR SERVICE CPT-GRD
0V	FJP - GRD
0VA	GRD STUD TO BAT.EQUALIZER
0W	FJP - GRD
0W	WORLD TRANSM. VIM CHASSIS GRD
0WA	PRE_HEAT WATER HEATER WEBASTO
0WB	PRE_HEAT WATER HEATER WEBASTO
0X	RJB - GRD
0Y1	ABS SYSTEM-GRD
0Y1	ABS SYSTEM-GRD
2	A/C & HEAT SYSTEM-CONSENSER
2A	A/C & HEAT SYSTEM-CONSENSER
2C	A/C & HEAT SYSTEM-CONSENSER
2D	A/C & HEAT SYSTEM-CONSENSER
3	A/C & HEAT SYSTEM-EVAPORATOR
3A	A/C & HEAT SYSTEM-EVAPORATOR
3B	A/C & HEAT SYSTEM-EVAPORATOR
4	CH|ME-PASSENGER & HOSTESS
4B	CH|ME-PASSENGER & HOSTESS
4B	CH|ME-PASSENGER & HOSTESS
4D	CH|ME-PASSENGER & HOSTESS
4E	CH|ME-PASSENGER & HOSTESS
5	INTERIOR LTS-EMERGENCY EXIT LTS
5A	INTERIOR LTS-EMERGENCY EXIT LTS
5B	INTERIOR LTS-EMERGENCY EXIT LTS
6	INTERIOR LTS-AISLE LTS
7	INTERIOR LTS-STEPWELL LTS
8A	INTERIOR LTS-AISLE & EMERG. LTS
8B	INTERIOR LTS-AISLE & EMERG. LTS
9	INTERIOR LTS-ENGINE CPT
9	INTERIOR LTS-RR JCT BOX
9A	INTERIOR LTS-FR SERVICE CPT
9A	INTERIOR LTS-FR JCT PANEL
9E	CH|ME-PASSENGER & HOSTESS
10	A/C & HEAT SYSTEM-LO PRES.

NO.	SYSTEM
10	INTERIOR LTS-LUGGAGE CPT
10A	INTERIOR LTS-LUGGAGE CPT
10A	A/C AUXILIARY-CLUTCH
10B	INTERIOR LTS-LUGGAGE CPT
10C	INTERIOR LTS-LUGGAGE CPT
11	FR.DESTINATION SIGN
11A	FR.DESTINATION SIGN
11B	FR.DESTINATION SIGN
11C	FR.DESTINATION SIGN
11D	FR.DESTINATION SIGN
11E	FR.DESTINATION SIGN
11F	FR.DESTINATION SIGN
11K	FR.DESTINATION SIGN
11P	FR.DESTINATION SIGN
12	12V BATTERY A1 TO BATTERY A
12A	12V BATTERY B1 TO BATTERY B
12B	12V BATTERY B1 TO BATTERY B
12C	12V VIDEO SYSTEM
12D	FR JCT PANEL 24V DISC SW
12E	RR JCT BOX 12V DISC SW
12F	FR JCT PANEL 12V DISC SW
12G	RR JCT BOX 12V DISC SW
12H	FR JCT PANEL 12V DISC SW
12I	RR JCT BOX 12V DISC SW
12J	FR JCT PANEL 12V DISC SW
12K	RR JCT BOX 12V DISC SW
12L	FR JCT PANEL 12V DISC SW
12M	RR JCT BOX 12V DISC SW
12N	FR JCT PANEL 12V DISC SW
12O	RR JCT BOX 12V DISC SW
12P	FR JCT PANEL 12V DISC SW
12P	FR JCT PANEL 12V DISC SW
12Q	12V BATTERY-SOUND SYSTEM RADIO
12R	12V BATTERY-SOUND SYSTEM RADIO
12S	12V BATTERY-SOUND SYSTEM RADIO
12S2	12V BATTERY-SOUND SYSTEM RADIO
12SB	12V BATTERY-SOUND SYSTEM
12SS	12V BATTERY-SOUND SYSTEM
12T	RR JCT BOX 12V DISC SW
12VA	12V BATTERY POST TO EQUALIZER
12V	12V FR JCT PANEL
12W	RR JCT BOX 12V IGNITION
12VR	RR JCT BOX 12V DISC SW
12W	12V HOT WIRE DOOR ILL FEED
13A	ALARM & SIGNAL-LO AIR PRIM.
13B	ALARM & SIGNAL-LO AIR SEC.
14	LAVATORY-FLUSHING SW
15	EXTERIOR LTS-MULTI FUNC LEVEL
31A	A/C & HEAT SYSTEM-PRESSURE SW
31B	A/C & HEAT SYSTEM-PRESSURE SW
31B	WIPER & WASHER SYSTEM
31B	SPEEDOMETER SIGNAL (+)
32A	BACK-UP MONITOR
32B	EXTERIOR LTS-FLASHER UNIT
32D	BACK-UP ALARM
32M	BACK-UP MONITOR
34	A/C & HEAT SYSTEM-CONDENSER
34A	A/C & HEAT SYSTEM-CONDENSER
35	INTERIOR LTS-STEPWELL LTS
36	ENGINE BRAKE SYSTEM & RETARDER
36A	ENGINE BRAKE SYSTEM
36C	ENGINE BRAKE SYSTEM-ABS CANCEL
37	LAVATORY-OCCUPIED LTS
38	FUEL WATER FILTER

NO.	SYSTEM
23B	EXTERIOR LTS-DIRECTIONAL RH
23E	KNEELING-RH EXT. FLASHING LTS
23F	KNEELING-RH EXT. FLASHING LTS
23H	EXTERIOR LTS-HAZARD SIGNAL
24	BATTERY B TO BATTERY B1
24	BOOSTER TO 24V DISC SW
24A	RR JCT BOX 24V DISC SW
24A	FR JCT PANEL 24V DISC SW
24B	FR JCT PANEL 24V DISC SW
24BE	BATTERY MONITOR
24C	FR JCT PANEL 24V DISC SW
24F	FR JCT PANEL 24V DISC SW
24I	FR JCT PANEL 24V IGNITION
24J	RR JCT BOX 24V IGNITION
24K	FR JCT PANEL 24V IGNITION
24L	FR JCT PANEL 24V IGNITION
24M	FR JCT PANEL 24V DISC SW
24N	FR JCT PANEL 24V DISC SW
24O	RR JCT BOX 24V DISC SW
24P	RR JCT BOX 24V DISC SW
24R	RR JCT BOX 24V DISC SW
24S	RR JCT BOX 24V DISC SW
24S2	24V BATTERY-SOUND SYSTEM
24S3	24V BATTERY-SOUND SYSTEM VIDEO
24S4	24V BATTERY-SOUND SYSTEM VIDEO
24SB	24V BATTERY-SOUND SYSTEM
24SS	24V BATTERY-SOUND SYSTEM
24T	RR JCT BOX 24V DISC SW
24VA	24V BATTERY POST TO EQUALIZER
24VI	RR JCT BOX 24V IGNITION
24VIF	FR JCT PANEL 24V IGNITION
24VD	FR JCT PANEL 24V HOT WIRE
24VE	RR JCTY BOX 24V HOT WIRE
24VF	FR JCT PANEL 24V DISC SW
25	24V SPEED SW & KNEELING
25	12VAC GEN RLY ON SIGNAL
25A	NOT GENERATOR-WARNING LT
26B	EXTERIOR LTS-DIRECTIONAL LTS
25L	12VAC GEN RLY ON SIGNAL
27	LAVATORY-EMERGENCY BUZZER
28	A/C & HEAT SYSTEM-WARNING LT
29	A/C & HEAT SYSTEM-DRIVER'S CTRL
29A	A/C & HEAT SYSTEM-DRIVER'S HTR
29B	A/C & HEAT SYSTEM-DRIVER'S HTR
30	GALLEY SYSTEM
30A	GALLEY SYSTEM
31A	A/C & HEAT SYSTEM-PRESSURE SW
31B	A/C & HEAT SYSTEM-PRESSURE SW
31B	WIPER & WASHER SYSTEM
32	EXTERIOR LTS-BACK-UP
32A	BACK-UP MONITOR
32B	EXTERIOR LTS-BACK-UP
32D	BACK-UP ALARM
32M	BACK-UP MONITOR
34	A/C & HEAT SYSTEM-CONDENSER
34A	A/C & HEAT SYSTEM-CONDENSER
35	INTERIOR LTS-STEPWELL LTS
36	ENGINE BRAKE SYSTEM & RETARDER
36A	ENGINE BRAKE SYSTEM
36C	ENGINE BRAKE SYSTEM-ABS CANCEL
37	LAVATORY-OCCUPIED LTS
38	FUEL WATER FILTER

NO.	SYSTEM
38	INTERIOR LTS-24V FLUORESCENT
38A	INTERIOR LTS-24V FLUORESCENT
38B	INTERIOR LTS-24V FLUORESCENT
38C	INTERIOR LTS-24V FLUORESCENT
38E	INTERIOR LTS-24V FLUORESCENT
38F	INTERIOR LTS-24V FLUORESCENT
39	INTERIOR LTS-DRIVER'S LTS
39A	INTERIOR LTS-DRIVER'S LTS
39B	INTERIOR LTS-DRIVER'S LTS
44	EXTERIOR LTS-FOG
44A	EXTERIOR LTS-FOG
44B	EXTERIOR LTS-FOG
44C	EXTERIOR LTS-FOG & HAZARD SW
45	A/C & HEAT SYSTEM-DRIVER'S CTRL
45A	A/C & HEAT SYSTEM-WATER VALVE
45A	A/C & HEAT SYSTEM-WATER VALVE
45B	A/C & HEAT SYSTEM-WATER VALVE
45E	A/C & HEAT SYSTEM-BYPASS VALVE
46	EXTERIOR LTS-MARKER
46A	EXTERIOR LTS-MARKER
46B	EXTERIOR LTS-MARKER
46C	EXTERIOR LTS-MARKER
47	A/C & HEAT SYSTEM-DRIVER'S HTR
47	A/C & HEAT SYSTEM-FULL AIR
48	INTERIOR LTS-STEPWELL LTS
51	INTERIOR LTS-READING LTS
52	ALARM & SIGNAL-ELEC. HORN
52A	ALARM & SIGNAL-ELEC. HORN
53	ALARM & SIGNAL-ELEC. HORN
53B	WIPER & WASHER SYSTEM
53C	WIPER & WASHER SYSTEM
53E	WIPER & WASHER SYSTEM
53F	WIPER & WASHER SYSTEM
53J	WIPER & WASHER SYSTEM
54	SPARE-F,J,B, TO FR ROOF
55	EXTERIOR LTS-HI BEAM
56	WORLD TRANSM-OIL TEMP GAUGE
57	EXTERIOR LTS-HI BEAM
57A	A/C & HEAT SYSTEM-WATER PUMP
57B	A/C & HEAT SYSTEM-WATER PUMP
57C	PRE-HEAT WATER HEATER
57D	PRE-HEAT WATER HEATER
57E	PRE-HEAT WTR HTR PUMP
57F	PRE-HEAT WATER HEATER
57G	PRE-HEAT WATER HEATER
58	EXTERIOR LTS-LO BEAM
58A	EXTERIOR LTS-LO BEAM
58B	EXTERIOR LTS-LO BEAM
58E	EXTERIOR LTS-LO BEAM
59A	ENGINE BRAKE SYSTEM
60	EXTERIOR LTS-FR ROOF GRD
61	EXTERIOR LTS-24V FEED SW
61A	EXTERIOR LTS-HEAD SIGNAL
62	LAVATORY-OCCUPIED LTS
62B	LAVATORY-OCCUPIED LTS
63	EXTERIOR LTS-CLEARANCE
63A	EXTERIOR LTS-CLEARANCE
63B	EXTERIOR LTS-CLEARANCE

CIRCUIT NUMBER CODE — PAGE: 2

NO.	SYSTEM
63C	EXTERIOR LTS-MARKER SIGNAL
63D	EXTERIOR LTS-MARKER & TAIL
63E	EXTERIOR LTS-CLEARANCE
63F	EXTERIOR LTS-MARKER BLINKER
63G	EXTERIOR LTS-TAIL
63K	EXTERIOR LTS-TAIL
64	DIFFERENTIAL OIL TEMP GAUGE
65A	PRE-HEAT WATER HEATER
66B	RR JCT BOX 12V HOT WIRE
67	A/C & HEAT SYSTEM
67A	A/C & HEAT SYSTEM
67B	A/C & HEAT SYSTEM
67C	A/C & HEAT SYSTEM
69	RR JCT BOX 24V HOT WIRE
70	INTERIOR LTS-READING LTS
70A	INTERIOR LTS-HAT RACK LTS
70B	INTERIOR LTS-HAT RACK LTS
71	A/C AUXILIARY-DASH SW
71B	A/ B -ORD-BACK UP ALARM
71B	A/C AUXILIARY-DASH SW
72	A/C AUXILIARY-DASH SW
72H	A/C AUXILIARY-DASH SW
73	LAVATORY-NIGHT LTS
74	INTERIOR LTS-READING LTS
74A	INTERIOR LTS-READING LTS
74B	INTERIOR LTS-READING LTS
75	INTERIOR LTS-READING LTS
76	FUEL TANK GAUGE
76A	LOW FUEL LT
76B	LOW FUEL LT
76C	LOW FUEL LT
76D	LOW FUEL LT
76L	LOW FUEL LT
76M	FUEL PRIME PUMP
76P	FUEL PRIME PUMP
77H	A/C & HEAT SYSTEM-CLUTCH
77B	A/C AUXILIARY-LIQ. SOL.
77C	A/C AUXILIARY-LIQ. SOL.
77H	A/C & HEAT SYSTEM-FAN CLUTCH
77E	24V HOT WIRE
78A	24V HOT WIRE
80	WORLD TRANSM-NEUTRAL SIGNAL GRD
81	EXTERIOR LTS-STOP SW
82	EXTERIOR LTS-STOP SIGNAL
82A	EXTERIOR LTS-STOP SIGNAL
82B	EXTERIOR LTS-STOP LTS
82K	EXTERIOR LTS-STOP RETARDER
82L	EXTERIOR LTS-STOP LTS
82R	EXTERIOR LTS-STOP LTS
83	ENGINE CTR-MAST KEY SW ACCES
84	ENGINE CTR-MAST KEY SW START
84A	ENGINE CTR-MAST KEY SW START
85	ENGINE CTR-MAST KEY SW IGN
85A	24V IGN DASH INSTRUMENTATION
85B	24V IGN DASH INSTRUMENTATION
85BE	BATTERY MONITOR 24V IGN
85C	ENGINE CTR-24V IGNITION
85C	PARKING BRAKE SWITCH
85F	LO AIR SONALERT
85W	ABS-24V IGN
85X	ABS-24V IGN

NO.	SYSTEM
85Y	ABS-WARNING LT
86	ENGINE CTR-STARTER SOL SIGN
86A	ENGINE CTR-STARTER SOL SIGN
87B	ENGINE CTR-24V IGNITION
88	ENGINE CTR-RR START SIGNAL
89	A/C & HEAT SYSTEM-WATER PUMP
90	GALLEY SYSTEM
90	DIGITAL CLOCK
90A	GALLEY SYSTEM
90B	ENGINE CTR-MAST KEY SW FEED
90C	GALLEY SYSTEM
90D	FR JCT PANEL 24V DISC SW
90E	ALARM & SIGNAL-FIRE DETECTOR
90F	GALLEY SYSTEM
90G	PARKING BRAKE SW SIGNAL
91	CH|ME-HOSTESS & PASSENGER
91A	DDEC III-FAST IDLE SIGNAL
91B	EXTERIOR LTS-DIR.SIG LTS CANCEL
91C	PRE-HEAT WATER HEATER
92	BATTERY MONITOR-CHECK BALANCE
92A	BATTERY MONITOR-CHECK BALANCE
93	BATTERY MONITOR-CHECK LO/HI
93A	BATTERY MONITOR-CHECK LO/HI
94	HIGH BUDY SYSTEM
94A	HIGH BUDY SYSTEM
95	ENGINE BRAKE & RETARDER SYSTEM
95A	ENGINE BRAKE & RETARDER SYSTEM
95B	ENGINE BRAKE & RETARDER SYSTEM
97	TACHOMETER
99	A/C AUXILIARY-DASH SW
100	INTERIOR LTS-GENERAL LTS
100A	INTERIOR LTS-GENERAL LTS
100B	INTERIOR LTS-GENERAL LTS
100C	INTERIOR LTS-GENERAL LTS
101	WORLD TRANSM-LO SIGNAL SOL. LO
101A	WORLD TRANSM-LO SIGNAL SOL.
102	24V STARTER TO GENERATOR
102	WORLD TRANSM-SOL. GRD 1
103	WORLD TRANSM-SOL. 1
104	WORLD TRANSM-SOL. FORWARD
105	WORLD TRANSM-RETARDER & SUMP
105W	WORLD TRANSM-RETARDER & SUMP
106	WORLD TRANSM-OIL LEVEL HI
107	CHARG SYST-VOLTAGE REGUL. 'F'
107	WORLD TRANSM-LOCKUP SOL. HI
108	WORLD TRANSM-RETARDER PUMP WAKE UP
108	24V DISC SW TO 24V SYSTEM
108A	CHARG SYST-VOLTAGE REGUL. 'B'
109	WORLD TRANSM-RET. SOL. LO
110	ALARM & SIGNAL-WATER TEMP
110	WORLD TRANSM-LOCKUP SOL. LO
111	BATTERY GRD
112	WORLD TRANSM-SOL. C6
112	WORLD TRANSM-SPARE OUTPUT (+)
113	ALARM & SIGNAL-OIL PRESS
113	WORLD TRANSM-REVERSE WARNING
114	WORLD TRANSM-SPARE OUTPUT (-)
114	INTERIOR LTS-DASH LT REGUL.
114A	INTERIOR LTS-DASH LT

NO.	SYSTEM
114B	INTERIOR LTS-DASH LT REGUL.
114C	INTERIOR LTS-DASH LT
115	ALARM & SIGNAL-TAG PRESS
115	DDEC III-COOLANT LEVEL
115	WORLD TRANSM-DO NOT SHIFT SIGNAL
115A	ALARM & SIGNAL-TAG PRESS
115B	ALARM & SIGNAL-TAG PRESS
115C	DDEC III-COOLANT LEVEL
115W	WORLD TRANSM-DO NOT SHIFT SIGNAL
116	WORLD TRANSM-LO SIGNAL SOL. HI
116	A/C & HEAT SYSTEM-DRIVER'S HTR
116A	A/C & HEAT SYSTEM-DRIVER'S HTR
116B	A/C & HEAT SYSTEM-DRIVER'S HTR
117	ALARM & SIGNAL-TRANSM OIL TEMP
117A	ALARM & SIGNAL-TRANSM OIL TEMP
118	WORLD TRANSM-SPARE INPUT (+)
119	CH|ME-HOSTESS & PASSENGER
119	WORLD TRANSM-ENG BRK INPUT (+)
119A	CH|ME-HOSTESS & PASSENGER
119B	CH|ME-HOSTESS & PASSENGER
120	12V HOT WIRE
120	WORLD TRANSM-SOL. C1
120D	12V HOT WIRE
120V	VIDEO SYSTEM
120Z	VIDEO SYSTEM
121	WORLD TRANSM-SOL. GRD 2
121	CIGAR LIGHTER
122	A/C & HEAT SYSTEM-DRIVER'S HTR
122	A/C & HEAT SYSTEM-FRESH AIR
122	WORLD TRANSM-SOL. 2
123	WORLD TRANSM-NEUTRAL START
123	ALARM & SIGNAL-FIRE DETECTOR
123A	ALARM & SIGNAL-FIRE DETECTOR
124	WORLD TRANSM-THROTTLE (HI)
124	LAVATORY-FAN
125	WORLD TRANSM-RETARDER INDICATOR
125W	WORLD TRANSM-RETARDER INDICATOR
126	ALARM & SIGNAL-PRESS SW.
126	KNEELING SYSTEM
126A	KNEELING SYSTEM
126B	KNEELING SYSTEM
126C	KNEELING SYSTEM
126E	KNEELING SYSTEM
127	WORLD TRANSM-RETARDER FEED SOL.
127	PRE-HEAT WATER HEATER
127A	PRE-HEAT WATER HEATER
127B	PRE-HEAT WATER HEATER
127K	PRE-HEAT WATER HEATER
127X	PRE-HEAT WATER HEATER
128	WORLD TRANSM-SOL. C2
128A	PRE-HEAT WATER HEATER
128B	PRE-HEAT WATER HEATER
128C	PRE-HEAT WATER HEATER
128D	PRE-HEAT WATER HEATER
128E	PRE-HEAT WATER HEATER
128F	PRE-HEAT WATER HEATER
128W	PRE-HEAT WATER HEATER
128X	PRE-HEAT WATER HEATER
129	WORLD TRANSM-SOL. C5

NO.	SYSTEM
129	PRE-HEAT WATER HEATER
129A	PRE-HEAT WATER HEATER
129B	PRE-HEAT WATER HEATER
130	WORLD TRANSM-SOL. GRD 3
130	A/C & HEAT SYSTEM-EVAPORATOR
130	A/C & HEAT SYSTEM-EVAPORATOR
131	24V DISC SW TO FR JCT PANEL
131	WORLD TRANSM-SOL. C4
132	WORLD TRANSM-ENG BRK OUTPUT (-)
132K	WORLD TRANSM-ENG BRK OUTPUT (-)
133	WORLD TRANSM-RET. ACTUATOR HI
133	GALLEY SYSTEM-CONTAINER RH
133A	GALLEY SYSTEM-CONTAINER RH
134	WORLD TRANSM-RET. APPLY SOL. HI
134	GALLEY SYSTEM-CONTAINER RH
134A	GALLEY SYSTEM-CONTAINER RH
135	WORLD TRANSM-ANALOG GRD
135	A/C AUXILIARY-FAN
135A	A/C AUXILIARY-FAN
135B	A/C AUXILIARY-COIL SENSING
135C	WORLD TRANSM-RETARDER TEMP
135D	WORLD TRANSM-RETARDER RES HOD
136	GALLEY SYSTEM-LAMP
136	WORLD TRANSM-ECU POWER
136V	WORLD TRANSM-12V BATTERY
136W	WORLD TRANSM-12V BATTERY
136X	WORLD TRANSM-12V BATTERY
137	WORLD TRANSM-RETARDER
137	RR VIEW MIRROR
137A	RR VIEW MIRROR
138	WORLD TRANSM-RETARDER TEMP
138	ABS SYSTEM
138A	A/C AUXILIARY-FAN
138B	ABS SYSTEM
138C	A/C AUXILIARY-FAN
139	ABS SYSTEM
139A	A/C AUXILIARY-FAN
139B	WORLD TRANSM-OUTPUT SPEED HI
139W	A/C AUXILIARY-FAN
140	A/C AUXILIARY-SHUTTER
140	WORLD TRANSM-OUTPUT SPEED LO
140	ABS SYSTEM
141	ABS SYSTEM
141	WORLD TRANSM-ENGINE SPEED HI
142	WORLD TRANSM-SERIAL COM. A
142	ABS SYSTEM
142	ABS SYSTEM
143	WORLD TRANSM-ECU BATTERY GRD
143W	WORLD TRANSM-BATTERY GRD
143X	WORLD TRANSM-BATTERY GRD
144	WORLD TRANSM-ECU CHASSIS GRD
144	ABS SYSTEM
144A	ABS SYSTEM
145	ABS SYSTEM
146	ABS SYSTEM
146	WORLD TRANSM-IGNITION SENSE
146W	WORLD TRANSM-12V IGNITION
146X	WORLD TRANSM-12V IGNITION

CIRCUIT NUMBER CODE — PAGE: 3

NO.	SYSTEM
147	WORLD TRANSM-OIL TEMP
147	ABS SYSTEM
147A	ETHER COLD START
147B	ABS SYSTEM
148	WORLD TRANSM-OUTPUT SPEED LO
149	WORLD TRANSM-TURBINE SPEED HI
149	ABS SYSTEM
149A	ABS SYSTEM
150	ABS SYSTEM-SPARE
150	WORLD TRANSM-ENGINE SPEED LO
150	DDEC III-ECM BATTERY GRD
150A	DDEC III-ECM BATTERY GRD
151	DDEC III-ECM BATTERY GRD
151	WORLD TRANSM-SERIAL COM. B
151	ABS SYSTEM-SPARE
152	ABS SYSTEM-SPARE
153	ABS SYSTEM
153	WORLD TRANSM-SPARE INPUT (-)
154	WORLD TRANSM-ABS RETARDER INPUT
155	WORLD TRANSM-SPARE INPUT (-)
155	ABS SYSTEM
156	WORLD TRANSM-THROTTLE POS.
156	ABS SYSTEM
156A	ABS SYSTEM
156C	ABS SYSTEM
156W	ABS SYSTEM
157	WORLD TRANSM-SPEEDOMETER SIGNAL
157	ABS SYSTEM
157A	ABS SYSTEM
157B	ABS SYSTEM
157C	ABS SYST.-CANCEL SEC. BRK
158	WORLD TRANSM-DIMMER
160	WORLD TRANSM-SERIAL INTERFACE (-)
161	WORLD TRANSM-SIGNAL GRD
161B	WORLD TRANSM-SIGNAL GRD
162	WORLD TRANSM-PRESS. SW C3
163	WORLD TRANSM-RETARDER PRESSURE
164	WORLD TRANSM-RET. ACTUATOR SIGN
165	WORLD TRANSM-OIL LEVEL SIGNAL
168	WORLD TRANSM-SERIAL INTERFACE (+)
170C	LUGGAGE DOOR LOCK
170D	LUGGAGE DOOR LOCK
170E	LUGGAGE DOOR LOCK
170F	LUGGAGE DOOR LOCK
170G	LUGGAGE DOOR LOCK
170H	LUGGAGE DOOR LOCK
170J	LUGGAGE DOOR LOCK
170L	LUGGAGE DOOR LOCK
170M	LUGGAGE DOOR LOCK
170N	LUGGAGE DOOR LOCK
170P	LUGGAGE DOOR LOCK
170R	LUGGAGE DOOR LOCK
170S	LUGGAGE DOOR LOCK
170V	LUGGAGE DOOR LOCK
170W	LUGGAGE DOOR LOCK
170X	LUGGAGE DOOR LOCK
170Y	LUGGAGE DOOR LOCK
170Z	LUGGAGE DOOR LOCK
182	PYROMETER
182A	PYROMETER

NO.	SYSTEM
197A	FUEL WATER FILTER
197B	FUEL WATER FILTER
201	WORLD TRANSM-SPARE
202	WORLD TRANSM-SPARE
203	WORLD TRANSM-SPARE
204	WORLD TRANSM-SPARE
205	WORLD TRANSM-SPARE
206	WORLD TRANSM-SPARE
214	WORLD TRANSM-BACK UP SIGNAL
214A	BACK UP SIGNAL
214B	BACK UP SIGNAL
231	NEUTRAL SIGNAL GRD
240	DDEC III-ECM 12V FEEDING
241	DDEC III-ECM 12V FEEDING
250	PROGRAMMING PLUG
290	FAN CLUTCH RADIATOR
291	FAN CLUTCH RADIATOR SPD 1
292	FAN CLUTCH RADIATOR SPD 2
417	DDEC III-LIMIT SPEED GOVERNOR
438	DDEC III-ENGINE ENGINE LIGHT
439	DDEC III-12V IGNITION
440	DDEC III-12V IGNITION
440A	DDEC III-12V IGNITION
451	DDEC III-A/C FAN CLUTCH
505	DDEC III-TACHOMETER DRIVE
509	DDEC III-STOP ENGINE LIGHT
513	DDEC III-FAST IDLE SIGNAL
521	DDEC III-ENGINE BRAKE DISABLE
525	DDEC III-STOP ENGINE
528	DDEC III-STOP ENG. OVERRIDE
531	DDEC III-CRUISE CLUTCH RELEASE
532	DDEC III-CRUISE SET SW
543	DDEC III-CRUISE STOP SW CUT IN
544	DDEC III-CRUISE ON/OFF SW
545	DDEC III-CRUISE RESUME SW
555	DDEC III-CRUISE CLUTCH SPEED 1
556	DDEC III-VEHICLE SPEED (+)
557	DDEC III-VEHICLE SPEED (-)
563	DDEC III-CRUISE CLUTCH SPEED* 2
583	DDEC III-ENGINE BRAKE 4 CYL.
584	DDEC III-PROGRAMMING LIGHT
900	DDEC III-DATA LINK (+)
901	DDEC III-DATA LINK (-)
908	DDEC III-HYDRAULIC TRANSM. MODUL.
916	DDEC III-SENSOR SUPPLY (5VDC)
952	DDEC III-DATA LINK RETURN
953	DDEC III-BATTERY GRD
953C	DDEC III-BATTERY GRD
979	DDEC III-ENGINE BRAKE 2 CYL.
A	A/C & HEAT SYSTEM-HI PRES.
A1	A/C & HEAT SYSTEM-LO PRES.
A4	A/C & HEAT SYSTEM-CONTROL SW
A5	A/C & HEAT SYSTEM-CONTROL SW
A6	A/C & HEAT SYSTEM-CONTROL SW
L	INTERIOR LTS-11OV FLUORESCENT
L1	INTERIOR LTS-11OV FLUORESCENT
L1A	INTERIOR LTS-11OV FLUORESCENT
L1C	INTERIOR LTS-11OV FLUORESCENT
L2A	INTERIOR LTS-11OV FLUORESCENT
L7	INTERIOR LTS-11OV FLUORESCENT
L8	ENG.BLK & WATER TANK-HEATER

NO.	SYSTEM
L9	ENG.BLK & WATER TANK-HEATER
N1	VIDEO SYSTEM- 11OV
N2	INTERIOR LTS-11OV FLUORESCENT
J4	A/C & HEAT SYSTEM-DRIVER'S HTR
O3	A/C & HEAT SYSTEM-DRIVER'S HTR
R1	A/C & HEAT SYSTEM-DRIVER'S HTR
R6	A/C & HEAT SYSTEM-DRIVER'S HTR
SH1	SHIELD WIRE GRD
SH2	SHIELD WIRE GRD
SH3	SHIELD WIRE GRD
V5	A/C & HEAT SYSTEM-DRIVER'S HTR
V7	A/C & HEAT SYSTEM-DRIVER'S HTR