

# PREVOST

## Instruction Sheet

## IS-97082

### MARKER LIGHT HOUSING (FRONT OR REAR)

#### MATERIAL

Kit #47-3745 includes the following parts :

Part No.	Description	Qty
5001364	Philipps screw	14
562834	Male connector	7
562835	Female connector	7
562836	Gasket	7
504661	Grommet	7
562837	Gasket	7
IS-97082	Instruction Sheet	1
FI-97082	Feuille d'instructions	1

#### PROCEDURE

**Warning :** Park vehicle safely, apply parking brake, stop engine and set battery master switch(es) to the OFF position prior to working on the vehicle..

1. Install a gasket on the lens assembly. Install two gaskets on the marker lights to be installed in the corners.
2. Install grommet in the housing.
3. Cut the existing connectors off the wires. Pass the wires through the grommet into the housing.
4. Remove some insulation on the wire's end and install a connector on each wire.
5. Put some nyogel (not included) on connectors and install to bulb assembly.
6. Insert the bulb assembly in the lens assembly. Fasten in place by turning about ¼ turn.
7. Screw the lens-bulb assembly to the housing with the included screws. Be careful to install lens so that the writing is right-side up.
8. Visually inspect for proper fit of seal.