

SUBJECT : PROTECTION OF CIRCUITS 103 AND 7B INSIDE FRONT SERVICE COMPARTMENT

APPLICATION

| Model | |
|---|--|
| XL2-45 Coaches Model Year: 2000 - 2002 | From 2PCX33491 <u>Y</u> 102 <u>7031</u> up to 2PCX33497 <u>2</u> 102 <u>7901</u> incl. |

DESCRIPTION

For the above-mentioned vehicles equipped with front suspension kneeling system but without high buoy or low buoy suspension system, a heat shrink tubing must be added to circuit 103 and 7B wire end.

MATERIAL

| Part No. | Description | Qty |
|----------|---------------------|-----|
| 561918 | Tubing, Heat shrink | 1 |

Note : Material can be obtained through regular channels.

PROCEDURE

Warning: Park vehicle safely, apply parking brake, stop engine and set battery master switch(es) to the OFF position prior to working on the vehicle.

- 1. Open front service compartment door.
- 2. Locate wires 103 and 7B (refer to figure 1).
- 3. Cut one piece of heat shrink tubing to isolate each wire end.
- 4. Insert each wire into heat shrink tubing then heat.
- 5. Secure wires inside compartment.

6. Close front service compartment door.



FIGURE 1: LOCATION OF WIRES INSIDE FRONT SERVICE COMPARTMENT

WARRANTY

This modification is covered by Prévost Car's normal warranty. We will reimburse you the parts and one quarter hour (0.25) of labor upon receipt of a completed A.F.A. form on which you must specify as per "Warranty Bulletin 02-11".

Parts / Waste disposal:

Discard waste according to applicable environmental regulations (Municipal/State[Prov.]/ Federal)