

## APPLICATION

Model	VIN	
All H3 Series Vehicles Model Year: 1990 - 1996	From 2P9V	33402 <u>L</u> 100 <u>1030</u> up to 2PCH33493 <u>T</u> 101 <u>1474</u> incl.

# **DESCRIPTION:**

On the above-mentioned vehicles, rear start switch box is replaced with a watertight assembly.

## MATERIAL

Part No.	Description	Qty
381804	Box assembly, rear start switch	1
562566	Connector	1
561608	Pin, contact	5

*Note*: Material can be obtained through regular channels.

## PROCEDURE

**Warning:** Park vehicle safely, apply parking brake, stop engine and set battery master switch(es) to the OFF position prior to working on the vehicle.

- 1. Open engine compartment door (refer to fig. 1).
- 2. Cut wires as close as possible to rear start switch input connector (refer to fig. 2).
- 3. Unfasten rear start swich box attaching parts and remove the box, keep attaching parts aside.
- 4. Secure new rear start switch box (Prévost #381804) using attaching parts.
- 5. Remove about 3/8 inch of sheath covering each wire and crimp a contact pin (Prévost #561608) onto each wire.

*Note :* It is recommended to use crimping tool (Prévost #682247) to crimp contact pins.



FIGURE 1 : ENGINE COMPARTMENT



FIGURE 2 : REAR START SWITCH BOX

6. Carefully insert contact pins into connector housings (Prévost #562566) as per figure 3 and join connector with rear start switch box input connector.



FIGURE 3 : CONNECTOR

# WARRANTY

This modification is covered by the manufacturer's normal warranty. We will reimburse you the parts and one hour (1.0) of labor upon receipt of a completed A.F.A. form on which you must specify as per "Warranty Bulletin 98-04".

#### Parts disposition:

- Discard according to applicable environmental regulations (Municipal/State[Prov.]/ Federal)

Expiration date : March 1999