PREVOST

Instruction Sheet

IS-98121B

TRANSMISSION BREATHER RELOCATION

Revision B:

In kit #071171, part 560480 is replaced by 949746

MATERIAL

Kit #071171 includes the following parts:

Part No.	Description	Qty
060840	Support Plate	1
071170	Transmission Breather Hose	1
500440	Washer, Flat	1
500476	Lockwasher, M8	1
500574	Bolt, 10-24 x 1-1/4	1
500786	Nut, 10-24	1
502790	Bolt, M8 x 20	1
504601	Clip, Retaining	1
949746	Clip, Retaining	1
5001194	Bolt, M12	1
IS-98121A	Instruction Sheet	1
FI-98121A	Feuille d'instructions	1

PROCEDURE

Warning: Park vehicle safely, apply parking brake, stop engine and set battery master switch(es) to the OFF position prior to working on the vehicle.

- 1. Place vehicle over a repair pit.
- 2. Find and remove the transmission breather, located on top of transmission housing.
- 3. Screw breather onto end of hose (#071170).
- 4. Screw the other end of breather hose onto transmission breather hole.
- 5. Place retaining clip (#949746) onto hose and fasten to support plate (#060840) using hardware (#500574, #500440 and #500786).

- 6. Fasten bracket assembly onto engine block as shown in figure 1 using the M12 bolt (#5001194).
- 7. Fasten the hose (#071170) to the transmission using retaining clip (#504601) and hardware (#502790 and #500476), as shown.
- 8. Keep breather hose away from heat sources using an existing retaining clip as shown.




FIGURE 1: ENGINE AND TRANSMISSION ASSEMBLY (TYPICAL)

07028