

FIRE DETECTOR INSTALLATION GUIDE

MATERIAL

Kit #065323 includes the following parts :

Part No.	Description	Qty
065290	Fire detector	1
562486	Connector, Deutsch 2C PHR	1
562487	Deutsch connector sec. lock 2C PHR	1
562286	Male contact pin	3
5001204	Screw, self-taping # 6x1 ½ FL ZP	2
IS-99091	Instruction Sheet	1
FI-99091	Feuille d'instructions	1

PROCEDURE

Warning : Park vehicle safely, apply parking brake, stop engine and set battery master switch(es) to the OFF position prior to working on the vehicle.

1. Locate the fire detector on the ceiling of the engine compartment.
2. Using pliers, cut the power supply leads.
3. Remove a part of the insulating sleeve and crimp the male contact pins (Prévost #562286) on the leads.
4. Insert the male contact pins in the Deutsch connector (Prévost #562486), placing lead 123B into port #1 and lead 0B into port #2.
5. Fix the male contact pins by inserting the Deutsch connector lock (Prévost #562487).
6. Drill two 1/8" (3.2mm) diameter holes.
7. Using the self-taping screws (Prévost #5001204), install the fire detector (Prévost #065290).
8. Set battery master switch(es) to the "ON" position.
9. You may test the installation by heating the fire detector with a heat gun. An alarm should ring and the fire indicator warning light should illuminate in the telltale panel.

Note : Fire detector will return to normal functioning mode after cooling down of the contact fingers.