

\*\*Ground distribution:\*\*

0-Electric gnd  
00- Electronic Gnd


A-Dash - Lh console harness  
F-Front junction box harness  
FH-Front harness  
R-Rear junction box harness  
FR-Front to rear

FJB  
Electronic GND


RJB  
Electronic GND

RJB  
Electronic GND


### Dash harness





### Lh console harness




### Front harness



### FJB harness



### RJB harness



gnd- 00-1/0 • 1.1\_batteries:2 B

## Electronic ground distribution

