


**Main distribution batteries & ignition
Customer Adaptation Offshore Heating Sys.**

REFER TO P3.1(STD) FOR ALL DETAILS



**CAUTION !
WITH OFFSHORE HEATING SYSTEM
MAIN CABLE CB3 ARE ON 24VD
OPEN CB3 BREAKER TO REMOVE THE POWER**