


**Main distribution batteries & ignition  
Customer Adaptation Aux. batteries in lugg. compt**

REFER TO P3.1(STD) FOR ALL DETAILS



**Note: Will be delivered F103 & CB15 unplugged in RJB**