




Forward collision warning


Sw122A
LDW





Connect to the terminal strip with 12V Ign stud. See P4.1



Connect to the terminal strip with 12V Bat stud. See p4.1




Connect to the front electronic terminal strip. See p2.1






Camera

See p6.2 existing wiring




Move pins from connector C7A (existing harness) pins A,B,C and D to C7AA (Service Fusion X harness)



Radar

Unplug the Res7 to the Dash board and plug at the Res7A. See P6.2



Connect Res7 to Res7B See p6.2

