

Circuits list

Circuit ID	Description	Circuit ID	Description	Circuit ID	Description
00	GND Batteries	0SB	Cadec	A1.11	Transmission Alisson
0A	12V outlets	0SB1	Cluster	A1.12	Transmission Alisson
00A	Entrance door	0SS	GND Stud	A1.15	Transmission Alisson
00A1	Multiplex power	0SS1	VSS	A1.16	Transmission Alisson
0AItLL	GND Chassis	0SS2	VSS	A1.18	Transmission Alisson
0AItR	GND Chassis	0SS2W	Cadec	A1.19	Transmission Alisson
0B	GND Chassis	0SS3	VSS	A1.24	Transmission Alisson
0C	Ignition & engine start	0SW	Indirect lights	A1.25	Transmission Alisson
0chgr	Pre heat	0SW1	Indirect lights	A1.31	Transmission Alisson
0COND	Condensor	0TR-White	VECT	A1.33	Transmission Alisson
0ECU	Engine ECU Volvo	00VA	RJB electronic GND	A1.36	Transmission Alisson
0EV2	HVAC passengers	0W	GND Stud	A1.37	Transmission Alisson
0EVAP1	HVAC passengers	12Ecu	12V ECU	A1.51	Transmission Alisson
0EVAP2	HVAC passengers	12ISH	Pwr I_Shift	A1.52	Transmission Alisson
0F	GND Customer	12VA	Batteries	A1.54	Transmission Alisson
00F	FJB electronic GND	12VD	Batteries	A1.55	Transmission Alisson
00F1	Multiplex power	12VD1	12VD	A1.58	Transmission Alisson
00F2	Multiplex power	12VD4	12VD	A1.71	Transmission Alisson
00F3	Multiplex power	12VDG	Cadec	A1.74	Transmission Alisson
00F6	Indirect lights	12VDG1	Cadec	A1.76	Transmission Alisson
0FE	GND stud	12VDG1A	Cadec	A1.77	Transmission Alisson
0FH	Wipers & washer	12VDG2	Cadec	A2A.9	Transmission Alisson
00FH	FJB electronic GND	12VDG3	Cadec	A2A.11	Transmission Alisson
00FH1	HVAC defroster	12VDG4	Cadec	A3.1	Transmission Alisson
00FH2	Multiplex power	12VIG	Cadec	A3.2	Transmission Alisson
00FR	FJB-RJB junction	12VIG1	Cadec	A3.3	Transmission Alisson
0P	120VAC outlets	12VIG1A	Cadec	A3.5	Transmission Alisson
0PA	GND stud	12VIG2	Cadec	A3.6	Transmission Alisson
0PR	120VAC outlets	12VIG3	Cadec	A3.7	Transmission Alisson
0R	GND Chassis	12VIG4	Cadec	A4B.8	Transmission Alisson
00R	Networks	12VIG5	Cadec	A5.B	Transmission Alisson
00R1	RJB electronic GND	24VA	Batteries	A9CX1.2	Cluster
00R2	Multiplex power	24VD	Batteries	A9CX1.4	ESP
00R3	Multiplex power	24VD2	Equalizer	A9CX1.5	ESP
00R4	Multiplex power	24VD3	Ignition & engine start	A9CX1.6	Cluster
00R5	RJB electronic GND	24VI	24 WUP	A9CX2.1	ESP
0RAD	GND Chassis	900	Networks	A9CX2.2	ESP
0RAD2	Fans drive electric	901	Networks	A9CX2.3	ESP

Circuits list

Circuit ID	Description	Circuit ID	Description	Circuit ID	Description
A9CX2.4	ESP	A34.A5	Fans drive electric	A41J1.10	Gateway A32
A9CX2.6	ESP	A34.B5	Fans drive electric	A41J1.16	Engine ECU Volvo
A9CX2.7	ESP	A34.C5	Fans drive electric	A41J1.19	Engine ECU Volvo
A9CX2.9	ESP	A34.D5	Fans drive electric	A41J2.11	Cadec
A9CX2.10	ESP	A34.E5	Fans drive electric	A41J2.12	Cadec
A9CX2.12	ESP	A34.F5	Fans drive electric	A41J2.13	Cadec
A9CX2.13	ESP	A34.G5	Fans drive electric	A42J1.1	Kneeling, tag, low buoy
A9CX2.16	ESP	A34.H5	Fans drive electric	A42J1.3	Kneeling, tag, low buoy
A9CX2.17	ESP	A34J.E	Fans drive electric	A42J1.4	Kneeling, tag, low buoy
A9CX3.2	ESP	A34J.F	Fans drive electric	A42J1.7	Kneeling, tag, low buoy
A9CX3.3	ESP	A34R.A3	Fans drive electric	A42J1.10	Kneeling, tag, low buoy
A9CX3.5	ESP	A34R.B3	Fans drive electric	A42J1.13	Kneeling, tag, low buoy
A9CX3.7	ESP	A34R.C3	Fans drive electric	A42J1.16	Kneeling, tag, low buoy
A9CX3.9	ESP	A34R.D3	Fans drive electric	A42J1.19	Kneeling, tag, low buoy
A9CX3.10	ESP	A34R.E3	Fans drive electric	A42J2.15	Kneeling, tag, low buoy
A9CX4.1	ESP	A34R.F3	Fans drive electric	A42RJ2.14	Kneeling, tag, low buoy
A9CX4.4	ESP	A34R.G3	Fans drive electric	A42RJ2.18	Kneeling, tag, low buoy
A9CX4.7	ESP	A34R.H3	Fans drive electric	A43J1.1	Lugg_door_lock
A9CX4.8	ESP	A36JA.11	Horn	A43J1.3	Lugg_door_lock
A9CX4.10	ESP	A36JA.15	Ignition & engine start	A43J1.7	TPMS
A9CX4.11	ESP	A36JA.17	Ignition & engine start	A43J2.1	Lugg_door_lock
A10X3.4	Pre heat	A36JA.25	Brake	A43J2.4	Lugg_door_lock
A10X3.6	Pre heat	A36JB.2	Ignition	A43J2.7	Engine ECU Volvo
A11A.2	Pre heat	A36JB.14	Fire suppression	A43J2.10	Engine ECU Volvo
A14.A12	Cluster	A39P101.1	Speakers	A43RJ1.17	ACB
A14.B1	Cluster	A39P101.2	Speakers	A44J1.1	Upper defrost
A14.B18	Cluster	A39P101.3	Speakers	A44J1.3	Upper defrost
A14.B20	Cluster	A39P101.4	Speakers	A44J1.4	Entrance door
A14.B21	Cluster	A39P101.5	Speakers	A44J1.7	Wipers & washer
A16.5	Destination signs	A39P101.6	Speakers	A44J1.10	Wipers & washer
A16.6	Destination signs	A39P101.8	Speakers	A44J1.13	Upper defrost
A17.24V	Pre heat	A39P101.9	Speakers	A44J1.16	Horn
A17.AC	Pre heat	A39P901.1	Speakers	A44J1.19	Engine & RJB cmpt. lights
A20.3	Digital clock	A39P901.4	Speakers	A44J2.1	Sun visor
A27.30	ZF steering	A39P901.5	Speakers	A44J2.4	Sun visor
A27.87A	ZF steering	A39P901.6	Speakers	A44J2.7	Driver lights
A32J2.1	Digital clock	A41J1.1	Pre heat	A44J2.10	Sun visor
A32J2.10	Digital clock	A41J1.7	Shutdown	A44J2.13	Sun visor

Circuits list

Circuit ID	Description	Circuit ID	Description	Circuit ID	Description
A44RJ1.17	Fr flashers, Mrk, Clr, head lgts	A48J1.1	Cornering & fog lights	A51J2.1	Rr flash, Mrk, Tail, Stop lgts
A44RJ1.18	Upper defrost	A48J1.4	Cornering & fog lights	A51J2.4	Transmission Alisson
A44RJ2.2	Entrance door	A48J1.7	Fr flashers, Mrk, Clr, head lgts	A51J2.7	Rr flash, Mrk, Tail, Stop lgts
A44RJ2.3	Wipers & washer	A48J1.10	Fr flashers, Mrk, Clr, head lgts	A51J2.10	Rr flash, Mrk, Tail, Stop lgts
A45J1.1	HVAC defroster	A48J2.1	Fr flashers, Mrk, Clr, head lgts	A51RJ1.17	Rr flash, Mrk, Tail, Stop lgts
A45J1.3	HVAC defroster	A48J2.4	Front lights	A51RJ1.18	WCL
A45J1.4	ZF steering	A48J2.13	Fr flashers, Mrk, Clr, head lgts	A52J1.1	Fans drive electric
A45J1.7	Parcel rack A/C system	A48RJ1.17	Cornering & fog lights	A52J1.3	Fans drive electric
A45J1.16	Mirrors	A48RJ1.18	Fr flashers, Mrk, Clr, head lgts	A52J1.4	Lavatory
A45J2.1	HVAC defroster	A48RJ2.2	Fr flashers, Mrk, Clr, head lgts	A52J1.7	Engine & RJB cmpt. lights
A45J2.4	HVAC defroster	A49J1.1	Fans drive electric	A52J1.10	Ignition & engine start
A45J2.7	Driver window	A49J1.3	Fans drive electric	A52J1.13	RJB Fan
A45J2.13	Driver window	A49J1.4	Kneeling, tag, low buoy	A52J2.1	Alternators
A45RJ1.17	Cornering & fog lights	A49J1.7	Cadec	A52J2.4	Alternators
A46J1.1	Horn	A49J2.1	Alternators	A52J2.13	Ignition & engine start
A46J1.4	Fr flashers, Mrk, Clr, head lgts	A49J2.13	Brake	A52RJ1.17	GND MUX modules
A46J1.7	Cornering & fog lights	A49J2.15	Weight monitoring	A52RJ1.18	Engine & RJB cmpt. lights
A46J1.10	Fr flashers, Mrk, Clr, head lgts	A49RJ1.6	Weight monitoring	A52RJ2.3	Ignition start
A46J1.13	Fr flashers, Mrk, Clr, head lgts	A49RJ1.17	Kneeling, tag, low buoy	A53J1.1	Parcel rack A/C system
A46J1.17	Front lights	A49RJ1.18	Cadec	A53J1.3	Parcel rack A/C system
A46J2.4	Fr flashers, Mrk, Clr, head lgts	A49RJ2.2	Fans drive electric	A53J1.4	Lavatory
A46J2.7	Front lights	A50J1.4	Air dryer	A53J1.13	Lavatory
A46RJ1.17	Fr flashers, Mrk, Clr, head lgts	A50J1.7	Back-up warnings	A53J2.1	Indirect lights
A46RJ1.18	Fr flashers, Mrk, Clr, head lgts	A50J1.13	Rr flash, Mrk, Tail, Stop lgts	A53J2.4	Reading lamps & chime
A47J1.1	HVAC defroster	A50J1.19	Rr flash, Mrk, Tail, Stop lgts	A53J2.7	lavatory lamp
A47J1.3	HVAC defroster	A50J2.1	Rr flash, Mrk, Tail, Stop lgts	A53J2.10	Reading lamps & chime
A47J1.4	HVAC defroster	A50J2.7	Rr flash, Mrk, Tail, Stop lgts	A53J2.13	Emergency & aisle lights
A47J1.7	Wipers & washer	A50J2.10	Back-up warnings	A53RJ1.17	Lavatory
A47J1.10	Entrance door	A50RJ1.17	Rr flash, Mrk, Tail, Stop lgts	A53RJ1.18	Emergency & aisle lights
A47J1.13	Entrance door	A50RJ1.18	Rr flash, Mrk, Tail, Stop lgts	A53RJ2.2	Parcel rack A/C system
A47J1.16	Entrance door	A50RJ2.2	Back-up warnings	A53RJ2.3	Reading lamps & chime
A47J1.19	Entrance door	A50RJ2.3	Air dryer	A54J1.1	HVAC passengers
A47J2.1	HVAC defroster	A51J1.4	Rr flash, Mrk, Tail, Stop lgts	A54J1.3	HVAC passengers
A47J2.7	Entrance door	A51J1.7	Stop lights	A54J1.4	Pre heat
A47RJ1.6	HVAC defroster	A51J1.10	Rr flash, Mrk, Tail, Stop lgts	A54J1.7	HVAC passengers
A47RJ1.17	HVAC defroster	A51J1.13	Rr flash, Mrk, Tail, Stop lgts	A54J1.10	Pre heat
A47RJ1.18	Entrance door	A51J1.16	Transmission Alisson	A54J1.16	HVAC passengers
A47RJ2.2	Entrance door	A51J1.19	WCL	A54J1.19	HVAC passengers

Circuits list

Circuit ID	Description	Circuit ID	Description	Circuit ID	Description
A54J2.1	Parcel rack A/C system	A80.3	Equalizer	A113D.1	VSS
A54J2.4	HVAC passengers	A80.4	Equalizer	A113D.2	VSS
A54J2.7	HVAC passengers	A81JB.4	Engine ECU Volvo	A113D.5	VSS
A54J2.10	HVAC passengers	A81JB.6	ZF steering	A120A.5	VSS
A54J2.13	HVAC passengers	A81JB.10	Engine ECU Volvo	A120B.1	VSS
A54J2.15	HVAC passengers	A81JB.15	Ignition & engine start	A120B.2	VSS
A54RJ1.6	HVAC passengers	A81JB.16	Engine ECU Volvo	A120B.3	VSS
A54RJ1.17	HVAC passengers	A81JB.17	Engine ECU Volvo	A120B.4	VSS
A54RJ1.18	Fans condensor	A81JB.19	Engine ECU Volvo	A120B.5	VSS
A54RJ2.2	HVAC passengers	A81JB.22	Engine ECU Volvo	A120B.6	VSS
A54RJ2.3	HVAC passengers	A81JB.23	Engine ECU Volvo	A120B.7	VSS
A55J1.1	Driver lights	A81JB.25	Engine ECU Volvo	A120B.8	VSS
A55J1.3	Weight monitoring	A81JB.26	Engine ECU Volvo	A120C.4	VSS
A55J1.4	Cluster	A96.8.Black	TPMS	A121A.18	VSS
A55J1.7	Back-up camera	A96.23.Red	TPMS	A121B.16	VSS
A55J2.15	Steering	A96.24.Black	TPMS	A121B.17	VSS
A55RJ1.18	Weight monitoring	A96.25.Red	TPMS	A121C.7	VSS
A56J1.3	Cluster	A96.27.Black	TPMS	A121C.11	VSS
A56J1.4	Cluster	A96.28.Red	TPMS	A121C.12	VSS
A56J1.7	Cluster	A100.3.White	TPMS	A121C.13	VSS
A56J1.10	Cluster	A101.3.White	TPMS	A121C.15	VSS
A56J1.13	Multiplex power	A101.7.White	TPMS	A130.3	Fire suppression
A56J1.19	VSS	A102.3.White	TPMS	A130.4	Fire suppression
A56J2.15	Lugg_door_lock	A103.1	Steering	A130.6	Fire suppression
A56RJ1.18	Windows ajar	A103.3	Steering	A130.8	Fire suppression
A57J1.1	WCL	A103.5	Horn	A130.11	Fire suppression
A57J1.3	WCL	A108.5	Transmission I_Shift	A131A.C	Fire suppression
A57J1.4	WCL	A108.7	Transmission I_Shift	A131B.A	Fire suppression
A57J1.10	WCL	A108.8	Transmission I_Shift	A131B.C	Fire suppression
A57RJ1.18	GND MUX modules	A108.9	Transmission I_Shift	A137A.4	Urea system
A60.Gnd	VSS	A108.10	Transmission I_Shift	A137A.7	Urea system
A60.L	VSS	A109A.7	Transmission I_Shift	A137A.8	Urea system
A60.R	VSS	A109A.8	Transmission I_Shift	A137A.24	Urea system
A77.A	Equalizer	A109A.9	Transmission I_Shift	A137A.28	Urea system
A77.H	Equalizer	A109A.10	Transmission I_Shift	A137A.40	Urea system
A78.3	Equalizer	A113.Gnd	VSS	A137A.44	Urea system
A78.4	Equalizer	A113.L	VSS	A137A.49	Urea system
A79.3	Equalizer	A113.R	VSS	A137A.50	Urea system

Circuits list

Circuit ID	Description	Circuit ID	Description	Circuit ID	Description
A137A.51	Urea system	CB3	HVAC passengers	DL7L	Networks ECU
A137A.54	Urea system	CB5	24 WUP	DL9H	Networks ECU
A137A.56	Urea system	CB6	24VD	DL9L	Networks ECU
A137A.59	Urea system	CB8	12 WUP	Drain	Audio
A137A.62	Urea system	CB9	Pre heat	DVD_Gnd	VSS
A138.3	Urea system	CB10	12 WUP	DVD_L+	VSS
A138.12	Urea system	CB11	VSS	DVD_R+	VSS
A150.GND	VSS	CB13	120VAC outlets	E1.7	Cluster
A150.L	VSS	CB48	Fr flashers, Mrk, Clr, head lgts	E1.18	Engine ECU Volvo
A150.R	VSS	CB128	24VD	EMS.EB29	Ignition & engine start
A151B.1	USB	CB201	Fans drive electric	F4	Volvo link TGW
A151B.2	USB_Gnd	CB202	Fans drive electric	F10	Cluster
A153A.5	VSS	CB203	Fans drive electric	F11	Horn
Alt_LL.2	Alternators	CB204	Fans drive electric	F13	12VD Customer
Alt_LR.2	Alternators	CB205	Fans drive electric	F16	12V Eng. run
Alt_UR.2	Alternators	CB206	Fans drive electric	F17	Multiplex power
AltLL	Alternators	CB207	Fans drive electric	F18	Multiplex power
AltLR	Alternators	CB208	Fans drive electric	F19	Multiplex power
AltUR	Alternators	Cd1	Networks	F20	Multiplex power
AuxVideoGnd	VSS	CTS	Networks	F21	Multiplex power
AuxVideoL	VSS	Cts	Networks	F22	Cadec
AuxVideoR	VSS	D1	Ignition & engine start	F23	ESP
B85.2	Urea system	D7	Entrance door	F24	12V Ign
B97.2	Urea system	D9	Pre heat	F25	12V outlets
B98.2	Urea system	D12	Horn	F26	Spares VECF
B115A.3	Urea system	D13	Horn	F27	Spares VECF
BLACK	120VAC outlets	D55	docking lights	F29	ECU ignition
Black	Pre heat	DL0H	Spares wires	F30	Networks
BLK1	VSS	DL0HS	Spares wires	F33	Multiplex power
BLK2	VSS	DL0L	Spares wires	F34	Multiplex power
Blue	Audio	DL0LS	Spares wires	F35	Multiplex power
BussBar	12VI to CB10	DL1H	Networks	F36	24VD Eng. Start Sw83
CAN1-HI	Cadec	DL1L	Networks	F37	Entrance door
CAN1-LO	Cadec	DL2H	Networks	F39	24 VD customer
CanH2	Spares wires	DL2L	Networks	F40	Fire suppression
CanL2	Spares wires	DL3H	Networks	F42	Transmission I_Shift
CB1	24 WUP	DL3L	Networks	F43	Transmission I_Shift
CB2	Ignition & engine start	DL7H	Networks ECU	F44	Multiplex power

Circuits list

Circuit ID	Description	Circuit ID	Description	Circuit ID	Description
F45	Multiplex power	F142	HVAC passengers	LightGreen	USB
F46	Multiplex power	F143	HVAC passengers	LR+	VSS
F47	Multiplex power	F144	HVAC passengers	LR-	VSS
F50	HVAC defroster	F147	CCust	Mo65.3	Fans drive electric
F51	Destination signs	F148	12VD	Mo67.3	Fans drive electric
F53	VSS	F152	Spares VECR	Mo68.3	Fans drive electric
F55	Back-up camera	F156	Unican	Mo69.3	Fans drive electric
F73	Engine ECU Volvo	F199	Fans drive electric	Mo70.3	Fans drive electric
F90	Urea system	F200	VSS	Mo71.3	Fans drive electric
F91	Engine ECU Volvo	F201	VSS	Mo72.3	Fans drive electric
F95	Volvo link TGW	F202	VSS	Mo73.3	Fans drive electric
F96	Urea system	F203	VSS	N1	Networks
F99	Engine ECU Volvo	F243	HVAC passengers	N2	Networks
F100	Engine ECU Volvo	gnd_1	Cantrack	N3	Networks
F101	R1 to Starter	Gnd_2	Cantrack	N4	Networks
F106	Multiplex power	GndA	Networks	N5	Networks
F107	Multiplex power	GndG	Cadec	N6	Networks
F108	Networks	GndG1	Cadec	N7	Networks
F109	Engine & RJB cmpt. lights	GREEN	120VAC outlets	N8	Networks
F110	Transmission Alisson	Green	Pre heat	N9	Networks
F112	Trailer interface	Green/White	USB	N10	Networks
F117	Spares VECR	GRN1	VSS	N11	Networks
F121	CCust	GRN2	VSS	N12	Networks
F122	Spares VECR	L+	VSS	N13	Networks
F123	Pre heat	L+TV	VSS	N14	Networks
F124	Pre heat	L-	VSS	N15	Networks
F126	HVAC passengers	L142.3	Lavatory	N16	Networks
F127	Pre heat	L207.1	WCL	N17	Networks
F131	CCust	L207.2	WCL	N18	Networks
F132	Multiplex power	L207.3	WCL	N19	Networks
F133	Multiplex power	L207.GND	WCL	N20	Networks
F134	Multiplex power	L207.X	WCL	N21	Networks
F135	Multiplex power	L350A.B2	Engine ECU Volvo	N22	Networks
F136	Multiplex power	L400.G	Engine heater outlet	N23	Networks
F137	Equalizer	L400.L	Engine heater outlet	N24	Networks
F138	Reading lamps & chime	L400.N	Engine heater outlet	N25	Networks
F139	Alternators	LF+	VSS	N26	Networks
F141	HVAC passengers	LF-	VSS	N27	Networks

Circuits list

Circuit ID	Description	Circuit ID	Description	Circuit ID	Description
N28	Networks	RED2	VSS	Se38.1	ESP
N29	Networks	RF+	VSS	Se38.2	ESP
N30	Networks	RF-	VSS	Se39.1	ESP
N31	Networks	RR+	VSS	Se39.2	ESP
N56-1	Networks	RR-	VSS	Se40.1	ESP
N56-2	Networks	RTS	Networks	Se40.2	ESP
N57_1	Networks	Rts	Networks	Se45.2	Wipers & washer
N57_2	Networks	RX	TPMS	Se46.B	Trailer park brake
Pot1	Driver lights	Rx	Cantrack	Se53.C	Cluster
R+	VSS	RxD	Networks	Se54.C	Cluster
R+TV	VSS	RxTx	Networks	Se55.C	Cluster
R-	VSS	Se4.1	Windows ajar	Se56.A	WCL
R4.85	Fire suppression	Se11.Sig	Cluster	Se62.B	WCL
R4.87A	Pre heat	Se11.Wrn	Cluster	Se63.1	ESP
R12	HVAC passengers	Se13.B	Engine ECU Volvo	Se63.2	ESP
R12VISS	VSS	Se14A.B	Engine ECU Volvo	Se64.1	ESP
R20.87	Pre heat	Se14B.C	Engine ECU Volvo	Se64.2	ESP
R21.87	Ignition & engine start	Se15.1	Entrance door	Se67.C	ESP
R22.87	ECU ignition	Se17.1	Entrance door	Se69.C	ESP
R23.30	Transmission Alisson	Se18.B	Brake	Se74.3	Transmission Alisson
R25.87	24V Ignition	Se19_P.D	Brake	Se75.C	Weight monitoring
R26.30	HVAC passengers	Se19_S.D	Brake	Se79.4	Kneeling, tag, low buoy
R27.87A	Wipers & washer	Se20.B	Cluster	Se80.C	Weight monitoring
R29	Engine ECU Volvo	Se21.2	HVAC defroster	Se100.4	WCL
R30.87	12V Eng run customer	Se23.C	HVAC passengers	Shield_149	GND stud
R31.87	12V Ign customer	Se24.2	HVAC passengers	Shield_149A	GND stud
R34.30	12V ECU	Se24.3	HVAC passengers	Shield_A16.7	Destination signs
R36.87	Horn	Se25.2	HVAC passengers	SHL2	VSS
R37.30	Horn	Se30.A	Engine & RJB cmpt. lights	So9.B	HVAC passengers
R38.87	12V outlets	Se32.A	Transmission Alisson	spare1	Cadec
R40.87	Transmission I_Shift	Se32.B	Transmission Alisson	spare10	Spares wires
R47.87	WCL	Se33.A	Transmission Alisson	spare11	Spares wires
R140	Lavatory	Se34.A	Transmission Alisson	spare12	Spares wires
R_Starter	Ignition & engine start	Se34.B	Transmission Alisson	spare13	Spares wires
Radio_Gnd	VSS	Se35.A	Transmission Alisson	spare14	Spares wires
Radio_R+	VSS	Se35.B	Transmission Alisson	spare15	Spares wires
Radoi_L+	VSS	Se37.1	ESP	spare16	Spares wires
RED1	VSS	Se37.2	ESP	spare17	Spares wires

Circuits list

Circuit ID	Description	Circuit ID	Description	Circuit ID	Description
spare18	Spares wires	Spk5_R	Speakers	Sw16.3	Brake
spare19	Spares wires	Spk6_L	Speakers	Sw16.8	Brake
spare20	Spares wires	Spk6_R	Speakers	Sw17.6	Engine ECU Volvo
spare21	Spares wires	Spk9_L	Speakers	Sw18A.2B	Lugg_door_lock
spare22	Spares wires	Spk9_R	Speakers	Sw20.3	WCL
spare23	Spares wires	Spk10_L	Speakers	Sw20.8	WCL
spare24	Spares wires	Spk10_R	Speakers	Sw21.3	Upper defrost
spare25	Spares wires	Spk11_L	Speakers	Sw21.8	Upper defrost
spare28	Spares wires	Spk11_R	Speakers	Sw24.3	Driver lights
spare29	Spares wires	Spk12_L	Speakers	Sw24.6	Driver lights
spare30	Spares wires	Spk12_R	Speakers	Sw25.3	Indirect lights
spare31	Spares wires	Spk13_L	Speakers	Sw25.6	Reading lamps & chime
spare32	Spares wires	Spk13_R	Speakers	Sw26.3	Reading lamps & chime
spare33	Spares wires	Spk14_L	Speakers	Sw26.8	Reading lamps & chime
spare34	Spares wires	Spk14_R	Speakers	Sw27.3	Parcel rack A/C system
spare35	Spares wires	STO-LOC sel	WCL	Sw27.8	Parcel rack A/C system
spare39	Spares wires	Sw1.5	Fr flashers, Mrk, Clr, head lgts	Sw29.2	Reading lamps & chime
spare40	Spares wires	Sw1C258.2	Wipers & washer	Sw29.3	Reading lamps & chime
spare41	Spares wires	Sw1C258.3	Wipers & washer	Sw29.8	Reading lamps & chime
spare42	Spares wires	Sw1C258.4	Wipers & washer	Sw31.A	WCL
spare43	Spares wires	Sw1C258.6	Wipers & washer	Sw32.3	Entrance door
spare44	Spares wires	Sw1C258.7	Wipers & washer	Sw33.3	Entrance door
spare64	Spares wires	Sw1C258.8	Fr flashers, Mrk, Clr, head lgts	Sw34.1	Entrance door
spare65	Spares wires	Sw1C259.1	Fr flashers, Mrk, Clr, head lgts	Sw34.4	Entrance door
spare72	Spares wires	Sw1C259.2	Fr flashers, Mrk, Clr, head lgts	Sw35.3	Engine ECU Volvo
spare73	Spares wires	Sw1C259.4	Fr flashers, Mrk, Clr, head lgts	Sw35.8	Engine ECU Volvo
spare210	Cadec	Sw2.3	Fr flashers, Mrk, Clr, head lgts	Sw38.2B	Driver window
spare212	Cadec	Sw2.6	Fr flashers, Mrk, Clr, head lgts	Sw40.B	Trailer park brake
spare214	Cadec	Sw3.3	Cornering & fog lights	Sw41.A1	Mirrors
Spk1_L	Speakers	Sw3.8	Cornering & fog lights	Sw41.A3	Mirrors
Spk1_R	Speakers	Sw4.3	Fr flashers, Mrk, Clr, head lgts	Sw41.B1	Mirrors
Spk2_L	Speakers	Sw4.8	Fr flashers, Mrk, Clr, head lgts	Sw41.B2	Mirrors
Spk2_R	Speakers	Sw6.4	Wipers & washer	Sw41.B4	Mirrors
Spk3_L	Speakers	Sw10A.2B	Kneeling, tag, low buoy	Sw42.2	WCL
Spk3_R	Speakers	Sw12.3	Destination signs	Sw42.3	WCL
Spk4_L	Speakers	Sw12.8	Destination signs	Sw42.4	WCL
Spk4_R	Speakers	Sw14.3	Engine ECU Volvo	Sw42.5	WCL
Spk5_L	Speakers	Sw14.8	Engine ECU Volvo	Sw42.6	WCL

Circuits list

Circuit ID	Description	Circuit ID	Description	Circuit ID	Description
Sw42.7	WCL	Sw135.N3	Reading lamps & chime		
Sw43.B	Kneeling, tag, low buoy	Sw150.1	Cadec		
Sw44	Engine & RJB cmpt. lights	Sw150.2	Cadec		
Sw46A	Engine & RJB cmpt. lights	Sw152.B	Fire suppression		
Sw55.1	Lavatory	Sw156.1	Mirrors		
Sw56.1	Lavatory	Sw156.6	Mirrors		
Sw57.A	WCL	Sw156.8	Mirrors		
Sw58.2	Ignition & engine start	Sw157.2B	Sun visor		
Sw58.3	Ignition & engine start	Sw158.2B	Sun visor		
Sw58.5	Ignition & engine start	Sw313.N3	Reading lamps & chime		
Sw58.7	Ignition & engine start	TR-Black	Trailer interface		
Sw59.3	Ignition & engine start	TR-Blue	VECT		
Sw63A.3	Horn	TR-Brown	Trailer interface		
Sw63A.4	Horn	TR-Green	Trailer interface		
Sw64	Kneeling, tag, low buoy	TR-Red	Trailer interface		
Sw82.4	Master relay & 12V Ign	TR-Yellow	Trailer interface		
Sw82.5	Master relay & 12V Ign	Tv.Gnd	VSS		
Sw83.Acc	Ignition & engine start	TV.L	VSS		
Sw83.Ign	Ignition & engine start	TV.R	VSS		
Sw83.St	Ignition & engine start	TvGnd	VSS		
Sw85.A1	Mirrors	TWU.3	WCL		
Sw85.A3	Mirrors	TX	TPMS		
Sw85.B1	Mirrors	Tx	Cantrack		
Sw85.B2	Mirrors	TxD	Networks		
Sw85.B4	Mirrors	ve+	Cantrack		
Sw94	WCL	WHITE	120VAC outlets		
Sw96.N3	Reading lamps & chime	White	Pre heat		
Sw97.N1	Reading lamps & chime	WHT1	VSS		
Sw100A.3	Cornering & fog lights	WHT2	VSS		
Sw109	Lugg_door_sw				
Sw110	Lugg_door_sw				
Sw111	Lugg_door_sw				
Sw112	Lugg_door_sw				
Sw113	Lugg_door_sw				
Sw114	Lugg_door_sw				
Sw115	Lugg_door_sw				
Sw124.3	Destination signs				
Sw125.B	Kneeling, tag, low buoy				