

Y78	Solenoid Valve, Middle Door	HD 3 D
Y79	Valve, Roof Heating System	ND 1 B
Y80	Valve, Passenger Heating System	ND 0 B
Y82	Valve, Defroster Heating System	ND 0 B
Y83M	Pneumatic Valve Isonic Wc, Middle Toilet	EC 1 A
Y86M	Central Lock Wc , Middle Toilet	EC 2 A
Y87	Gate Valve, Middle Toilet	EC 3 A
Y90	Valve, Bypass	ND 0 B
Y952	CLUTCH COMPRESSOR	NB 3 E
Y952A	DISCHARGE VALVE	NB 0 E
Y6009	AC DEFROSTER VALVE	NA 4 E
Y6014	SOLENOID VALVE	IA 2 C
Y6015	SOLENOID VALVE DOOR	HA 0 C
Y6016	ROOF VALVE, REHEATING SYSTEM	NC 0 D
Y6017A	PASSENGER VALVE	NA 2 E
Y6017B	DEFROSTER VALVE	NA 2 E
Y6017C	BYPASS VALVE	NA 2 E
Y6042	ISONIC PNEUMATIC VALVE	EA 2 E
Y6042L	PNEUMATIC VALVE, LEFT TOILET	EB 2 D
Y6070	SOLENOID VALVE AUXILIARY STEP	HB 1 D
Y_	FUSE TERMINAL I-START	AB 1 C
YA	TERMINAL, POWER CABLE	AC 1 D

VOLVO

Volvo Bus Corporation

Document Title

WIRING DIAGRAM

Document Type

PRODUCT SCHEMATIC

Document No

22600119

Issue Index

04

Volume No

02

Page No

18(18)