

# RELAYS NUMBER CODE

No.	PAGE	COIL V	#PREV.	LOCATION	FUNCTION	No.	PAGE	COIL V	#PREV.	LOCATION	FUNCTION
RF1	8	24V	561707	RR JCT BOX	FAN CLUTCH W/RET. SPEED 1	R 92	13	24V	561707	FR JCT BOX	HEATING WINDSHIELD
RF2	8	24V	561707	RR JCT BOX	FAN CLUTCH W/RET. SPEED 2	R 93	14	24V	561707	RR JCT BOX	PRE-HEAT WATER HEATER (WEBASTO)
RF3	8	24V	560772	RR JCT BOX	TIME DELAY	R 99	8	24V	561707	RR JCT BOX	RADIATOR FAN CLUTCH
R 1	1.1	24V	561991	FR JCT BOX	ENGINE RUN (24) FR	R 100	4	12V	561538	RR JCT BOX	GENERATOR SIGNAL
R 2	2	24V	561991	BATT. CPT.	ENGINE RUN (12) FR & RR	R 2010	14.2	24V	561230	WEBASTO PRE-HEAT	WEBASTO
R 3	4	24V	561707	BATT. CPT.	FIELD RELAY	V IMN	6	12V	562092	RR JCT BOX	VIM WORLD TR.-NEUTRAL SIGNAL
R 4	4	24V	561005	BATT. CPT.	STARTING MOTOR	V IMR	6	12V	562092	RR JCT BOX	VIM WORLD TR.-B/U SIGNAL
R 5	5	24V	561707	FR JCT BOX	CRUISE CTR. STOP SIGN.	V IM1	6	12V	562092	RR JCT BOX	VIM WORLD TR.-OUTPUT 1
R 6	9.3	24V	561707	RR JCT BOX	STOP LTS-PARKING BRAKE	V IM2	6	12V	562092	RR JCT BOX	VIM WORLD TR.-OUTPUT 2 ENG. BRK DISABLE
R 7	5	24V	561707	FR JCT BOX	FAST IDLE	V IM3	6	12V	562092	RR JCT BOX	VIM WORLD TR.-OUTPUT 3 SPD SW. 5MPH NO NC
R 8	6	24V	561707	RR JCT BOX	12V IGNITION WT	V IM4	6	12V	562092	RR JCT BOX	VIM WORLD TR.-OUTPUT 4 RETARD. ON SIGNAL
R 9	9.3	24V	561707	RR JCT BOX	BACK-UP LTS						
R 11	5	24V	561707	RR JCT BOX	12V IGNITION DDEC3						
R 12	7	12V	562092	FR JCT BOX	ELECTRICAL HORNS						
R 13	9.3	24V	561707	FR JCT BOX	FOG LTS						
R 14	9.1	24V	561707	FR JCT BOX	BLINKER						
R 15	9.1	24V	561707	FR JCT BOX	FR MARKER LTS						
R 16	9.1	24V	561707	FR JCT BOX	IDENT. & CLEARANCE LTS						
R 17	9.1	24V	561707	RR JCT BOX	TAIL,LICENCE,MARKER-RR LTS						
R 18	9.1	24V	561707	FR JCT BOX	D R L-PARK BRK CUT-IN						
R 19	9.1	24V	561707	FR JCT BOX	HEADLAMPS (HI)						
R 20	9.1	24V	561707	FR JCT BOX	HEADLAMPS (LO)						
R 21	9.2	24V	561707	FR JCT BOX	L.H. DIRECTIONNAL LT						
R 22	8	24V	561707	FR JCT BOX	PARKING BRAKE -ALARM						
R 23	9.2	24V	561707	FR JCT BOX	R.H. DIRECTIONNAL LT						
R 24	9.2	24V	561707	FR JCT BOX	R.H. CORNERING LT						
R 25	9.2	24V	561707	FR JCT BOX	L.H. CORNERING LT						
R 26	9.3	24V	561707	RR JCT BOX	STOP LTS						
R 28	11.2	24V	561707	FR JCT BOX	DASH LTS RHEOSTAT						
R 33	15.1	12V	562092	FR JCT BOX	BLOWER CUT-IN RLY						
R 34	15.1	24V	561707	RJB A/C JCT PANEL	A/C LOGIC PANEL						
R 35	15.1	24V	561707	RJB A/C JCT PANEL	WATER PUMP						
R 36	15.1	24V	561707	RJB A/C JCT PANEL	A/C COMPRESSOR CLUTCH						
R 39	15.2	24V	561005	BATT. CPT.	CONDENSER FAN MOTOR						
R 40	15.2	24V	561014	BATT. CPT.	CONDENSER SPEED CTR HI						
R 41	15.2	24V	561005	BATT. CPT.	CONDENSER SPEED CTR HI						
R 46	20	24V	561707	FR JCT BOX	CAMERA DOOR						
R 49	22	24V	561707	FR JCT BOX	ABS - SERVICE BRK RLY						
R 50	22	24V	561707	FR JCT BOX	ABS - VR2 RLY						
R 51	22	24V	561707	FR JCT BOX	ABS - WARNING RLY						
R 52	22	24V	561707	FR JCT BOX	ABS - VR1 RLY						
R 53	1.1	24V	561991	RR JCT BOX	ENGINE RUN (24) RR						
R 54	1.1	24V	561991	BATT. CPT.	12V CUT OUT RLY RR						
R 55	1.1	24V	561991	BATT. CPT.	12V CUT OUT RLY FR						
R 57	9.1	24V	561707	FR JCT BOX	DAY'S BLINKER						
R 59	9.3	12V	562092	RR JCT BOX	DOCKING LTS						
R 61	9.3	24V	561707	RR JCT BOX	STOP LTS-JACOB & RET. SIGNAL						
R 64	11.2	12V	562092	FR JCT BOX	ENTRANCE DOOR SW. & LTS						
R 65	9.2	24V	561707	FR JCT BOX	CORNERING LTS CONTROL						
R 66	9.2	24V	561707	FR JCT BOX	LOW DOCKING LTS -FR CORNERING						
R 67	9.3	24V	561707	RR JCT BOX	LOW DOCKING LTS						
R 69	12	12V	562092	RR JCT BOX	LUGGAGE DOOR LOCK						
R 70	12	12V	562092	RR JCT BOX	LUGGAGE DOOR UNLOCK						
R 71	12	24V	561707	RR JCT BOX	LUGGAGE DOOR UNLOCK T.T. LT.						
R 74	12	12V	562092	RR JCT BOX	LUGGAGE DOOR LOCK						
R 75	12	12V	562092	RR JCT BOX	LUGGAGE DOOR UNLOCK						
R 78	1.1	12V	562092	FR JCT BOX	MASTER SWITCH						
R 80	11.1	24V	561707	RR JCT BOX	ENGINE COMPARTMENT LTS						
R 82	21	24V	561707	FR JCT BOX	RETARDER WT						
R 84	8	24V	561707	RR JCT BOX	FAN CLUTCH-FIRST SPEED						
R 85	8	24V	561707	RR JCT BOX	FAN CLUTCH-SECOND SPEED						
R 87	21	24V	561707	RR JCT BOX	ENGINE BRAKE REQUEST WT						
R 89	13	24V	561707	FR JCT BOX	HEATING WINDSHIELD						
R 90	13	24V	561707	FR JCT BOX	HEATING WINDSHIELD						
R 91	13	24V	561707	FR JCT BOX	HEATING WINDSHIELD						