

LAZER FORMAT "A" ECHELLE 3.2:1

RESISTOR CODE (RS)

Page J : 1

NO. PAGE OHM(S) *PREVOST LOCATION FUNCTION

RS1	5	11 K	561898	FR JCT BOX	FAST IDLE DDEC CONTROL
RS2	5	3.6 K	561897	FR JCT BOX	FAST IDLE DDEC CONTROL
RS3	11	1 (2)	561537	FR SERV. COMPT.	FOG LT - RH
RS4	11	1 (2)	561537	FR SERV. COMPT.	FOG LT - LH
RS5	10	1 (2)	061976	FR JCT BOX	CORNERING LT - LH
RS7	11	.82 (2)	060806	RR JCT BOX	PARKING BRAKE STOP LTS
RS8	10	1 (2)	061976	FR JCT BOX	CORNERING LT - RH
RS9	11	1 (2)	061976	RR JCT BOX	DOCKING LT - RH
RS10	11	1 (2)	061976	RR JCT BOX	DOCKING LT - LH
RS14	9	.82 (2)	060806	FR JCT BOX	DAYTIME RUN LTS
RS15	10	1 (2)	061976	FR JCT BOX	LOW DOCKING LTS - FRONT
RS16	11	1 (2)	061976	RR JCT BOX	LOW DOCKING LTS - REAR
RS17	7	220	562498	ALARM JCT. BOX	FIRE ALARM

RESISTOR CODE (RS)

Page J : 1

NO. PAGE OHM(S) *PREVOST LOCATION FUNCTION