

RESISTOR CODE (RS)

Page J : 1

NO.	PAGE	DHM(S)	#PREVOST	LOCATION	FUNCTION
RS1	3	11 K	562307	FR SERV JCT BOX	DDEC III-FAST IDLE
RS2	3	3.6 K	562306	FR SERV JCT BOX	DDEC III-FAST IDLE
RS3	6	1 (2)	561537	FR SERV. COMPT.	FOG LT - RH
RS4	6	1 (2)	561537	FR SERV. COMPT.	FOG LT - LH
RS11	16	2	062289	REAR A/C AUX.	A/C AUXILIAIRE FAN
RS12	16	2	062289	REAR A/C AUX.	A/C AUXILIAIRE FAN
RS13	16	470 K	061962	RR JCT BOX	AUX. A/C TO COMPR. CLUTCH
RS14	6	.82 (2)	060806	FR SERV. COMPT.	DAYTIME RUN LTS
RS15	12	33	063073	RR JCT BOX	COMPR CLUTCH TIME DELAY ON
RS16	31	80	562108	FR DEST. SIGN	FR DESTINATION SIGN
RS17	5	220	562498	UNDER DASH	FIRE ALARM

RESISTOR CODE (RS)

Page J : 1

NO.	PAGE	DHM(S)	#PREVOST	LOCATION	FUNCTION
-----	------	--------	----------	----------	----------