

# Main distribution batteries & ignition

## Booster block



## 24VD Jct block

2.1\_Gnd\_Electro:1 F • gnd-00R1-18

3.2\_Ign\_Start:4 C • 24-Sw82.5-18


5.1\_Dist\_RJB:3 E • 12-12VD1-10

## 12VD Jct block

1.1\_batteries:0 C • 12-12VA-2  
1.1\_batteries:2 C • 12-12VD-1

12-12VD1-10

## R1 Master Relay



## R3 12v Ign & Acc Relay



## 24V Cut off Jct block

F101 300 Amp

564520

24-AltL-3/0

24-AltR-3/0

24-F101-2/0

5/16

3.2\_Ign\_Start:3 E

14.1\_Engine\_Ecu:3 E

1.1\_SP1\_Alternators\_Remy:4 C

1.1\_SP1\_Alternators\_Remy:4 B

3.2\_Ign\_Start:2 E

13.1\_FanDriveElectric:1 B

12VD

24VD

24WUP

12WUP

568113 70 amp

568113 70 amp

563707 70 amp

563708 90 amp

563708 90 amp

563708 90 amp

568127 50 amp

568114 150 amp

563708 90 amp

568114 150 amp

12-CB10-2 • 4.1\_Dist\_12V\_FJB:0 B

12-CB8-4 • 5.1\_Dist\_RJB:1 B

24-CB13-2 • 40.1\_Inverters:1 B

24-CB11-6 • 35.6\_VSS\_HDMI:2 H

24-CB5-4 • 5.1\_Dist\_RJB:1 D

24-CB3-4 • 18.2\_HvacPass:3 C

24-CB1-4 • 4.2\_Dist\_24V\_FJB:1 C

24-CB9-4 • 17.1\_Pre\_Heat:1 A

24-CB6-8 • 36.1\_WCL\_Ricon:4 D

24-CB6-6 • 5.1\_Dist\_RJB:1 C

12-CB2-6 • 4.1\_Dist\_12V\_FJB:0 A

12-CB2-8 • 3.2\_Ign\_Start:3 D