

Circuits list

Circuit ID	Description	Circuit ID	Description	Circuit ID	Description
0	GND Batteries	00R5	RJB electronic GND	A1.36	Transmission Alisson
0A	12V outlets	0RAD	GND Chassis	A1.37	Transmission Alisson
00A	Entrance door	0RAD2	Fans drive electric	A1.51	Transmission Alisson
00A1	Multiplex power	0RC4	Gnd Upper Pump	A1.52	Transmission Alisson
00A2	Indirect lights	0SS	VSS GND	A1.54	Transmission Alisson
0AltLL	GND Chassis	0SS1	VSS	A1.55	Transmission Alisson
0AltR	GND Chassis	0SS2	VSS	A1.58	Transmission Alisson
0B	GND Chassis	0SS3	VSS	A1.71	Transmission Alisson
0C	Ignition & engine start	0SW	Indirect lights	A1.74	Transmission Alisson
0chgr	Pre heat	0SW1	Indirect lights	A1.76	Transmission Alisson
0COND	Condensor fans GND	0TR-White	VECT	A1.77	Transmission Alisson
0ECU	Engine ECU Volvo	00VA	RJB electronic GND	A2A.9	Transmission Alisson
0EV2	HVAC passengers	0W	WCL GND	A2A.11	Transmission Alisson
0EVAP1	HVAC passengers	0WC	Gnd WCL Remote CTRL	A3.1	Transmission Alisson
0EVAP2	HVAC passengers	5	Upper Defrost fan	A3.2	Transmission Alisson
0F	GND Customer	12Ecu	12V ECU	A3.3	Transmission Alisson
00F	FJB electronic GND	12ISH	Pwr I Shift	A3.5	Transmission Alisson
0F1	Upper wipers GND	12VA	Batteries	A3.6	Transmission Alisson
00F1	Multiplex power	12VD	Batteries	A3.7	Transmission Alisson
00F2	Multiplex power	12VD1	12VD	A4B.8	Transmission Alisson
00F3	Multiplex power	24VA	Batteries	A5.B	Transmission Alisson
00F6	Lights switch	24VD	Batteries	A9CX1.2	Cluster
0FE	GND stud	24VD2	Equalizer	A9CX1.4	ESP
0FH	Wipers & washer	24VD3	Ignition & engine start	A9CX1.5	ESP
00FH	FJB electronic GND	24VI	24 WUP	A9CX1.6	Cluster
00FH1	HVAC defroster	71	Upper Defrost Pump	A9CX2.1	ESP
00FH2	Multiplex power	900	Networks	A9CX2.2	ESP
00FR	FJB-RJB junction	901	Networks	A9CX2.3	ESP
0P	120VAC outlets	A1.11	Transmission Alisson	A9CX2.4	ESP
0PA	GND stud	A1.12	Transmission Alisson	A9CX2.6	ESP
0PR	120VAC outlets	A1.15	Transmission Alisson	A9CX2.7	ESP
0PR1	120VAC outlets	A1.16	Transmission Alisson	A9CX2.9	ESP
0R	GND Chassis	A1.18	Transmission Alisson	A9CX2.10	ESP
00R	Networks	A1.19	Transmission Alisson	A9CX2.12	ESP
00R1	RJB electronic GND	A1.24	Transmission Alisson	A9CX2.13	ESP
00R2	Multiplex power	A1.25	Transmission Alisson	A9CX2.16	ESP
00R3	Multiplex power	A1.31	Transmission Alisson	A9CX2.17	ESP
00R4	Multiplex power	A1.33	Transmission Alisson	A9CX3.2	ESP

Circuits list

Circuit ID	Description	Circuit ID	Description	Circuit ID	Description
A9CX3.3	ESP	A34R.D3	Fans drive electric	A42J1.10	Kneeling & Tag & low buoy
A9CX3.5	ESP	A34R.E3	Fans drive electric	A42J1.13	Kneeling & Tag & low buoy
A9CX3.7	ESP	A34R.F3	Fans drive electric	A42J1.16	Kneeling & Tag & low buoy
A9CX3.9	ESP	A34R.G3	Fans drive electric	A42J1.19	Kneeling & Tag & low buoy
A9CX3.10	ESP	A34R.H3	Fans drive electric	A42J2.15	Kneeling & Tag & low buoy
A9CX4.1	ESP	A36JA.11	Horn	A42RJ2.14	Kneeling & Tag & low buoy
A9CX4.4	ESP	A36JA.15	Ignition & engine start	A42RJ2.18	Kneeling & Tag & low buoy
A9CX4.7	ESP	A36JA.17	Ignition & engine start	A43J1.1	Lugg door lock
A9CX4.8	ESP	A36JA.25	Brake & Eng.brake & retarder	A43J1.3	Lugg door lock
A9CX4.10	ESP	A36JB.2	Ignition	A43J1.7	TPMS
A9CX4.11	ESP	A36JB.14	Fire suppression	A43J1.10	Air dryer
A10X3.4	Pre heat	A39P101.1	Speakers	A43J2.5	Lugg. lock press sw.
A10X3.6	Pre heat	A39P101.2	Speakers	A43J2.7	Engine ECU Volvo
A11A.2	Pre heat	A39P101.3	Speakers	A43J2.10	Engine ECU Volvo
A14.A12	Cluster	A39P101.4	Speakers	A43RJ1.17	ACB
A14.B1	Cluster	A39P101.5	Speakers	A43RJ1.18	Lugg. lock GND
A14.B18	Cluster	A39P101.6	Speakers	A43RJ2.2	Air dryer
A14.B20	Cluster	A39P101.8	Speakers	A44J1.1	Upper wipers
A14.B21	Cluster	A39P101.9	Speakers	A44J1.3	Upper wipers
A16.5	Destination signs	A39P901.1	Speakers	A44J1.4	Entrance door
A16.6	Destination signs	A39P901.4	Speakers	A44J1.7	Wipers & washer
A17.AC	Pre heat	A39P901.5	Speakers	A44J1.10	Wipers & washer
A20.3	Digital clock	A39P901.6	Speakers	A44J1.13	Upper defrost
A27.30	ZF steering	A41J1.1	Pre heat	A44J1.16	Horn
A27.87A	ZF steering	A41J1.3	Step lights	A44J1.19	Engine & RJB cmpt. lights
A34.A5	Fans drive electric	A41J1.4	Front occ. lamp	A44J2.1	Sun visor
A34.B5	Fans drive electric	A41J1.7	Shutdown	A44J2.4	Sun visor
A34.C5	Fans drive electric	A41J1.10	Kneeling & Tag & low buoy	A44J2.7	Driver lights
A34.D5	Fans drive electric	A41J1.16	Engine ECU Volvo	A44J2.10	Sun visor
A34.E5	Fans drive electric	A41J1.19	Engine ECU Volvo	A44J2.13	Sun visor
A34.F5	Fans drive electric	A41RJ1.2	Lights GND	A44RJ1.17	Flashers & markers, Clearance lgts
A34.G5	Fans drive electric	A41RJ1.6	Kneeling & Tag & low buoy	A44RJ1.18	Upper defrost
A34.H5	Fans drive electric	A41RJ1.18	Lights GND	A44RJ2.2	Entrance door
A34J.E	Fans drive electric	A41RJ2.14	Front occ. lamp GND	A44RJ2.3	Wipers GND
A34J.F	Fans drive electric	A42J1.1	Kneeling & Tag & low buoy	A45J1.1	HVAC defroster
A34R.A3	Fans drive electric	A42J1.3	Kneeling & Tag & low buoy	A45J1.3	HVAC defroster
A34R.B3	Fans drive electric	A42J1.4	Kneeling & Tag & low buoy	A45J1.4	ZF steering
A34R.C3	Fans drive electric	A42J1.7	Kneeling & Tag & low buoy	A45J1.7	Driver's lights

Circuits list

Circuit ID	Description	Circuit ID	Description	Circuit ID	Description
A45J1.16	Mirrors	A48RJ1.18	Flashers & markers, Clearance lgts	A52J2.13	Ignition & engine start
A45J2.1	HVAC defroster	A48RJ2.2	Flashers & markers, Clearance lgts	A52RJ1.17	Lavatory
A45J2.4	HVAC defroster	A49J1.1	Fans drive electric	A52RJ1.18	Engine & RJB cmpt. lights
A45J2.7	Driver window	A49J1.3	Fans drive electric	A52RJ2.3	Ignition & engine start
A45J2.13	Driver window	A49J2.1	Alternators	A53J1.1	Parcel rack A/C system
A45RJ1.17	Cornering & fog lights	A49J2.13	Brake & Eng.brake & retarder	A53J1.3	Parcel rack A/C system
A46J1.1	Horn	A49RJ2.2	Fans drive electric	A53J1.4	Lavatory
A46J1.4	Flashers & markers, Clearance lgts	A50J1.7	Back-up warnings	A53J1.13	Lavatory
A46J1.7	Cornering & fog lights	A50J1.13	Flashers & markers, Tail lgts	A53J2.1	Indirect lights
A46J1.10	Flashers & markers, Clearance lgts	A50J1.19	Flashers & markers, Tail lgts	A53J2.4	Reading lamps & chime
A46J1.13	Flashers & markers, Clearance lgts	A50J2.1	Flashers & markers, Tail lgts	A53J2.7	Lavatory
A46J2.4	Flashers & markers, Clearance lgts	A50J2.7	Flashers & markers, Tail lgts	A53J2.10	Reading lamps & chime
A46J2.7	Flashers & markers, Clearance lgts	A50J2.10	Back-up warnings	A53J2.13	Emergency & aisle lights
A46RJ1.17	Flashers & markers, Clearance lgts	A50RJ1.17	Flashers & markers, Tail lgts	A53RJ1.17	Lavatory
A46RJ1.18	Flashers & markers, Clearance lgts	A50RJ1.18	Flashers & markers, Tail lgts	A53RJ1.18	Emergency & aisle lights
A47J1.1	HVAC defroster	A50RJ2.2	Back-up warnings	A53RJ2.2	Parcel rack A/C system
A47J1.3	HVAC defroster	A50RJ2.3	Air dryer	A53RJ2.3	Reading lamps & chime
A47J1.4	HVAC defroster	A51J1.1	Docking lights	A54J1.1	HVAC passengers
A47J1.7	Wipers & washer	A51J1.3	Docking lights	A54J1.3	HVAC passengers
A47J1.10	Entrance door	A51J1.4	Flashers & markers, Tail lgts	A54J1.4	Pre heat
A47J1.13	Entrance door	A51J1.7	Lights	A54J1.7	HVAC passengers
A47J1.16	Entrance door	A51J1.10	Flashers & markers, Tail lgts	A54J1.10	Pre heat
A47J1.19	Entrance door	A51J1.13	Flashers & markers, Tail lgts	A54J1.16	HVAC passengers
A47J2.1	HVAC defroster	A51J1.16	Transmission Alisson	A54J1.19	HVAC passengers
A47J2.7	Entrance door	A51J1.19	WCL	A54J2.1	Parcel rack A/C system
A47RJ1.6	HVAC defroster	A51J2.1	Flashers & markers, Tail lgts	A54J2.4	HVAC passengers
A47RJ1.17	HVAC defroster	A51J2.4	Transmission Alisson	A54J2.7	HVAC passengers
A47RJ1.18	Entrance door	A51J2.7	Flashers & markers, Tail lgts	A54J2.10	HVAC passengers
A47RJ2.2	Entrance door	A51J2.10	Flashers & markers, Tail lgts	A54J2.13	HVAC passengers
A47RJ2.3	Upper def. water pump GND	A51RJ1.17	Flashers & markers, Tail lgts	A54J2.15	HVAC passengers
A48J1.1	Cornering & fog lights	A51RJ1.18	WCL	A54RJ1.6	HVAC passengers
A48J1.4	Cornering & fog lights	A52J1.1	Fans drive electric	A54RJ1.17	HVAC passengers
A48J1.7	Flashers & markers, Clearance lgts	A52J1.3	Fans drive electric	A54RJ1.18	HVAC GND
A48J1.10	Flashers & markers, Clearance lgts	A52J1.4	Lavatory	A54RJ2.2	HVAC GND
A48J2.1	Flashers & markers, Clearance lgts	A52J1.7	Engine & RJB cmpt. lights	A54RJ2.3	HVAC passengers
A48J2.4	Flashers & markers, Clearance lgts	A52J1.10	Ignition & engine start	A55J1.1	Driver lights
A48J2.13	Flashers & markers, Clearance lgts	A52J2.1	Alternators	A55J1.4	Cluster
A48RJ1.17	Cornering & fog lights	A52J2.4	Alternators	A55J1.7	Back-up camera

Circuits list

Circuit ID	Description	Circuit ID	Description	Circuit ID	Description
A55J2.15	Steering	A96.23.Red	TPMS	A121C.15	VSS
A55RJ1.18	Steering	A96.24.Black	TPMS	A121D.7	VSS
A56J1.3	Cluster	A96.25.Red	TPMS	A130.3	Fire suppression
A56J1.4	Cluster	A96.27.Black	TPMS	A130.4	Fire suppression
A56J1.7	Cluster	A96.28.Red	TPMS	A130.6	Fire suppression
A56J1.10	Cluster	A100.3.White	TPMS	A130.8	Fire suppression
A56J1.13	Multiplex power	A101.3.White	TPMS	A130.11	Fire suppression
A56J1.19	12VISS	A101.7.White	TPMS	A131A.C	Fire suppression
A56J2.15	Lugg door lock	A102.3.White	TPMS	A131B.A	Fire suppression
A56RJ1.18	Windows ajar	A103.1	Steering	A131B.C	Fire suppression
A57J1.1	WCL	A103.3	Steering	A137A.4	Urea system
A57J1.3	WCL	A103.5	Horn	A137A.7	Urea system
A57RJ2.14	WCL system GND	A108.5	Transmission I Shift	A137A.8	Urea system
A60 Gnd	VSS	A108.7	Transmission I Shift	A137A.24	Urea system
A60 L+	VSS	A108.8	Transmission I Shift	A137A.28	Urea system
A60 R+	VSS	A108.9	Transmission I Shift	A137A.40	Urea system
A65 Gnd	VSS	A108.10	Transmission I Shift	A137A.44	Urea system
A65 L+	VSS	A109A.7	Transmission I Shift	A137A.49	Urea system
A65 R+	VSS	A109A.8	Transmission I Shift	A137A.50	Urea system
A77.A	Equalizer	A109A.9	Transmission I Shift	A137A.51	Urea system
A77.H	Equalizer	A109A.10	Transmission I Shift	A137A.54	Urea system
A78.3	Equalizer	A120A.5	VSS	A137A.56	Urea system
A78.4	Equalizer	A120B.1	VSS	A137A.59	Urea system
A79.3	Equalizer	A120B.2	VSS	A137A.62	Urea system
A80.3	Equalizer	A120B.3	VSS	A138.3	Urea system
A80.4	Equalizer	A120B.4	VSS	A138.12	Urea system
A81JB.4	Engine ECU Volvo	A120B.5	VSS	A150.GND	VSS
A81JB.6	ZF steering	A120B.6	VSS	A150.L	VSS
A81JB.10	Engine ECU Volvo	A120B.7	VSS	A150.R	VSS
A81JB.15	Ignition & engine start	A120B.8	VSS	A151B.1	USB
A81JB.16	Engine ECU Volvo	A120C.4	VSS	A151B.2	USB Gnd
A81JB.17	Engine ECU Volvo	A121A.18	VSS	Alt LL.2	Alternators
A81JB.19	Engine ECU Volvo	A121B.16	VSS	Alt LR.2	Alternators
A81JB.22	Engine ECU Volvo	A121B.17	VSS	Alt UR.2	Alternators
A81JB.23	Engine ECU Volvo	A121C.7	VSS	AltLL	Alternators
A81JB.25	Engine ECU Volvo	A121C.11	VSS	AltLR	Alternators
A81JB.26	Engine ECU Volvo	A121C.12	VSS	AltUR	Alternators
A96.8.Black	TPMS	A121C.13	VSS	Audio Out HDMI L+	VSS

Circuits list

Circuit ID	Description	Circuit ID	Description	Circuit ID	Description
Audio Out HDMI R+	VSS	D3	Upper wipers	F25	12V outlets
Audio Out HDMI R-L-	VSS	D7	Entrance door	F26	Spares VECF
AuxVideoGnd	VSS	D9	Pre heat	F27	Spares VECF
AuxVideoL	VSS	D12	Horn	F29	ECU ignition
AuxVideoR	VSS	D13	Horn	F30	Networks
B85.2	Urea system	D55	Lights	F33	Multiplex power
B97.2	Urea system	DL0H	Spares wires	F34	Multiplex power
B98.2	Urea system	DL0HS	Spares wires	F35	Multiplex power
B115A.3	Urea system	DL0L	Spares wires	F36	24VD Eng. Start Sw83
BLACK	120VAC outlets	DL0LS	Spares wires	F37	Entrance door
Black	Pre heat	DL1H	Networks	F39	24 VD customer
BLK1	VSS	DL1L	Networks	F40	Fire suppression
BLK2	VSS	DL2H	Network	F42	Transmission I Shift
BussBar	12VD TO CB2	DL2L	Network	F43	Transmission I Shift
CB1	24 WUP	DL3H	Networks	F44	Multiplex power
CB2	Ignition & engine start	DL3L	Networks	F45	Multiplex power
CB3	HVAC passengers	DL7H	Networks ECU	F46	Multiplex power
CB5	24 WUP	DL7L	Networks ECU	F47	Multiplex power
CB6	24VD	DL9H	Networks ECU	F50	HVAC defroster
CB8	12 WUP	DL9L	Networks ECU	F51	Destination signs
CB9	Pre heat	DVD Gnd	VSS	F53	Digital clock
CB10	12 WUP	DVD L+	VSS	F54	Upper wipers
CB11	VSS	DVD R+	VSS	F55	Back-up camera
CB13	120VAC outlets	EI.7	Cluster	F73	Engine ECU Volvo
CB48	Flashers & markers, Clearance lgts	EI.18	Engine ECU Volvo	F90	Urea system
CB128	24VD	EMS.EB29	Ignition & engine start	F91	Engine ECU Volvo
CB201	Fans drive electric	F4	Volvo link TGW	F95	Volvo link TGW
CB202	Fans drive electric	F10	Cluster	F96	Urea system
CB203	Fans drive electric	F11	Horn	F96AH	VSS
CB204	Fans drive electric	F13	12VD Customer	F99	Engine ECU Volvo
CB205	Fans drive electric	F16	12V Eng. run	F100	Engine ECU Volvo
CB206	Fans drive electric	F17	Multiplex power	F101	R1 to Starter
CB207	Fans drive electric	F18	Multiplex power	F106	Multiplex power
CB208	Fans drive electric	F19	Multiplex power	F107	Multiplex power
Cd1	Networks	F20	Multiplex power	F108	Networks
CTS	Networks	F21	Multiplex power	F109	Engine & RJB cmpt. lights
Cts	Networks	F23	ESP	F110	Transmission Alisson
D1	Ignition & engine start	F24	12V Ign	F112	Trailer interface

Circuits list

Circuit ID	Description	Circuit ID	Description	Circuit ID	Description
F117	Spares VECR	L-	VSS	N17	Networks
F121	CCust	L142.3	Lavatory	N18	Networks
F122	Spares VECR	L207.1	WCL	N19	Networks
F123	Pre heat	L207.2	WCL lights platform	N20	Networks
F124	Pre heat	L207.3	WCL	N21	Networks
F126	HVAC passengers	L207.GND	WCL	N22	Networks
F127	Pre heat	L350A.B2	Engine ECU Volvo	N23	Networks
F131	CCust	L400.G	Engine heater outlet	N24	Networks
F132	Multiplex power	L400.L	Engine heater outlet	N25	Networks
F133	Multiplex power	L400.N	Engine heater outlet	N26	Networks
F134	Multiplex power	LF+	VSS	N27	Networks
F135	Multiplex power	LF-	VSS	N28	Networks
F136	Multiplex power	LR+	VSS	N29	Networks
F137	Equalizer	LR-	VSS	N30	Networks
F138	Reading lamps & chime	Mo65.3	Fans drive electric	N31	Networks
F139	Alternators	Mo67.3	Fans drive electric	N56-1	Networks
F141	HVAC passengers	Mo68.3	Fans drive electric	N56-2	Networks
F142	HVAC passengers	Mo69.3	Fans drive electric	N57 1	Networks
F143	HVAC passengers	Mo70.3	Fans drive electric	N57 2	Networks
F144	HVAC passengers	Mo71.3	Fans drive electric	Pot1	Driver lights
F147	CCust	Mo72.3	Fans drive electric	R+	VSS
F148	12VD	Mo73.3	Fans drive electric	R-	VSS
F152	Spares VECR	N1	Networks	R-12VISS	VSS
F156	Unican	N2	Networks	R4.85	Fire suppression
F199	Fans drive electric	N3	Networks	R4.87A	Pre heat
F200	VSS	N4	Networks	R12	HVAC passengers
F201	VSS	N5	Networks	R12VISS	VSS
F202	VSS	N6	Networks	R20.87	Pre heat
F203	VSS	N7	Networks	R21.87	Ignition & engine start
F243	HVAC passengers	N8	Networks	R22.87	ECU ignition
gnd 1	Cantrack	N9	Networks	R23.30	Transmission Alisson
Gnd 2	Cantrack	N10	Networks	R25.87	24V Ignition
GndA	Networks	N11	Networks	R26.30	HVAC passengers
GREEN	120VAC outlets	N12	Networks	R27.87A	Wipers & washer
Green	Pre heat	N13	Networks	R28.87A	Upper wipers
GRN1	VSS	N14	Networks	R29	Engine ECU Volvo
GRN2	VSS	N15	Networks	R30.87	12V Eng run customer
L+	VSS	N16	Networks	R31.87	12V Ign customer

Circuits list

Circuit ID	Description	Circuit ID	Description	Circuit ID	Description
R34.30	12V ECU	Se21.2	HVAC defroster	Shield A16.7	Destination signs
R36.87	Horn	Se23.C	HVAC passengers	SHL2	VSS
R37.30	Horn	Se24.2	HVAC passengers	So9.B	HVAC passengers
R38.87	12V outlets	Se24.3	HVAC passengers	spare10	Spares wires
R40.87	Transmission I Shift	Se25.2	HVAC passengers	spare11	Spares wires
R47.87	WCL	Se30.A	Engine & RJB cmpt. lights	spare12	Spares wires
R Starter	Ignition & engine start	Se32.A	Transmission Alisson	spare13	Spares wires
Radio Gnd	VSS	Se32.B	Transmission Alisson	spare14	Spares wires
Radio L+	Audio	Se33.A	Transmission Alisson	spare15	Spares wires
Radio R+	Audio	Se34.A	Transmission Alisson	spare16	Spares wires
Red	USB	Se34.B	Transmission Alisson	spare17	Spares wires
RED1	VSS	Se35.A	Transmission Alisson	spare18	Spares wires
RED2	VSS	Se35.B	Transmission Alisson	spare19	Spares wires
Res21	RJB Cmpt. light	Se37.1	ESP	spare20	Spares wires
Res22	Engine & RJB cmpt. lights	Se37.2	ESP	spare21	Spares wires
Res23	WCL	Se38.1	ESP	spare22	Spares wires
RF+	VSS	Se38.2	ESP	spare23	Spares wires
RF-	VSS	Se39.1	ESP	spare24	Spares wires
RR+	VSS	Se39.2	ESP	spare25	Spares wires
RR-	VSS	Se40.1	ESP	spare28	Spares wires
RTS	Networks	Se40.2	ESP	spare29	Spares wires
Rts	Networks	Se41	Cond. door sw.	spare30	Spares wires
RX	TPMS	Se45.2	Wipers & washer	spare31	Spares wires
Rx	Cantrack	Se46.B	Trailler park Brake & Eng.brake	spare32	Spares wires
RxD	Networks	Se53.C	Cluster	spare33	Spares wires
RxTx	Networks	Se54.C	Cluster	spare34	Spares wires
Se4.1	Windows ajar	Se55.C	Cluster	spare35	Spares wires
Se11.Sig	Cluster	Se63.1	ESP	spare39	Spares wires
Se11.Wrn	Cluster	Se63.2	ESP	spare40	Spares wires
Se13.B	Engine ECU Volvo	Se64.1	ESP	spare41	Spares wires
Se14A.B	Engine ECU Volvo	Se64.2	ESP	spare42	Spares wires
Se14B.C	Engine ECU Volvo	Se67.C	ESP	spare43	Spares wires
Se15.1	Entrance door	Se69.C	ESP	spare44	Spares wires
Se17.1	Entrance door	Se74.3	Transmission Alisson	spare64	Spares wires
Se18.B	Brake & Eng.brake & retarder	Se79.4	Kneeling & Tag & low buoy	spare65	Spares wires
Se19 P.D	Brake & Eng.brake & retarder	Se100.4	WCL	spare72	Spares wires
Se19 S.D	Brake & Eng.brake & retarder	Shield 149	GND stud	spare73	Spares wires
Se20.B	Cluster	Shield 149A	GND stud	Spk1 L	Speakers

Circuits list

Circuit ID	Description	Circuit ID	Description	Circuit ID	Description
Spk1 R	Speakers	Sw4.3	Flashers & markers, Clearance lgts	Sw39	Engine & RJB cmpt. lights
Spk2 L	Speakers	Sw4.8	Flashers & markers, Clearance lgts	Sw40.B	Trailer park Brake & Eng.brake
Spk2 R	Speakers	Sw5.3	Upper wipers sw.	Sw41.A1	Mirrors
Spk3 L	Speakers	Sw5.6	Upper wipers sw.	Sw41.A3	Mirrors
Spk3 R	Speakers	Sw6.3	Upper wipers sw.	Sw41.B1	Mirrors
Spk4 L	Speakers	Sw6.4	Wipers & washer	Sw41.B2	Mirrors
Spk4 R	Speakers	Sw10A.2B	Kneeling & Tag & low buoy	Sw41.B4	Mirrors
Spk5 L	Speakers	Sw12.3	Destination signs	Sw42.2	WCL
Spk5 R	Speakers	Sw12.8	Destination signs	Sw42.3	WCL
Spk6 L	Speakers	Sw14.3	Engine ECU Volvo	Sw42.4	WCL
Spk6 R	Speakers	Sw14.8	Engine ECU Volvo	Sw42.5	WCL
Spk9 L	Speakers	Sw16.3	Brake & Eng.brake & retarder	Sw42.6	WCL
Spk9 R	Speakers	Sw16.8	Brake & Eng.brake & retarder	Sw42.7	WCL
Spk10 L	Speakers	Sw17.6	Engine ECU Volvo	Sw43.B	Kneeling & Tag & low buoy
Spk10 R	Speakers	Sw18A.2B	Lugg door lock	Sw44	Engine & RJB cmpt. lights
Spk11 L	Speakers	Sw20.3	WCL	Sw46	Engine & RJB cmpt. lights
Spk11 R	Speakers	Sw20.8	WCL	Sw55.1	Lavatory
Spk12 L	Speakers	Sw21.3	Upper defrost	Sw56.1	Lavatory
Spk12 R	Speakers	Sw21.8	Upper defrost	Sw57	WCL Sliding door Sig
Spk13 L	Speakers	Sw24.3	Driver lights	Sw58.2	Ignition & engine start
Spk13 R	Speakers	Sw24.6	Driver lights	Sw58.3	Engine shutdown sw.
Spk14 L	Speakers	Sw25.3	Lights switch	Sw58.5	Ignition & engine start
Spk14 R	Speakers	Sw25.6	Reading lamps & chime	Sw58.7	Ignition & engine start
STO-LOC solenoid	WCL	Sw26.3	Reading lamps & chime	Sw59.3	Ignition & engine start
Sw1.5	Flashers & markers, Clearance lgts	Sw26.8	Reading lamps & chime	Sw63A.3	Horn
Sw1C258.2	Wipers & washer	Sw27.3	Parcel rack A/C system	Sw63A.4	Horn
Sw1C258.3	Wipers & washer	Sw27.8	Parcel rack A/C system	Sw64	Kneeling & Tag & low buoy
Sw1C258.4	Wipers & washer	Sw29.2	Reading lamps & chime	Sw82.4	Master relay & 12V Ign
Sw1C258.6	Wipers & washer	Sw29.3	Reading lamps & chime	Sw82.5	Master relay & 12V Ign
Sw1C258.7	Wipers & washer	Sw29.8	Reading lamps & chime	Sw83.Acc	Ignition & engine start
Sw1C258.8	Flashers & markers, Clearance lgts	Sw31	WCL System	Sw83.Ign	Ignition & engine start
Sw1C259.1	Flashers & markers, Clearance lgts	Sw32.3	Entrance door	Sw83.St	Ignition & engine start
Sw1C259.2	Flashers & markers, Clearance lgts	Sw33.3	Entrance door	Sw85.A1	Mirrors
Sw1C259.4	Flashers & markers, Clearance lgts	Sw34.1	Entrance door	Sw85.A3	Mirrors
Sw2.3	Flashers & markers, Clearance lgts	Sw34.4	Entrance door	Sw85.B1	Mirrors
Sw2.6	Flashers & markers, Clearance lgts	Sw35.3	Engine ECU Volvo	Sw85.B2	Mirrors
Sw3.3	Cornering & fog lights	Sw35.8	Engine ECU Volvo	Sw85.B4	Mirrors
Sw3.8	Cornering & fog lights	Sw38.2B	Driver window	Sw94	WCL

Circuits list

Circuit ID	Description	Circuit ID	Description	Circuit ID	Description
Sw96.N3	Reading lamps & chime				
Sw97.N1	Reading lamps & chime				
Sw100A.1	Docking swith				
Sw100A.3	Cornering & fog lights				
Sw124.3	Destination signs				
Sw125.B	Kneeling & Tag & low buoy				
Sw152.B	Fire suppression				
Sw156.1	Mirrors				
Sw156.6	Mirrors				
Sw156.8	Mirrors				
Sw157.2B	Sun visor				
Sw158.2B	Sun visor				
TR-Black	Trailer interface				
TR-Blue	VECT				
TR-Brown	Trailer interface				
TR-Green	Trailer interface				
TR-Red	Trailer interface				
TR-Yellow	Trailer interface				
TWU.3	WCL				
TX	TPMS				
Tx	Cantrack				
TxD	Networks				
ve+	Cantrack				
WHITE	120VAC outlets				
White	Pre heat				
WHT1	VSS				
WHT2	VSS				