

## Diodes list

Diode ID	Location	Part No	Function	Page
D1	FJB	561740	Accessories diode	3.2 Ign Start 3 B
D2	FJB	561740	Driver liquid solenoid diode	18.1 Defroster 2 D
D3	RH Console	561740	Flyback diode upper wipers motor	34.1 wiper washer 4 C
D4	RH Console	561740	Flyback diode lower wipers motor	34.1 wiper washer 4 D
D5	RH Console	561740	Flyback diode lower wipers motor	34.1 wiper washer 4 D
D6	RJB	561740	Flyback diode Master relay	3.1 Main Disti 1 B
D7	RH Console	561740	Entrance door diode	29.1 Entrance door 1 B
D8	Evap Cmpt	561740	Parcel rack liquid solenoid diode	18.3 Parcel Rack Vent 2 E
D9	Evap Cmpt	561740	HVAC diode	17.1 Pre Heat 3 B
D10	Evap Cmpt	561740	Pre-Heat diode	17.1 Pre Heat 3 B
D11	Evap Cmpt	561740	Passengers liquid solenoid diode	18.2 HvacPass 2 B
D12	FJB	565973	Horn while fire extinguisher diode	9.1 Horn 2 A
D13	FJB	561740	Front clearance lights diode	26.1 Front Lighting 2 D
D14	FJB	561740	Front clearance lighting while fire extinguisher diode	9.1 Horn 2 A
D15	Service Cmpt	561740	Flyback diode upper defrost water pump	18.4 Upper Defrost 3 D
D18	FJB	561740	5th luggage compartement lighting diode	25.1 Cmpt Lighting 3 C
D26	LH P-Rack	561740	Flyback diode Parcel rack fan	18.3 Parcel Rack Vent 3 B
D27	RH P-Rack	561740	Flyback diode Parcel rack fan	18.3 Parcel Rack Vent 3 C
D29	RJB	561740	Flyback diode Unloader	18.2 HvacPass 3 D
D30	Evap Cmpt	561740	Flyback diode Water pump	18.2 HvacPass 1 D
D31	RJB	561740	Flyback diode A/C clutch	18.2 HvacPass 3 D
D32	Engine Cmpt	561740	Flyback diode Air exhaust	11.1 Lavatory 3 E
D33	RJB	561740	Flyback diode Flushing pump	11.1 Lavatory 3 C
D44	FJB	561740	Ignition diode	3.2 Ign Start 3 B
D55	RJB	561740	Indirect & reading & docking lights diode	23.1 Indirect Lights 1 A
D73	Evap Cmpt	561740	Evaporator relay diode	18.2 HvacPass 4 C
D80	Evap Cmpt	561740	Cut off water preheater diode	38.1 Fire Supp 3 B