

Relays list

Relay ID	Location	Part No	Function	Page
R1	RJB	560843	Master Relay	3.1
R3	RJB	563348	12v Ignition & Accessories	3.1
R4	FJB	563332	Cut off water preheater	38.1
R5	RJB	563332	Batteries Charging Optionnal	17.1
R12	Evap cmpt.	563348	Evaporator	18.2
R16	RJB	563332	Preheat Max temp	17.1
R20	Evap cmpt.	563332	Water Pump	17.1
R21	FJB	560493	Emergency cutout	3.2
R22	FJB VECF	563269	Ecu Ignition	4.1
R23	FJB VECF	563269	Shutdown 12V	4.1
R23A	FJB	563269	Shutdown 24V	4.1
R24	FJB VECF	563269	Ecu IShift	4.1
R25	FJB VECF	563269	24V Ignition	4.2
R26	Evap Cmpt	563332	Pre-Heat	18.2
R27	RH Console	563332	Lower wipers	34.1
R28	FJB	563332	Upper wipers	34.1
R29	RJB	563348	Preheater Volvo	14.1
R30	FJB	563269	12v Engine running	4.1
R31	FJB	563269	12v Ignition	4.1
R34	RJB	564218	12v Rr Engine Ecu	3.2
R36	FJB	563269	Fire Extinguisher	9.1
R37	FJB	563269	Electric horn	9.1
R38	FJB	563269	Cigar lighter / 12V Outlet	30.2
R40	FJB	563332	Transmission IShift	15.2
R47	WCL Pump	563332	WCL Door Open Option	36.1
R52	RJB VECT	563270	Clearance lights & side markers	26.4
R53	RJB VECT	563270	Flashers left side	26.4
R54	RJB VECT	563270	Brake lights	26.4
R55	RJB VECT	563270	Flashers right side	26.4
R56	RJB VECT	563270	Tail & licence lights	26.4
R72	5th Bay	563348	Inverter 1	40.1
R73	5th Bay	563348	Inverter 2	40.1
R 12VISS	Parcel Rack LH 1st Cmpt	563337	Sound System	35.6
R Starter	RJB	564095	Starter Relay Control	3.2