

CONNECTORS CODE (C)					CONNECTORS CODE (C)				
No.	LOCATION	TYPE	CAVITY	*SOCKET HOUSING HOUSING	No.	LOCATION	TYPE	CAVITY	*SOCKET HOUSING HOUSING
C3	UNDER DASH LH	AMP CPC	37	56145 56146					
C7	FR SERV COMP.-CLUTCH SW	ITT SS	3	56111 56100					
C8	FR JCT PANEL VCR FEED	AMP MNL	3	561248 562147 PRIOR REV 008					
C11	LH CONSOLE SW-MIRROR	AMP MNL	3	561951 56150					
C12	LH CONSOLE SW-MIRROR HTR	AMP MNL	2	561248 561247					
C13	LH CONSOLE SW-MIRROR	AMP MNL	6	561552 56155					
C14	UNDER DASH LH-MIRROR	AMP MNL	9	561970 561669					
C15	UNDER DASH RH-MIRROR	AMP MNL	9	561970 561669					
C16	UNDER DASH-FIRE ALARM	AMP MNL	2	560900 560998					
C19	UNDER DASH-A/C HEAT SYST. TC	AMP MNL	10	561072 56110					
C20	RR JCT BOX DOORS	AMP MNL	9	561970 561669					
C21	LUIGAGE COMP.-LOCK DOOR MTD PED	AMP MNL	2	561072 562076					
C22	ENGINE COMP.-CYCLO LT	SWF	2	561566 56190					
C26	UNDER INSTRUMENT-PANEL RHED. TC	SWF	2	561030 560997					
C29	FR SERVICE COMP.-VW FEED PED WP	AMP MNL	3	561781 561782					
C32	LH CONSOLE DRV PANEL SENSOR BUNDY	3	561566 56190						
C33	FR SERVICE COMP. DOCC VSS PED WP	2	561566 56190						
C34	RH CONSOLE DRV TEMP CTRL BUNDY	6	561566 56190						
C35	REGULATED AIR CTRL-SENSOR BUNDY	3	561566 56190						
C36	LH CONSOLE SW-COURSE ON/OFF SWF	8	561566 56190						
C37	LH CONSOLE SW-COURSE SET SWF	8	561566 56190						
C38	LH CONSOLE SW-COURSE RESUME SWF	8	561566 56190						
C41	UNDER DASH-FLASHER UNIT TC	2	560900 560998						
C49	LAVATORY NIGHT LITS	AMP MNL	2	560900 560998					
C50	RH CONSOLE-PAS TEMP CTRL BUNDY	6	561566 56190						
C51	RH CONSOLE SW-A/C & HEAT SWF	8	561566 56190						
C52	ENGINE COMP.-COMPRESSOR DOG PED WP	2	561566 56190						
C53	ENGINE COMP.-COMPRESSOR DOG PED WP	2	561566 56190						
C54	ENGINE COMP.-COMPRESSOR DOG TC	1	560900 560998						
C61	ENGINE COMP.-FUEL FILTER PED WP	2	561566 56190						
C67	LH UNDER DASH-AMPLF. RH SPK. BLAUPUNKT	2	561988						
C68	LH UNDER DASH-AMPLF. RH SPK. BLAUPUNKT	2	561988						
C73	LH SW PANEL-MULTIFUNC. LEV. AMP FF	8	561988						
C74	LH SW PANEL-MULTIFUNC. LEV. AMP FF	8	561988						
C78	LUIGAGE COMP.-DOOR LOCK 4 LH AMP MNL	4	560851 560852						
C79	LUIGAGE COMP.-DOOR LOCK 4 RH AMP MNL	4	560851 560852						
C80	FR JCT PANEL-LUG. DOOR LOCK AMP MNL	6	561552 56155						
C81	LUIGAGE COMP.-DOOR LOCK LH AMP MNL	4	560851 560852						
C82	LUIGAGE COMP.-DOOR LOCK RH AMP MNL	4	560851 560852						
C84	UNDER DASH-FLASHER MODULE TC	10	561072 56110						
C85	LUIGAGE COMP.-DOOR LOCK 3 RH AMP MNL	4	560851 560852						
C86	LUIGAGE COMP.-DOOR LOCK 3 LH AMP MNL	4	560851 560852						
C88	RR END ROOF-CLEARANCE LITS AMP MNL	2	560900 560998						
C89	RR ROOF AUX. A/C THERMOST. BUNDY	6	561030 56103						
C91	RR ROOF AUX. A/C TEMP SENSOR BUNDY	6	561030 56103						
C92	RR ROOF AUX. A/C FAN RH TC	2	561030 560997						
C93	RR ROOF AUX. A/C FAN LH TC	2	561030 560997						
C94	RR ROOF AUX. A/C FAN RES LH AMP MNL	2	560900 560998						
C95	RR ROOF AUX. A/C FAN RES RH AMP MNL	2	560900 560998						
C96	RR ROOF AUX. A/C LUG SOL VAL TC	2	561030 560997						
C97	RR ROOF AUX. A/C SHUT SOL VAL AMPHENOL	2	561030 560997						
C105	UNDER DASH RH-DRV LUG SOL VL TC	2	561030 560997						
C106	UNDER DASH RH-DRV HTR VALVE TC	2	561030 560997						
C107	UNDER DASH RH-DRV HTR RH FAN TC	2	561030 560997						
C108	UNDER DASH RH-DRV HTR LH FAN TC	2	561030 560997						
C111	LH CONSOLE SW-DRIVER LITS SWF	8	561566 56190						

CONNECTORS CODE (C)					CONNECTORS CODE (C)				
No.	LOCATION	TYPE	CAVITY	*SOCKET HOUSING HOUSING	No.	LOCATION	TYPE	CAVITY	*SOCKET HOUSING HOUSING
C112	LH CONSOLE SW-GENERAL LITS	SWF	8	561566 56190					
C114	ENGINE DOCC-SPEED SIGNAL PED WP	2	561566 56190						
C116	DRIVE AILE COMP.-AIR DRYER PED WP	40	562125 562251						
C118	ENGINE COMP.-LH LOWER LAMP PED WP	6	561900 56190						
C120	ENGINE COMP.-LH LOWER LAMP PED WP	6	561900 56190						
C123	HAT RACK-BALLAST RH	AMP MNL	6	561552 56155					
C124	HAT RACK-FLUORESCENT AMP MNL	4	561551 56190						
C125	HAT RACK-FLUORESCENT AMP MNL	4	561551 56190						
C126	HAT RACK-READING LITS AMP MNL	2	560900 560998						
C130	LH CONSOLE SW-READING LITS SWF	8	561566 56190						
C131	LH CONSOLE SW-READING LITS SWF	8	561566 56190						
C132	LH CONSOLE SW-PAD & HOS CHM. SWF	8	561566 56190						
C133	LH CONSOLE SW-JACOBI OR RET. SWF	8	561566 56190						
C134	LH CONSOLE SW-GALLEY SWF	8	561566 56190						
C135	LH SW PANEL-LEVER SWF	8	561566 56190						
C136	LH CONSOLE SW-MIRROR HTR SWF	8	561566 56190						
C137	RH SW PANEL-HEAD LAMP SWF	8	561566 56190						
C138	RH SW PANEL-SPARE SWF	8	561566 56190						
C139	RH SW PANEL-FOG LAMP SWF	8	561566 56190						
C140	FR SERVICE OPT-LH MARKER LITS ITT SS	3	561111 56100						
C41	ENGINE COMP.-BUP ALARM PED WP	2	561566 56190						
C42	FR SERVICE OPT-LH MARKER LITS ITT SS	3	561111 56100						
C43	RR LH HAT RACK-FEEDING AMP MNL	9	561661 561662						
C44	RR RH HAT RACK-FEEDING AMP MNL	9	561661 561662						
C45	RH HAT RACK-BALLAST AMP MNL	4	560851 560852						
C46	FR SERVICE OPT-RH MARKER LITS ITT SS	3	561111 56100						
C47	RR ROOF LH-EMERGENCY EXT LITS AMP MNL	2	560900 560998						
C48	RR ROOF RH-EMERGENCY EXT LITS AMP MNL	2	560900 560998						
C49	LH HAT RACK-BALLAST AMP MNL	4	560851 560852						
C50	RR RH HAT RACK-10V FLUOR AMP MNL	2	561248 561247						
C51	RR LH HAT RACK-10V FLUOR AMP MNL	2	561248 561247						
C52	LH HAT RACK-GENERAL LITS AMP MNL	3	561667 561550						
C53	RH HAT RACK-GENERAL LITS AMP MNL	3	561667 561550						
C54	RH SW PANEL-HEAD SWF	8	561566 56190						
C55	LH SW PANEL-FAST OLE SWF	8	561566 56190						
C56	LH SW PANEL-SP. ENG. DIVER SWF	8	561566 56190						
C58	RR ROOF AUX. A/C FEEDING AMP MNL	3	561667 561550						
C60	FR SERVICE OPT-INTERFACE AMP CPC	37	561664 561666						
C62	ENGINE DOCC-B/E-COM PED WP	30	561566 56190						
C63	ENGINE DOCC-B/ACCESSORIES PED WP	4	561610 561611						
C64	FR SERVICE JCT BOX AMP CPC	22	561709 561710						
C65	FR SERVICE JCT BOX AMP CPC	16	561639 561640						
C66	UNDER INSTRUMENT PANEL AMP CPC	16	561639 561640						
C67	FR SERVICE OPT-EL FOOT PEDAL PED WP	3	561781 561782						
C68	FR SERVICE OPT-DOOR DEUTSCH	6	562350						
C69	FR SERVICE OPT-WORLD TR. VW AMP CPC	16	561638 561640						
C70	ENGINE COMP.-WATER TANK HEAT PED WP	2	561566 56190						
C71	LAV-POTABLE-WATER TANK HEAT AMP MNL	2	560900 560998						
C72	FR SERV OPT-HEATING FEEDING PED WP	2	561781 561782						
C73	GALLEY-REFRIGERATOR AMP MNL	2	561248 561247						
C79	RH HAT RACK-10V MONITOR MOLEX	4	561477 561478 PRIOR REV 008						
C81	FR SERV OPT-HEATING MODULE AMP MNL	12	561735 561734						
C82	FR SERVICE OPT-SPEED SW PED WP	15	561566 562012						
C84	FR SERV OPT-KNEEL MOD. CTRL AMP MNL	3	561667 561550						
C85	FR AXLE-KNEELING PROXIMITY SW AMP MNL	3	561667 561550						
C86	FR SERV OPT-KNEEL MOD. EXH. AMP MNL	3	561667 561550						

CONNECTORS CODE (C)					CONNECTORS CODE (C)				
No.	LOCATION	TYPE	CAVITY	*SOCKET HOUSING HOUSING	No.	LOCATION	TYPE	CAVITY	*SOCKET HOUSING HOUSING
C251	RH SW PANEL-SEAT HTR	SWF	8	561907					
C252	LH SW PANEL-SWITCH LT SWF	2	561907						
C254	FR SERVICE JCT BOX-ABS AMP CPC	16	561983 561985						
C255	RH CONSOLE-HEAD AMP MNL	9	561970 561669 PRIOR REV 008						
C257	ENGINE COMP.-WATER HEATER AMP FF	6	561986						
C258	DRIVER GUARD WATER HTR TIMER AMP FF	8	561986 562363						
C259	ENGINE COMP.-WATER HEATER TC	2	561987						
C260	ENGINE COMP.-WATER HEATER TC	1	561973						
C261	ENGINE COMP.-WATER HEATER TC	2	561987						
C267	LUIGAGE COMP. LITS - 1 AMP MNL	2	561248 561247						
C268	LUIGAGE COMP. LITS - 2 AMP MNL	2	561248 561247						
C269	LUIGAGE COMP. LITS - 3 RH AMP MNL	2	561248 561247						
C270	LUIGAGE COMP. LITS - 3 LH AMP MNL	2	561248 561247						
C271	LUIGAGE COMP. LITS - 4 AMP MNL	2	561248 561247						
C272	FR SERVICE OPT LITS AMP MNL	2	561248 561247						
C274	FR JCT PANEL-DOORS AMP MNL	10	561987 561988						
C276	FR JCT PANEL-ALARM BUZZER BOSCH	5	561983						
C281	LH CONSOLE-FR. DEST. SIGN SWF	2	561983						
C282	FR ROOF-DEST. SIGN AMP CPC	9	561936 561937						
C290	LUIGAGE OPT-DOOR LOCK AMP MNL	4	560851 560852						
C291	LUIGAGE OPT-DOOR LOCK AMP MNL	4	560851 560852						
C292	LUIGAGE OPT-DOOR LOCK AMP MNL	4	560851 560852						
C293	WIPER MOTOR AMP FF	6	561566 56190						
C294	UNDER DASH-WIPER SYST. FEED AMP MNL	6	561552 56155						
C295	UNDER DASH-WIPER FUSIBLE DEN. AMP FF	6	561566 56190						
C296	FR SERVICE OPT-HEAD LITS ITT SS	3	561111 56100						
C298	FR LH HAT RACK-AMPL. MOLEX	6	561477 561478 PRIOR REV 008						
C299	FR LH HAT RACK-AMPL. MOLEX	10	561477 561478 PRIOR REV 008						
C302	UNDER DASH-FLASHER MODULE AMP MNL	2	560900 560998						
C309	ENGINE DOCC-B/E-COM POWER PED WP	3	561566 56190						
C310	ENGINE DOCC-B/E-COM SIGNAL PED WP	3	561781 561782						
C313	ENGINE DOCC-B/OUTPUT PED WP	4	562398						
C314	FR SERVICE OPT-PRESS SW KNEEL PED WP	2	561566 56190						
C315	FR SERVICE OPT-NEEL ALARM PED WP	2	561566 56190						
C316	FR SERVICE OPT-KNEEL ALARM AMP MNL	2	560900 560998						
C318	ENGINE DOCC-B/ MANUAL TR. PED WP	4	561610 561611						
C326	ENGINE DOCC-B/ MANUAL TR. PED WP	4	561610 561611						
C344	FR ROOF-DESTINATION SIGN AMP MNL	3	561987 561988						
C345	FR ROOF-DESTINATION SIGN AMP MNL	2	560900 560998						
C368	FR ROOF-DEST. SIGN BALLAST AMP MNL	3	561987 561988						
C369	FR ROOF-DEST. SIGN OPER. SW. TORQUE	5	561987 561988						
C370	FR ROOF-DEST. SIGN FLUOR. AMP MNL	2	560900 560998						
C371	FR ROOF-DEST. SIGN FLUOR. AMP MNL	2	560900 560998						
C372	FR ROOF-DEST. SIGN SPEED SW. MOLEX	4	561477 561478						
C382	ENGINE GENERATOR ID VAC. RLY PED WP	1	561905 561906						
C383	LH UNDER DASH-MICRO W/O WIRE AMP MNL	2	561248 561247 PRIOR REV 008						
C384	LH UNDER DASH-MICRO W/O WIRE AMP MNL	3	561550 561661 PRIOR REV 008						
C385	EVAPORATOR OPT-WATER PUMP PED WP	2	561566 56190						
C386	EVAPORATOR OPT-BYPASS VALVE PED WP	2	561566 56190						
C387	CONSUMER OPT-FAN PRES. SW. PED WP	2	561566 56190						
C394	LH OVER CONSOLE - BU MONITOR AMP MNL	4	560851 560852						
C398	LH OVER CONSOLE - BU MONITOR AMP MNL	5	560851 560852						
C396	HAT RACK-FLASHER TC MOLEX	4	562012 562013						
C400	ENGINE OPT-BLOCK HEATER PED WP	3	561781 561782						
C426	ENGINE 560 RAD FAN CLUTCH PED WP	3	561781 561782						
C430	DRIVER GUARD WATER HTR TIMER AMP FF	8	561986 562363						