

0

1

2

3

4

**12-24V Power distribution FJB
Customer adaptation option RH console switch**

A

A

Terminal strip 5 pos.
#10

Loc. 5 B

B

B

4.2_Dist_24V_FJB_: 3 B ●

24-F39-14



Note:
Temporary
Connection

**When this option is requested
the converter has to provide 24VDC
from home batteries on Term16
to power the luggage lights circuit**

C

C

Refer to page 4.1 for complete details

24-F167-16

25.1_SP1_CA_Lugg_Compt_Lights_Option:1 C
Option Lugg. Lts Sw167

D

D

E

E

0

1

2

3

4