

CONTROL VALVE OPT. "LOW-BUOY", "A" OR "B" SETTING:

POSITION "A": VALVE IS OPEN,
AIR FLOW BETWEEN SUPPLY (S) AND
DELIVERY (D), LOW-BUOY IS IN FUNCTION.

POSITION "B": VALVE CLOSED,
AIR DOES'NT FLOW BETWEEN SUPPLY (S) AND
DELIVERY (D), LOW-BUOY IS NOT IN FUNCTION.

BALLOON	PIPE
#1	1/4" O.D. BLUE
#2	3/8" O.D. BLUE
#3	1/2" O.D. BLUE
#4	1/4" O.D. BLACK
# 5	3/8" O.D. BLACK
#6	3/8" O.D. YELLOW

PREVOST®

DESCRIPTION:

H3-45 COACHES, WITH INDEPENDENT FRONT SUSPENSION (I.F.S.) WITH KNEELING, LOW-BUOY & HIGH-COMBINATION

REV.: DATE: 2010/09

PAGE:

D140380 P6.1