

CONTROL VALVE OPT. "LOW-BUOY", "A" OR "B" SETTING:

POSITION "A": VALVE IS OPEN,

AIR FLOW BETWEEN SUPPLY (S) AND DELIVERY (D), LOW-BUOY IS IN FUNCTION.

POSITION "B": VALVE CLOSED, AIR DOES'NT FLOW BETWEEN SUPPLY (S) AND DELIVERY (D), LOW-BUOY IS NOT IN FUNCTION.

BALLOON	PIPE
*1	1/4" O.D. BLUE
*2	3/8" O.D. BLUE
*3	1/2" O.D. BLUE
*4	1/4" O.D. BLACK
<b>*</b> 5	3/8" O.D. BLACK
*6	3/8" O.D. YELLOW

PREVOST<sub>®</sub>

DESCRIPTION:

H3-45 COACHES, WITH INDEPENDENT FRONT SUSPENSION (I.F.S.) WITH KNEELING, LOW-BUOY & HIGH-COMBINATION

EFF. W/ VEH:

#9-1470

DATE: 2009/05 REV.: PAGE:

D140367 P5.1